

SIPROTEC

Multifunctional machine protection 7UM62

Communication module

PROFIBUS-DP
Bus mapping

Preface

Table of contents

Data of the PROFIBUS-DP messages

1

Standard mappings 3-1 to 3-3

2

Standard mapping 3-4

3

Standard mapping 3-5

4

Index

Edition: March 2013

C53000-L1840-B009-04

Liability statement

We have checked the contents of this manual against the hardware and software described. Exclusions and deviations cannot be ruled out; we accept no liability for lack of total agreement.

The information in this manual is checked periodically, and necessary corrections will be included in future editions. We appreciate any suggested improvements.

We reserve the right to make technical improvements without notice.

Document version: V03.11.01

Copyright

Copyright © Siemens AG 2013. All rights reserved.

Dissemination or reproduction of this document, or evaluation and communication of its contents, is not authorized except where expressly permitted. Violations are liable for damages. All rights reserved, particularly for the purposes of patent application or trademark registration.

Registered trademarks

SIPROTEC[®], SIMATIC[®], SIMATIC NET[®], SINAUT[®], SICAM[®] and DIGSI[®] are registered trademarks of Siemens AG.

Other designations in this manual may be trademarks that if used by third parties for their own purposes may violate the rights of the owner.

Preface

Purpose of this manual

This manual describes the data in the PROFIBUS-DP messages of the SIPROTEC device 7UM62 and is divided into the following topics:

- Data of the PROFIBUS-DP messages → Chapter 1,
- Standard mappings 3-1 to 3-3 → Chapter 2,
- Standard mapping 3-4 → Chapter 3,
- Standard mapping 3-5 → Chapter 4.

General details about the function, operation, assembly and commissioning of the SIPROTEC devices you find in the

- SIPROTEC4 System Manual, order no. E50417–H1176–C151.

PROFIBUS-DP communication profile documentation

The following additional manual informs you about the data types, bus specific parameters and hardware interface of the PROFIBUS-DP slave module of the SIPROTEC devices:

| Manual | Order number |
|--|----------------------|
| SIPROTEC Communication module, PROFIBUS-DP - Communication profile | C53000-L1840-B001-03 |

PROFIBUS-DP specification

The PROFIBUS-DP specification and the structure of the PROFIBUS-DP messages are defined in the International Standards:

- IEC 61158
“Digital data communications for measurement and control -
Fieldbus for use in industrial control systems”
Communication profile type 3
- IEC 61784
“Digital data communications for measurement and control”
Communication profile family CPF3/1

| | |
|---------------------------|---|
| Validity | <p>This manual is valid for the SIPROTEC device:</p> <ul style="list-style-type: none">• 7UM62 (firmware version 4.00 or higher),• 7UM62 (firmware version 4.10 or higher) at use of<ul style="list-style-type: none">• Standard mapping 3-5 <p>with</p> <ul style="list-style-type: none">• PROFIBUS-DP communication module version 02.00.05 or higher,• PROFIBUS-DP communication module version 03.00.03 or higher at use of<ul style="list-style-type: none">• Standard mappings 3-4 and 3-5. <p>For device parameterization have to be used:</p> <ul style="list-style-type: none">• DIGSI 4.3 or higher,• DIGSI 4.21 considering the preconditions explained in the manual “SIPROTEC Communication module, PROFIBUS-DP - Communication profile” (ref. to page 3),• PROFIBUS-DP standard mappings 3-1 to 3-n (n = device type dependent number of standard mappings). |
| Additional Support | <p>For questions regarding SIPROTEC4 devices, please contact your Siemens representative.</p> |
| Training courses | <p>Individual course offerings may be found in our Training Catalog and questions can be directed to our Training Centre. Please contact your Siemens representative.</p> |
| Target audience | <p>Protection engineers, commissioning engineers, personnel concerned with adjustment, checking and service of selective protective equipment, automatic and control facilities and personnel of electrical facilities and power plants.</p> |



Warning!

Hazardous voltages are present in this electrical equipment during operation. Non-observance of the safety rules can result in severe personal injury or property damage.

Only qualified personnel shall work on and around this equipment after becoming thoroughly familiar with all warnings and safety notices of this and the associated manuals as well as with the applicable safety regulations.

The successful and safe operation of this device is dependent on proper transport and storage, proper handling, installation, operation, and maintenance by qualified personnel under observance of all warnings and hints contained in this and the associated manuals.

In particular the general erection and safety regulations (e.g. IEC, EN, DIN, VDE, or other national and international standards) regarding the correct use of high-voltage installations must be observed. Non-observance can result in death, personal injury or substantial property damage.

QUALIFIED PERSONNEL

For the purpose of this manual and product labels, a qualified person is one who is familiar with the installation, construction and operation of the equipment and the hazards involved. In addition, he has the following qualifications:

- Is trained and authorized to energize, de-energize, clear, ground and tag circuits and equipment in accordance with established safety practices.
- Is trained in the proper care and use of protective equipment in accordance with established safety practices.
- Is trained in rendering first aid.

Typographic and graphical conventions

The following text formats are used to identify concepts giving device information described by the text flow:

Parameter names, or identifiers for configuration or function parameters that appear in the device display or on the screen of a PC (with DIGSI) are shown in mono-script (same point size) bold text. This also applies to header bars for selection menus.

Parameter conditions, or possible settings of parameters that appear in the device display or on the screen of a PC (with DIGSI), are additionally shown in italic style. This also applies to selection items for selection menus.

„Annunciations“, or identifiers for information produced by the device or required by other devices or from the switchgear is shown in mono-script (same point size) and placed into quotation marks.

For diagrams in which the identifier type results from the representation itself, text conventions may differ from the above-mentioned.



Revision index

Listing of the changes between the editions of this manual:

| Modified chapters / pages | Edition | Reasons of modification |
|--|---------|--|
| | 1.00 | First edition, Doc.-No.: C53000-L1840-B009-04 Sept. 26 th , 2001 |
| Chap. 1.4 Chap. 2.1.3 Chap. 2.2.1.27 Chap. 2.2.1.32 - 2.2.1.36 Chap. 2.2.2 | 2.00 | <ul style="list-style-type: none"> • Standard mapping's data sizes now listed by information types • Message positions 5/4 to 5/7 available for double commands • Offset 13/5: 64R-2 picked up --> 64R-1 picked up • Additional indications at byte offsets 18 and 19 with 7UM62 V4.10 • Offset 42: $\Theta R/\Theta R_{max}$ --> <user-defined> March 26 th , 2002 |
| general Chap. 1.4, 3 Chap. 1.3.2 | 3.00 | <ul style="list-style-type: none"> • Page numbering in the manual now continuous, not chapter-related any more • New: description of Standard mapping 3-4 with event list • note added: Temperature measured values from the RTD-Box can only be transmitted as primary values Nov. 18 th , 2004 |
| Chap. 1.4, 4 | 3.10 | <ul style="list-style-type: none"> • New: description of Standard mapping 3-5 with event list Oct. 23 rd , 2006 |
| Chap. 1.3.3 | 3.11 | <ul style="list-style-type: none"> • Scaling of the metered measurands March 21 st , 2013 |



Table of contents

| | | |
|----------|--|-----------|
| | Preface | 3 |
| | Revision index | 7 |
| 1 | Data of the PROFIBUS-DP messages | 13 |
| 1.1 | Explanations | 14 |
| 1.2 | Messages in output direction: PROFIBUS-DP master to the SIPROTEC device | 15 |
| 1.2.1 | Commands | 15 |
| 1.2.2 | Measured values | 15 |
| 1.3 | Messages in input direction: SIPROTEC device to the PROFIBUS-DP master | 16 |
| 1.3.1 | Indications | 16 |
| 1.3.2 | Measured values | 16 |
| 1.3.3 | Metered measurands..... | 17 |
| 1.4 | Configuration data of the standard mappings..... | 18 |
| 1.5 | Notes to SIPROTEC objects | 22 |
| 1.5.1 | Changing the setting group | 22 |
| 1.5.2 | Cooling medium temperature | 23 |
| 2 | Standard mappings 3-1 to 3-3 | 25 |
| 2.1 | Message in output direction..... | 26 |
| 2.1.1 | User-defined commands and taggings..... | 26 |
| 2.1.2 | Internal Commands | 27 |
| 2.1.3 | Double commands..... | 27 |
| 2.1.4 | Measured values | 28 |
| 2.2 | Message in input direction..... | 29 |
| 2.2.1 | Indications | 29 |
| 2.2.1.1 | User-defined indications..... | 29 |
| 2.2.1.2 | Diagnosis..... | 29 |
| 2.2.1.3 | Overcurrent time protection I>..... | 30 |
| 2.2.1.4 | Overcurrent time protection I>>..... | 30 |
| 2.2.1.5 | Inverse time overcurrent protection | 30 |
| 2.2.1.6 | Thermal overload protection..... | 30 |
| 2.2.1.7 | Unbalanced load protection..... | 31 |

| | | |
|----------|---|-----------|
| 2.2.1.8 | Sensitive ground fault protection | 31 |
| 2.2.1.9 | Stator ground fault protection | 31 |
| 2.2.1.10 | Stator ground fault protection with 3 rd harmonic..... | 31 |
| 2.2.1.11 | Overvoltage protection..... | 32 |
| 2.2.1.12 | Undervoltage protection..... | 32 |
| 2.2.1.13 | Frequency protection | 32 |
| 2.2.1.14 | Overexcitation protection | 32 |
| 2.2.1.15 | Reverse power protection..... | 33 |
| 2.2.1.16 | Forward power supervision..... | 33 |
| 2.2.1.17 | Fuse Failure Monitor..... | 33 |
| 2.2.1.18 | Underexcitation protection | 33 |
| 2.2.1.19 | Circuit breaker failure protection | 33 |
| 2.2.1.20 | Impedance protection | 34 |
| 2.2.1.21 | Binary inputs | 34 |
| 2.2.1.22 | Inadvertent energisation protection | 34 |
| 2.2.1.23 | Trip coil monitor | 34 |
| 2.2.1.24 | Inverse undervoltage protection | 35 |
| 2.2.1.25 | Startup supervision of motors | 35 |
| 2.2.1.26 | Startup counter for motors | 35 |
| 2.2.1.27 | Rotor ground fault protection | 35 |
| 2.2.1.28 | DC voltage/current protection | 35 |
| 2.2.1.29 | State of the out-of-step protection | 36 |
| 2.2.1.30 | Differential Protection | 36 |
| 2.2.1.31 | User-defined indications | 36 |
| 2.2.1.32 | Stator ground fault protection 100% | 37 |
| 2.2.1.33 | Rotor ground fault protection 1-3 Hz..... | 37 |
| 2.2.1.34 | Restricted ground fault protection..... | 37 |
| 2.2.1.35 | Fault indications of protection functions..... | 38 |
| 2.2.1.36 | Double-point indications | 38 |
| 2.2.2 | Measured values | 39 |
| 2.2.3 | Metered measurands..... | 40 |
| 3 | Standard mapping 3-4 | 41 |
| 3.1 | Message in output direction..... | 42 |
| 3.1.1 | Event list | 42 |
| 3.1.2 | Double commands..... | 42 |
| 3.1.3 | Internal Commands | 42 |
| 3.1.4 | User-defined commands and taggings..... | 43 |
| 3.1.5 | Measured values | 43 |
| 3.2 | Message in input direction..... | 44 |
| 3.2.1 | Indications | 44 |
| 3.2.1.1 | Double-point indications | 44 |
| 3.2.1.2 | Single-point indications..... | 44 |
| 3.2.1.3 | Setting group | 44 |
| 3.2.1.4 | Diagnosis..... | 45 |
| 3.2.1.5 | Protection pickup indications | 45 |
| 3.2.1.6 | Protection trip indications..... | 47 |
| 3.2.1.7 | User-defined indications (RTD-Box) | 49 |
| 3.2.1.8 | Device status | 50 |

| | | |
|----------|--|-----------|
| 3.2.1.9 | User-defined indications | 50 |
| 3.2.2 | Measured values | 51 |
| 3.2.3 | Metered measurands..... | 51 |
| 3.2.4 | Event list..... | 52 |
| 4 | Standard mapping 3-5 | 53 |
| 4.1 | Message in output direction..... | 54 |
| 4.1.1 | Event list..... | 54 |
| 4.1.2 | User-defined commands and taggings..... | 54 |
| 4.1.3 | Internal Commands | 55 |
| 4.1.4 | Double commands..... | 56 |
| 4.1.5 | Measured values | 56 |
| 4.2 | Message in input direction..... | 57 |
| 4.2.1 | Indications | 57 |
| 4.2.1.1 | User-defined indications | 57 |
| 4.2.1.2 | Diagnosis..... | 57 |
| 4.2.1.3 | Overcurrent time protection I>..... | 58 |
| 4.2.1.4 | Overcurrent time protection I>>..... | 58 |
| 4.2.1.5 | Inverse time overcurrent protection | 58 |
| 4.2.1.6 | Thermal overload protection..... | 58 |
| 4.2.1.7 | Unbalanced load protection..... | 59 |
| 4.2.1.8 | Sensitive ground fault protection | 59 |
| 4.2.1.9 | Stator ground fault protection | 59 |
| 4.2.1.10 | Stator ground fault protection with 3 rd harmonic | 59 |
| 4.2.1.11 | Overvoltage protection | 60 |
| 4.2.1.12 | Undervoltage protection | 60 |
| 4.2.1.13 | Frequency protection..... | 60 |
| 4.2.1.14 | Overexcitation protection..... | 60 |
| 4.2.1.15 | Reverse power protection..... | 61 |
| 4.2.1.16 | Forward power supervision | 61 |
| 4.2.1.17 | Fuse Failure Monitor..... | 61 |
| 4.2.1.18 | Underexcitation protection..... | 61 |
| 4.2.1.19 | Circuit breaker failure protection..... | 61 |
| 4.2.1.20 | Impedance protection..... | 62 |
| 4.2.1.21 | Binary inputs..... | 62 |
| 4.2.1.22 | Inadvertent energisation protection | 62 |
| 4.2.1.23 | Trip coil monitor | 62 |
| 4.2.1.24 | Inverse undervoltage protection | 63 |
| 4.2.1.25 | Startup supervision of motors..... | 63 |
| 4.2.1.26 | Startup counter for motors..... | 63 |
| 4.2.1.27 | Rotor ground fault protection..... | 63 |
| 4.2.1.28 | DC voltage/current protection..... | 63 |
| 4.2.1.29 | State of the out-of-step protection | 64 |
| 4.2.1.30 | Differential Protection | 64 |
| 4.2.1.31 | User-defined indications | 64 |
| 4.2.1.32 | Stator ground fault protection 100% | 65 |
| 4.2.1.33 | Rotor ground fault protection 1-3 Hz | 65 |
| 4.2.1.34 | Restricted ground fault protection..... | 65 |
| 4.2.1.35 | Fault indications of protection functions | 65 |

| | | |
|-----------------------|--------------------------------|-----------|
| 4.2.1.36 | Double-point indications | 66 |
| 4.2.2 | Measured values | 67 |
| 4.2.3 | Metered measurands | 68 |
| 4.2.4 | Event list | 68 |
| Glossary | | 69 |
| Index | | 71 |

Data of the PROFIBUS-DP messages

This chapter delivers explanations to the data descriptions of the standard mappings as well as notes for evaluation of selected SIPROTEC objects and for the configuration of the standard mapping in the PROFIBUS-DP master.

| | | |
|-----|---|----|
| 1.1 | Explanations | 14 |
| 1.2 | Messages in output direction: PROFIBUS-DP master to the SIPROTEC device | 15 |
| 1.3 | Messages in input direction: SIPROTEC device to the PROFIBUS-DP master | 16 |
| 1.4 | Configuration data of the standard mappings | 18 |
| 1.5 | Notes to SIPROTEC objects | 22 |

1.1 Explanations



Note:

The examples shown in this chapter 1.1 do not necessarily correspond to the real allocation of the objects in the bus mapping.

Chapters 2 to 4 define the data area of the PROFIBUS-DP messages for data transfer between the PROFIBUS-DP slave of the SIPROTEC device 7UM62 and the PROFIBUS-DP master.

The columns "Designation of the SIPROTEC objects" contain the names of the SIPROTEC objects for "US English" device language.

The listed SIPROTEC objects in the PROFIBUS-DP messages' data area are sorted after byte offset, beginning with 0.

Variables with data type greater than or equal to 1 byte

The offset defines the start of the most significant byte in the message, e.g.:

| Offset | Designation of the SIPROTEC objects | Comments | Scaling (32767 corresponds to...) | Internal object no. |
|--------|-------------------------------------|--------------------------------|-----------------------------------|---------------------|
| 20 | IA S2 = | Operat. meas. current A side 2 | 327.67 % | 724 |

The measured value "IA S2" is assigned to data byte 20 (most significant byte of the measured value) and data byte 21 (least significant byte of the measured value) in the PROFIBUS-DP message

Bit variables (SP/SC, DP/DC)

The offset indicates the byte which contains the bit value and the position of bit 0 of the bit variable, e.g. (input message):

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 2 / 0 | 50/51-1 Ph A PU | 1 = 50/51-1 Phase A picked up | 1811 |

The single-point indication "50/51 - 1 Ph A PU" is located in byte 2, bit position 2⁰.



Note:

The definition of the data types (single-point indication, measured value etc.) are contained in the manual "SIPROTEC Communication module, PROFIBUS-DP - Communication profile" (ref. to page 3).

1.2 Messages in output direction: PROFIBUS-DP master to the SIPROTEC device

The messages in PROFIBUS-DP output direction (ref to chap. 2.1, 3.1 and 4.1) allow:

- command outputs through the output relays of the SIPROTEC devices (external commands),
- manipulation of taggings (internal commands),
- transmission of measured values to the SIPROTEC device.

1.2.1 Commands



Note:

- The allocation of the output relays to the switching devices and to the output channels is defined during parameterization of the SIPROTEC devices.
 - Depending on the device composition there may be less than indicated output relays (and corresponding PROFIBUS-DP message positions) available in the SIPROTEC device.
-

1.2.2 Measured values



Note:

- Unlike measured values in input direction, the identification "Overflow" or "Invalid" is not indicated with the value -32768 (ref. to manual "SIPROTEC Communication module, PROFIBUS-DP - Communication profile").
 - If an evaluation of the measurement status of the cooling medium temperature is required then the indication ">Fail.Temp.inp" (>49 Failure temperature input, internal object no. = 1508), routed to "Destination system interface" in the **DIGSI Configuration matrix**, has to be used for this separately.
-

1.3 Messages in input direction: SIPROTEC device to the PROFIBUS-DP master

The messages in PROFIBUS-DP input direction (ref. to chap. 2.2, 3.2 and 4.2) allow:

- polling of switching devices' status and binary inputs,
- transmission of indications, measurands and meter values to the PROFIBUS-DP master.

1.3.1 Indications



Note:

- The allocation of the input channels to the binary inputs is defined during parameterization of the devices.
 - Depending on the device composition and the existing protection packages not all of the indicated binary inputs or protection indications (and corresponding PROFIBUS-DP message positions) may be available in the SIPROTEC device.
-

1.3.2 Measured values



Note:

- Depending on the device composition not all of the indicated analog inputs (and corresponding PROFIBUS-DP message positions) may be available in the SIPROTEC device.
 - The transferred percentage values are with reference to the nominal values of the primary equipment.
 - Changes of the scaling of the measured values and the type (percentage value or primary value) are possible in adaptation to the concrete installation environment. You find information about this in the manual "SIPROTEC Communication module, PROFIBUS-DP - Communication profile" (ref. to page 3).
 - Temperature measured values from the RTD-Box can only be transmitted as primary values.
-

1.3.3 Metered measurands

Scaling

The scaling of the metered measurands which are derived from measured values refers to:

$$(60000 * V_{\text{nom, secondary}}/100 \text{ V}) \text{ impulses per hour for } S = S_{\text{nom}}$$

S_{nom} = Rated Apparent Power of the Generator (parameter address = 0252)

$V_{\text{nom,secondary}}$ = phase-to-phase secondary voltage of the voltage transformer (parameter address = 0222)

Example

In the parameter set is configured:

$$S_{\text{nom}} = 5.27 \text{ MVA}$$

$$V_{\text{nom,secondary}} = 100 \text{ V}$$

60000 impulses correspond so that:

$$1 \text{ h} * 5.27 \text{ MVA} * 100 \text{ V}/100 \text{ V} = 5.27 \text{ MVAh}$$



Note:

- The type of the update (cyclic, with or without deletion) and the update interval must be programmed for the metered measurands with the parameterization software DIGSI.
 - The scaling of the metered measurands at binary inputs (pulse counters) depends on the externally connected pulse generator.
-

1.4 Configuration data of the standard mappings

There are five standard mappings (standard mapping 3-1 to standard mapping 3-5) available for the SIPROTEC device 7UM62 which differ in the available data size in the PROFIBUS-DP messages.

Standard mapping 3-1

The standard mapping 3-1 contains:

Output direction:

- 2 Double commands (with 7UM62 V4.10 or higher)
- 22 Single commands
- 1 Measured value (Cooling medium temperature)

Input direction:

- 2 Double-point indications (with 7UM62 V4.10 or higher)
- 160 Single-point indications (7UM62 V4.0: 144 Single-point indications)
- 16 Measured values (integer)
- 4 Metered measurands (counter, unsigned long)

Standard mapping 3-2

The standard mapping 3-2 contains:

Output direction:

- 2 Double commands (with 7UM62 V4.10 or higher)
- 22 Single commands

Input direction:

- 2 Double-point indications (with 7UM62 V4.10 or higher)
- 160 Single-point indications (7UM62 V4.0: 144 Single-point indications)
- 16 Measured values (integer)

Unlike the standard mapping 3-1 there are no measured values in output direction and no metered measurands in input direction contained in the standard mapping 3-2.

Standard mapping 3-3

The standard mapping 3-3 contains:

Output direction:

- 2 Double commands (with 7UM62 V4.10 or higher)
- 22 Single commands

Input direction:

- 2 Double-point indications (with 7UM62 V4.10 or higher)
- 160 Single-point indications (7UM62 V4.0: 144 Single-point indications)

Unlike the standard mapping 3-1 there are no measured values in output direction as well as no measured values and metered measurands in input direction contained in the standard mapping 3-3.

**Standard mapping
3-4***The standard mapping 3-4 contains:*

Output direction:

- Handshake byte for event list via PROFIBUS-DP
- 4 Double commands
- 12 Single commands
- 1 Measured value (Cooling medium temperature)

Input direction:

- 4 Double-point indications
- 152 Single-point indications
- 16 Measured values (integer)
- 4 Metered measurands (counters, unsigned long)
- Handshake byte and three message blocks for event list via PROFIBUS-DP

**Standard mapping
3-5***The standard mapping 3-5 contains:*

Output direction:

- Handshake byte for event list via PROFIBUS-DP
- 2 Double commands
- 22 Single commands
- 1 Measured value (Cooling medium temperature)

Input direction:

- 2 Double-point indications
- 160 Single-point indications
- 16 Measured values (integer)
- 4 Metered measurands (counter, unsigned long)
- Handshake byte and three message blocks for event list via PROFIBUS-DP

Configuration data*Standard mapping 3-1:* **1FH 1FH 1FH 1FH 13H 27H**

(68 bytes input-, 8 bytes output direction)

Standard mapping 3-2: **1FH 1FH 1FH 13H 25H**

(52 bytes input-, 6 bytes output direction)

Standard mapping 3-3: **1FH 13H 25H**

(20 bytes input-, 6 bytes output direction)

Standard mapping 3-4: **1FH 1FH 1FH 1FH 13H DFH 27H**

(100 bytes input-, 8 bytes output direction)

Standard mapping 3-5: **1FH 1FH 1FH 1FH 13H DFH 29H**

(100 bytes input-, 10 bytes output direction)

PROFIBUS-DP master

At the configuration of a PROFIBUS-DP slave of the SIPROTEC devices in the parameterization system of the PROFIBUS-DP masters are to select the following modules for the 7UM62 standard mappings and to allocate associated addresses in the I/O addressing range of the PROFIBUS-DP master:

Standard mapping 3-1:

| Module | Order number | Input address | Output address |
|--------|------------------|---------------|----------------|
| 0 | Input - 16 Bytes | Adr_Ix | |
| 1 | Input - 16 Bytes | Adr_Ix + 16 | |
| 2 | Input - 16 Bytes | Adr_Ix + 32 | |
| 3 | Input - 16 Bytes | Adr_Ix + 48 | |
| 4 | Input - 4 Bytes | Adr_Ix + 64 | |
| 5 | Output - 8 Bytes | | Adr_Ox |

Standard mapping 3-2:

| Module | Order number | Input address | Output address |
|--------|------------------|---------------|----------------|
| 0 | Input - 16 Bytes | Adr_Ix | |
| 1 | Input - 16 Bytes | Adr_Ix + 16 | |
| 2 | Input - 16 Bytes | Adr_Ix + 32 | |
| 3 | Input - 4 Bytes | Adr_Ix + 48 | |
| 4 | Output - 6 Bytes | | Adr_Ox |

Standard mapping 3-3:

| Module | Order number | Input address | Output address |
|--------|------------------|---------------|----------------|
| 0 | Input - 16 Bytes | Adr_Ix | |
| 1 | Input - 4 Bytes | Adr_Ix + 16 | |
| 2 | Output - 6 Bytes | | Adr_Ox |

Standard mapping 3-4:

| Module | Order number | Input address | Output address |
|--------|------------------------------|---------------|----------------|
| 0 | Input - 16 Bytes | Adr_Ix | |
| 1 | Input - 16 Bytes | Adr_Ix + 16 | |
| 2 | Input - 16 Bytes | Adr_Ix + 32 | |
| 3 | Input - 16 Bytes | Adr_Ix + 48 | |
| 4 | Input - 4 Bytes | Adr_Ix + 64 | |
| 5 | Input - 16 Words, consistent | Adr_Ix + 68 | |
| 6 | Output - 8 Bytes | | Adr_Ox |

Standard mapping 3-5:

| Module | Order number | Input address | Output address |
|--------|------------------------------|---------------|----------------|
| 0 | Input - 16 Bytes | Adr_lx | |
| 1 | Input - 16 Bytes | Adr_lx + 16 | |
| 2 | Input - 16 Bytes | Adr_lx + 32 | |
| 3 | Input - 16 Bytes | Adr_lx + 48 | |
| 4 | Input - 4 Bytes | Adr_lx + 64 | |
| 5 | Input - 16 Words, consistent | Adr_lx + 68 | |
| 6 | Output - 10 Bytes | | Adr_Ox |

Adr_lx and Addr_Ox indicates arbitrary (as a rule even) addresses in the I/O addressing range of the PROFIBUS-DP master.

Adr_lx (base address of the inputs) is identical with offset 0 of the PROFIBUS-DP message data of the SIPROTEC device in input direction (ref. to chap. 2.2, 3.2 and 4.2).

Addr_Ox (base address of the outputs) is identical with offset 0 of the PROFIBUS-DP message data of the SIPROTEC device in output direction (ref. to chap. 2.1, 3.1 and 4.1).

*Note:*

There is dependently on the PROFIBUS-DP master in addition possibly the demand to put the base address of the inputs on a value divisible by four so that accesses on the metered measurands (unsigned long values, ref. to chap. 2.2.3, 3.2.3 and 4.2.3) can be correctly carried out in the PROFIBUS-DP master.

1.5 Notes to SIPROTEC objects

This chapter contains notes for the use and evaluation of certain SIPROTEC objects.



Note:

- The descriptions of the standard mappings (ref. to chap. 2 to 4) contain the pre-allocation of the mapping files at delivery or at first assignment of a mapping in DIGSI to the SIPROTEC device.
 - Changes of the allocation and the scaling of the measured values are possible in adaptation to the concrete installation environment.
You find information about this in the manual "SIPROTEC Communication module, PROFIBUS-DP - Communication profile" (ref. to page 3).
 - If a mapping file is assigned to a SIPROTEC device and if the data size of the PROFIBUS-DP message of this SIPROTEC device is changed by choice of a new mapping file then assignments which are not available in the existing mapping file remain unassigned furthermore.
-

1.5.1 Changing the setting group

In order to change the setting group, the value "10" = ON must be transmitted to the corresponding pair of bits and afterwards be reset to "00" = "Quiescent status" (controlled by an impulse from the PROFIBUS-DP master).

- Switching ON one setting group automatically switches OFF the current active setting group.
- Transmission of the value "01" = OFF is insignificant for the change of the setting group and is refused by the device.
- A change of the setting group is only possible via PROFIBUS-DP if the parameter **Change to Another Setting Group** (parameter address = 302) has the value **Protocol**.

References

Standard mappings 3-1 to 3-3: ref. to chap. 2.1.2

Standard mapping 3-4: ref. to chap. 3.1.3

Standard mapping 3-5: ref. to chap. 4.1.3

1.5.2 Cooling medium temperature

- The cooling medium temperature is transferred in per cent (%) to the 7UM62. The protection device must be informed about the 100 % corresponding temperature using parameter **49 Temperature for Scaling** (function **49 Thermal Overload**, parameter address = 1608).
- The temperature value via PROFIBUS-DP is only taken into account and shown at the SIPROTEC device if the parameter **49 Temperature Input** (function **49 Thermal Overload**, parameter address = 1607) has the value **Fieldbus**.

Reference

Standard mapping 3-1: ref. to chap. 2.1.4

Standard mappings 3-2 and 3-3: not available

Standard mapping 3-4: ref. to chap. 3.1.5

Standard mapping 3-5: ref. to chap. 4.1.5



Standard mappings 3-1 to 3-3

This chapter describes the data in the PROFIBUS-DP messages between the PROFIBUS-DP master and the SIPROTEC device 7UM62 if one of the standard mappings 3-1 to 3-3 is selected.

| | | |
|-----|-----------------------------|----|
| 2.1 | Message in output direction | 26 |
| 2.2 | Message in input direction | 29 |

2.1 Message in output direction

2.1.1 User-defined commands and taggings

- User-defined commands and taggings can be routed on these positions as “Source system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 0 / 0 | <user-defined> OFF | not pre-allocated | - |
| 0 / 1 | <user-defined> ON | | |
| 0 / 2 | <user-defined> OFF | not pre-allocated | - |
| 0 / 3 | <user-defined> ON | | |
| 0 / 4 | <user-defined> OFF | not pre-allocated | - |
| 0 / 5 | <user-defined> ON | | |
| 0 / 6 | <user-defined> OFF | not pre-allocated | - |
| 0 / 7 | <user-defined> ON | | |
| 1 / 0 | <user-defined> OFF | not pre-allocated | - |
| 1 / 1 | <user-defined> ON | | |
| 1 / 2 | <user-defined> OFF | not pre-allocated | - |
| 1 / 3 | <user-defined> ON | | |
| 1 / 4 | <user-defined> OFF | not pre-allocated | - |
| 1 / 5 | <user-defined> ON | | |
| 1 / 6 | <user-defined> OFF | not pre-allocated | - |
| 1 / 7 | <user-defined> ON | | |
| 2 / 0 | <user-defined> OFF | not pre-allocated | - |
| 2 / 1 | <user-defined> ON | | |
| 2 / 2 | <user-defined> OFF | not pre-allocated | - |
| 2 / 3 | <user-defined> ON | | |
| 2 / 4 | <user-defined> OFF | not pre-allocated | - |
| 2 / 5 | <user-defined> ON | | |
| 2 / 6 | <user-defined> OFF | not pre-allocated | - |
| 2 / 7 | <user-defined> ON | | |
| 3 / 0 | <user-defined> OFF | not pre-allocated | - |
| 3 / 1 | <user-defined> ON | | |
| 3 / 2 | <user-defined> OFF | not pre-allocated | - |
| 3 / 3 | <user-defined> ON | | |
| 3 / 4 | <user-defined> OFF | not pre-allocated | - |
| 3 / 5 | <user-defined> ON | | |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 3 / 6 | <user-defined> OFF | not pre-allocated | - |
| 3 / 7 | <user-defined> ON | | |

2.1.2 Internal Commands

- Ref. to chap. 1.5.1 for additional notes regarding “Changing the setting group”.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 4 / 0 | Setting Group A | Activation of setting group A | - |
| 4 / 1 | Setting Group A | | |
| 4 / 2 | Setting Group B | Activation of setting group B | - |
| 4 / 3 | Setting Group B | | |
| 4 / 4 | <user-defined> OFF | not pre-allocated | - |
| 4 / 5 | <user-defined> ON | | |
| 4 / 6 | <user-defined> OFF | not pre-allocated | - |
| 4 / 7 | <user-defined> ON | | |
| 5 / 0 | <user-defined> OFF | not pre-allocated | - |
| 5 / 1 | <user-defined> ON | | |
| 5 / 2 | <user-defined> OFF | not pre-allocated | - |
| 5 / 3 | <user-defined> ON | | |

2.1.3 Double commands

- With 7UM62 V4.10 or higher, double commands with double-point indications as checkback indication can be routed on these positions as “Source system interface” using the **DIGSI Configuration matrix**.
- 7UM62 V4.0: single commands can be routed on these positions as “Source system interface”.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 5 / 4 | <user-defined> OFF | not pre-allocated | - |
| 5 / 5 | <user-defined> ON | | |
| 5 / 6 | <user-defined> OFF | not pre-allocated | - |
| 5 / 7 | <user-defined> ON | | |

2.1.4 Measured values

- Measured values in output direction are only available at use of standard mapping 3-1 (ref. to chap. 1.4).
- Ref. to chap. 1.5.2 for additional notes regarding the measured value “Cooling medium temperature”.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling (32767 corresponds to ...) | Internal object no. |
|--------|-------------------------------------|----------------------------|---------------------------------------|---------------------|
| 6 | AMB.TEMP = | Cooling medium temperature | 327.67 % | - |

2.2 Message in input direction

2.2.1 Indications

2.2.1.1 User-defined indications

- User-defined protection indications, single-point indications and taggings can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 0 / 0 | <user-defined> | not pre-allocated | - |
| 0 / 1 | <user-defined> | not pre-allocated | - |
| 0 / 2 | <user-defined> | not pre-allocated | - |
| 0 / 3 | <user-defined> | not pre-allocated | - |
| 0 / 4 | <user-defined> | not pre-allocated | - |
| 0 / 5 | <user-defined> | not pre-allocated | - |
| 0 / 6 | <user-defined> | not pre-allocated | - |
| 0 / 7 | <user-defined> | not pre-allocated | - |

2.2.1.2 Diagnosis

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 1 / 0 | Device OK | 1 = Update of the device replica in the SIPROTEC device completed after initial start or restart | 51 |
| 1 / 1 | ProtActive | 1 = At least one protection function is active | 52 |
| 1 / 2 | Error Sum Alarm | 1 = Error with a summary alarm ON | 140 |
| 1 / 3 | Alarm Sum Event | 1 = Alarm summary event ON | 160 |
| 1 / 4 | Relay PICKUP | 1 = Relay PICKUP (group signal) | 501 |
| 1 / 5 | Relay TRIP | 1 = Relay GENERAL TRIP command | 511 |
| 1 / 6 | Operat. Cond. | 1 = Suitable measured quantities are present at the device inputs ($V > 0,1 * V_{nom}$, $I > 0,1 * I_{nom}$ and $10 \text{ Hz} < \text{Freq.} < 70 \text{ Hz}$) | 5002 |
| 1 / 7 | Data valid | 1 = Data in the PROFIBUS-DP message are valid. (This indication is created by the PROFIBUS-DP slave; not available in DIGSI and not relocatable.) | - |

2.2.1.3 Overcurrent time protection I>

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|----------------------------------|---------------------|
| 2 / 0 | 50/51-1 Ph A PU | 1 = 50/51-1 Phase A picked up | 1811 |
| 2 / 1 | 50/51-1 Ph B PU | 1 = 50/51-1 Phase B picked up | 1812 |
| 2 / 2 | 50/51-1 Ph C PU | 1 = 50/51-1 Phase C picked up | 1813 |
| 2 / 3 | V< seal in | 1 = 50/51-1 undervoltage seal-in | 1970 |
| 2 / 4 | 50/51 TRIP | 1 = 50/51 I> TRIP | 1815 |

2.2.1.4 Overcurrent time protection I>>

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 2 / 5 | 67 forward | 1 = 67 I>> direction forward | 1806 |
| 2 / 6 | 67 backward | 1 = 67 I>> direction backward | 1807 |
| 2 / 7 | 50/51-2 Ph A PU | 1 = 50/51-2 Phase A picked up | 1801 |
| 3 / 0 | 50/51-2 Ph B PU | 1 = 50/51-2 Phase B picked up | 1802 |
| 3 / 1 | 50/51-2 Ph C PU | 1 = 50/51-2 Phase C picked up | 1803 |
| 3 / 2 | 51/67 TRIP | 1 = 50/51/67 I>> TRIP | 1809 |

2.2.1.5 Inverse time overcurrent protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---------------------------|---------------------|
| 3 / 3 | 51V Ph A PU | 1 = 51V Phase A picked up | 1896 |
| 3 / 4 | 51V Ph B PU | 1 = 51V Phase B picked up | 1897 |
| 3 / 5 | 51V Ph C PU | 1 = 51V Phase C picked up | 1898 |
| 3 / 6 | 51V TRIP | 1 = 51V TRIP | 1900 |
| 3 / 7 | <user-defined> | not pre-allocated | - |

2.2.1.6 Thermal overload protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 4 / 0 | 49 O/L I Alarm | 1 = 49 Overload Current Alarm (I alarm) | 1515 |
| 4 / 1 | 49 O/L Θ Alarm | 1 = 49 Thermal Overload Alarm | 1516 |
| 4 / 2 | 49 Th O/L TRIP | 1 = 49 Thermal Overload TRIP | 1521 |

2.2.1.7 Unbalanced load protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------------------|---------------------|
| 4 / 3 | 46-1 Warn | 1 = 46-1 Current warning stage | 5156 |
| 4 / 4 | 46-1 picked up | 1 = 46-1 picked up | 5165 |
| 4 / 5 | 46-2 picked up | 1 = 46-2 picked up | 5159 |
| 4 / 6 | 46-2 TRIP | 1 = 46-2 TRIP of current stage | 5160 |
| 4 / 7 | 46-⊖ TRIP | 1 = 46 TRIP of thermal stage | 5161 |

2.2.1.8 Sensitive ground fault protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 5 / 0 | Failure 64R In< | 1 = Failure 64R In<: measuring circuit | 5396 |
| 5 / 1 | 50Ns-1 Pickup | 1 = 50Ns-1 Pickup | 1224 |
| 5 / 2 | 50Ns-1 TRIP | 1 = 50Ns-1 TRIP | 1226 |
| 5 / 3 | 50Ns-2 Pickup | 1 = 50Ns-2 Pickup | 1221 |
| 5 / 4 | 50Ns-2 TRIP | 1 = 50Ns-2 TRIP | 1223 |

2.2.1.9 Stator ground fault protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|----------------------------|---------------------|
| 5 / 5 | 59/67 V0 PU | 1 = 59N/67GN V0 picked up | 5186 |
| 5 / 6 | 59/67 I0 PU | 1 = 59N/67GN I0 picked up | 5188 |
| 5 / 7 | 59/67 V0 TRIP | 1 = 59N/67GN V0 stage TRIP | 5187 |
| 6 / 0 | 59N/67GN TRIP | 1 = 59N/67GN TRIP | 5193 |

2.2.1.10 Stator ground fault protection with 3rd harmonic

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 6 / 1 | 27TN/59TN PU | 1 = 27TN/59TN with 3 rd harmonic picked up | 5567 |
| 6 / 2 | 27TN/59TN TRP | 1 = 27TN/59TN with 3 rd harmonic TRIP | 5568 |

2.2.1.11 Overvoltage protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|------------------------------------|---------------------|
| 6 / 3 | 59-1 picked up | 1 = 59-1 Overvoltage V> picked up | 6568 |
| 6 / 4 | 59-2 picked up | 1 = 59-2 Overvoltage V>> picked up | 6571 |
| 6 / 5 | 59-1 TRIP | 1 = 59-1 Overvoltage V> TRIP | 6570 |
| 6 / 6 | 59-2 TRIP | 1 = 59-2 Overvoltage V>> TRIP | 6573 |

2.2.1.12 Undervoltage protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------------|---------------------|
| 6 / 7 | 27-1 picked up | 1 = 27-1 Undervoltage V< picked up | 6533 |
| 7 / 0 | 27-2 picked up | 1 = 27-2 Undervoltage V<< picked up | 6537 |
| 7 / 1 | 27-1 TRIP | 1 = 27-1 Undervoltage V< TRIP | 6539 |
| 7 / 2 | 27-2 TRIP | 1 = 27-2 Undervoltage V<< TRIP | 6540 |

2.2.1.13 Frequency protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------|---------------------|
| 7 / 3 | 81-1 picked up | 1 = 81-1 picked up | 5232 |
| 7 / 4 | 81-2 picked up | 1 = 81-2 picked up | 5233 |
| 7 / 5 | 81-3 picked up | 1 = 81-3 picked up | 5234 |
| 7 / 6 | 81-4 picked up | 1 = 81-4 picked up | 5235 |
| 7 / 7 | 81-1 TRIP | 1 = 81-1 TRIP | 5236 |
| 8 / 0 | 81-2 TRIP | 1 = 81-2 TRIP | 5237 |
| 8 / 1 | 81-3 TRIP | 1 = 81-3 TRIP | 5238 |
| 8 / 2 | 81-4 TRIP | 1 = 81-4 TRIP | 5239 |

2.2.1.14 Overexcitation protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|------------------------------|---------------------|
| 8 / 3 | 24 warn | 1 = 24 V/f warning stage | 5367 |
| 8 / 4 | 24-1 picked up | 1 = 24-1 V/f> picked up | 5370 |
| 8 / 5 | 24-2 picked up | 1 = 24-2 V/f>> picked up | 5373 |
| 8 / 6 | 24 th.TRIP | 1 = 24 TRIP of thermal stage | 5372 |
| 8 / 7 | 24-2 TRIP | 1 = 24-2 TRIP of V/f>> stage | 5371 |

2.2.1.15 Reverse power protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|------------------------------|---------------------|
| 9 / 0 | 32R picked up | 1 = 32R picked up | 5096 |
| 9 / 1 | 32R TRIP | 1 = 32R TRIP | 5097 |
| 9 / 2 | 32R+SV TRIP | 1 = 32R TRIP with stop valve | 5098 |

2.2.1.16 Forward power supervision

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|----------------------------|---------------------|
| 9 / 3 | 32F< picked up | 1 = 32F P< stage picked up | 5126 |
| 9 / 4 | 32F> picked up | 1 = 32F P> stage picked up | 5127 |
| 9 / 5 | 32F P< TRIP | 1 = 32F P< stage TRIP | 5128 |
| 9 / 6 | 32F P> TRIP | 1 = 32F P> stage TRIP | 5129 |

2.2.1.17 Fuse Failure Monitor

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------------------------|---------------------|
| 9 / 7 | VT Fuse Failure | 1 = Voltage Transformer Fuse Failure | 6575 |

2.2.1.18 Underexcitation protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 10 / 0 | 40 Vexc failure | 1 = 40 Exc. voltage failure recognized | 5336 |
| 10 / 1 | 40 picked up | 1 = 40 picked up | 5337 |
| 10 / 2 | 40-1 TRIP | 1 = 40 characteristic 1 TRIP | 5344 |
| 10 / 3 | 40-2 TRIP | 1 = 40 characteristic 2 TRIP | 5345 |
| 10 / 4 | 40&V<TRIP | 1 = 40 characteristic&Vexc< TRIP | 5346 |
| 10 / 5 | 40-3 TRIP | 1 = 40 characteristic 3 TRIP | 5343 |

2.2.1.19 Circuit breaker failure protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------|---------------------|
| 10 / 6 | 50BF pickup | 1 = 50BF picked up | 1455 |
| 10 / 7 | 50BF TRIP | 1 = 50BF TRIP | 1471 |

2.2.1.20 Impedance protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------------------------|---------------------|
| 11 / 0 | 21 Fault Ph A | 1 = 21 Fault detection Phase A | 3967 |
| 11 / 1 | 21 Fault Ph B | 1 = 21 Fault detection Phase B | 3968 |
| 11 / 2 | 21 Fault Ph C | 1 = 21 Fault detection Phase C | 3969 |
| 11 / 3 | 21 I> & U< | 1 = 21 O/C with undervoltage seal in | 3970 |
| 11 / 4 | 21 Z1< TRIP | 1 = 21 Z1< TRIP | 3977 |
| 11 / 5 | 21 Z1B< TRIP | 1 = 21 Z1B< TRIP | 3978 |
| 11 / 6 | 21 Z2< TRIP | 1 = 21 Z2< TRIP | 3979 |
| 11 / 7 | 21 T3> TRIP | 1 = 21 T3> TRIP | 3980 |

2.2.1.21 Binary inputs

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------------|---------------------|
| 12 / 0 | Ext 1 Gen.TRIP | 1 = External trip 1: General TRIP | 4537 |
| 12 / 1 | Ext 2 Gen.TRIP | 1 = External trip 2: General TRIP | 4557 |
| 12 / 2 | Ext 3 Gen.TRIP | 1 = External trip 3: General TRIP | 4577 |
| 12 / 3 | Ext 4 Gen.TRIP | 1 = External trip 4: General TRIP | 4597 |

2.2.1.22 Inadvertent energisation protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---------------------|---------------------|
| 12 / 4 | 50/27 picked up | 1 = 50/27 picked up | 5547 |
| 12 / 5 | 50/27 TRIP | 1 = 50/27 TRIP | 5548 |

2.2.1.23 Trip coil monitor

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 12 / 6 | FAIL: Trip cir. | 1 = 74TC Failure Trip Circuit | 6865 |

2.2.1.24 Inverse undervoltage protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 12 / 7 | Vp< picked up | 1 = Inverse Undervoltage Vp< picked up | 6525 |
| 13 / 0 | Vp< TRIP | 1 = Inverse Undervoltage Vp< TRIP | 6527 |

2.2.1.25 Startup supervision of motors

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 13 / 1 | 48 Rot. locked | 1 = 48 Rotor LOCKED after Lock. Rotor Time | 6822 |
| 13 / 2 | 48 picked up | 1 = 48 Starting time supervision picked up | 6823 |
| 13 / 3 | 48 TRIP | 1 = 48 Starting time supervision TRIP | 6821 |

2.2.1.26 Startup counter for motors

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------------|---------------------|
| 13 / 4 | 66 TRIP | 1 = 66 Restart inhibit motor TRIP | 4827 |

2.2.1.27 Rotor ground fault protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------|---------------------|
| 13 / 5 | 64R-1 picked up | 1 = 64R-1 picked up (Alarm) | 5397 |
| 13 / 6 | 64R-2 TRIP | 1 = 64R-2 TRIP | 5399 |

2.2.1.28 DC voltage/current protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------|---------------------|
| 13 / 7 | DC Prot.pick.up | 1 = DC protection picked up | 5306 |
| 14 / 0 | DC Prot. TRIP | 1 = DC protection TRIP | 5307 |

2.2.1.29 State of the out-of-step protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------------|---------------------|
| 14 / 1 | 78 det. char. 1 | 1 = 78 characteristic 1 picked up | 5069 |
| 14 / 2 | 78 det. char. 2 | 1 = 78 characteristic 2 picked up | 5070 |
| 14 / 3 | 78 TRIP char. 1 | 1 = 78 TRIP characteristic 1 | 5071 |
| 14 / 4 | 78 TRIP char. 2 | 1 = 78 TRIP characteristic 2 | 5072 |

2.2.1.30 Differential Protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 14 / 5 | 87 picked up | 1 = 87 Differential protection picked up | 5631 |
| 14 / 6 | 87 TRIP | 1 = 87 Differential protection TRIP | 5671 |
| 14 / 7 | 87 TRIP Phase A | 1 = 87 Differential protection: TRIP Phase A | 5672 |
| 15 / 0 | 87 TRIP Phase B | 1 = 87 Differential protection: TRIP Phase B | 5673 |
| 15 / 1 | 87 TRIP Phase C | 1 = 87 Differential protection: TRIP Phase C | 5674 |
| 15 / 2 | 87 Diff> TRIP | 1 = 87 Differential prot.: TRIP by IDIFF> | 5691 |
| 15 / 3 | 87 Diff>> TRIP | 1 = 87 Diff>> TRIP | 5692 |

2.2.1.31 User-defined indications

- User-defined protection indications, single-point indications and taggings can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 15 / 4 | <user-defined> | not pre-allocated | - |
| 15 / 5 | <user-defined> | not pre-allocated | - |
| 15 / 6 | <user-defined> | not pre-allocated | - |
| 15 / 7 | <user-defined> | not pre-allocated | - |
| 16 / 0 | <user-defined> | not pre-allocated | - |
| 16 / 1 | <user-defined> | not pre-allocated | - |
| 16 / 2 | <user-defined> | not pre-allocated | - |
| 16 / 3 | <user-defined> | not pre-allocated | - |
| 16 / 4 | <user-defined> | not pre-allocated | - |
| 16 / 5 | <user-defined> | not pre-allocated | - |
| 16 / 6 | <user-defined> | not pre-allocated | - |
| 16 / 7 | <user-defined> | not pre-allocated | - |
| 17 / 0 | <user-defined> | not pre-allocated | - |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 17 / 1 | <user-defined> | not pre-allocated | - |
| 17 / 2 | <user-defined> | not pre-allocated | - |
| 17 / 3 | <user-defined> | not pre-allocated | - |
| 17 / 4 | <user-defined> | not pre-allocated | - |
| 17 / 5 | <user-defined> | not pre-allocated | - |
| 17 / 6 | <user-defined> | not pre-allocated | - |
| 17 / 7 | <user-defined> | not pre-allocated | - |

2.2.1.32 Stator ground fault protection 100%

- Message positions 18 / 0 and 18 / 1 are available with 7UM62 V4.10 or higher.
7UM62 V4.00: the value 0 is transmitted at these positions.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 18 / 0 | SGF100 Alarm | 1 = Stator ground fault prot. 100%: Alarm stage | 5487 |
| 18 / 1 | SGF100 TRIP | 1 = Stator ground fault prot. 100%: TRIP | 5489 |

2.2.1.33 Rotor ground fault protection 1-3 Hz

- Message positions 18 / 2 and 18 / 3 are available with 7UM62 V4.10 or higher.
7UM62 V4.00: the value 0 is transmitted at these positions.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------------|---------------------|
| 18 / 2 | 64R-1_3Hzpickup | 1 = 64R-1 (1-3Hz) picked up (Alarm) | 5403 |
| 18 / 3 | 64R-2_3Hz TRIP | 1 = 64R-2 (1-3Hz) TRIP | 5407 |

2.2.1.34 Restricted ground fault protection

- Message positions 18 / 4 and 18 / 5 are available with 7UM62 V4.10 or higher.
7UM62 V4.00: the value 0 is transmitted at these positions.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 18 / 4 | 87N picked up | 1 = 87N picked up | 5817 |
| 18 / 5 | 87N TRIP | 1 = 87N TRIP | 5821 |

2.2.1.35 Fault indications of protection functions

- Message positions 18 / 6 to 19 / 3 are available with 7UM62 V4.10 or higher. User-defined protection indications, single-point indications or taggings can be routed on the positions "<user-defined>" as "Destination system interface" using the **DIGSI Configuration matrix**.
- 7UM62 V4.00: the value 0 is transmitted at these positions.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 18 / 6 | Failure SGF | 1 = Failure stator ground fault prot. 100% | 5486 |
| 18 / 7 | Failure 64R | 1 = Failure 64R: measuring circuit | 5400 |
| 19 / 0 | Fail 64R 1-3Hz | 1 = Failure 64R protection (1-3Hz) | 5401 |
| 19 / 1 | <user-defined> | not pre-allocated | - |
| 19 / 2 | <user-defined> | not pre-allocated | - |
| 19 / 3 | <user-defined> | not pre-allocated | - |

2.2.1.36 Double-point indications

- Message positions 19 / 4 to 19 / 7 are available with 7UM62 V4.10 or higher. User-defined double-point indications (e.g. checkback indications of double commands) can be routed on these positions as "Destination system interface" using the **DIGSI Configuration matrix**.
- 7UM62 V4.00: the value 0 is transmitted at these positions.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 19 / 4 | <user-defined> OFF | not pre-allocated | - |
| 19 / 5 | <user-defined> ON | | |
| 19 / 6 | <user-defined> OFF | not pre-allocated | - |
| 19 / 7 | <user-defined> ON | | |

2.2.2 Measured values

- Measured values in input direction are only available at use of standard mapping 3-1 or standard mapping 3-2 (ref. to chap. 1.4).
- Ref. to chap. 1.3.2 for notes regarding scaling of measured values.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling (32767 corresponds to ...) | Internal object no. |
|--------|-------------------------------------|---------------------------------------|------------------------------------|---------------------|
| 20 | IA S2 = | Operat. meas. current A side 2 | 327.67 % | 724 |
| 22 | IB S2 = | Operat. meas. current B side 2 | 327.67 % | 725 |
| 24 | IC S2 = | Operat. meas. current C side 2 | 327.67 % | 726 |
| 26 | Va-b = | Va-b | 327.67 % | 624 |
| 28 | Vb-c = | Vb-c | 327.67 % | 625 |
| 30 | Vc-a = | Vc-a | 327.67 % | 626 |
| 32 | P = | P (active power) | 327.67 % | 641 |
| 34 | Q = | Q (reactive power) | 327.67 % | 642 |
| 36 | f = | Frequency | 327.67 Hz | 644 |
| 38 | I2 = | I2 (negative sequence) | 327.67 % | 606 |
| 40 | Θ/Θtrip = | Temperature rise for warning and trip | 327.67 % | 801 |
| 42 | <user-defined> | not pre-allocated | - | - |
| 44 | IA S1 = | Operat. meas. current A side 1 | 327.67 % | 721 |
| 46 | IB S1 = | Operat. meas. current B side 1 | 327.67 % | 722 |
| 48 | IC S1 = | Operat. meas. current C side 1 | 327.67 % | 723 |
| 50 | <user-defined> | not pre-allocated | - | - |

2.2.3 Metered measurands

- Metered measurands are only available at use of standard mapping 3-1 (ref. to chap. 1.4).
- Ref. to chap. 1.3.3 for notes regarding scaling of metered measurands.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling ($2^{31}-1$ corresponds to ...) | Internal object no. |
|--------|-------------------------------------|---|---|---------------------|
| 52 | Wp+ | Wp Forward (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 924 |
| 56 | Wq+ | Wq Forward (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 925 |
| 60 | Wp- | Wp Reverse (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 928 |
| 64 | Wq- | Wq Reverse (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 929 |



Standard mapping 3-4

This chapter describes the data in the PROFIBUS-DP messages between the PROFIBUS-DP master and the SIPROTEC device 7UM62 if standard mapping 3-4 is selected.

| | | |
|-----|-----------------------------|----|
| 3.1 | Message in output direction | 42 |
| 3.2 | Message in input direction | 44 |

3.1 Message in output direction

3.1.1 Event list

- Information regarding the handshake bytes as well as the retrieval methods of the event list via PROFIBUS-DP can be found in the manual "SIPROTEC Communication module, PROFIBUS-DP - Communication profile".

| Offset | Designation | Comments | Internal object no. |
|--------|-------------|--|---------------------|
| 0 | Control_O | Handshake byte for event list via PROFIBUS-DP | - |
| 1 | SPARE | reserved for future use (the value at this position is ignored) | - |

3.1.2 Double commands

- Double commands with double-point indications as checkback indication can be routed on these positions as "Source system interface" using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 2 / 0 | <user-defined> OFF | not pre-allocated | - |
| 2 / 1 | <user-defined> ON | | |
| 2 / 2 | <user-defined> OFF | not pre-allocated | - |
| 2 / 3 | <user-defined> ON | | |
| 2 / 4 | <user-defined> OFF | not pre-allocated | - |
| 2 / 5 | <user-defined> ON | | |
| 2 / 6 | <user-defined> OFF | not pre-allocated | - |
| 2 / 7 | <user-defined> ON | | |

3.1.3 Internal Commands

- Ref. to chap. 1.5.1 for additional notes regarding "Changing the setting group".

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 3 / 0 | Setting Group A | Activation of setting group A | - |
| 3 / 1 | Setting Group A | | |
| 3 / 2 | Setting Group B | Activation of setting group B | - |
| 3 / 3 | Setting Group B | | |
| 3 / 4 | <user-defined> OFF | not pre-allocated | - |
| 3 / 5 | <user-defined> ON | | |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 3 / 6 | <user-defined> OFF | not pre-allocated | - |
| 3 / 7 | <user-defined> ON | | |

3.1.4 User-defined commands and taggings

- User-defined commands and taggings can be routed on these positions as “Source system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 4 / 0 | <user-defined> OFF | not pre-allocated | - |
| 4 / 1 | <user-defined> ON | | |
| 4 / 2 | <user-defined> OFF | not pre-allocated | - |
| 4 / 3 | <user-defined> ON | | |
| 4 / 4 | <user-defined> OFF | not pre-allocated | - |
| 4 / 5 | <user-defined> ON | | |
| 4 / 6 | <user-defined> OFF | not pre-allocated | - |
| 4 / 7 | <user-defined> ON | | |
| 5 / 0 | <user-defined> OFF | not pre-allocated | - |
| 5 / 1 | <user-defined> ON | | |
| 5 / 2 | <user-defined> OFF | not pre-allocated | - |
| 5 / 3 | <user-defined> ON | | |
| 5 / 4 | <user-defined> OFF | not pre-allocated | - |
| 5 / 5 | <user-defined> ON | | |
| 5 / 6 | <user-defined> OFF | not pre-allocated | - |
| 5 / 7 | <user-defined> ON | | |

3.1.5 Measured values

- Ref. to chap. 1.5.2 for additional notes regarding the measured value “Cooling medium temperature”.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling (32767 corresponds to ...) | Internal object no. |
|--------|-------------------------------------|----------------------------|------------------------------------|---------------------|
| 6 | AMB.TEMP = | Cooling medium temperature | 327.67 % | - |

3.2 Message in input direction

3.2.1 Indications

3.2.1.1 Double-point indications

- User-defined double-point indications (e.g. checkback indications of double commands) can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 0 / 0 | <user-defined> OFF | not pre-allocated | - |
| 0 / 1 | <user-defined> ON | | |
| 0 / 2 | <user-defined> OFF | not pre-allocated | - |
| 0 / 3 | <user-defined> ON | | |
| 0 / 4 | <user-defined> OFF | not pre-allocated | - |
| 0 / 5 | <user-defined> ON | | |
| 0 / 6 | <user-defined> OFF | not pre-allocated | - |
| 0 / 7 | <user-defined> ON | | |

3.2.1.2 Single-point indications

- User-defined single-point indications (e.g. checkback indications of single commands) can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 1 / 0 | <user-defined> | not pre-allocated | - |
| 1 / 1 | <user-defined> | not pre-allocated | - |
| 1 / 2 | <user-defined> | not pre-allocated | - |
| 1 / 3 | <user-defined> | not pre-allocated | - |

3.2.1.3 Setting group

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------|---------------------|
| 1 / 4 | Group A | 1 = Group A is active | - |
| 1 / 5 | Group B | 1 = Group B is active | - |
| 1 / 6 | <user-defined> | not pre-allocated | - |
| 1 / 7 | <user-defined> | not pre-allocated | - |

3.2.1.4 Diagnosis

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 2 / 0 | Device OK | 1 = Update of the device replica in the SIPROTEC device completed after initial start or restart | 51 |
| 2 / 1 | ProtActive | 1 = At least one protection function is active | 52 |
| 2 / 2 | <user-defined> | not pre-allocated | - |
| 2 / 3 | Error Sum Alarm | 1 = Error with a summary alarm ON | 140 |
| 2 / 4 | Alarm Sum Event | 1 = Alarm summary event ON | 160 |
| 2 / 5 | Relay PICKUP | 1 = Relay PICKUP (group signal) | 501 |
| 2 / 6 | Relay TRIP | 1 = Relay GENERAL TRIP command | 511 |
| 2 / 7 | Data valid | 1 = Data in the PROFIBUS-DP message are valid. (This indication is created by the PROFIBUS-DP slave; not available in DIGSI and not relocatable.) | - |

3.2.1.5 Protection pickup indications

- User-defined protection indications, single-point indications and taggings can be routed on the positions "<user-defined>" as "Destination system interface" using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 3 / 0 | 87 picked up | 1 = 87 Differential protection picked up | 5631 |
| 3 / 1 | 50/51-1 Ph A PU | 1 = 50/51-1 Phase A picked up | 1811 |
| 3 / 2 | 50/51-1 Ph B PU | 1 = 50/51-1 Phase B picked up | 1812 |
| 3 / 3 | 50/51-1 Ph C PU | 1 = 50/51-1 Phase C picked up | 1813 |
| 3 / 4 | V< seal in | 1 = 50/51-1 undervoltage seal-in | 1970 |
| 3 / 5 | 67 forward | 1 = 67 I>> direction forward | 1806 |
| 3 / 6 | 67 backward | 1 = 67 I>> direction backward | 1807 |
| 3 / 7 | 50/51-2 Ph A PU | 1 = 50/51-2 Phase A picked up | 1801 |
| 4 / 0 | 50/51-2 Ph B PU | 1 = 50/51-2 Phase B picked up | 1802 |
| 4 / 1 | 50/51-2 Ph C PU | 1 = 50/51-2 Phase C picked up | 1803 |
| 4 / 2 | 51V Ph A PU | 1 = 51V Phase A picked up | 1896 |
| 4 / 3 | 51V Ph B PU | 1 = 51V Phase B picked up | 1897 |
| 4 / 4 | 51V Ph C PU | 1 = 51V Phase C picked up | 1898 |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 4 / 5 | 49 O/L I Alarm | 1 = 49 Overload Current Alarm (I alarm) | 1515 |
| 4 / 6 | 49 O/L Θ Alarm | 1 = 49 Thermal Overload Alarm | 1516 |
| 4 / 7 | 59/67 V0 PU | 1 = 59N/67GN V0 picked up | 5186 |
| 5 / 0 | 59/67 I0 PU | 1 = 59N/67GN I0 picked up | 5188 |
| 5 / 1 | 50Ns-1 Pickup | 1 = 50Ns-1 Pickup | 1224 |
| 5 / 2 | 50Ns-2 Pickup | 1 = 50Ns-2 Pickup | 1221 |
| 5 / 3 | 59-1 picked up | 1 = 59-1 Overvoltage V> picked up | 6568 |
| 5 / 4 | 59-2 picked up | 1 = 59-2 Overvoltage V>> picked up | 6571 |
| 5 / 5 | Vp< picked up | 1 = Inverse Undervoltage Vp< picked up | 6525 |
| 5 / 6 | 81-1 picked up | 1 = 81-1 picked up | 5232 |
| 5 / 7 | 81-2 picked up | 1 = 81-2 picked up | 5233 |
| 6 / 0 | 81-3 picked up | 1 = 81-3 picked up | 5234 |
| 6 / 1 | 81-4 picked up | 1 = 81-4 picked up | 5235 |
| 6 / 2 | 24 warn | 1 = 24 V/f warning stage | 5367 |
| 6 / 3 | 24-1 picked up | 1 = 24-1 V/f> picked up | 5370 |
| 6 / 4 | 24-2 picked up | 1 = 24-2 V/f>> picked up | 5373 |
| 6 / 5 | 32R picked up | 1 = 32R picked up | 5096 |
| 6 / 6 | 32F< picked up | 1 = 32F P< stage picked up | 5126 |
| 6 / 7 | 32F> picked up | 1 = 32F P> stage picked up | 5127 |
| 7 / 0 | 50BF pickup | 1 = 50BF picked up | 1455 |
| 7 / 1 | 46-1 Warn | 1 = 46-1 Current warning stage | 5156 |
| 7 / 2 | 46-1 picked up | 1 = 46-1 picked up | 5165 |
| 7 / 3 | 46-2 picked up | 1 = 46-2 picked up | 5159 |
| 7 / 4 | 48 picked up | 1 = 48 Starting time supervision picked up | 6823 |
| 7 / 5 | 64R-1 picked up | 1 = 64R-1 picked up (Alarm) | 5397 |
| 7 / 6 | 50/27 picked up | 1 = 50/27 picked up | 5547 |
| 7 / 7 | 27TN/59TN PU | 1 = 27TN/59TN with 3 rd harmonic picked up | 5567 |
| 8 / 0 | 40 Vexc failure | 1 = 40 Exc. voltage failure recognized | 5336 |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------------------------|---------------------|
| 8 / 1 | 40 picked up | 1 = 40 picked up | 5337 |
| 8 / 2 | 21 Fault Ph A | 1 = 21 Fault detection Phase A | 3967 |
| 8 / 3 | 21 Fault Ph B | 1 = 21 Fault detection Phase B | 3968 |
| 8 / 4 | 21 Fault Ph C | 1 = 21 Fault detection Phase C | 3969 |
| 8 / 5 | 21 I> & U< | 1 = 21 O/C with undervoltage seal in | 3970 |
| 8 / 6 | <user-defined> | not pre-allocated | - |
| 8 / 7 | <user-defined> | not pre-allocated | - |
| 9 / 0 | <user-defined> | not pre-allocated | - |
| 9 / 1 | <user-defined> | not pre-allocated | - |
| 9 / 2 | <user-defined> | not pre-allocated | - |
| 9 / 3 | <user-defined> | not pre-allocated | - |
| 9 / 4 | <user-defined> | not pre-allocated | - |
| 9 / 5 | <user-defined> | not pre-allocated | - |
| 9 / 6 | <user-defined> | not pre-allocated | - |
| 9 / 7 | <user-defined> | not pre-allocated | - |

3.2.1.6 Protection trip indications

- User-defined protection indications, single-point indications and taggings can be routed on the positions "<user-defined>" as "Destination system interface" using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 10 / 0 | 87 TRIP Phase A | 1 = 87 Differential protection: TRIP Phase A | 5672 |
| 10 / 1 | 87 TRIP Phase B | 1 = 87 Differential protection: TRIP Phase B | 5673 |
| 10 / 2 | 87 TRIP Phase C | 1 = 87 Differential protection: TRIP Phase C | 5674 |
| 10 / 3 | 87 Diff> TRIP | 1 = 87 Differential prot.: TRIP by IDIFF> | 5691 |
| 10 / 4 | 87 Diff>> TRIP | 1 = 87 Diff>> TRIP | 5692 |
| 10 / 5 | 50/51 TRIP | 1 = 50/51 I> TRIP | 1815 |
| 10 / 6 | 51/67 TRIP | 1 = 50/51/67 I>> TRIP | 1809 |
| 10 / 7 | 51V TRIP | 1 = 51V TRIP | 1900 |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 11 / 0 | 49 Th O/L TRIP | 1 = 49 Thermal Overload TRIP | 1521 |
| 11 / 1 | 59/67 V0 TRIP | 1 = 59N/67GN V0 stage TRIP | 5187 |
| 11 / 2 | 59N/67GN TRIP | 1 = 59N/67GN TRIP | 5193 |
| 11 / 3 | 50Ns-1 TRIP | 1= 50Ns-1 TRIP | 1226 |
| 11 / 4 | 50Ns-2 TRIP | 1 = 50Ns-2 TRIP | 1223 |
| 11 / 5 | 59-1 TRIP | 1 = 59-1 Overvoltage V> TRIP | 6570 |
| 11 / 6 | 59-2 TRIP | 1 = 59-2 Overvoltage V>> TRIP | 6573 |
| 11 / 7 | Vp< TRIP | 1 = Inverse Undervoltage Vp< TRIP | 6527 |
| 12 / 0 | 81-1 TRIP | 1 = 81-1 TRIP | 5236 |
| 12 / 1 | 81-2 TRIP | 1 = 81-2 TRIP | 5237 |
| 12 / 2 | 81-3 TRIP | 1 = 81-3 TRIP | 5238 |
| 12 / 3 | 81-4 TRIP | 1 = 81-4 TRIP | 5239 |
| 12 / 4 | 24 th.TRIP | 1 = 24 TRIP of thermal stage | 5372 |
| 12 / 5 | 24-2 TRIP | 1 = 24-2 TRIP of V/f>> stage | 5371 |
| 12 / 6 | 32R TRIP | 1 = 32R TRIP | 5097 |
| 12 / 7 | 32R+SV TRIP | 1 = 32R TRIP with stop valve | 5098 |
| 13 / 0 | 32F P< TRIP | 1 = 32F P< stage TRIP | 5128 |
| 13 / 1 | 32F P> TRIP | 1 = 32F P> stage TRIP | 5129 |
| 13 / 2 | 50BF TRIP | 1 = 50BF TRIP | 1471 |
| 13 / 3 | 46-2 TRIP | 1 = 46-2 TRIP of current stage | 5160 |
| 13 / 4 | 46-⊖ TRIP | 1 = 46 TRIP of thermal stage | 5161 |
| 13 / 5 | 48 TRIP | 1 = 48 Starting time supervision TRIP | 6821 |
| 13 / 6 | 66 TRIP | 1 = 66 Restart inhibit motor TRIP | 4827 |
| 13 / 7 | 64R-2 TRIP | 1 = 64R-2 TRIP | 5399 |
| 14 / 0 | 50/27 TRIP | 1 = 50/27 TRIP | 5548 |
| 14 / 1 | 27TN/59TN TRP | 1 = 27TN/59TN with 3 rd harmonic TRIP | 5568 |
| 14 / 2 | 21 Z1< TRIP | 1 = 21 Z1< TRIP | 3977 |
| 14 / 3 | 21 Z1B< TRIP | 1 = 21 Z1B< TRIP | 3978 |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------------|---------------------|
| 14 / 4 | 21 Z2< TRIP | 1 = 21 Z2< TRIP | 3979 |
| 14 / 5 | 21 T3> TRIP | 1 = 21 T3> TRIP | 3980 |
| 14 / 6 | 40-1 TRIP | 1 = 40 characteristic 1 TRIP | 5344 |
| 14 / 7 | 40-2 TRIP | 1 = 40 characteristic 2 TRIP | 5345 |
| 15 / 0 | 40&V<TRIP | 1 = 40 characteristic&Vexc< TRIP | 5346 |
| 15 / 1 | 40-3 TRIP | 1 = 40 characteristic 3 TRIP | 5343 |
| 15 / 2 | Ext 1 Gen.TRP | 1 = External trip 1: General TRIP | 4537 |
| 15 / 3 | Ext 2 Gen.TRP | 1 = External trip 2: General TRIP | 4557 |
| 15 / 4 | Ext 3 Gen.TRP | 1 = External trip 3: General TRIP | 4577 |
| 15 / 5 | Ext 4 Gen.TRP | 1 = External trip 4: General TRIP | 4597 |
| 15 / 6 | <user-defined> | not pre-allocated | - |
| 15 / 7 | <user-defined> | not pre-allocated | - |

3.2.1.7 User-defined indications (RTD-Box)

- User-defined protection indications, single-point indications and taggings (e.g. indications from the RTD-Box) can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 16 / 0 | <user-defined> | not pre-allocated | - |
| 16 / 1 | <user-defined> | not pre-allocated | - |
| 16 / 2 | <user-defined> | not pre-allocated | - |
| 16 / 3 | <user-defined> | not pre-allocated | - |
| 16 / 4 | <user-defined> | not pre-allocated | - |
| 16 / 5 | <user-defined> | not pre-allocated | - |
| 16 / 6 | <user-defined> | not pre-allocated | - |
| 16 / 7 | <user-defined> | not pre-allocated | - |
| 17 / 0 | <user-defined> | not pre-allocated | - |
| 17 / 1 | <user-defined> | not pre-allocated | - |
| 17 / 2 | <user-defined> | not pre-allocated | - |
| 17 / 3 | <user-defined> | not pre-allocated | - |
| 17 / 4 | <user-defined> | not pre-allocated | - |

3.2.1.8 Device status

- User-defined protection indications, single-point indications and taggings (e.g. Test mode, Control authority, Control mode) can be routed on the positions “<user-defined>” as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 17 / 5 | <user-defined> | not pre-allocated | - |
| 17 / 6 | <user-defined> | not pre-allocated | - |
| 17 / 7 | <user-defined> | not pre-allocated | - |
| 18 / 0 | <user-defined> | not pre-allocated | - |
| 18 / 1 | <user-defined> | not pre-allocated | - |
| 18 / 2 | <user-defined> | not pre-allocated | - |
| 18 / 3 | <user-defined> | not pre-allocated | - |
| 18 / 4 | <user-defined> | not pre-allocated | - |
| 18 / 5 | VT Fuse Failure | 1 = Voltage Transformer Fuse Failure | 6575 |
| 18 / 6 | FAIL: Trip cir. | 1 = 74TC Failure Trip Circuit | 6865 |
| 18 / 7 | Failure 64R In< | 1 = Failure 64R In<: measuring circuit | 5396 |

3.2.1.9 User-defined indications

- User-defined protection indications, single-point indications and taggings can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 19 / 0 | <user-defined> | not pre-allocated | - |
| 19 / 1 | <user-defined> | not pre-allocated | - |
| 19 / 2 | <user-defined> | not pre-allocated | - |
| 19 / 3 | <user-defined> | not pre-allocated | - |
| 19 / 4 | <user-defined> | not pre-allocated | - |
| 19 / 5 | <user-defined> | not pre-allocated | - |
| 19 / 6 | <user-defined> | not pre-allocated | - |
| 19 / 7 | <user-defined> | not pre-allocated | - |

3.2.2 Measured values

- Ref. to chap. 1.3.2 for notes regarding scaling of measured values.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling (32767 corresponds to ...) | Internal object no. |
|--------|-------------------------------------|--------------------------------|---------------------------------------|---------------------|
| 20 | IA S2 = | Operat. meas. current A side 2 | 327.67 kA | 724 |
| 22 | IB S2 = | Operat. meas. current B side 2 | 327.67 kA | 725 |
| 24 | IC S2 = | Operat. meas. current C side 2 | 327.67 kA | 726 |
| 26 | Va-b = | Va-b | 327.67 kV | 624 |
| 28 | Vb-c = | Vb-c | 327.67 kV | 625 |
| 30 | Vc-a = | Vc-a | 327.67 kV | 626 |
| 32 | P = | P (active power) | 32767 kW | 641 |
| 34 | Q = | Q (reactive power) | 32767 kVAr | 642 |
| 36 | f = | Frequency | 327.67 Hz | 644 |
| 38 | <user-defined> | not pre-allocated | - | - |
| 40 | <user-defined> | not pre-allocated | - | - |
| 42 | <user-defined> | not pre-allocated | - | - |
| 44 | <user-defined> | not pre-allocated | - | - |
| 46 | <user-defined> | not pre-allocated | - | - |
| 48 | <user-defined> | not pre-allocated | - | - |
| 50 | <user-defined> | not pre-allocated | - | - |

3.2.3 Metered measurands

- Ref. to chap. 1.3.3 for notes regarding scaling of metered measurands.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling ($2^{31}-1$ corresponds to ...) | Internal object no. |
|--------|-------------------------------------|---|---|---------------------|
| 52 | Wp+ | Wp Forward (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 924 |
| 56 | Wq+ | Wq Forward (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 925 |
| 60 | Wp- | Wp Reverse (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 928 |
| 64 | Wq- | Wq Reverse (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 929 |

3.2.4 Event list

- Information regarding the handshake bytes as well as the retrieval methods of the event list via PROFIBUS-DP can be found in the manual “SIPROTEC Communication module, PROFIBUS-DP - Communication profile”.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|---------|-------------------------------------|--|---------------------|
| 68 | Control_I | Handshake byte for event list via PROFIBUS-DP | - |
| 69 | SPARE | reserved for future use (the value 0 is transmitted at this position) | - |
| 70 | Message block #1 | Identification #1 | - |
| 71 | | Value #1 | |
| 72 | | Time stamp #1 | |
| - 79 | | | |
| 80 | Message block #2 | Identification #2 | - |
| 81 | | Value #2 | |
| 82 | | Time stamp #2 | |
| - 89 | | | |
| 90 | Message block #3 | Identification #3 | - |
| 91 | | Value #3 | |
| 92 | | Time stamp #3 | |
| - 99 | | | |



Standard mapping 3-5

This chapter describes the data in the PROFIBUS-DP messages between the PROFIBUS-DP master and the SIPROTEC device 7UM62 if the standard mapping 3-5 is selected.

| | | |
|-----|-----------------------------|----|
| 4.1 | Message in output direction | 54 |
| 4.2 | Message in input direction | 57 |

4.1 Message in output direction

4.1.1 Event list

- Information regarding the handshake bytes as well as the retrieval methods of the event list via PROFIBUS-DP can be found in the manual "SIPROTEC Communication module, PROFIBUS-DP - Communication profile".

| Offset | Designation | Comments | Internal object no. |
|--------|-------------|--|---------------------|
| 0 | Control_O | Handshake byte for event list via PROFIBUS-DP | - |
| 1 | SPARE | reserved for future use (the value at this position is ignored) | - |

4.1.2 User-defined commands and taggings

- User-defined commands and taggings can be routed on these positions as "Source system interface" using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 2 / 0 | <user-defined> OFF | not pre-allocated | - |
| 2 / 1 | <user-defined> ON | | |
| 2 / 2 | <user-defined> OFF | not pre-allocated | - |
| 2 / 3 | <user-defined> ON | | |
| 2 / 4 | <user-defined> OFF | not pre-allocated | - |
| 2 / 5 | <user-defined> ON | | |
| 2 / 6 | <user-defined> OFF | not pre-allocated | - |
| 2 / 7 | <user-defined> ON | | |
| 3 / 0 | <user-defined> OFF | not pre-allocated | - |
| 3 / 1 | <user-defined> ON | | |
| 3 / 2 | <user-defined> OFF | not pre-allocated | - |
| 3 / 3 | <user-defined> ON | | |
| 3 / 4 | <user-defined> OFF | not pre-allocated | - |
| 3 / 5 | <user-defined> ON | | |
| 3 / 6 | <user-defined> OFF | not pre-allocated | - |
| 3 / 7 | <user-defined> ON | | |
| 4 / 0 | <user-defined> OFF | not pre-allocated | - |
| 4 / 1 | <user-defined> ON | | |
| 4 / 2 | <user-defined> OFF | not pre-allocated | - |
| 4 / 3 | <user-defined> ON | | |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 4 / 4 | <user-defined> OFF | not pre-allocated | - |
| 4 / 5 | <user-defined> ON | | |
| 4 / 6 | <user-defined> OFF | not pre-allocated | - |
| 4 / 7 | <user-defined> ON | | |
| 5 / 0 | <user-defined> OFF | not pre-allocated | - |
| 5 / 1 | <user-defined> ON | | |
| 5 / 2 | <user-defined> OFF | not pre-allocated | - |
| 5 / 3 | <user-defined> ON | | |
| 5 / 4 | <user-defined> OFF | not pre-allocated | - |
| 5 / 5 | <user-defined> ON | | |
| 5 / 6 | <user-defined> OFF | not pre-allocated | - |
| 5 / 7 | <user-defined> ON | | |

4.1.3 Internal Commands

- Ref. to chap. 1.5.1 for additional notes regarding “Changing the setting group”.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 6 / 0 | Setting Group A | Activation of setting group A | - |
| 6 / 1 | Setting Group A | | |
| 6 / 2 | Setting Group B | Activation of setting group B | - |
| 6 / 3 | Setting Group B | | |
| 6 / 4 | <user-defined> OFF | not pre-allocated | - |
| 6 / 5 | <user-defined> ON | | |
| 6 / 6 | <user-defined> OFF | not pre-allocated | - |
| 6 / 7 | <user-defined> ON | | |
| 7 / 0 | <user-defined> OFF | not pre-allocated | - |
| 7 / 1 | <user-defined> ON | | |
| 7 / 2 | <user-defined> OFF | not pre-allocated | - |
| 7 / 3 | <user-defined> ON | | |

4.1.4 Double commands

- Double commands with double-point indications as checkback indication can be routed on these positions as “Source system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 7 / 4 | <user-defined> OFF | not pre-allocated | - |
| 7 / 5 | <user-defined> ON | | |
| 7 / 6 | <user-defined> OFF | not pre-allocated | - |
| 7 / 7 | <user-defined> ON | | |

4.1.5 Measured values

- Ref. to chap. 1.5.2 for additional notes regarding the measured value “Cooling medium temperature”.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling (32767 corresponds to ...) | Internal object no. |
|--------|-------------------------------------|----------------------------|------------------------------------|---------------------|
| 8 | AMB.TEMP = | Cooling medium temperature | 327.67 % | - |

4.2 Message in input direction

4.2.1 Indications

4.2.1.1 User-defined indications

- User-defined protection indications, single-point indications and taggings can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 0 / 0 | <user-defined> | not pre-allocated | - |
| 0 / 1 | <user-defined> | not pre-allocated | - |
| 0 / 2 | <user-defined> | not pre-allocated | - |
| 0 / 3 | <user-defined> | not pre-allocated | - |
| 0 / 4 | <user-defined> | not pre-allocated | - |
| 0 / 5 | <user-defined> | not pre-allocated | - |
| 0 / 6 | <user-defined> | not pre-allocated | - |
| 0 / 7 | <user-defined> | not pre-allocated | - |

4.2.1.2 Diagnosis

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 1 / 0 | Device OK | 1 = Update of the device replica in the SIPROTEC device completed after initial start or restart | 51 |
| 1 / 1 | ProtActive | 1 = At least one protection function is active | 52 |
| 1 / 2 | Error Sum Alarm | 1 = Error with a summary alarm ON | 140 |
| 1 / 3 | Alarm Sum Event | 1 = Alarm summary event ON | 160 |
| 1 / 4 | Relay PICKUP | 1 = Relay PICKUP (group signal) | 501 |
| 1 / 5 | Relay TRIP | 1 = Relay GENERAL TRIP command | 511 |
| 1 / 6 | Operat. Cond. | 1 = Suitable measured quantities are present at the device inputs ($V > 0,1 * V_{nom}$, $I > 0,1 * I_{nom}$ and $10 \text{ Hz} < \text{Freq.} < 70 \text{ Hz}$) | 5002 |
| 1 / 7 | Data valid | 1 = Data in the PROFIBUS-DP message are valid. (This indication is created by the PROFIBUS-DP slave; not available in DIGSI and not relocatable.) | - |

4.2.1.3 Overcurrent time protection I>

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|----------------------------------|---------------------|
| 2 / 0 | 50/51-1 Ph A PU | 1 = 50/51-1 Phase A picked up | 1811 |
| 2 / 1 | 50/51-1 Ph B PU | 1 = 50/51-1 Phase B picked up | 1812 |
| 2 / 2 | 50/51-1 Ph C PU | 1 = 50/51-1 Phase C picked up | 1813 |
| 2 / 3 | V< seal in | 1 = 50/51-1 undervoltage seal-in | 1970 |
| 2 / 4 | 50/51 TRIP | 1 = 50/51 I> TRIP | 1815 |

4.2.1.4 Overcurrent time protection I>>

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 2 / 5 | 67 forward | 1 = 67 I>> direction forward | 1806 |
| 2 / 6 | 67 backward | 1 = 67 I>> direction backward | 1807 |
| 2 / 7 | 50/51-2 Ph A PU | 1 = 50/51-2 Phase A picked up | 1801 |
| 3 / 0 | 50/51-2 Ph B PU | 1 = 50/51-2 Phase B picked up | 1802 |
| 3 / 1 | 50/51-2 Ph C PU | 1 = 50/51-2 Phase C picked up | 1803 |
| 3 / 2 | 51/67 TRIP | 1 = 50/51/67 I>> TRIP | 1809 |

4.2.1.5 Inverse time overcurrent protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---------------------------|---------------------|
| 3 / 3 | 51V Ph A PU | 1 = 51V Phase A picked up | 1896 |
| 3 / 4 | 51V Ph B PU | 1 = 51V Phase B picked up | 1897 |
| 3 / 5 | 51V Ph C PU | 1 = 51V Phase C picked up | 1898 |
| 3 / 6 | 51V TRIP | 1 = 51V TRIP | 1900 |
| 3 / 7 | <user-defined> | not pre-allocated | - |

4.2.1.6 Thermal overload protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 4 / 0 | 49 O/L I Alarm | 1 = 49 Overload Current Alarm (I alarm) | 1515 |
| 4 / 1 | 49 O/L Θ Alarm | 1 = 49 Thermal Overload Alarm | 1516 |
| 4 / 2 | 49 Th O/L TRIP | 1 = 49 Thermal Overload TRIP | 1521 |

4.2.1.7 Unbalanced load protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------------------|---------------------|
| 4 / 3 | 46-1 Warn | 1 = 46-1 Current warning stage | 5156 |
| 4 / 4 | 46-1 picked up | 1 = 46-1 picked up | 5165 |
| 4 / 5 | 46-2 picked up | 1 = 46-2 picked up | 5159 |
| 4 / 6 | 46-2 TRIP | 1 = 46-2 TRIP of current stage | 5160 |
| 4 / 7 | 46-⊖ TRIP | 1 = 46 TRIP of thermal stage | 5161 |

4.2.1.8 Sensitive ground fault protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 5 / 0 | Failure 64R In< | 1 = Failure 64R In<: measuring circuit | 5396 |
| 5 / 1 | 50Ns-1 Pickup | 1 = 50Ns-1 Pickup | 1224 |
| 5 / 2 | 50Ns-1 TRIP | 1 = 50Ns-1 TRIP | 1226 |
| 5 / 3 | 50Ns-2 Pickup | 1 = 50Ns-2 Pickup | 1221 |
| 5 / 4 | 50Ns-2 TRIP | 1 = 50Ns-2 TRIP | 1223 |

4.2.1.9 Stator ground fault protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|----------------------------|---------------------|
| 5 / 5 | 59/67 V0 PU | 1 = 59N/67GN V0 picked up | 5186 |
| 5 / 6 | 59/67 I0 PU | 1 = 59N/67GN I0 picked up | 5188 |
| 5 / 7 | 59/67 V0 TRIP | 1 = 59N/67GN V0 stage TRIP | 5187 |
| 6 / 0 | 59N/67GN TRIP | 1 = 59N/67GN TRIP | 5193 |

4.2.1.10 Stator ground fault protection with 3rd harmonic

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 6 / 1 | 27TN/59TN PU | 1 = 27TN/59TN with 3 rd harmonic picked up | 5567 |
| 6 / 2 | 27TN/59TN TRP | 1 = 27TN/59TN with 3 rd harmonic TRIP | 5568 |

4.2.1.11 Overvoltage protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|------------------------------------|---------------------|
| 6 / 3 | 59-1 picked up | 1 = 59-1 Overvoltage V> picked up | 6568 |
| 6 / 4 | 59-2 picked up | 1 = 59-2 Overvoltage V>> picked up | 6571 |
| 6 / 5 | 59-1 TRIP | 1 = 59-1 Overvoltage V> TRIP | 6570 |
| 6 / 6 | 59-2 TRIP | 1 = 59-2 Overvoltage V>> TRIP | 6573 |

4.2.1.12 Undervoltage protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------------|---------------------|
| 6 / 7 | 27-1 picked up | 1 = 27-1 Undervoltage V< picked up | 6533 |
| 7 / 0 | 27-2 picked up | 1 = 27-2 Undervoltage V<< picked up | 6537 |
| 7 / 1 | 27-1 TRIP | 1 = 27-1 Undervoltage V< TRIP | 6539 |
| 7 / 2 | 27-2 TRIP | 1 = 27-2 Undervoltage V<< TRIP | 6540 |

4.2.1.13 Frequency protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------|---------------------|
| 7 / 3 | 81-1 picked up | 1 = 81-1 picked up | 5232 |
| 7 / 4 | 81-2 picked up | 1 = 81-2 picked up | 5233 |
| 7 / 5 | 81-3 picked up | 1 = 81-3 picked up | 5234 |
| 7 / 6 | 81-4 picked up | 1 = 81-4 picked up | 5235 |
| 7 / 7 | 81-1 TRIP | 1 = 81-1 TRIP | 5236 |
| 8 / 0 | 81-2 TRIP | 1 = 81-2 TRIP | 5237 |
| 8 / 1 | 81-3 TRIP | 1 = 81-3 TRIP | 5238 |
| 8 / 2 | 81-4 TRIP | 1 = 81-4 TRIP | 5239 |

4.2.1.14 Overexcitation protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|------------------------------|---------------------|
| 8 / 3 | 24 warn | 1 = 24 V/f warning stage | 5367 |
| 8 / 4 | 24-1 picked up | 1 = 24-1 V/f> picked up | 5370 |
| 8 / 5 | 24-2 picked up | 1 = 24-2 V/f>> picked up | 5373 |
| 8 / 6 | 24 th.TRIP | 1 = 24 TRIP of thermal stage | 5372 |
| 8 / 7 | 24-2 TRIP | 1 = 24-2 TRIP of V/f>> stage | 5371 |

4.2.1.15 Reverse power protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|------------------------------|---------------------|
| 9 / 0 | 32R picked up | 1 = 32R picked up | 5096 |
| 9 / 1 | 32R TRIP | 1 = 32R TRIP | 5097 |
| 9 / 2 | 32R+SV TRIP | 1 = 32R TRIP with stop valve | 5098 |

4.2.1.16 Forward power supervision

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|----------------------------|---------------------|
| 9 / 3 | 32F< picked up | 1 = 32F P< stage picked up | 5126 |
| 9 / 4 | 32F> picked up | 1 = 32F P> stage picked up | 5127 |
| 9 / 5 | 32F P< TRIP | 1 = 32F P< stage TRIP | 5128 |
| 9 / 6 | 32F P> TRIP | 1 = 32F P> stage TRIP | 5129 |

4.2.1.17 Fuse Failure Monitor

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------------------------|---------------------|
| 9 / 7 | VT Fuse Failure | 1 = Voltage Transformer Fuse Failure | 6575 |

4.2.1.18 Underexcitation protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 10 / 0 | 40 Vexc failure | 1 = 40 Exc. voltage failure recognized | 5336 |
| 10 / 1 | 40 picked up | 1 = 40 picked up | 5337 |
| 10 / 2 | 40-1 TRIP | 1 = 40 characteristic 1 TRIP | 5344 |
| 10 / 3 | 40-2 TRIP | 1 = 40 characteristic 2 TRIP | 5345 |
| 10 / 4 | 40&V<TRIP | 1 = 40 characteristic&Vexc< TRIP | 5346 |
| 10 / 5 | 40-3 TRIP | 1 = 40 characteristic 3 TRIP | 5343 |

4.2.1.19 Circuit breaker failure protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------|---------------------|
| 10 / 6 | 50BF pickup | 1 = 50BF picked up | 1455 |
| 10 / 7 | 50BF TRIP | 1 = 50BF TRIP | 1471 |

4.2.1.20 Impedance protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--------------------------------------|---------------------|
| 11 / 0 | 21 Fault Ph A | 1 = 21 Fault detection Phase A | 3967 |
| 11 / 1 | 21 Fault Ph B | 1 = 21 Fault detection Phase B | 3968 |
| 11 / 2 | 21 Fault Ph C | 1 = 21 Fault detection Phase C | 3969 |
| 11 / 3 | 21 I> & U< | 1 = 21 O/C with undervoltage seal in | 3970 |
| 11 / 4 | 21 Z1< TRIP | 1 = 21 Z1< TRIP | 3977 |
| 11 / 5 | 21 Z1B< TRIP | 1 = 21 Z1B< TRIP | 3978 |
| 11 / 6 | 21 Z2< TRIP | 1 = 21 Z2< TRIP | 3979 |
| 11 / 7 | 21 T3> TRIP | 1 = 21 T3> TRIP | 3980 |

4.2.1.21 Binary inputs

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------------|---------------------|
| 12 / 0 | Ext 1 Gen.TRIP | 1 = External trip 1: General TRIP | 4537 |
| 12 / 1 | Ext 2 Gen.TRIP | 1 = External trip 2: General TRIP | 4557 |
| 12 / 2 | Ext 3 Gen.TRIP | 1 = External trip 3: General TRIP | 4577 |
| 12 / 3 | Ext 4 Gen.TRIP | 1 = External trip 4: General TRIP | 4597 |

4.2.1.22 Inadvertent energisation protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---------------------|---------------------|
| 12 / 4 | 50/27 picked up | 1 = 50/27 picked up | 5547 |
| 12 / 5 | 50/27 TRIP | 1 = 50/27 TRIP | 5548 |

4.2.1.23 Trip coil monitor

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------|---------------------|
| 12 / 6 | FAIL: Trip cir. | 1 = 74TC Failure Trip Circuit | 6865 |

4.2.1.24 Inverse undervoltage protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 12 / 7 | Vp< picked up | 1 = Inverse Undervoltage Vp< picked up | 6525 |
| 13 / 0 | Vp< TRIP | 1 = Inverse Undervoltage Vp< TRIP | 6527 |

4.2.1.25 Startup supervision of motors

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 13 / 1 | 48 Rot. locked | 1 = 48 Rotor LOCKED after Lock. Rotor Time | 6822 |
| 13 / 2 | 48 picked up | 1 = 48 Starting time supervision picked up | 6823 |
| 13 / 3 | 48 TRIP | 1 = 48 Starting time supervision TRIP | 6821 |

4.2.1.26 Startup counter for motors

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------------|---------------------|
| 13 / 4 | 66 TRIP | 1 = 66 Restart inhibit motor TRIP | 4827 |

4.2.1.27 Rotor ground fault protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------|---------------------|
| 13 / 5 | 64R-1 picked up | 1 = 64R-1 picked up (Alarm) | 5397 |
| 13 / 6 | 64R-2 TRIP | 1 = 64R-2 TRIP | 5399 |

4.2.1.28 DC voltage/current protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------|---------------------|
| 13 / 7 | DC Prot.pick.up | 1 = DC protection picked up | 5306 |
| 14 / 0 | DC Prot. TRIP | 1 = DC protection TRIP | 5307 |

4.2.1.29 State of the out-of-step protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-----------------------------------|---------------------|
| 14 / 1 | 78 det. char. 1 | 1 = 78 characteristic 1 picked up | 5069 |
| 14 / 2 | 78 det. char. 2 | 1 = 78 characteristic 2 picked up | 5070 |
| 14 / 3 | 78 TRIP char. 1 | 1 = 78 TRIP characteristic 1 | 5071 |
| 14 / 4 | 78 TRIP char. 2 | 1 = 78 TRIP characteristic 2 | 5072 |

4.2.1.30 Differential Protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 14 / 5 | 87 picked up | 1 = 87 Differential protection picked up | 5631 |
| 14 / 6 | 87 TRIP | 1 = 87 Differential protection TRIP | 5671 |
| 14 / 7 | 87 TRIP Phase A | 1 = 87 Differential protection: TRIP Phase A | 5672 |
| 15 / 0 | 87 TRIP Phase B | 1 = 87 Differential protection: TRIP Phase B | 5673 |
| 15 / 1 | 87 TRIP Phase C | 1 = 87 Differential protection: TRIP Phase C | 5674 |
| 15 / 2 | 87 Diff> TRIP | 1 = 87 Differential prot.: TRIP by IDIFF> | 5691 |
| 15 / 3 | 87 Diff>> TRIP | 1 = 87 Diff>> TRIP | 5692 |

4.2.1.31 User-defined indications

- User-defined protection indications, single-point indications and taggings can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 15 / 4 | <user-defined> | not pre-allocated | - |
| 15 / 5 | <user-defined> | not pre-allocated | - |
| 15 / 6 | <user-defined> | not pre-allocated | - |
| 15 / 7 | <user-defined> | not pre-allocated | - |
| 16 / 0 | <user-defined> | not pre-allocated | - |
| 16 / 1 | <user-defined> | not pre-allocated | - |
| 16 / 2 | <user-defined> | not pre-allocated | - |
| 16 / 3 | <user-defined> | not pre-allocated | - |
| 16 / 4 | <user-defined> | not pre-allocated | - |
| 16 / 5 | <user-defined> | not pre-allocated | - |
| 16 / 6 | <user-defined> | not pre-allocated | - |
| 16 / 7 | <user-defined> | not pre-allocated | - |
| 17 / 0 | <user-defined> | not pre-allocated | - |

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 17 / 1 | <user-defined> | not pre-allocated | - |
| 17 / 2 | <user-defined> | not pre-allocated | - |
| 17 / 3 | <user-defined> | not pre-allocated | - |
| 17 / 4 | <user-defined> | not pre-allocated | - |
| 17 / 5 | <user-defined> | not pre-allocated | - |
| 17 / 6 | <user-defined> | not pre-allocated | - |
| 17 / 7 | <user-defined> | not pre-allocated | - |

4.2.1.32 Stator ground fault protection 100%

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|---|---------------------|
| 18 / 0 | SGF100 Alarm | 1 = Stator ground fault prot. 100%: Alarm stage | 5487 |
| 18 / 1 | SGF100 TRIP | 1 = Stator ground fault prot. 100%: TRIP | 5489 |

4.2.1.33 Rotor ground fault protection 1-3 Hz

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------------------------|---------------------|
| 18 / 2 | 64R-1_3Hzpickup | 1 = 64R-1 (1-3Hz) picked up (Alarm) | 5403 |
| 18 / 3 | 64R-2_3Hz TRIP | 1 = 64R-2 (1-3Hz) TRIP | 5407 |

4.2.1.34 Restricted ground fault protection

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 18 / 4 | 87N picked up | 1 = 87N picked up | 5817 |
| 18 / 5 | 87N TRIP | 1 = 87N TRIP | 5821 |

4.2.1.35 Fault indications of protection functions

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|--|---------------------|
| 18 / 6 | Failure SGF | 1 = Failure stator ground fault prot. 100% | 5486 |
| 18 / 7 | Failure 64R | 1 = Failure 64R: measuring circuit | 5400 |
| 19 / 0 | Fail 64R 1-3Hz | 1 = Failure 64R protection (1-3Hz) | 5401 |
| 19 / 1 | <user-defined> | not pre-allocated | - |
| 19 / 2 | <user-defined> | not pre-allocated | - |
| 19 / 3 | <user-defined> | not pre-allocated | - |

4.2.1.36 Double-point indications

- User-defined double-point indications (e.g. checkback indications of double commands) can be routed on these positions as “Destination system interface” using the **DIGSI Configuration matrix**.

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|--------|-------------------------------------|-------------------|---------------------|
| 19 / 4 | <user-defined> OFF | not pre-allocated | - |
| 19 / 5 | <user-defined> ON | | |
| 19 / 6 | <user-defined> OFF | not pre-allocated | - |
| 19 / 7 | <user-defined> ON | | |

4.2.2 Measured values

- Ref. to chap. 1.3.2 for notes regarding scaling of measured values.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling (32767 corresponds to ...) | Internal object no. |
|--------|-------------------------------------|--------------------------------|---------------------------------------|---------------------|
| 20 | IA S2 = | Operat. meas. current A side 2 | 32.767 kA | 724 |
| 22 | IB S2 = | Operat. meas. current B side 2 | 32.767 kA | 725 |
| 24 | IC S2 = | Operat. meas. current C side 2 | 32.767 kA | 726 |
| 26 | <user-defined> | not pre-allocated | - | - |
| 28 | <user-defined> | not pre-allocated | - | - |
| 30 | <user-defined> | not pre-allocated | - | - |
| 32 | Va-b = | Va-b | 32.767 kV | 624 |
| 34 | Vb-c = | Vb-c | 32.767 kV | 625 |
| 36 | Vc-a = | Vc-a | 32.767 kV | 626 |
| 38 | P = | P (active power) | 327.67 % | 641 |
| 40 | Q = | Q (reactive power) | 327.67 % | 642 |
| 42 | <user-defined> | not pre-allocated | - | - |
| 44 | f = | Frequency | 327.67 Hz | 644 |
| 46 | <user-defined> | not pre-allocated | - | - |
| 48 | <user-defined> | not pre-allocated | - | - |
| 50 | <user-defined> | not pre-allocated | - | - |

4.2.3 Metered measurands

- Ref. to chap. 1.3.3 for notes regarding scaling of metered measurands.

| Offset | Designation of the SIPROTEC objects | Comments | Scaling ($2^{31}-1$ corresponds to ...) | Internal object no. |
|--------|-------------------------------------|---|---|---------------------|
| 52 | Wp+ | Wp Forward (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 924 |
| 56 | Wq+ | Wq Forward (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 925 |
| 60 | Wp- | Wp Reverse (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 928 |
| 64 | Wq- | Wq Reverse (Metered measurand derived from measured values) | $2^{31}-1$ impulses | 929 |

4.2.4 Event list

- Information regarding the handshake bytes as well as the retrieval methods of the event list via PROFIBUS-DP can be found in the manual "SIPROTEC Communication module, PROFIBUS-DP - Communication profile".

| Offset | Designation of the SIPROTEC objects | Comments | Internal object no. |
|---------|-------------------------------------|--|---------------------|
| 68 | Control_I | Handshake byte for event list via PROFIBUS-DP | - |
| 69 | SPARE | reserved for future use (the value 0 is transmitted at this position) | - |
| 70 | Message block #1 | Identification #1 | - |
| 71 | | Value #1 | |
| 72 | | Time stamp #1 | |
| - 79 | | | |
| 80 | Message block #2 | Identification #2 | - |
| 81 | | Value #2 | |
| 82 | | Time stamp #2 | |
| - 89 | | | |
| 90 | Message block #3 | Identification #3 | - |
| 91 | | Value #3 | |
| 92 | | Time stamp #3 | |
| - 99 | | | |



Glossary

| | |
|---|---|
| CFC | Continuous Function Chart |
| DC | Double command |
| GSD file | <p>The GSD file contains the General Station Description (technical characteristics) of the PROFIBUS-DP communication module (PROFIBUS-DP slave).</p> <p>This file is required for configuration of the PROFIBUS-DP master and is supplied together with DIGSI.</p> |
| DIGSI | Parameterization system / parameterization software for SIPROTEC devices |
| DP | Double-point indication |
| Input data / Input direction | Data from the PROFIBUS-DP slave to the PROFIBUS-DP master. |
| Octet | Term from EN 50170, one octet corresponds to 8 bits. |
| OLM | Optical Link Module |
| Output data / Output direction | Data from the PROFIBUS-DP master to the PROFIBUS-DP slave. |
| PNO | PROFIBUS Nutzerorganisation (PROFIBUS International Organization) |
| PROFIBUS-DP | PROFIBUS - Decentralized Peripherals |
| PSE | PROFIBUS interface module with (electrical) isolated RS485 interface for the SIPROTEC devices from Siemens. |
| PSO | PROFIBUS interface module with fibre-optical interface for the SIPROTEC devices from Siemens. |
| SC | Single command |
| SP | Single-point indication |



Index

Numerics

| | |
|-------|----------------------------|
| 21 | 34, 47, 62 |
| 24 | 32, 46, 60 |
| 27 | 32, 46, 60 |
| 32F | 33, 46, 61 |
| 32R | 33, 46, 61 |
| 40 | 33, 46, 61 |
| 46 | 31, 46, 59 |
| 48 | 35, 46, 63 |
| 49 | 30, 46, 58 |
| 50/27 | 34, 46, 62 |
| 50/51 | 30, 45, 58 |
| 50BF | 33, 46, 61 |
| 50Ns | 31, 46, 59 |
| 59 | 32, 46, 60 |
| 59/67 | 31, 46, 59 |
| 64R | 31, 35, 37, 46, 59, 63, 65 |
| 66 | 35, 48, 63 |
| 67 | 30, 45, 58 |
| 74TC | 34, 50, 62 |
| 78 | 36, 64 |
| 81 | 32, 46, 60 |
| 87 | 36, 45, 64 |
| 87N | 37, 65 |

C

| | |
|------------------------------------|--------|
| Changing the setting group | 22 |
| Circuit breaker failure protection | 33, 61 |
| Commands | 26, 54 |
| Configuration data | 18 |
| Cooling medium temperature | 23 |

D

| | |
|-------------------------------|------------|
| DC voltage/current protection | 35, 63 |
| Differential Protection | 36, 64 |
| Double commands | 27, 42, 56 |
| Double-point indications | 38, 44, 66 |

E

| | |
|------------------------------------|--------|
| Event list | |
| Handshake byte in input direction | 52, 68 |
| Handshake byte in output direction | 42, 54 |
| Message blocks | 52, 68 |

F

| | |
|---------------------------|--------|
| Fault indications | 38, 65 |
| Forward power supervision | 33, 61 |
| Frequency protection | 32, 60 |
| Fuse Failure Monitor | 33, 61 |

I

| | |
|-------------------------------------|--------|
| Impedance protection | 34, 62 |
| Inadvertent energisation protection | 34, 62 |
| Indications | 16 |
| Inverse Undervoltage Protection | 35, 63 |

M

| | |
|--------------------|----------------|
| Measured values | |
| Input direction | 16, 39, 51, 67 |
| Output direction | 15, 28, 43, 56 |
| Metered measurands | 17, 40, 51, 68 |

O

| | |
|-----------------------------|--------|
| Overcurrent time protection | 30, 58 |
| Overexcitation protection | 32, 60 |
| Overvoltage protection | 32, 60 |

P

PROFIBUS-DP
Configuration data18
Configuration in the master system20
Event list 52, 68
Message in input direction29, 44, 57
Message in output direction26, 42, 54
Protection pickup indications45

Q

Qualified personnel (definition)5

R

Restricted ground fault protection 37, 65
Reverse power protection 33, 61
Rotor ground fault protection 35, 63
1-3 Hz 37, 65
RTD-Box
Indications49
Measured values16

S

Sensitive ground fault protection 31, 59
Startup counter for motors 35, 63
Startup supervision of motors 35, 63
State of the out-of-step protection 36, 64
Stator ground fault protection 31, 59
100% 37, 65

T

Target audience 4
Thermal overload protection 30, 58
Trip coil monitor 34, 62
Typographic conventions 5

U

Unbalanced load protection 31, 59
Underexcitation protection 33, 61
Undervoltage protection 32, 60

V

Validity of the manual 4