



INSTALLATION

BASE CONTROL MODULE II (BCM II) A53444

MARCH 2013 (REVISED JUNE 2014)

DOCUMENT NO. COM-00-01-02
VERSION C.1

Siemens Industry, Inc., Rail Automation
9568 Archibald Ave., Suite 100,
Rancho Cucamonga, California 91730
1-800-793-SAFE

Copyright © 2013- 2014 Siemens Industry, Inc.
All rights reserved

PRINTED IN U.S.A.

PROPRIETARY INFORMATION

Siemens Industry, Inc. has a proprietary interest in the information contained herein and, in some instances, has patent rights in the systems and components described. It is requested that you distribute this information only to those responsible people within your organization who have an official interest.

This document or the information disclosed herein, shall not be reproduced or transferred to other documents or used or disclosed for manufacturing or for any other purpose except as specifically authorized in writing by **Siemens Industry, Inc.**

TRANSLATIONS

The manuals and product information of Siemens Industry, Inc. are intended to be produced and read in English. Any translation of the manuals and product information are unofficial and can be imprecise and inaccurate in whole or in part. Siemens Industry, Inc. does not warrant the accuracy, reliability, or timeliness of any information contained in any translation of manual or product information from its original official released version in English and shall not be liable for any losses caused by such reliance on the accuracy, reliability, or timeliness of such information. Any person or entity that relies on translated information does so at his or her own risk.

WARRANTY INFORMATION

Siemens Industry, Inc. warranty policy is as stated in the current Terms and Conditions of Sale document. Warranty adjustments will not be allowed for products or components which have been subjected to abuse, alteration, improper handling or installation, or which have not been operated in accordance with Seller's instructions. Alteration or removal of any serial number or identification mark voids the warranty.

SALES AND SERVICE LOCATIONS

Technical assistance and sales information on **Siemens Industry, Inc.** products may be obtained at the following locations:

SIEMENS INDUSTRY, INC., RAIL AUTOMATION
2400 NELSON MILLER PARKWAY
LOUISVILLE, KENTUCKY 40223
TELEPHONE: (502) 618-8800
FAX: (502) 618-8810
SALES & SERVICE: (800) 626-2710
WEB SITE: <http://www.rail-automation.com/>

SIEMENS INDUSTRY, INC., RAIL AUTOMATION
939 S. MAIN STREET
MARION, KENTUCKY 42064
TELEPHONE: (270) 918-7800
CUSTOMER SERVICE: (800) 626-2710
TECHNICAL SUPPORT: (800) 793-7233
FAX: (270) 918-7830

FCC RULES COMPLIANCE

The equipment covered in this manual has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC PART 90 AND PART 101 REQUIREMENTS

This device contains a radio transceiver which operates under Parts 90.210 and 101.101 of the FCC rules in a licensed part of the radio spectrum. It is the user's responsibility to obtain required licensing and authorization to operate this device. Qualified personnel must perform service or repairs to the radio portion of this device. Any unauthorized modification to the radio module, shielding, or antenna system may void the user's authority to operate this device.

RF EXPOSURE WARNING

All antenna installation and servicing is to be performed by qualified technical personnel only. When servicing or working at distances closer than 10 feet (3.05 meters), ensure the transmitter has been disabled. Depending upon the application and the gain of the antenna, the total composite power could exceed 200 watts EIRP. The antenna location should be such that only qualified technical personnel can access it, and under normal operating conditions no other person can come in contact or approach within 10 feet (3.05 meters) of the antenna.

More information on RF exposure can be found online at the following website:
www.fcc.gov/oet/info/documents/bulletins.

This device complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI)/Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation - Human Exposure) Standard, 2003
- ANATEL, Brasil Regulatory Authority, Resolution 256 (April 11, 2001)

DOCUMENT HISTORY

Version	Release Date	Sections Changed	Details of Change
A	11/6/98		Initial Release
B	4/11/05		Incorporate latest configuration changes
C	3-29-13	Entire Book	Addition of MTR3000 Base Station Update XCMMaint software.
C.1	6/6/14	Entire Book	Change to Siemens format and branding

Table of Contents

Section	Title	Page
	PROPRIETARY INFORMATION	ii
	TRANSLATIONS	ii
	WARRANTY INFORMATION.....	ii
	SALES AND SERVICE LOCATIONS.....	ii
	DOCUMENT HISTORY	iv
	NOTES, CAUTIONS, AND WARNINGS	xi
	ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS	xii
	GLOSSARY	xiii
	CHANGE NOTICE	xix
1.0	INTRODUCTION	1-1
1.1	Scope	1-1
1.2	BASE CONTROL MODULE OVERVIEW.....	1-1
1.3	SPECIFICATIONS	1-2
1.4	ORDERING INFORMATION.....	1-2
2.0	FUNCTIONAL DESCRIPTION.....	2-1
2.1	BASE COMMUNICATIONS PACKAGE OVERVIEW	2-1
2.2	ATCS MESSAGE TRANSMISSION.....	2-2
2.2.1	ATCS RF Message Reception	2-2
2.2.2	Duplexer	2-2
2.2.3	Communication Links.....	2-2
2.3	BASE CONTROL MODULE DESCRIPTION.....	2-2
3.0	PHYSICAL DESCRIPTION.....	3-1
3.1	General.....	3-1
3.2	FRONT PANEL CONTROLS AND INDICATORS	3-1
3.3	BCM EXTERNAL CONNECTORS.....	3-2
3.3.1	25 Pin D Type Client Port Connectors (Female)	3-2
3.3.1.1	Client Port Interface Cable Requirements	3-4
3.3.2	9 Pin D Type Diagnostic Connector (Female)	3-4
3.3.3	15 Pin D Type Radio Connector (Female)	3-5
3.3.4	2 Terminal Power Connector (TB-1).....	3-5
3.3.5	12 Pin I/O Connector (Male)	3-6
4.0	CONFIGURATION AND ALIGNMENT	4-1
4.1	INTRODUCTION	4-1
4.2	CONFIGURATION.....	4-1

4.2.1	EEPROM Memory Structure	4-2
4.2.1.1	Boot Code.....	4-2
4.2.1.2	Debugger.....	4-3
4.2.1.3	Code Plug.....	4-3
4.2.1.4	Ladder Logic.....	4-3
4.2.1.5	Executive	4-3
4.2.1.6	Application Task	4-4
4.3	FRONT PANEL CONFIGURATION	4-4
4.3.1	Alphanumeric Display	4-8
4.3.2	Site Edit	4-8
4.3.3	RF Edit.....	4-9
4.3.4	Port J1	4-10
4.3.5	Port J2	4-12
4.3.6	Port DC.....	4-12
4.3.7	Diagnostics	4-13
4.3.8	Date and Time	4-14
4.3.9	Reset	4-14
4.4	BCM II CONFIGURATION PROGRAM.....	4-15
4.4.1	Installation.....	4-15
4.4.2	Using the BCM Configuration Program	4-15
4.4.2.1	Accessing a Saved Codeplug File.....	4-16
4.4.2.2	Read BCM II Codeplug	4-17
4.4.3	Main Editor Screen	4-18
4.4.3.1	Using the Main Editor Screen	4-18
4.4.3.2	Edit Function.....	4-21
4.4.3.3	Online Menu	4-21
4.4.3.4	Help Window	4-31
4.4.3.5	Version Window (Alt-V).....	4-32
4.4.4	Radio Settings Display	4-32
4.4.4.1	Type and Usage Fields	4-32
4.4.4.2	Channel Field	4-34
4.4.4.3	Invert Field.....	4-34
4.4.4.4	RSSI Scale and Base Fields	4-34
4.4.4.5	Radio Gain.....	4-35
4.4.4.6	Default Value Setup	4-35
4.4.5	Site Settings Display	4-35
4.4.5.1	Local Addr Field.....	4-35
4.4.5.2	FEPCC Addr Field	4-36
4.4.5.3	Enable Code App Field (Not used with BCM II).....	4-37
4.4.5.4	Enable Simulation Field (Not Used with BCM II)	4-38
4.4.5.5	Enable Ladder Logic Field (Not Used With BCM II)	4-38
4.4.6	LonTalk® Network Configuration	4-40

4.4.7	BCM Port Configuration	4-40
4.4.7.1	Serial Client Ports J1 and J2	4-40
4.4.7.2	IP Addressing	4-42
4.4.7.3	LON Port.....	4-43
4.4.7.4	DC1 and DC2 Ports	4-43
4.4.7.5	DC1 Codeline Configuration Screen	4-45
4.4.7.6	Loading a New Executive	4-47
4.4.7.7	Installing New Executive Program Version.....	4-47
4.4.7.8	Reinstalling Existing Executive Program Version	4-47
4.4.7.9	Installing New Xilinx Program Version	4-47
4.4.7.10	Reinstalling Existing Xilinx Program Version.....	4-47
4.4.7.11	Installing New DSP Program Version.....	4-47
4.4.7.12	Reinstalling Existing DSP Program Version	4-48
4.4.7.13	GF1, GF2, GF4.....	4-48
5.0	DIAGNOSTICS	5-1
5.1	SELF TEST.....	5-1
5.2	ON-LINE TERMINAL	5-1
5.3	BASE COMMUNICATIONS PACKAGE LOG.....	5-2
5.3.1	Log Event Display	5-2
5.3.2	Log Capture	5-3
A.	ADVANCED TRAIN CONTROL SYSTEM.....	A-1
A.1	OVERVIEW	A-1
A.2	ATCS ADDRESSING.....	A-2
A.2.1	Locomotive Addresses (Type 1).....	A-2
A.2.2	Office Equipment Addresses (Type 2).....	A-2
A.2.3	Base Station Address (Type 3)	A-2
A.2.4	Wayside Equipment (Type 5).....	A-3
A.2.5	Wayside Equipment (Type 7).....	A-3
A.2.6	Other Address Types	A-4
A.3	ATCS MESSAGE FORMATS	A-4
A.4	ATCS RADIO NETWORK – LAYER 1	A-4
B.	RAILROAD CODE LISTING	B-1
C.	BCM CODEPLUG PARAMETERS	C-1
C.1	CODEPLUG PARAMETERS	C-1
D.	GENERIC GROUNDING PROCEDURES.....	D-1
D.1	GENERAL.....	D-1
D.2	EXTERNAL BUILDING GROUND	D-1
D.3	INTERNAL BUILDING GROUND.....	D-3
D.4	ANTENNA GROUND	D-4
D.4.1	Antenna Ground – Roof-Mount Yagi	D-4
D.4.2	Antenna Ground – Towers and Poles	D-4

D.5	AC POWER GROUND.....	D-6
D.6	COMMUNICATIONS GROUND.....	D-7
D.7	CABLING	D-7
D.8	SURGE PROTECTION.....	D-7

List of Figures

Section	Title	Page
Figure 2-1	Base Communications Package Simplified Block Diagram	2-1
Figure 2-2	Base Control Module Simplified Block Diagram	2-3
Figure 3-1	Base Control Module – A53444	3-3
Figure 3-2	Typical Internal Circuitry of J4 Aux DC Input & Output Ports	3-6
Figure 4-1	BCM II Memory Configuration Map	4-2
Figure 4-2	Base Control Module II Front Panel	4-5
Figure 4-3	BCM II Function Menus	4-7
Figure 4-4	BCM II to Personal Computer Interconnection Diagram	4-15
Figure 4-5	Configuration Editor Startup Screen	4-16
Figure 4-6	Codeplug File List	4-16
Figure 4-7	Typical Main Editor Screen	4-17
Figure 4-8	Read BCM II Codeplug File	4-17
Figure 4-9	Read Codeplug from BCM II	4-18
Figure 4-10	XCM File Name and Path	4-19
Figure 4-11	Terminal Sub Menus	4-21
Figure 4-12	Online Terminal Screen Command List	4-23
Figure 4-13	Status Log Enable Command	4-24
Figure 4-14	View Log	4-25
Figure 4-15	Bitmap Display Screen	4-29
Figure 4-16	Help Window	4-31
Figure 4-17	MainEditor Screen – Site Local Address Selection	4-36
Figure 4-18	Main Editor – Site FEPCC Address Selection	4-37
Figure 4-19	Main Editor Screen – Site Enable Code Application Selection	4-37
Figure 4-20	Main Editor Screen – Site Enable Simulation Selection	4-38
Figure 4-21	Main Editor Screen – Site Enable Ladder Logic Selection	4-38
Figure 4-22	Main Editor Screen – Site Logic File Designation	4-39
Figure 4-23	Serial Port Protocol Select	4-41
Figure 4-24	IP Address Assignments Screen	4-42
Figure 4-25	LON Enable Select	4-43
Figure 4-26	DC Port Protocol	4-44
Figure 4-27	DC Alarm Control Configuration	4-44
Figure 4-28	DC Codeline Configuration Screen	4-45
Figure 4-29	Timecode Configuration Defaults	4-46
Figure 5-1	On-Line Terminal Screen Log Record List Initial Display	5-2
Figure 5-2	On-Line Terminal Screen Log New Record Display	5-3
Figure 5-3	Log File List	5-4
Figure A-1	Typical ATCS Network	A-1
Figure A-2	Major Fields Of An ATCS Message	A-4
Figure D-1	Typical Ground Connections	D-2
Figure D-2	Typical Internal Building Ground	D-3
Figure D-3	Typical Tower and Pole Ground Connections	D-5
Figure D-4	Typical Connections for Grounding and Bonding	D-6

List of Tables

Section	Title	Page
Table 3-1	Front Panel Control & Indicator Functions.....	3-1
Table 3-2	25 Pin D Type Connector Pin Assignments	3-2
Table 3-3	9 Pin Female D Type Connector Pin Assignments	3-4
Table 3-4	15 Pin D Type Connector Pin Assignments	3-5
Table 3-5	Power Terminal Block (TB-1) Pin Assignments.....	3-5
Table 3-6	12 Pin Male I/O Connector Pin Assignments	3-6
Table 4-1	Alphanumeric Display Acronyms	4-8
Table 4-2	Site Edit Sub Functions.....	4-9
Table 4-3	RF Edit Sub Functions	4-9
Table 4-4	Port J1 Sub Functions	4-11
Table 4-5	Diagnostic Sub Function.....	4-13
Table 4-6	BCM II Self Tests	4-14
Table 4-7	Client Port Field Descriptions	4-40
Table 4-8	Client Port Protocol Descriptions.....	4-41
Table 5-1	On-Line Terminal Commands.....	5-1
Table C-1	BCM CPU II Code Plug Parameters	C-1
Table C-2	System Configuration Compatibility Summary.....	C-13
Table C-3	Motorola PHD2000 BCP Codeplug Configuration Summary.....	C-15

NOTES, CAUTIONS, AND WARNINGS

Throughout this manual, notes, cautions, and warnings are frequently used to direct the reader's attention to specific information. Use of the three terms is defined as follows:



WARNING

INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY. WARNINGS ALWAYS TAKE PRECEDENCE OVER NOTES, CAUTIONS, AND ALL OTHER INFORMATION.



CAUTION

REFERS TO PROPER PROCEDURES OR PRACTICES WHICH IF NOT STRICTLY OBSERVED, COULD RESULT IN A POTENTIALLY HAZARDOUS SITUATION AND/OR POSSIBLE DAMAGE TO EQUIPMENT. CAUTIONS TAKE PRECEDENCE OVER NOTES AND ALL OTHER INFORMATION, EXCEPT WARNINGS.

NOTE

NOTE

Generally used to highlight certain information relating to the topic under discussion.

If there are any questions, contact Siemens Rail Automation Corporation Application Engineering.

ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS

Static electricity can damage electronic circuitry, particularly low voltage components such as the integrated circuits commonly used throughout the electronics industry. Therefore, procedures have been adopted industry-wide which make it possible to avoid the sometimes invisible damage caused by electrostatic discharge (ESD) during the handling, shipping, and storage of electronic modules and components. Siemens Rail Automation has instituted these practices at its manufacturing facility and encourages its customers to adopt them as well to lessen the likelihood of equipment damage in the field due to ESD. Some of the basic protective practices include the following:

- Ground yourself before touching card cages, assemblies, modules, or components.
- Remove power from card cages and assemblies before removing or installing modules.
- Remove circuit boards (modules) from card cages by the ejector lever only. If an ejector lever is not provided, grasp the edge of the circuit board but avoid touching circuit traces or components.
- Handle circuit boards by the edges only.
- Never physically touch circuit board or connector contact fingers or allow these fingers to come in contact with an insulator (e.g., plastic, rubber, etc.).
- When not in use, place circuit boards in approved static-shielding bags, contact fingers first. Remove circuit boards from static-shielding bags by grasping the ejector lever or the edge of the board only. Each bag should include a caution label on the outside indicating static-sensitive contents.
- Cover workbench surfaces used for repair of electronic equipment with static dissipative workbench matting.
- Use integrated circuit extractor/inserters tools designed to remove and install electrostatic-sensitive integrated circuit devices such as PROM's (OK Industries, Inc., Model EX-2 Extractor and Model MOS-40 Inserter (or equivalent) are highly recommended).
- Utilize only anti-static cushioning material in equipment shipping and storage containers.

For information concerning ESD material applications, please contact the Technical Support Staff at 1-800-793-7233. ESD Awareness Classes and additional ESD product information are also available through the Technical Support Staff.

GLOSSARY

AAR:	<u>Association of American Railroads</u> - An organization that establishes uniformity and standardization among different railroad systems.
ABM:	<u>Asynchronous Balance Mode</u> – Used as an identifier for a HDLC protocol.
ADM:	<u>Asynchronous Disconnect Mode</u> – Used as an identifier for a HDLC protocol.
AEI:	<u>Automatic Equipment Identification</u> - Equipment installed at sites along the track to read and report train consist information.
ARES:	<u>Advanced Railroad Electronics System</u> - Made by Rockwell International as an alternative to AAR ATCS.
ATCS:	<u>Advanced Train Control System</u> - A set of standards compiled by the AAR for controlling all aspects of train operation.
BCM II:	<u>Base Control Module II</u> – The Safetran 53444 assembly that centrally controls the functions of the BCP II.
BCP II:	<u>Base Communications Package II</u> - Defined by the ATCS specifications as the transmitter / receiver base station and associated processors to handle communications between mobile and central office equipment.
BER:	<u>Bit Error Rate</u> - Expresses the quality of a communications in the number of errors per bits sent.
BPSK:	<u>Binary Phase Shift Keying</u> - A method of modulating a carrier signal to carry two bits of information in every cycle.
CBT:	Common Base Technology – A term referring to product design using a modular based approach.
CC:	<u>Cluster Controller</u> - An ATCS ground network node responsible for the control of BCP II's.
CHIPS:	The number of bits in the PN code used to represent each data bit.
CODEPLUG:	An area of non-volatile memory in a BCM II or WCM that contains site configuration data.
CPC:	<u>Central Protocol Converter</u> - Modular component of Safetran's R/Link™ Radio Control System that converts CTC code line control and indication message data to ATCS-compatible data.
CRC:	<u>Cyclic Redundancy Check</u> - The CRC on a data packet is normally calculated and appended to the data so that the receiver can verify that no data was lost or corrupted during transit.
CSAT:	<u>Cut Section SAT</u> - A Signaling Application Task allowing a Virtual Circuit to be broken in a manner similar to a relay contact in a pole line system.
CMSA/CA:	<u>Carrier-Sense-Multiple-Access/Collision Avoidance</u> - A scheme for allowing multiple transmitters sharing a single medium to cooperatively timeshare with a minimum of overlap and interference.

GLOSSARY

CTC:	<u>Central Traffic Control System</u>
CTS:	<u>Clear To Send</u>
DAX:	<u>Downstream Adjacent Crossing</u> - A prediction indication for a remote GCP located somewhere other than the equipment feed point.
DATAGRAM:	In general, any ATCS packet. Several types of datagrams are defined for specific functions within an ATCS environment.
dB:	Abbreviation for decibel. The standard unit for expressing transmission gain or loss and relative power levels. Decibels indicate the log ratio of power output to power input.
dB _i :	Abbreviation for decibels referenced to an isotropic (unipole) antenna.
dB _m :	Abbreviation for decibels above (or below) one milliwatt.
DCE:	<u>Data Communications Equipment</u> - A device that merely transports but does not originate or consume data.
DEVICE:	Specific to the Contents Listing, MCF Approval Listing, and Diagnostic Terminal Utility, a device represents the smallest possible breakdown of an ATCS address which may identify a Virtual Circuit, cut section, signal SAT, module, etc.
DT:	<u>Diagnostic Terminal</u> - A DOS-based PC utility for configuring a module and reading status and diagnostic information.
DTE:	<u>Data Terminal Equipment</u> - Any device (printer, terminal, PC, host computer) that originates or consumes data over a transmission facility.
ECD:	<u>External Configuration Device</u> - The EEPROM on the interface connector used for storing the module configuration data.
EIA:	<u>Electronics Industries Association</u> - A standards organization in the U.S. specializing in the electrical and functional characteristics of interface equipment.
ECP:	<u>Emergency Control Protocol</u>
ERP:	<u>Effective Radiated Power</u> - The product of the antenna power (transmitter power less transmission-line loss) times either the antenna power gain or the antenna field gain squared.
FEP:	<u>Front End Processor</u> - An ATCS ground network node responsible for providing network access to ground host and terminal users (provides network interfacing).
FIFO:	<u>First In, First Out</u> - A buffer or shift register configured so that the first data queued is the first data dequeued - i.e. the sequence is preserved.
FSK:	<u>Frequency Shift Keying</u> - A baseband modulation technique that conveys digital information over analog facilities by associative discrete logical states with pre-defined frequencies.

GLOSSARY

GMSK:	<u>Gaussian Mask Shift Keying</u> - A complex signal conditioning process employed by the BCM II prior to audio transmission.
GENI (F):	<u>Genesys Field Protocol</u>
GENI (O):	<u>Genesys Office Protocol</u>
GTC:	<u>Ground Terminal Computer</u>
HAYES AT COMMAND:	A set of commands defined by the Hayes Corporation for the control and configuration of modems.
HD POLE LINE:	Wires strung along wayside poles for carrying signal aspect and other train control signals. HD stands for Home/Distant, referring to track block signals.
HDF:	<u>Hardware Description Files</u> - A utility file for configuring a module and reading status and diagnostic information.
HDLC:	<u>High-level Data Link Control</u> - A serial protocol for exchanging synchronous information.
IDTU:	<u>Installers Diagnostic Terminal Utility</u> - A DOS-based PC utility for configuring a module and reading status and diagnostic information.
IN SERVICE CHECK NUMBER:	A number, unique to a particular HD/LINK module that is logged in the Event Log when the HD/LINK module is in service.
IP:	<u>Internet Protocol</u> - ISO Model Layer 3 (network) protocol that performs proper routing of packets.
LAN:	<u>Local Area Network</u> - A limited network where the data transfer medium is generally wires or cable.
LEFT NEIGHBOR:	The Group displayed on the Main Window virtual-circuit configuration display to the left of the MCF documented Group.
LINK MARGIN:	The amount of received signal strength beyond the receiver threshold reserved to compensate for normal signal fluctuations.
LOD:	<u>Light Out Detector</u> - A device that monitors current flowing in a circuit such as a signal light, switch, etc., for the purpose of detecting a fault condition in the circuit.
LSB:	<u>Least Significant Bit</u> of a binary number (having the lowest numerical weight)
MCF:	<u>Module Configuration File</u> - The HD/LINK configuration software.
MCI:	<u>Module Configuration Information</u> - The collection of database records that represents the MCF data.
MCP/WCP:	<u>Mobile/Wayside Communications Package</u> - The radio and associated processor used by mobile and wayside ATCS compatible equipment to communicate to the central office.

GLOSSARY

MCP:	<u>Mobile Communications Package</u> - The radio and associated processor used by mobile ATCS compatible equipment to communicate to the central office.
MCS:	Harmon Protocol
MCS2000	Discontinued Motorola 900MHz radio used in the legacy WCP units.
MDF:	<u>Module Description Files</u> – The configuration and capability information for the MEF.
MDS SD9	<u>Microwave Data Systems</u> SD9 - 900 MHz radio used in WCP
MEF:	<u>Module Executable File</u> - The HD/LINK executable software.
MSB:	Most Significant Bit of a binary number (having the greatest numerical weight)
NUL:	<u>Null</u> – Used as an identifier for a HDLC protocol.
NULL MODEM:	A cable or other device that connects two DTE devices directly by emulating the physical connections of a DCE (the Transmit output of each DTE is connected to the Receive input of the other DTE).
OUT SERVICE CHECK NUMBER:	A number, unique to a particular HD/LINK module that is logged in the Event Log when the HD/LINK module is out of service.
POL	<u>Polled</u> – Used as an identifier for a HDLC protocol.
PN CODE:	<u>Pseudo Noise code</u> - A binary code mathematically optimized in such a way that when used to modulate a transmit carrier signal, the energy is spread evenly over the complete band.
QPSK:	<u>Quadrature Phase Shift Keying</u> - A method of modulating a carrier signal in such a way that each cycle carries four bits of information.
RCI:	<u>Receive Clock In</u>
RIGHT NEIGHBOR:	The Group displayed on the Main Window virtual-circuit configuration display to the right of the MCF documented Group.
RS232:	EIA interface standard between DTE and DCE, employing serial binary data interchange.
RS422:	EIA interface standard that extends transmission speeds and distances beyond RS232, employing a balanced-voltage system with a high level of noise immunity.
RSSI:	<u>Received Signal Strength Indication</u> - A numerical value indicating the relative strength of received carrier.
RTS:	<u>Ready To Send</u>
RTU:	<u>Remote Terminal Unit</u> - Also known as Field Code Unit or Code Unit. Used to perform non-vital I/O under control of a central office unit.
RXD:	<u>Receive Data</u>
SAT:	<u>Signaling Application Task</u> - A Virtual Circuit of cut sections.

GLOSSARY

SB9600:	A specification for a proprietary 2-wire data bus used by Motorola for control and programming of microprocessor-based two-way radio equipment.
SCM:	<u>System Control Module</u> – The module within a Motorola ATCS base station that centrally controls the functions of the transceiver and all other components of the station.
SCS:	<u>Safetran Code System</u>
SIGNAL ASPECT:	The appearance of a fixed signal conveying an indication as viewed from the direction of an approaching train; the appearance of a cab signal conveying an indication as viewed by an observer in the cab.
SIN:	<u>Site (Subnode) Identification Number</u> - A twelve-digit ATCS address representing the module as a subnode on the network.
SPREAD SPECTRUM:	A method of radio transmission in which the transmitted energy is evenly spread over the complete bandwidth of the radio, resulting in a low RF profile.
SSI:	<u>Signal Strength Indicator</u> - A measure of the relative strength of an incoming RF signal when it was received by a BCP II.
SSR:	<u>Spread Spectrum Radio</u> - A transmitter/receiver that uses a method of radio transmission in which the transmitted energy is evenly spread over the complete bandwidth of the radio, resulting in small RF signature.
TCI:	<u>Transmit Clock In</u>
TCO:	<u>Transmit Clock Out</u>
TCP/IP:	<u>Transmission Control Protocol / Internet Protocol</u> - The Internet protocol used to connect a world-wide internetwork of universities, research laboratories, military installations, organizations, and corporations. The TCP/IP includes standards for how computers communicate and conventions for connecting network and routing traffic.
TXD:	<u>Transmit Data</u>
UAX:	<u>Upstream Adjacent Crossing</u> - A control indication typically driven from a remote GCP (DAX) location.
UCN:	<u>Unique Check Number</u> - A configuration validation number calculated from the contents of an approved MCF and issued to be entered into an HD/LINK module for the purpose of verifying proper configuration.
UDP:	<u>User Datagram Protocol</u> - A transport protocol used primarily for the transmission of network management information. Not as reliable as TCP.
VCE:	<u>Virtual Circuit Editor</u> - The functional element of the HD/LINKer program used to graphically design the group-specific virtual line circuit configurations of the H/D LINK Vital I/O Modules.
VPI:	<u>Vital Parallel Input</u> – A module input circuit the function of which affects the safety of train operation.

GLOSSARY

VRO:	<u>Vital Relay Output</u> – A module output circuit the function of which affects the safety of train operation.
VSAT:	<u>Virtual Circuit SAT</u> – A software Virtual Circuit termination device known as a Signaling Application Task for providing logical functionality, and possessing its own unique ATCS address
WCM:	<u>Wayside Control Module</u> – The Safetran A53105 assembly that centrally controls the functions of a WCP
WCP:	<u>Wayside Communications Package</u> – The transmitter/receiver and associated control processors that handle communications between field equipment and BCP II equipment.
WIU	<u>Wayside Interface Unit</u> –
XCM FILE:	An MS-DOS file with an “.XCM” extension. A Safetran codeplug file for the BCM II or WCM.

CHANGE NOTICE

The following changes were made to this document:

Revision Number	Description of Changes	Date Revised
C	Updated entire manual Addition of MTR3000 Base Station Update XCMMAINT software information	3-29-13

This Page Intentionally Left Blank

SECTION I INTRODUCTION

1.0 INTRODUCTION

1.1 SCOPE

This manual describes operation and configuration of the A53444 Base Control Module II (BCM II) portion of the Siemens Base Communications Package II (BCP II) Radio System.

- The BCP II includes the BCM II, the MTR3000A Motorola Base Station/Repeater and Receiver and the RF Duplexer.
- Complete installation instructions for all BCP II components are provided in the Base Communications Package II Installation Manual (Siemens Document No. COM-00-97-20).

The BCP II is periodically upgraded with additional features; therefore, prospective users are encouraged to contact Siemens for the latest technical information, or to request customization.

1.2 BASE CONTROL MODULE OVERVIEW

The major features of the BCM are:

- 30% Lower power consumption during key-up and 200% lower power on standby
- RS-232 / RS422 connection option on two client ports
- 16-character front-panel display provides clear diagnostic messages
- Front-panel push-button configuration – no laptop needed during routine maintenance
- Inbound RSSI reading provides additional system information of signal strength at BCM location
- Optional on-board ladder-logic processing for code system applications
- Protocol emulation and conversion of many industry standard code-line protocols
- GMSK direct FM signaling at 4800 baud rate (software upgraded to 9600 baud)

1.3 SPECIFICATIONS

Input Voltage:	9V to 36VDC
Input Isolation:	2000V rms
Power Consumption:	200mA @ 13.5V
Client Ports:	2 x RS-232 / RS-422 software selectable to 256k baud, 25-pin D connectors
Display:	16-character Alphanumeric
Configuration:	Locally via front-panel switches / display Locally via laptop PC Remotely via Siemens Network Management System
Aux I/O:	Two opto-isolated inputs 10V DC to 36VDC Two switchable supply outputs to 1.5A
LED Indications:	RF TX, RF RX, Power On, LAN activity, Echelon [®] Service
Dimensions:	17.28 inches (43.89 centimeters) wide 1.74 inches (4.42 centimeters) high 8.3 inches (21.08 centimeters) deep
Weight:	7.5 pounds (3.375 kilograms) (approximately)
Operating Temperature	-40°F to +158°F (-40°C to +70°C)

1.4 ORDERING INFORMATION

To order, specify the Base Control Module part number, 9000-53444-0001.

SECTION II

FUNCTIONAL DESCRIPTION

2.0 FUNCTIONAL DESCRIPTION

2.1 BASE COMMUNICATIONS PACKAGE OVERVIEW

The BCP II, Figure 2-1, is used in an Advanced Train Control System (ATCS) data network.

- It provides the interface between the ATCS RF network and the Cluster Controller (CC).




Figure 2-1 Base Communications Package Simplified Block Diagram

2.2 ATCS MESSAGE TRANSMISSION

ATCS messages (see Appendix A) to be transmitted over the ATCS RF network are processed by the BCM II into two functional signals: Transmit (TX) Enable, which initiates Base Station transmission; and TX Audio, a sinusoidal representation of ATCS Messages.

- The TX Audio signal is used within the Base Station to FM modulate an RF carrier and thus create the TX signal, which is fed through the Duplexer to the antenna for transmission over the ATCS RF network.
- At the completion of the ATCS messages, the TX Enable signal is removed and Base Station transmission stops.
- The ATCS Messages may originate either from the CC or the LAN.

2.2.1 ATCS RF Message Reception

ATCS messages received from the ATCS RF network are routed through the Duplexer and applied to the Base Station as the Receive (RX) signal.

- The RX signal is demodulated and a corresponding RX Audio signal is fed to the BCM II.
- This signal, together with a Receive Signal Strength Indication (RSSI) signal, are processed by the BCM II and applied in the ATCS Message format to either the CC.
- The ATCS Message destination is determined by the ATCS Address (see Appendix A for a description of the ATCS address scheme).

2.2.2 Duplexer

The BCP Duplexer enables simultaneous transmission and reception of ATCS messages.

2.2.3 Communication Links

Communication between the BCP and the CC is via several serial interface options.

2.3 BASE CONTROL MODULE DESCRIPTION

The BCM, Figure 2-2, consists of three functional circuits interconnected by a common data bus: the Transceiver/Processor (T/P), the Gaussian Mask Shift Key (GMSK) Modem.

- Each of these circuits is able both to receive and transmit ATCS message data.
- Transmission circuit selection is determined by the ATCS destination address.
 - ◆ For example, when an ATCS message is received from the CC addressed to equipment on the ATCS RF network, the GMSK Modem is enabled to transmit.




Figure 2-2 Base Control Module Simplified Block Diagram

Master control of the data bus is exercised by the T/P.

- Messages are routed through the BCM in accordance with client (configuration) data resident within memory (flash EEPROM) of the T/P.
- ATCS messages are converted from a serial to a parallel format by the receiving circuit and placed on the data bus.
- The message is then analyzed by the T/P and the appropriate circuit is enabled for transmission.
 - ◆ During the transmission process, the parallel message data is converted to a serial format by the transmitting circuit and routed to the specified ATCS address.

This page intentionally left blank

SECTION III PHYSICAL DESCRIPTION

3.0 PHYSICAL DESCRIPTION

3.1 GENERAL

The BCM is designed for 19-inch rack mounting.

- Adjustable mounting brackets allow the front of the module to be aligned with the MTR3000™ during installation.
- Refer to the Base Communications Package Installation Manual (Siemens Document No. COM-00-97-20) for BCM installation procedures.

3.2 FRONT PANEL CONTROLS AND INDICATORS

The Base Control Module front panel controls and indicators are identified on Figure 3-1.

- Their type and function are listed in Table 3-1.

Table 3-1 Front Panel Control & Indicator Functions

Indicator/Control	Type	Function
POWER	Push-button Switch	Applies power to the BCM II.
RESET	Push-button Switch	Press to reset the BCM II
16-Character Alphanumeric Display		Displays various status and configuration messages depending on display mode
ENTER	Push-button Switch	Confirms selection options (see below)
SELECT	Push-button Switch	Selects between various operating and configuration options
POWER GOOD	LED	Lit when power is applied to the BCM II
LAN TX*	LED	Lights to indicate transmit activity on the local area network (LAN)
LAN RX*	LED	Lights to indicate receive activity on the local area network (LAN)
RF-RX	LED	Lit when BCM II is receiving a properly formatted message
RF-TX	LED	Lit when BCP II Base Station/Repeater is keyed and transmitting a properly formatted message
HEALTH CHK	LED	Flashes to indicate the system is operational
ALARM 1	LED	For future application
ALARM 2	LED	For future application

3.3 BCM EXTERNAL CONNECTORS

The BCM is equipped with six connectors (see Figure 3-1) which include two 25-pin D-type client port connectors, a 15-pin D-type radio connector, a 12-pin male I/O connector, a 9-pin D-type diagnostic connector, and two connection terminal block.

- The pin assignments for each of these connectors are described in the following paragraphs.

3.3.1 25 Pin D Type Client Port Connectors (Female)

The female, 25-pin, D-type connectors (J1 and J2) located on the 23388 ATCS Serial Interface Assembly panel at the back of the BCM II enclosure provide serial client ports that can be configured for RS-232 or RS-422 operation during configuration (see Section 4).

- Similarly, for synchronous protocols, the direction of the transmit clock for each port is software configurable to work either as a DCE or DTE device.
- Table 3-2 lists the pin assignments for the 25-pin connectors.
- See paragraph 3.3.1.1 for client port interface cable requirements.

Table 3-2 25 Pin D Type Connector Pin Assignments

Pin	RS-232	RS-422
2	Tx Data out	Tx data (-) out
3	Rx Data in	Rx data (-) in
4	RTS out	RTS (-) out
5	CTS in	CTS (-) in
7	Common	Common
9		Rx Clock (+) in
12		Tx Clock (+) in
13		CTS (+) in
14		Tx data (+) out
15	Tx clock in	Tx clock (-) in
16		Rx data (+) in
17	Rx clock in	Rx clock (-) in
18		Tx clock (+) out
19		RTS (+) out
24	Tx clock out	Tx clock (-) out

3.3.1.1 Client Port Interface Cable Requirements

The client port interface cable used to connect 25-pin connector J1 or J2, located on the back panel of the BCM II, to a modem, consists of 8-conductor RJ45 cable and two RJ45-to-DB25 male adapters.

- This is a straight-through cable with the following pin connections on the adapters:

Pin	Pin
2	2
3	3
4	4
5	5
7	7
15	15
17	17
24	24

NOTE**NOTE**

Do not use a standard RS-232 or other 25-pin cable for this connection when interfacing to a modem. Use only the cable specified by Safetran.
➤ Failure to do so could result in improper operation of the BCM II.

3.3.2 9 Pin D Type Diagnostic Connector (Female)

The female, 9-pin, D-type connector (Diagnostics) located on the front panel provides access to the BCM II diagnostic and configuration data during maintenance operations.

- Table 3-3 lists the pin assignments for this connector.
- Use a straight-through cable to connect to the diagnostic computer.

Table 3-3 9 Pin Female D Type Connector Pin Assignments

Pin	Function
2	Tx data out
3	Rx data in
5	Common
7	RTS out
8	CTS in

3.3.3 15 Pin D Type Radio Connector (Female)

The female, 15-pin, D-type connector (J3) located on the 23372 BCM II Radio Interface panel at the back of the BCM II enclosure provides interface to the BCP II radio.

- Table 3-4 lists the pin assignments for the 15-pin connector.

Table 3-4 15 Pin D Type Connector Pin Assignments

Pin	Function
1	Channel Active (MCS2000 applications only)
2	Radio Push to Talk out
3	TX Audio
4	Analog Ground
5	RX Audio
7	Reset (MCS2000 applications only)
8	Digital Ground
9	SB9600 bus (+) (MCS2000 applications only)
10	SB9600 bus (-) (MCS2000 applications only)
11	Analog Ground
12	RSSI
13	SB9600 bus busy (MCS2000 applications only)
14	Status (MCS2000 applications only)
15	Digital ground

3.3.4 2 Terminal Power Connector (TB-1)

The two-terminal power connector is a standard terminal strip with screw terminals.

- Polarity is clearly marked on the BCM II rear panel directly above the terminal strip.
- The left terminal is negative (–) and the right terminal is positive (+).

Table 3-5 Power Terminal Block (TB-1) Pin Assignments

Pin	Function
1	Battery Minus
2	Battery Plus

3.3.5 12 Pin I/O Connector (Male)

The male, 12-pin, I/O connector (J4) located on the 23372 BCM II Radio Interface panel at the back of the BCM enclosure provides eight opto-isolated input connections and two opto-isolated output connections.

- Table 3-6 lists the pin assignments for the 12-pin connector.
- Typical internal circuitry of auxiliary DC input & output ports are shown in Figure 3-2.

Table 3-6 12 Pin Male I/O Connector Pin Assignments

Pin	Function
1	Output 1
2	Output 2
3	Input 1
4	Input 2
5	Input 3
6	Input 4
7	Input 5
8	Input 6
9	Input 7
10	Input 8
11	Output common negative (-)
12	Input common negative (-)




Figure 3-2 Typical Internal Circuitry of J4 Aux DC Input & Output Ports

SECTION IV

CONFIGURATION AND ALIGNMENT

4.0 CONFIGURATION AND ALIGNMENT

4.1 INTRODUCTION

BCM II configuration data identifies the BCM II with a specific location and establishes its communications, I/O, and ancillary function parameters. BCM II alignment sets the operational parameters of the MTR3000 base station.

4.2 CONFIGURATION

Ordinarily, initial setup and routine maintenance tasks consist of making changes to the site configuration (code plug) and storing the data permanently in the BCM II.

- While most of the parameters are factory set and do not require user alteration, site-specific data such as local ATCS address, remote FEPCC address, client port assignments, system timers, hardware configuration, and etc. may be programmed onsite by field maintenance personnel.
- This is accomplished in one of three ways:
 1. Manually, by means of the front panel push buttons and display.
 2. Using the configuration editor in XCMMaint.EXE and uploading the complete modified code plug information. This is the recommended method.
 3. Patching the code plug data one byte at a time in the online terminal mode of XCMMaint.EXE. This method is more likely to be used by experienced maintenance personnel for updating or making small changes at an in-service site.

The advantage of the front-panel method is that no diagnostic equipment (typically a laptop computer) is necessary to check configuration data or to perform routine maintenance.

When using the Safetran XCMMaint configuration/online utility, all code plug data (as well as other site data) may be stored in a PC data file.

- The MS-DOS file extension for this type of file is “.XCM” and is used to refer to code plug files for the BCM II.
- This allows code plug files for each BCP II to be saved with a unique file name.
 - ◆ One or more ‘default’ code plug files may be generated and saved to disk.
- The advantage to this method is that commonly-used configurations may be conveniently stored and later used by the XCMMaint utility to configure new units as they are installed.

A complete list of all code plug parameters is provided in Appendix C.

4.2.1 EEPROM Memory Structure

All user data and executable programs within the BCM II are stored in a 256kb block of on-board flash EEPROM memory.

- The BCM II logical memory map is illustrated below.

Debugger	400000
Configuration	410000
Xilinx	420000
DSP	440000
Ladder Logic Appl.	460000
Ladder Logic Labels	470000
Executive Firmware	480000
HWCT	4F0000

Figure 4-1 BCM II Memory Configuration Map

- The memory sections of the BCM II's on-board flash EEPROM are described in the following paragraphs.

4.2.1.1 Boot Code

Boot Code refers to the bootstrap program that is run when the system is powered up or reset.

- This code performs a system self-test and exits to the loaded application software or the debugger.
- The boot code is preloaded at the factory but can be updated with newer versions by field personnel.

4.2.1.2 Debugger

This program provides low-level diagnostics and direct access to hardware and firmware for testing purposes.

- The debugger is bundled with the boot code and is therefore field upgradable.

4.2.1.3 Code Plug

The code plug is the section of memory set aside for storage of configuration data specific to the installation site.

- All field-programmable data such as ATCS addresses, channel information, timer values, etc. are stored in the code plug.
- See Appendix C for details.

NOTE**NOTE**

The term “codeplug” is also used for the same configuration data storage function in the associated MTR radio, but access to the latter is only possible by using a separate utility with different maintenance hardware. Refer to the RSS Startup Manual for detailed instructions.

4.2.1.4 Ladder Logic

The ladder logic is an optional application task that consists of compiled Boolean equations for decision-making based on local I/O and data traffic.

- There is a standalone Siemens utility for creating and compiling ladder logic files that is separate from the module configuration utility.
- The ladder logic utility is available for future BCM II applications.

4.2.1.5 Executive

The executive program is a set of application tasks that can be considered the “operating system” for the BCM II.

- These application tasks are preloaded at the factory, but may be field upgraded to accommodate newer applications.

4.2.1.6 Application Task

An application task accommodates any site-specific program that is run or loaded, and which uses components of the executive program for I/O, system access and low-level functions.

- Application task programs are not used by the BCM II.

4.3 FRONT PANEL CONFIGURATION

Each time power is applied, the BCM II performs a series of tests to evaluate its operational status.

- The tests performed and their results are presented on the alphanumeric display (see Figure 4-2).
- At the completion of these tests, a **TESTS COMPLETE** message is displayed.
- This message is automatically turned off approximately 5 minutes after test completion.

NOTE**NOTE**

Pressing the **SELECT** push button while the **Reset** function is displayed, turns off the display and returns the BCM II to normal operation. (If the **ENTER** push button is pressed, the unit will reset.)




Figure 4-2 Base Control Module II Front Panel

The display is reactivated by the **SELECT** push button.

- When this push button is pressed, **Site Edit**, the first of eight functions, is displayed.
- Subsequently, each time the **SELECT** push button is pressed, the display advances to a new function (see Figure 4-2).

These functions may be sequentially accessed as follows:


- Site Edit
- RF Edit
- Port J1
- Port J2
- Port DC
- Diagnostics
- Date/Time
- Reset

Most of the display functions listed above contains subfunctions that allow the user to change and/or monitor Codeplug data.

- The subfunctions accessible from each function are identified in the following paragraphs.

Subfunctions are selected as follows:

1. Press and release the **SELECT** push button until the desired function is displayed.
2. Press the **ENTER** push button.
The first subfunction listing is displayed.
3. Press and release the **SELECT** push button until the desired subfunction is displayed.
4. Press the **ENTER** push button.
An “*” appears at the right of the subfunction display.
5. Press and release the **SELECT** push button until the desired value or item is displayed.
6. Press the **ENTER** push button.
 - **Confirm (Enter)** is displayed.
7. Press the **ENTER** push button to confirm the selected value or item.
8. Press and release the **SELECT** push button until the function of step 1 is again displayed.
9. Repeat steps 1 through 8 as required.




R031105_0821-MOD
06-04-14

Figure 4-3 BCM II Function Menus

4.3.1 Alphanumeric Display

The Alphanumeric Display is divided into two sections as shown below. The seven most significant bits of each section are identified by an acronym as shown below:



The acronyms above section 1 have no relevance at this time.


- The acronyms above section 2 correspond to and identify the relevant serial bits of BCM II ports J1 and J2 and the local, opto-isolated I/O of 12-pin connector J4.
- The definitions for these acronyms are listed in Table 4-1.

Table 4-1 Alphanumeric Display Acronyms

Acronym	Definition
RXD	Receive Data
TXD	Transmit Data
TCO	Transmit Clock Out
RCI	Receive Clock In
RTS	Ready To Send
CTS	Clear To Send
TCI	Transmit Clock In

4.3.2 Site Edit

The **Site Edit** function display is shown below:




The sub functions listed in Table 4-2 may be accessed from this function.

Table 4-2 Site Edit Sub Functions

Subfunction Display	Item/Value Range	Description
Set	Factory	Factory code set
XCM id:	Enable	Local address enable
	Disable	Local address disable

4.3.3 RF Edit

The **RF Edit** function display is shown below:




The sub functions listed in Table 4-3 may be accessed from this function.

Table 4-3 RF Edit Sub Functions

Subfunction Display	Item/Value Range	Description
Chan	1...6	Not Used
Power:	Auto	Sets radio RF output power level
	Low	
	High	
TX	Normal	Normal bit-sense transmission
	Invert	Invert the bit-sense of transmitted data
RX	Normal	Normal bit-sense reception
	Invert	Inverts the bit-sense of receive data

4.3.4 Port J1

The **Port J1** function display is shown below:



For Port J1 data activity display above a zero (0) is represented by a dash (-) and a one (1) is represented by an asterisk (*). The serial bits are described in Table 4-1. The sub functions listed in Table 4-4 may be accessed from this function.

Table 4-4 Port J1 Sub Functions


Subfunction Display	Item/Value Range	Description
See Note.	Wayside	Selects wayside equipment - MCM II
	Mobile	Selects mobile equipment - BCM II
See Note.	HDLC ADM	Selects serial port communications protocol.
	HDLC ABM	
	HDLC POL	
	HDLC UI	
	HDLC NUL	
	GENI (0)	
	ECP	
	BCP GENI	
	MCS 1	
	ASYN	
	SSR	
	SCS128	
	GENI (F)	
	CN2000A	
	CN2000B	
	CN DHP	
	SLIP	
	CENTRA	
	FRM RLY	
	BGENI (O)	
	PPP	
	PPPMCast	
	GPRS (bu)	
	GPRScont	
	ARES	
Baud: ### See Note.	300	Selects serial port communications baud rate.
	600	
	1200	
	2400	
	4800	
	9600	
	19.2 (K)	
See Note.	RS422 RS232	Serial port configuration.
See Note.	SYNC ASYN	Clock sync mode.
Poll = # See Note.	0 – 127	Module polling address
Max Poll	0 – 127	Sets polling range

NOTE**NOTE**

Sub function default display is dependent on current Codeplug parameters.

4.3.5 Port J2

The **Port J2** function display is shown on the following page.




Sub functions corresponding to those listed in Table 4-4 may be accessed from this function.

- This function also monitors the serial bit activity of connector J2.
- The serial bits are described in Table 4-1.
- A zero (0) is represented by a dash (–) and a one (1) is represented by an asterisk (*).

4.3.6 Port DC

The **Port DC** function display is shown below:




This function monitors the I/O bit activity of connector J4.

- The I/O bits are displayed at the RXD and TXD positions of section 2.
- Zero (0) bits are represented by a dash (–) and one (1) bits are represented by an asterisk (*).
- No sub functions are available from this function.

4.3.7 Diagnostics

The **Diagnostics** function display is shown below:




The sub functions listed in Table 4-5 may be accessed from this function. Typical values for each sub function display are shown.

Table 4-5 Diagnostic Sub Function

Subfunction Display	Item/Value	Description
X:	355AA12AA10000	Local ATCS address display. Varies per site.
GC:	Passive	Displays whether ground contact has been established.
	Active	
XCM Ver.	BCM-II V01.08.00	Displays version of installed software
Conf. CRC:	D757	CRC of site configuration file
TEST	F3FF	Name and CRC of installed logic file
RSSI(L)	-70dB	RSSI of last data packet
RSSI(C)	-120dB	Current signal strength of received carrier
PTT	off	Toggles push-to-talk line to radio
	on	
COR raw	000	Carrier Operated Relay (Not Used)
RSSI raw	000	Current RSSI value as read from analog input.
DCIO_IN	HHHHHHHH LLLLLLLLLL	State of 8 alarm inputs where H is for high and L is for low. Starting from left-to-right, leftmost is alarm1 and rightmost is alarm 8

4.3.8 Date and Time


The **Date and Time** function display is shown below:



This is a display of the date and time obtained from the Central Office. No sub functions are available from this function.

4.3.9 Reset

The **Reset** function display is shown below:



When this function is activated, it first resets the BCM II and then conducts a series of tests to determine BCM II operational status.

- Table 4-6 list the tests performed.

Table 4-6 BCM II Self Tests

Subfunction Display	Test Results Displayed	Test Description
ROM RAM *****	OK /FAILED	Performs CRC of Executive Firmware in ROM and performs memory test on RAM
CODEPLUG *****	OK /FAILED	Verifies CRC of configuration data in codeplug
MODULATOR ****	OK /FAILED	Verifies the modulator & demodulator via an internal loopback test of the TX and RX audio data paths
RADIO *****	OK /FAILED	Resets Motorola radios equipped with an SB9600 bus; has no effect on MTR2000 or MTR3000 radios
HDLc PORT 0 **	OK /FAILED	Verifies the client ports via an internal loopback test of the TX and RX data paths
HDLc PORT 1 **	OK /FAILED	Verifies the client ports via an internal loopback test of the TX and RX data paths

NOTE**NOTE**

Alphanumeric display is automatically turned off approximately 12 minutes after the **SELECT** or **ENTER** push buttons are last activated.

4.4 BCM II CONFIGURATION PROGRAM

The BCM Configuration program (XCMMaint.EXE or similar name) and associated files are distributed on a CD ROM or is available on the Siemens Download Center.

- The XCMMaint.EXE program or similar name must be installed on an MS-DOS compatible computer with a serial port. For computers without a serial port, use a USB-to-Serial adapter. Not all adapters will work for all computers. A suggested adapter is the Cables Unlimited USB-2920, USB 2.0 to Serial DB-9 Adapter.

4.4.1 Installation

To install the BCM Configuration program proceed as follows:

1. Insert the installation CD to the CD Drive.
2. Make a folder on the drive where CD Files will reside. Keep file path as short as possible.
3. Copy the files from CD to the folder.
4. Create a shortcut to the XCMMaint's executable file onto the computer desktop.

4.4.2 Using the BCM Configuration Program

Connect the serial port of the PC to the Diagnostic Port on the front of the BCM II as shown in the figure below.




Figure 4-4 BCM II to Personal Computer Interconnection Diagram

Start the XCMMAINT configuration Editor by opening the XCMMAINT.EXE file. The name of this executable file will change per the installation CD.




Figure 4-5 Configuration Editor Startup Screen

4.4.2.1 Accessing a Saved Codeplug File

To access a saved configuration code-plug file from the Configuration Editor Startup Screen:

1. Press the **ENTER** key.
- A list of Codeplug files (*.xcm), Figure 4-6, displays within the Startup Screen.




Figure 4-6 Codeplug File List

2. Place the cursor on the desired codeplug file name within the list using the arrow keys.
3. Press the **ENTER** key.
 - The selected codeplug file is displayed within the Main Editor Screen, Figure 4-7.




Figure 4-7 Typical Main Editor Screen

4.4.2.2 Read BCM II Codeplug

To read the codeplug currently stored in BCM II unit for display on editor screen:

- Enter **Alt-O** and use down arrow key to select '**Read Codeplug from Unit**'. Press **Enter** key.




Figure 4-8 Read BCM II Codeplug File

- The codeplug file is read from the BCM II and displayed as shown in Figure 4-9.




Figure 4-9 Read Codeplug from BCM II

4.4.3 Main Editor Screen

Codeplug configuration is performed from the Main Editor Screen. This screen is divided into four functional sections:

- RF Settings
- Site Settings
- LonTalk® Network Configuration
- Port Selection

4.4.3.1 Using the Main Editor Screen

The name and path for the selected file is identified at the upper left corner of the display as shown in Figure 4-10.

- At the top of the display is the Menu Bar.
- The Menu Bar contains the names of five drop-down menus or functions that are accessible from the Main Editor Screen.
- To display a drop-down menu or access the indicated function, simultaneously press the **ALT** key and the letter key corresponding to the first letter of the menu name (e.g., **ALT-F** for the **File** menu).
- Items are highlighted within each drop-down menu by using the arrow keys or mouse. Pressing **Enter** selects the highlighted item.




Figure 4-10 XCM File Name and Path

- **File Menu**

The **File (Alt-F)** drop-down menu contains the following five entries:

- **Load**

The **Load** entry allows another codeplug file (.XCM extension) to be loaded in place of the one currently displayed.

To select the **Load** entry:

1. Highlight the **Load** entry using the arrow keys.
2. Press the **Enter** key.
 - The following prompt is displayed:



3. Enter a file name by performing one of the following actions:
 - Type the file name (maximum of eight characters plus the .XCM extension) at the **Enter Filename** prompt.
 - Press the **Enter** key to bring up the Codeplug File List and make a file selection from the presented list using the arrow keys.
4. Press the **Enter** key.

- **Save**

Selecting this entry saves the currently displayed code-plugin configuration data to the file listed in the upper left corner of the Main Editor Screen.

- After the file is saved, the code-plugin configuration data remains displayed within the Screen.



- **Save As**

This entry permits the currently displayed code-plugin configuration data to be saved to a file other than the one named in the upper left corner of the Main Editor Screen.

The **Save As** entry is selected as follows:



1. Highlight the **Save As** entry using the arrow keys.
2. Press the **Enter** key.
 - The following prompt is displayed:



3. Enter a file name by performing one of the following actions:
 - Type the file name (maximum of eight characters plus the **.XCM** extension) at the **Enter Filename** prompt.
 - Press the **Enter** key to bring up the Codeplug File List, **Error! Reference source not found.**, and then make a file selection from the presented list using the arrow keys.
4. Press the **Enter** key.

NOTE

NOTE

When a file name is selected from the Codeplug File List, the currently displayed codeplug configuration data overwrites any data in the selected file.

- **Save + ABS**

This entry permits the currently displayed code-plugin configuration data to be saved in the modified binary s-record format (ABS).



- **Exit**

Select this entry to quit the Configuration program and return to the DOS prompt or Desktop.

The **Exit** entry is selected as follows:



1. Highlight the **Exit** entry using the arrow keys.
2. Press the **Enter** key.
- If the codeplug has been changed without being saved, the **Verify** prompt is displayed (see right).
3. Type **Y** (yes) to save the changes to the configuration or **N** (no) to discard the changes to the configuration.
4. Press the **Enter** key.
 - The Main Editor Screen closes and the DOS prompt is displayed.

Verify
 Codeplug modified - save?

4.4.3.2 Edit Function

The Edit Function is not used.

4.4.3.3 Online Menu

The **Online** (**Alt-O**) drop-down menu contains the following eight entries:

- **Terminal**

This entry provides access to a number of diagnostic tools and access to the event log.

- When **Terminal** is selected a blank screen appears displaying only the Menu bar containing the name of the three available drop down menus: **File**, **Online**, and **Upload**.

Terminal
 Bitmap Display
 Read DC Conf. from Unit
 Read Codeplug from Unit
 Write Codeplug to Unit
 Write DC Conf. to Unit
 Write Logic to Unit
 Write Labels to Unit




Figure 4-11 Terminal Sub Menus

- **File Menu (Not Used)**

The **File** menu contains five entries that function as follows:

- a. Selecting **Edit** closes the Online Terminal Screen and returns to the Main Editor Screen display.



- 1. The **Status** entry screen is identical in display and function to the **Terminal** entry described above.

- b. Selecting **Log Open** brings up the following prompt:



Enter Filename

*.log

Type a log file name to be created (the **.log** extension will be appended) and press **Enter**.

All subsequent BCM II log entries will be written to this file until it is closed or until the XCMMMAINT.EXE utility is exited.

NOTE**NOTE**

Only one log capture file may be opened at one time. If a log capture file is already open, the prompt to enter a log file name will not display.

- c. Selecting **Log Close** will close the currently open log file, if any, without prompting.



- d. Selecting **Exit** terminates the program.



- **Online Menu**

The **Online** drop-down menu of this screen is the same as the Main Editor **Online** drop-down menu.

- Several commands may be initiated from the Online Terminal Screen.
 - ◆ Selecting the **Alt** key while activating the **O** key causes the **Online** drop-down menu to display.
 - ◆ Selecting the **Terminal** entry from the drop-down menu causes a blank Online Terminal Screen to display.
 - ◆ Pressing the **ENTER** key causes an "*" prompt to display.
 - ◆ Typing **HELP** after the on screen "*" and pressing the **ENTER** key causes the Command List to be displayed within the Online Terminal Screen as shown in Figure 4-12.

```

C:\XCM500\XCMMAINT.EXE
File      Online      Upload
*
*
*HELP
Display Codeplug Contents - DCP
Display DC Configuration - DDC
Display Client List       - CL
Enter Service Mode        - SERU
Version Identification     - UER
Base Station List         - BSTAI
Communication Statistics   - CSTAI
HDLC Statistics            - HSTAI
Manufacturer Statistics    - MSTAI
Alarm Logging              - AL  <en/ds>
View log                   - LOG  <CLEAR>
Status Logging             - SL  <en/ds>
Key or Dekey Radio         - PIT  <en/ds>
Radio Simplex Operation    - SIMP <en/ds>
COS status                 - COS  <en/ds>
Enter Channel Number       - CHAN <number>
Send Local Message         - LOCAL <label> <message>
Self Test                  - TEST <1=cold / 0=warm>
Patch Codeplug             - PCP  <location> <new_value>
Disable Tracing Mechanism  - MOND <layer> <port> <link>
Enable Tracing Mechanism   - MONE <layer> <port> <link>
Send Mobile Message        - SEND <layer> <port> <link> <msg>
Error Rate Test            - ERT  <mode> <layer> <port> <full report> <pattern>
Enable / Disable SWI       - SWI  en/ds
Enable / Disable LADL      - LADL en/ds
Program Codeplug           - FPROG
Show HW/SW Version Info    - SCT
Reset RSSI Statistics       - RSSI
Reset MCS/SB9600           - RIFRESET 1=MCS reset, 2=SB reset, 3=SB prog, other=P
PPP Status                 - PPP
Ping                       - PINGIP address, client num <0:1>
Timer Status               - TIMERS
Set Date                   - DATE <year> <month> <day>
Set Time                   - TIME <hour> <minute> <second>
*
*OST
  
```

Figure 4-12 Online Terminal Screen Command List

NOTE

NOTE

<Page Up> may be used to view lines that have scrolled off the screen

The Online Terminal Screen Commands may be initiated from the Online Terminal Screen by:

1. Pressing the **Enter** key.
 - An * is displayed at the top left of the Screen, verifying that the program is communicating with the BCM II.
2. Typing the command followed by a space and the desired parameter designation.
 - Examples:
 - ◆ Status Log enable command is entered as: **SL<space>en**.

- Commands requiring multiple parameters are entered with a space between each parameter.
- Send Local Message command is entered as: **LOCAL** <space> <label> <space> <message>.

3. Pressing the **Enter** key.

- The command executes and the results are displayed on the Screen as shown in Figure 4-13.




Figure 4-13 Status Log Enable Command

- **Viewing and/or logging the WCP CPU II Event Log**

1. Press the **ENTER** key.

A "*" prompt is displayed.

2. To create a new event log for logging WCP CPU II events, select **Log Open** from the **Terminal's** drop-down **File** menu.

- a. Type a log file name to be created (the **.log** extension will be appended) and press **Enter**.

3. Type **LOG** at the "*" prompt.

4. Press the **Enter** key.

The event log of the WCP CPU II is displayed on the Screen as shown in Figure 4-14. As each new event occurs, it is added to the end of the event log file.

```

C:\XCMMAI~1.EXE
File      Online      Upload
*LOG
Log display - hit ESC to exit
End *****
MC0 00/01/11 21:01:47 Sent Codeplug Values to Host
MC0 00/01/11 21:03:40 Sent Codeplug Values to Host
MC0 00/00/00 00:00:04 MCP Cold reset
MC0 00/01/13 23:43:34 Port $100: mode= 1 9600 timer= 1 usage=12 config=2
MC0 00/01/13 23:43:35 Port $101: mode= 1 9600 timer= 1 usage=12 config=2
MC0 00/01/13 23:43:38 Logic Pass-Through operation enabled
MC0 00/01/13 23:43:38 Network address initialized
MC0 00/01/13 23:43:38 Alarm dump created
MC0 00/01/13 23:43:39 Client 76201000020104 found
MC0 00/01/13 23:43:41 Ground Contact Alarm On
MC0 00/01/13 23:44:34 Alarm dump created
MC0 00/01/13 23:44:34 Port Contact 0 Alarm On
MC0 00/01/13 23:44:35 Alarm dump created
MC0 00/01/13 23:44:35 Port Contact 1 Alarm On
MC0 00/01/13 23:56:24 Sent Codeplug Values to Host
MC0 00/01/13 23:56:24 Sent Codeplug Values to Host

```

Figure 4-14 View Log

NOTE**NOTE**

Each new event also displays at the bottom of the screen as it occurs.

While viewing the event log, the following commands may be executed:

- Typing **B** moves the previous sixteen entries to the bottom of the display.
- Typing **F** moves the display down (forward) sixteen entries.
- Typing **S** moves the display to the start of the log.
- Typing **E** moves the display to the end of the log.
- Typing **P** pauses the log updates.
- Typing **W** erases all events in the log.
- Pressing the Esc key interrupts the log display and disables log command execution.

5. At the completion of event log viewing and logging, perform the following:

1. If a log file is open, select **Log Close** from the **Terminal's** drop-down **File** menu.
2. To return to main edit screen, select **Edit** from the drop-down **File** menu.

The Online Terminal Screen closes and the Main Editor Screen displays.

- **Upload Menu**


Upload (Alt-U) performs firmware upgrading and has the following three drop-down selections:



The files associated with each of three drop-down selections are stored on the installation CD. File 'xcmmain.ini' specifies the path to each of these files.

1. **Executive** – The executive firmware consists of BCM II's operating system software and system application software. As BCM II's firmware is changed and updated by Siemens, select this command to flash an updated executive into BCM II. Upon selecting this command, BCM II configuration program will automatically establish a session with the BCM II unit and write new executive to BCM II's flash memory. The entire operation takes about 6 minutes.


To begin this operation, enter **Alt-U** and use up/down arrow keys to highlight **Executive** selection. Then press **ENTER** key.




The following sequence of screens show the steps automatically performed by BCM II configuration program to accomplish re-flashing of new executive firmware:



New executive firmware is being serially sent to BCM II with percentage of completion shown.



Percentage complete is now 100%, new executive firmware has completely been serially sent to BCM II. New executive firmware is written to flash memory. Upon completion of flash operation, BCM II will automatically reboot.




BCM II is rebooting. Old executive has been overwritten with new executive firmware.


2. XCM-II Xilinx – Xilinx firmware handles the FPGA logic functionality.

As BCM II's Xilinx logic is changed and updated by Siemens, select this command to flash updated Xilinx firmware into BCM II. Upon selecting this command, BCM II configuration program will automatically establish a session with BCM II unit and write new Xilinx firmware to BCM II's flash memory. The entire operation takes about 100 seconds.


To begin this operation, enter **Alt-U** and use up/down arrow keys to highlight **XCM-II Xilinx** selection. Then press **ENTER** key.




The following sequence of screens show the steps automatically performed by BCM II configuration program to accomplish re-flashing of Xilinx firmware:



New Xilinx firmware is being serially sent to BCM II with percentage of completion shown.



Percentage complete is now 100%, new Xilinx firmware has completely been serially sent to BCM II. New Xilinx firmware is written to flash memory. Upon completion of flash operation, BCM II will automatically reboot.




BCM II is rebooting. Old Xilinx firmware has been overwritten with new Xilinx firmware.

3. XCM-II DSP - DSP firmware handles the RF processing functionality.


As BCM II's DSP firmware is changed and updated by Siemens, select this command to flash updated DSP firmware into BCM II. Upon selecting this command, BCM II configuration program will automatically establish a session with BCM II unit and write new DSP firmware to BCM II's flash memory. The entire operation takes about 60 seconds.

To start the DSP firmware update operation:


Enter **Alt-U** and use up/down arrow keys to highlight **XCM-II DSP** selection. Then press **ENTER** key.




The following sequence of screens show the steps automatically performed by BCM II configuration program to accomplish re-flashing of DSP firmware:



New DSP firmware is being serially sent to BCM II with percentage of completion shown.



Percentage complete is now 100%, new DSP firmware has completely been serially sent to BCM II. New DSP firmware is written to flash memory. Upon completion of flash operation, BCM II will automatically reboot.



BCM II is rebooting. Old DSP firmware has been overwritten with new DSP firmware

• Bitmap Display

This function is not used in BCM II.

Selecting the **Bitmap Display** entry causes the Bitmap screen, Figure 4-15, to display.

- The Bitmap screen is an online dynamic display of the logic state of any physical inputs or outputs associated with the BCM II via ladder logic.
- The logic states of all internal bitfields are displayed as well.
- When properly configured I/O modules are installed on the local Echelon® LAN, the current state of their inputs and outputs can be viewed in real time using this screen.

```
Terminal
Bitmap Display
Read DC Conf. from Unit
Read Codeplug from Unit
Write Codeplug to Unit
Write DC Conf. to Unit
Write Logic to Unit
Write Labels to Unit
```




Figure 4-15 Bitmap Display Screen

Read DC Conf.

This function is not used in BCM II.

Selecting this function and pressing **ENTER**, causes the configuration of the DC port of the BCM II (associated with connector J4) to be read.

- The **Receiving data** popup box displays briefly as the data is read.
- The main edit screen is updated to reflect the configuration data that is read.

```
Terminal
Bitmap Display
Read DC Conf. from Unit
Read Codeplug from Unit
Write Codeplug to Unit
Write DC Conf. to Unit
Write Logic to Unit
Write Labels to Unit
```



- **Read Codeplug from Unit**

Selecting this function and pressing **ENTER**, causes the Codeplug portion of the BCM II configuration data to be read.

- This is a 512-byte data array that stores all the user-modifiable BCM II configuration information.
- The **Receiving data** popup box (see above) displays briefly as the data is read.
- The main edit screen is updated to reflect the codeplug data that is read.
- See Appendix C for code plug parameter details.

```
Terminal
Bitmap Display
Read DC Conf. from Unit
Read Codeplug from Unit
Write Codeplug to Unit
Write DC Conf. to Unit
Write Logic to Unit
Write Labels to Unit
```

- **Write Codeplug to Unit**

Selecting this function and pressing **ENTER**, causes all the configuration data appearing on the main edit screen to be written to the BCM II non-volatile memory.

- The **sending data** popup box displays briefly as codeplug data is written.

```
Terminal
Bitmap Display
Read DC Conf. from Unit
Read Codeplug from Unit
Write Codeplug to Unit
Write DC Conf. to Unit
Write Logic to Unit
Write Labels to Unit
```

CAUTION



WHEN THE UPLOAD CODEPLUG FUNCTION IS SELECTED, THE EXISTING CODEPLUG DATA IN THE BCM II IS OVERWRITTEN AND IRRETRIEVABLY LOST.

- **Write DC Conf. To Unit**

This function is not used in BCM II.
DC functionality is not supported by the BCM II.

```
Terminal
Bitmap Display
Read DC Conf. from Unit
Read Codeplug from Unit
Write Codeplug to Unit
Write DC Conf. to Unit
Write Logic to Unit
Write Labels to Unit
```

- **Write Logic To Unit Logic**

This function uploads compiled ladder logic to the BCM II if the following conditions are met:

- Appropriate ladder logic has been compiled
- The name of the logic file generated has been entered on the main edit screen (in the Site Settings section).
 - ◆ The file extension is omitted.

```
Terminal
Bitmap Display
Read DC Conf. from Unit
Read Codeplug from Unit
Write Codeplug to Unit
Write DC Conf. to Unit
Write Logic to Unit
Write Labels to Unit
```


After the upload sequence is complete, the BCM II calculates a CRC value for the ladder logic.

- If this CRC value does not match the CRC embedded in the logic file, the process aborts with the BCM II unchanged.

- **Write Labels to Units Labels**

Selecting this function and pressing **ENTER** causes the tokenized label file associated with the ladder logic to be uploaded to the BCM II.

- The conditions for uploading are the same as for the logic upload described above.
- The label file and the logic file are generated by the logic compiler and have the same base filename (with different extensions).
 - ♦ It is only necessary to specify the base filename in the **Logic File** field on the main edit screen.



4.4.3.4 Help Window

The **Help** window, Figure 4-16, provides general help instructions.





Figure 4-16 Help Window

- **Help For Each Configuration Parameter**

Help text is available for each configuration parameter by one of two methods:

1. Use arrow keys to move cursor to a configuration parameter and press **Alt-H**.
2. Use mouse to move cursor to a configuration parameter and **right-click** the mouse.

For example the figure below shows the help text for 'protocol' parameter in port configuration section of configuration screen:



To return back to main configuration screen press **ESC** key.

4.4.3.5 Version Window (Alt-V)

The Version (**Alt-V**) window shown below displays the executive software version running in the BCM II.



To return back to main configuration screen press **ESC** key.


4.4.4 Radio Settings Display

The **Radio Settings** section configuration is determined by the **Type** field setting.

4.4.4.1 Type and Usage Fields

- The **Type**: field selection range and the default field configuration for each selected radio are as follows

- ◆ **None**



◆ MCS (Not Used With BCP II)

```

Radio Settings
Type: MCS Usage: ---
Channel: Min:01 Max:06 Def:02
Invert: TX:No RX: Yes
Rssi: Scale: 009/025 Base:-137 dB
Radio Gain: In: 1024 Out: 1250
    
```

◆ MSF

```

Radio Settings
Type: MSF Usage: ---
Invert: TX:Yes RX: Yes
Rssi: Scale: 060/210 Base:-132 dB
Radio Gain: In: 1024 Out: 1664
    
```

◆ MTR

```

Radio Settings
Type: MTR Usage: ---
Invert: TX:No RX: Yes
Rssi: Scale: 001/002 Base:-125 dB
Radio Gain: In: 1024 Out: 0970
    
```

MTR3000 - Gain Out = 0970

```

Radio Settings
Type: MTR Usage: ---
Invert: TX:No RX: Yes
Rssi: Scale: 001/002 Base:-125 dB
Radio Gain: In: 1024 Out: 0640
    
```

MTR2000 (Discontinued) - Gain Out = 0640

◆ PHD

```

Radio Settings
Type: PHD Usage: ---
Invert: TX:Yes RX: Yes
Rssi: Scale: 070/067 Base:-152 dB
Radio Gain: In: 1024 Out: 1664
    
```

◆ ASTRO (Not Used With BCP II)

```

Radio Settings
Type: ASTRO Usage: ---
Channel: Min:01 Max:06 Def:02
Invert: TX:Yes RX: Yes
Rssi: Scale: 070/067 Base:-152 dB
Radio Gain: In: 0000 Out: 0000
    
```

◆ EFJ (Not Used With BCP II)

```

Radio Settings
Type: EFJ Usage: ---
Invert: TX:Yes RX: No
Rssi: Scale: 040/206 Base:-110 dB
Radio Gain: In: 1024 Out: 1664
    
```

◆ **KENWD (Not Used With BCP II)**

```

Radio Settings
Type: KENWD Usage: ---
Channel: Min:01 Max:06 Def:02
Invert: TX:No RX: Yes
Rssi: Scale: 001/001 Base:-151 dB
Radio Gain: In: 1024 Out: 1227

```

◆ **MDS (Not Used With BCP II)**

```

Radio Settings
Type: MDS Usage: ---
Channel: Min:01 Max:06 Def:02
Invert: TX:Yes RX: No
Rssi: Scale: 060/138 Base:-146 dB
Radio Gain: In: 1024 Out: 1250

```

- The **Usage:** field selection range is as follows:
 - ◆ **BCP**
 - ◆ **MCP**

NOTE

NOTE

1. As shown above, not all of the **Radio Settings** fields are displayed for each radio.
 - The fields displayed are dependent on the radio selected.
2. For current BCP applications, set **Usage:** to **BCP** and select either **MTR** (MTR-3000), **MSF** (earlier Motorola MSF-5000), or **MDS** for the **Radio:** field.

4.4.4.2 Channel Field

In a BCM II configuration, the **Channel:** field, is not used. The ATCS channel assigned to the BCM II radio is set using Motorola Customer Programming Software (CPS) and associated test hardware.

4.4.4.3 Invert Field

The **Invert:** fields are used to invert the bit-sense of the transmitted data to or the received data from the WCP. This function is intended for cross-functionality with foreign equipment.

- The **Invert TX** and **Invert RX** field selection ranges are as follows:
 - ◆ **No**
 - ◆ **Yes**

4.4.4.4 RSSI Scale and Base Fields

RSSI (Received Signal Strength Indicator) scaling and base values are included on the configuration screen only for compatibility with foreign equipment.

- The default values result in proper RSSI reporting for current Siemens BCP equipment.

4.4.4.5 Radio Gain

Radio Gain is used to control the sensitivity of the RX audio detector (**In**), or to adjust the radio deviation (**Out**).

- Radio input gain is normally not changed from the default values.
- The **Radio Gain** fields default values for are:
- **MTR2000**
 - ♦ **In: 1024**
 - ♦ **Out: 0640**
- **MTR3000**
 - ♦ **In: 1024**
 - ♦ **Out: 0970**

4.4.4.6 Default Value Setup

When the cursor is in the **Radio Settings Type** field, pressing <Alt-E> will cause XCMMaint to load the default values for the radio type selected.

- This will overwrite all radio parameters except channel (when applicable).

4.4.5 Site Settings Display

4.4.5.1 Local Addr Field

When the **Enable** function is selected this field sets the ATCS address for the BCM II as shown in Figure 4-17.

- Field selection range: **0.000.00.0000 to 9.999.99.9999**

NOTE**NOTE**

The default value of **A.AAA.AA.AAAA** corresponds to a setting of **0.000.00.0000**.

This represents the local ATCS address assigned to BCM II. This should always be enabled. Since BCM II is a base station, ATCS address format is 3.RRR.NN.DDD where:

- 3 = Wire line address type
- RRR = Railroad number(see Appendix B)
- NN = Node number(railroad defined)
- DDD = Base device number(railroad defined)

The ATCS specification recommends that the node number (NN) be the same as the node number of the cluster controller to which it is connected.




Figure 4-17 MainEditor Screen – Site Local Address Selection

4.4.5.2 FEPCC Addr Field

When the **Enable** function is selected (see Figure 4-18) this field sets the FEP/CC address for the initial inbound transmissions.

- Field selection range: **0.000.00.0000** to **9.999.99.9999**

NOTE

NOTE

The default value of **A.AAA.AA.AAAA** corresponds to a setting of **0.000.00.0000**.




Figure 4-18 Main Editor – Site FEPCC Address Selection

- This field is required for systems where the BCP equipment does not support packets with a zero destination length.
- When the **Disable** function is selected, the address set into the **FEPCC Addr:** field is ignored.

4.4.5.3 Enable Code App Field (Not used with BCM II)

The **Enable Code App** field (see Figure 4-19) enables the internal BCM II code system application when used with Siemens I/O modules.

- Field selection option:
 - ◆ **No** = If not using R/Link I/O modules
 - ◆ **Yes** = If using R/Link I/O modules (defined on XCMMAINT screen's LonTalk® Network Configuration)




Figure 4-19 Main Editor Screen – Site Enable Code Application Selection

4.4.5.4 Enable Simulation Field (Not Used with BCM II)

The **Enable Simulation** field (see Figure 4-20) enables simulation, allowing inputs from the diagnostic program to toggle bits in the ladder logic application.

- Field selection option:
 - ◆ **No** = Disables manipulation of bits from diagnostic terminal
 - ◆ **Yes** = Enables manipulation of bits from diagnostic terminal




Figure 4-20 Main Editor Screen – Site Enable Simulation Selection

4.4.5.5 Enable Ladder Logic Field (Not Used With BCM II)

The **Enable Ladder Logic** field (see Figure 4-21) enables the internal ladder (PLC) logic.

- Field selection option:
 - ◆ **No** = Don't use Ladder Logic
 - ◆ **Yes** = Use Ladder Logic
- If disabled, indications from the I/O modules are passed straight through to the office, and office controls are passed straight through to the I/O module outputs.




Figure 4-21 Main Editor Screen – Site Enable Ladder Logic Selection

- When the **Logic File: *** field is highlighted (see Figure 4-22) and **Enter** is pressed, the following prompt is displayed:



- Field selection option:
 - ♦ **blank** with **Enable Ladder Logic** set to **No**.
 - ♦ ***** with **Enable Ladder Logic** set to **Yes**.
- To enter a ladder logic file name, perform one of the following:
 - ♦ Type the file name (maximum of eight characters plus the .LLW extension) at the **Enter Filename** prompt.





Figure 4-22 Main Editor Screen – Site Logic File Designation

- ♦ Press the **Enter** key to bring up the Ladder Logic File List (see below) and make a file selection from the presented list using the arrow keys.



4.4.6 LonTalk® Network Configuration

The LonTalk® Network is not used with the BCP II. No configuration settings are required. Any settings (other than default) will be ignored by the BCP II equipment.

4.4.7 BCM Port Configuration

See Figure 4-22

4.4.7.1 Serial Client Ports J1 and J2

Table 4-7 Client Port Field Descriptions

Field Name	Range	Description
Protocol	See Error! Reference source not found.	Serial protocol used by client. See Table 4-8
Baud	00300 to 19200 in 300 baud increments	Baud rate for specified port
Clock	SYNC and ASYNC	Specifies synchronous or asynchronous clocking
Level	RS232 and RS422	Selects RS-232 or RS-422 interface
CTS	No and Yes	Handshaking flag. If YES, the serial port uses RTS-CTS flow control.
TXC	Int and Ext	Synchronous clock only: Int sets the BCM client port as clock source
FLG	No and Yes	Synchronous only: YES causes BCM to send HDLC idle flags to serial port
Timer	00000 to 99999	Code line protocol poll timer in 10ms tics; can be left at 160 (1.6 sec) for most applications
Usage	Ground, OBC, and WIU	Denotes type of equipment connected to port: Ground network(BCM II application). Onboard(OBC) Controller(mobile application), and Wayside Interface Unit(WCP application)..
LL	Y and N	Enables ladder logic operations
PL	Y and N	Enables polling operations
ID	L and S	Selects (L)ong or (S)hort RX idle character delays.
Link	000 to 999	Sets the poll address or start of poll range for some emulations
Max	000 to 231	Sets the end of poll range for some emulations




Figure 4-23 Serial Port Protocol Select

Table 4-8 Client Port Protocol Descriptions

Protocol	Description
NOT USED	No Protocol Selected - Not Used
HDLC ADM	HDLC Asynchronous Disconnect Mode
HDLC ABM	HDLC Asynchronous Balanced Mode
HDLC POL	HDLC polled operation: Will answer to poll ID set in LINK field
HDLC UI	HDLC Unnumbered Information mode
HDLC NULL	HDLC Null (connectionless) mode
GENI (O)	Emulates US&S Genisys office. Polling range set by Link/Max fields
ECP	Interface to Safetran Emergency Control Panel
BCP GENI	Emulates Genisys field for sending and receiving Genisys ATCS packets. Link field defines Genisys station address.
MCS 1	Emulates Harmon MCS-1 office. Polling range set by Link/Max fields
ASYNC	Standard ASYNC port: inbound data converted to ATCS packets and outbound packets are stripped of ATCS headers
SSR	Interfaces to Safetran Spread Spectrum Radio linear network
SCS128	Safetran SCS128 office emulation. Polling range set by Link/Max fields
GENI (F)	Emulates US&S Genisys field. Used for dial backup operation
CN2000A	Canadian National proprietary (new) asynchronous field station protocol
CN2000B	Canadian National proprietary (old) asynchronous field station protocol
CN DHP	DHP2000 Series equipment
SLIP	Single Line IP Protocol
CENTRA	Centra-Code protocol
FRM RLY	Frame Relay Protocol
BGENI (O)	Genisys ATCS BCP Office interface
PPP	Point-Point Protocol
PPPMCast	Point-Point Protocol with Multicast capability
GPRS(bu)	GPRS Backup protocol
GPRSCont	GPRS Continuous protocol
ARES	ARES Protocol

4.4.7.2 IP Addressing

Six protocol assignments require IP addressing.

- These are:
 - ♦ SLIP
 - ♦ FRM RLY
 - ♦ PPP
 - ♦ PPPMCast
 - ♦ GPRS(bu)
 - ♦ GPRScont
- The **IP Address Assignments** screen, Figure 4-24, displays when the cursor is placed on one of the above protocol fields and <Alt-E> is pressed.
- The fields in this screen are:
 - ♦ **Local IP:**
 - IP address of the BCP
 - ♦ **Remote Host IP:**
 - IP address of the packet switch or office equipment
 - ♦ **Base Route ID:**
 - Base routing number (ATCS)
 - ♦ **Port J1 Routing Priority Tag**
 - ♦ **Port J2 Routing Priority Tag**
 - ♦ **RF Port Routing Priority Tag**
- One of two separate ATCS Routing Priority Tag values may be assigned to each port.
 - ♦ **\$85** designates that a port is used as a secondary connection to the office
 - ♦ **\$45** designates that a port is used as a primary connection to the office.




Figure 4-24 IP Address Assignments Screen

4.4.7.3 LON Port

- The Lon Port is **NOT USED**. The BCM component does not support Echelon® LonTalk®.
- Not Used
- Normal

NOTE

NOTE

BCM II **DOES NOT USE** Echelon® Lon Talk®, therefore this setting is Not Used.




Figure 4-25 LON Enable Select

4.4.7.4 DC1 and DC2 Ports

These auxiliary I/O ports can be individually configured to drive a DC code line or to report a change of inputs to the office as alarms.

- The field port protocol selection ranges for each port are as follows:

Protocol	Description	Usage
NOT USED	The DC ports are unused.	WIU
506 CODE	Emulates DC 506 office protocol. Use ALT-E to access configuration screen.	WIU
514 Code	Emulates DC 514 office protocol. Use ALT-E to access configuration screen.	WIU
J Code	Not Supported	WIU
K Code	Not Supported	WIU
Alarms	J4 inputs reports as alarms report to office: IN1, IN2, IN3, IN4, IN5, IN6, IN7, IN8	WIU
Control	Enables J4 OUT1, OUT2 to be controlled by J4 inputs, or internal alarm conditions. Enter Alt-E to access configuration screen.	WIU

- The **DC1 and DC2 Port Baud** field selection ranges:

Usage	Description
Ground	Ground network
OBC	mobile application
WIU	WCP application

- The **CRC** value displayed changes with each new protocol selection.

The **TIMECODE CONFIGURATION** edit screen, Figure 4-26, may be accessed when either the **506 Code** or **514 Code** field port protocols are selected.

- Accessed by entering **Alt – E**.

Port	Protocol	Baud	Clock	Level	CIS	TRC	FLG	Timer	Usage	LL	PL	ID	Link/Max
J1	HDLC POL	,09600	,SYNC	,RS232	,Yes	,Ext	,No	,01300	Grnd	N	N	S	001/001
J2	HDLC POL	,09600	,SYNC	,RS232	,Yes	,Ext	,No	,01300	Grnd	N	N	S	001/001
Lon	Not Used	Subnet: 01		Subnode:01									
DC1	Control	Grnd	CRC: 3308										
DC2	Control	Grnd											

Figure 4-26 DC Port Protocol

The DC Alarm Control configuration screen appears by pressing Alt-E. The screen will appear as shown in Figure 4-27.

DC ALARM CONTROL OUTPUT CONFIGURATION

Control Engage Delay: 0000 x 100ms Momentary Output: No
Control Release Delay: 0000 x 100ms Control Output Invert: No

Control Selection		Alarm	
Sel	Inv	Sel	Inv
Radio	No	External 3	No
R1	No	External 4	No
R2	No	External 5	No
R3	No	External 6	No
Codeplug	No	External 7	No
Cos Without Data	No	External 8	No
Modulator	No	External 9	No
Ground Contact	No	Port Contact 0	No
Codefail	No	Port Contact 1	No
Mobile Channel Usage	No	Port Hardware 0	No
Out Of Coverage	No	Port Hardware 1	No
A/D Hardware	No		
Lon I/F	No		
External 0	No		
External 1	No		
External 2	No		

Figure 4-27 DC Alarm Control Configuration

The DC Alarm Control has the following configuration adjustments:

- **Control Engage Delay** - delays output activation.
- **Control Release Delay** – delays output de-activation.
- **Momentary Output** – Allows for a single pulse on activation.
- **Control Output Invert** – No for active closed output, or Yes for active open output.
- **Alarm Sel** – Select Yes allow the Alarm condition specified to control the output.
- **Alarm Inv** – Select Yes or NO to configure the state of the alarm condition required to control the output. The alarm condition must also have Sel set to Yes.

4.4.7.5 DC1 Codeline Configuration Screen

The Timecode Configuration Screen, Figure 4-28, is divided into two sections: **US&S 5XX Timecode Configuration** and **Station Data**.

US&S 5XX TIMECODE CONFIGURATION

Control Step1:	042 x 10ms	Minimum short ind.	005 x 10ms
Long:	040 x 10ms	Maximum long ind.	090 x 10ms
Short:	010 x 10ms	Ind - Ind rest	075 x 10ms
Cont - Cont Rest:	090 x 10ms	Long/short threshold	025 x 10ms
Ind. - Cont Rest:	090 x 10ms	RX Clearout time	005 x 10ms
Step 9 recall:	097 x 10ms	Invert input:	No
Extension bit:	L	Invert output:	Yes

Station Data

Addr	C/I	Main	Addr	C/I	Main	Addr	C/I	Main	Addr	C/I	Main
01:000	07/07	00	11:000	07/08	00	21:000	07/08	00	31:000	07/08	00
02:358	16/16	00	12:000	07/08	00	22:000	07/08	00	32:000	07/08	00
03:000	07/08	00	13:000	07/08	00	23:000	07/08	00	33:000	07/08	00
04:000	07/08	00	14:000	07/08	00	24:000	07/08	00	34:000	07/08	00
05:000	07/08	00	15:000	07/08	00	25:000	07/08	00	35:000	07/08	00
06:000	07/08	00	16:000	07/08	00	26:000	07/08	00			
07:000	07/08	00	17:000	07/08	00	27:000	07/08	00			
08:000	07/08	00	18:000	07/08	00	28:000	07/08	00			
09:000	07/08	00	19:000	07/08	00	29:000	07/08	00			
10:000	07/08	00	20:000	07/08	00	30:000	07/08	00			

Figure 4-28 DC Codeline Configuration Screen

- The **US&S 5XX Timecode Configuration** section provides a means to modify step timing and other parameters as required.
 - ♦ As described below, a default set of parameters may be applied which will be suitable for most configurations.

- The **Station Data** section allows entry of station and pup addresses.

- ♦ The fields are filled in as follows:

Addr C/I Main
Node #: **aaa** **cc/ii** **mm**

where:

aaa is the 3-digit address of the field unit

cc is the number of control bits (default of 7)

ii is the number of indication bits (default of 8)

mm is the address of the main unit where multiple field units are installed

- **DC Codeline Configuration Screen Pull-down Menus**

- **File Menu**

Pressing **ALT-F** will display the File menu,

- Selecting the **Return** entry returns the display to the Main Edit Screen.
- All data on the Configuration Screen is saved when the .XCM file is saved from the Main Edit Screen.



- **Edit Menu**

Pressing **ALT-E** will display the Edit Menu. This menu has three entries:

- **Default**

- ◆ When this entry is selected and the **ENTER** key pressed, the Timecode Configuration section fields are set to the most commonly used timing settings as shown in Figure 4-29.



- **Copy**

- ◆ When this entry is selected and the **ENTER** key pressed, the contents of all fields on the screen are saved in memory and are held until the XCMMAINT utility exits.
 - ◆ This is similar to the familiar Windows copy/paste function but is local to the XCMMAINT application only.
 - ◆ The purpose of this feature is to facilitate multiple copies of identical DC codeline parameters and/or addressing across multiple .XCM files.



- **Paste**

- ◆ When this option is selected and the **ENTER** key pressed, the fields on the Main Edit Screen are set to values saved in a previous copy operation.



File Edit Help

US&S 5XX TIMECODE CONFIGURATION

Control Step1:	042 x 10ms	Minimum short ind.	005 x 10ms
Long:	040 x 10ms	Maximum long ind.	065 x 10ms
Short:	010 x 10ms	Ind - Ind rest	075 x 10ms
Cont - Cont Rest:	090 x 10ms	Long/short threshold	025 x 10ms
Ind. - Cont Rest:	090 x 10ms	RX Clearout time	005 x 10ms
Step 9 recall:	097 x 10ms	Invert input:	No
Extension bit:	L	Invert output:	No

Station Data

Addr	C/I	Main	Addr	C/I	Main	Addr	C/I	Main	Addr	C/I	Main
01:000	07/08	00	11:000	07/08	00	21:000	07/08	00	31:000	07/08	00
02:000	07/08	00	12:000	07/08	00	22:000	07/08	00	32:000	07/08	00
03:000	07/08	00	13:000	07/08	00	23:000	07/08	00	33:000	07/08	00
04:000	07/08	00	14:000	07/08	00	24:000	07/08	00	34:000	07/08	00
05:000	07/08	00	15:000	07/08	00	25:000	07/08	00	35:000	07/08	00
06:000	07/08	00	16:000	07/08	00	26:000	07/08	00			
07:000	07/08	00	17:000	07/08	00	27:000	07/08	00			
08:000	07/08	00	18:000	07/08	00	28:000	07/08	00			
09:000	07/08	00	19:000	07/08	00	29:000	07/08	00			
10:000	07/08	00	20:000	07/08	00	30:000	07/08	00			

Figure 4-29 Timecode Configuration Defaults

4.4.7.6 Loading a New Executive

New versions of the executive program are distributed as XCMxxxxy.BIN, where xxx is the major version number and y is the minor revision number.

- Two methods may be used to install the executive program.

4.4.7.7 Installing New Executive Program Version

See Section 4.4.3.3

4.4.7.8 Reinstalling Existing Executive Program Version

When installing an executive program whose version is older than the version currently running in the BCM II, the following message will appear:



```
0110AL
Upload file is older version of software, upload canceled.
* Hit <ESC> to continue *
```

Go to Section 4.4.7.13 (GF1, GF2, GF4) for the procedure to install an existing executive program.

4.4.7.9 Installing New Xilinx Program Version

See Section 4.4.3.3

4.4.7.10 Reinstalling Existing Xilinx Program Version

When installing a Xilinx program whose version is older than the version currently running in the BCM II, the following message will appear:



```
0110AL
Upload file is older version of software, upload canceled.
* Hit <ESC> to continue *
```

Go to Section 4.4.7.13 (GF1, GF2, GF4) for the procedure to install an existing Xilinx program.

4.4.7.11 Installing New DSP Program Version

See Section 4.4.3.3

4.4.7.12 Reinstalling Existing DSP Program Version

When installing a DSP program whose version is older than the version currently running in the BCM II the following message will appear:



Go to Section 4.4.7.13 (GF1, GF2, GF4) for the procedure to install an existing DSP program.

4.4.7.13 GF1, GF2, GF4

Use the following commands for sending and flashing file(s) to BCM II if file is an older version than what is currently installed:


- **GF1** – send and flash Xilinx (Step 11 below)
- **GF2** – send and flash DSP (Step 14 below)
- **GF4** – send and flash executive (Step 8 below)


NOTE

NOTE

File 'xcmmaint.ini' specifies the path to each file to be installed. However, if the file does not exist, then a prompt will appear asking for the path to file to be installed.

1. Run the XCMMMAINT.EXE program.
 - The Main Editor Screen displays.
2. Hold down the **ALT** key and type **O**.
 - The **Online** drop-down menu displays.
3. Select **Terminal** from the drop-down menu.
 - The Online Terminal Screen displays.
4. Press the **ENTER** key
 - Verify that the "*" prompt is displayed.
5. Enter **test** and then press **ENTER** key. BCM II will reset. While the unit is resetting, press **CTRL** and **A** keys together and hold them down until the following screen is observed:






```

*
*
*TEST

Safetran BCM II/MCM II 68302 Debugger Version 1.00
Booting from Diagnostic ROM
SCC3 debug> 0000000000
MCP 00/00/00 00:00:05 MCP Cold reset
  
```

6. When **SCC3 debug>** appears, press **Enter** key
7. Enter **W** followed by **Enter** key to enable kicking of system watchdog.



```

Safetran BCM II/MCM II 68302 Debugger Version 1.00
Booting from Diagnostic ROM
SCC3 debug> 0000000000000000
?Invalid command -- type '?' for help
SCC3 debug> W
*** WATCHDOG kick enabled ***
SCC3 debug>
MCP 00/01/01 00:01:48 Port Contact 1 Alarm On
  
```

8. For sending and flashing executive firmware enter **GF4** followed by **Enter** key to start the firmware upload operation. A window will appear showing the percentage of upload completed.




```

SCC3
?Inv
SCC3
***
SCC3
Booting from serial port
  
```

C:*.BIN

File C:\M2A115S1.BIN: sent 2%

9. After upload is complete, prompt will appear as follows:



```

WARNING: Existing Flash applications will be ERASED
Program the Flash (Y/N)?_
  
```

Enter the following:

- **Y** to write file to flash memory. System will restart.
- **N** to abort operation.

10. During system restart, executive firmware will read Xilinx and DSP firmware from flash memory. If there is an incompatibility between executive firmware and Xilinx or DSP an error will be displayed on front-panel display. In this case proceed to step 11. Otherwise, firmware updating is complete.
11. To upload new **Xilinx** firmware, perform steps 5, 6, and 7. Then, enter **GF1** followed by **Enter** key to start the firmware upload operation. A window will appear showing the percentage of upload completed.

```
WARN      Sending Files To XIL
Prog File ..\bmbxil\b2x_0104.bin: sent 8%
SCC3
Safe
SCC3 debug> 
```

12. After upload is complete, prompt will appear as follows:

```
WARNING: Existing Flash applications will be ERASED
Program the Flash (Y/N)?_
```

Enter the following:

- **Y** to write file to flash memory. System will restart.
- **N** to abort operation.

13. During system restart, executive firmware will read Xilinx and DSP firmware from the flash memory. If there is an incompatibility between the executive firmware and Xilinx or DSP an error will be displayed on the front panel display. In this case proceed to step 14. Otherwise, the firmware updating is complete.

SECTION V

DIAGNOSTICS

5.0 DIAGNOSTICS

5.1 SELF TEST

Self Test of the BCM is conducted when power is initially applied and when requested by the CC.

- Self-test results are reported directly to the CC, if configured to send Health/Alarm messages.

5.2 ON-LINE TERMINAL

An on-line debugging terminal is built into the XCMMaint program for extended diagnostics and to access the event log,

- To access the terminal, use the **ALT-O** / Terminal option from the main XCMMaint screen.
- The commands listed in Table 5-1 are available.
- This listing can also be displayed using the **HELP** command.

Table 5-1 On-Line Terminal Commands

Command	Parameters	Function
DCP	None	Display Code plug Contents
CL	None	Display Client List
SERV	None	Enter Service Mode
VER	None	Version Identification
CSTAT	None	Communication Statistics
HSTAT	None	HDLC Statistics
MSTAT	None	Manufacturer Statistics
AL	None	Alarm Logging
LOG	None	View log
SL	None	Status Logging
PTT	EN / DS	Key or Dekey Radio
SIMP	EN / DS	Radio Simplex Operation
COS	EN / DS	COS status
CHAN	Number (1 to 6)	Enter Channel Number
LOCAL	Label, Message	Send Local Message
TEST	0 = Warm, 1 = Cold	Reset and self test
PCP	Location, Value	Patch Code plug
MOND	Layer, Port, Link	Disable Tracing Mechanism
MONE	Layer, Port, Link	Enable Tracing Mechanism
SEND	Layer, Port, Link, Message	Send Mobile Message
ERT	Mode, Layer, Port, Pattern	Error Rate Test
SCT	None	Display software versions
SWI	EN / DS	Enable / Disable SWI
FPROG	None	Program Code plug

5.3 BASE COMMUNICATIONS PACKAGE LOG

The event log for the Base Communication Package resides in non-volatile RAM within the BCM.

- Log event records are displayed in real time at the bottom of the Online Terminal Screen.
- As new log events occur, the previous record display is overwritten.

5.3.1 Log Event Display

Entering a **Log** command displays a list of the last 16 log records as shown in Figure 5-1 On-Line Terminal Screen Log Record List Initial Display.

NOTE

NOTE

Depending on type of computer connected to the diagnostic port, a list of up to 24 log records may be displayed.

```

C:\IN_PRO~1\BCPIIU~1\Software\BCMII\XCMMAI~1.EXE
File      Online    Upload
*LOG
Log display - hit ESC to exit
MC0 00/00/00 00:00:05 MCP Cold reset
MC0 00/00/00 00:00:09 A/D Hardware Alarm On
MC0 00/00/00 00:00:09 Codeplug Values have been updated
MC0 00/00/00 00:00:30 Port $100: mode 3 9600 timer 1300 usage 5 config 0
MC0 00/00/00 00:00:31 Port $101: mode 3 9600 timer 1300 usage 5 config 0
MC0 00/00/00 00:00:34 Logic Pass-Through operation enabled
MC0 00/00/00 00:00:34 External 4 Alarm On
MC0 00/00/00 00:00:34 External 5 Alarm On
MC0 00/00/00 00:00:34 External 6 Alarm On
MC0 00/00/00 00:00:34 External 7 Alarm On
MC0 00/00/00 00:00:34 External 8 Alarm On
MC0 00/00/00 00:00:34 External 9 Alarm On
MC0 00/00/00 00:00:34 .\PL_SE_SE.C:50 from .\LD_SE_XI.C:109 31 Tail1 A100000A
MC0 00/00/00 00:00:34 .\RAQ.C:79 from .\LD_SE_XI.C:109 31 Tail1 A100000A
MC0 00/00/00 00:00:34 .\RQ_XID.C:163 from .\LD_SE_XI.C:109 31 Tail1 A100000A
MC0 00/00/00 00:01:30 Port Contact 0 Alarm On
MC0 00/00/00 00:01:31 Port Contact 1 Alarm On

```

Figure 5-1 On-Line Terminal Screen Log Record List Initial Display

The following subcommands may be used to manipulate the Online Terminal Screen log event list display:

- Pressing the **E** (End) key displays the last 16 records in the BCM log
- Pressing the **S** (Start) key displays the first 16 records in the BCM log
- Pressing the **F** (Forward) key advance the BCM log 16 records forward
- Pressing the **B** (Backward) key advance the BCM log 16 records backwards

When one of the above subcommands is implemented, the event list scrolls up on the screen and the selected records are placed at the end of the list.

- As new events occur, the event record is added to the end of the event list as shown in Figure 5-2 On-Line Terminal Screen Log New Record Display.

```

File      Online      Upload
Enter ESC to quit, <B>ack, <F>orward, <S>tart, <E>nd, <P>ause, <W>ipe
Enter ESC to quit, <B>ack, <F>orward, <S>tart, <E>nd, <P>ause, <W>ipe
Enter ESC to quit, <B>ack, <F>orward, <S>tart, <E>nd, <P>ause, <W>ipe
Enter ESC to quit, <B>ack, <F>orward, <S>tart, <E>nd, <P>ause, <W>ipe
***** START *****
MC0 00/00/00 00:00:05 MCP Cold reset
MC0 00/00/00 00:00:09 A/D Hardware Alarm On
MC0 00/00/00 00:00:09 Codeplug Values have been updated
MC0 00/00/00 00:00:30 Port $100: mode 3 9600 timer 1300 usage 5 config 0
MC0 00/00/00 00:00:31 Port $101: mode 3 9600 timer 1300 usage 5 config 0
MC0 00/00/00 00:00:34 Logic Pass-Through operation enabled
MC0 00/00/00 00:00:34 External 4 Alarm On
MC0 00/00/00 00:00:34 External 5 Alarm On
MC0 00/00/00 00:00:34 External 6 Alarm On
MC0 00/00/00 00:00:34 External 7 Alarm On
MC0 00/00/00 00:00:34 External 8 Alarm On
MC0 00/00/00 00:00:34 External 9 Alarm On
MC0 00/00/00 00:00:34 .\PL_SE_SE.C:50 from .\LD_SE_XI.C:109 31 Tail1 A100000A
MC0 00/00/00 00:00:34 .\RAQ.C:79 from .\LD_SE_XI.C:109 31 Tail1 A100000A
MC0 00/00/00 00:00:34 .\RQ_XID.C:163 from .\LD_SE_XI.C:109 31 Tail1 A100000A
MC0 00/00/00 00:01:30 Port Contact 0 Alarm On
MC0 00/00/00 00:01:31 Port Contact 1 Alarm On
MC0 00/00/00 00:00:34 .\PL_SE_SE.C:50 from .\LD_SE_XI.C:109 31 Tail1 A100000A


```

Figure 5-2 On-Line Terminal Screen Log New Record Display

5.3.2 Log Capture

Log event lists may be captured (copied) to a log text file as follows:

- Simultaneously press the **ALT** and **O** keys (**ALT-O**).
 - The **Online** drop-down menu (see right) displays with **Terminal** highlighted.
- Press the **Enter** key.
 - A blank Online Terminal Screen displays.
- Press the **Enter** key.
 - An * is displayed at the top left of the Online Terminal Screen, verifying that the program is communicating with the BCM.
- Type **LOG**.
- Press the **Enter** key.
 - A list of the last 16 log records displays within the Online Terminal Screen as shown in Figure 5-1 On-Line Terminal Screen Log Record List Initial Display.
- If a portion of the log other than the first 16 records is to be recorded, proceed as follows:
 - Use the subcommands listed in paragraph 5.3.1 to display the beginning of the portion of the log to be captured.
 - Press the **B** key.
 - The screen displays the 16 records immediately before the records to be captured.



7. Simultaneously press the **ALT** and **F** keys (**ALT-F**).
 - The **File** drop-down menu (see right) displays.



8. Highlight the **Log Open** entry using the arrow keys.

9. Press the **Enter** key.
 - The following prompt is displayed:

**NOTE****NOTE**

Only one log capture file may be opened at a time. If a log capture file is already open, then the above prompt will not appear.

10. Enter a file name by performing one of the following actions:
 - Create a new log file by typing the file name (maximum of eight characters plus the .log extension) at the **Enter Filename** prompt.
 - Select a saved log file by pressing the **Enter** key to bring up the log File List, Figure 5-3 Log File List and making a file selection from the presented list using the arrow keys.




Figure 5-3 Log File List

11. Press the **Enter** key.
12. If only a portion of the log is to be recorded, proceed to step 14.
13. If all of the log records are to be captured, press the **S** key.

The start of log list is displayed and captured to the selected log file.

13. Press the **F** key to go forward in the log list.

As each section of the log is displayed it is captured to the log file.

14. Repeat step 13 until the desired log records are captured.

15. Simultaneously press the **ALT** and **F** keys (**ALT-F**).

The **File** drop-down menu displays.

16. Highlight the **Log Close** entry using the arrow keys.

17. Press the **Enter** key.



This Page Intentionally Left Blank

APPENDIX A

ADVANCED TRAIN CONTROL SYSTEM

A. ADVANCED TRAIN CONTROL SYSTEM

A.1 OVERVIEW

The Advanced Train Control System (ATCS) standardizes the message formats and addressing scheme used by all railroads for train control applications. The system operates by sending and receiving standard datagrams (using a standard addressing scheme) between the various ATCS compatible signaling and operating equipment. Addresses are provided for wayside equipment, central office equipment, on-board equipment, base stations, maintenance equipment, railcars, and anything else found in a railroad environment. These messages convey operating instructions and status information such as track-and-time permits, codeline controls and indications, hot-box data, etc.

A typical ATCS network is shown in Figure A-1. Centralized Train Control (CTC) office equipment communicates with the onboard and wayside equipment via Base Communication Packages (BCPs), controlled by Cluster Controllers (CCs). Network Management System (NMS) office equipment monitors the dynamic performance of the network. Field radios are a mixture of Wayside Communication Packages (WCPs) and Spread-Spectrum Radios (SSRs). All communications use ATCS datagrams or packets.




Figure A-1 Typical ATCS Network

A.2 ATCS ADDRESSING

Each ATCS datagram carries with it a destination address (i.e., the address of the equipment it is destined for), and a source address (i.e., the equipment that generated it). These addresses are constructed with slight differences for the various uses. For example, on-board equipment will have a Type 1 (locomotive) address while wayside equipment will have a Type 7 (wayside) address. A number of the various types of addresses used are described in the following paragraphs. For further information concerning ATCS addressing, refer to the following specifications:

ATCS Specification 200 (March 1993) - ATCS Protocols

ATCS Specification 250 (March 1993) - ATCS Message Formats

ATCS Specification 700 (March 1993) - CPC Specification

ATCS Specification 157 (March 1993) - CPC Operation

R/Link ATCS Radio Code Line System Application Logic Generation Guide (Siemens Rail Automation Document No. C-00-94-06).

A.2.1 Locomotive Addresses (Type 1)

Each locomotive address consists of twelve digits in the following format: **1.RRR.VVVVVV.DD**

where:

1	=	Locomotive address type
RRR	=	Railroad number (see Appendix D)
VVVVVV	=	Locomotive number
DD	=	Device on board locomotive (e.g., Engineers display)

A.2.2 Office Equipment Addresses (Type 2)

Each office equipment address consists of ten digits in the following format: **2.RRR.NN.DDDD**

where:

2	=	Office equipment address type
RRR	=	Railroad number (see Appendix D)
NN	=	Unit in the office (e.g., CTC computer, A53401 Packet Switch, etc.)
DDDD	=	Application in the office (e.g., maintenance alarm monitoring)

A.2.3 Base Station Address (Type 3)

Each address consists of ten digits in the following format: **3.RRR.NN.DDDD**

where:

3	=	Wire line address type
RRR	=	Railroad number (see Appendix D)
NN	=	Node number (railroad defined)
DDDD	=	Base device number (railroad defined)

The ATCS specification recommends that the BCP node number be the same as the node number of the CC (A47620) to which it is connected. The device number is user defined, and can be set to any convenient value.

A.2.4 Wayside Equipment (Type 5)

The type 5 wayside address was used on earlier ATCS systems and is the default addressing scheme for Advanced Railroad Electronic System (ARES) wayside equipment. Although the ARES network differs slightly from the ATCS specification, for purposes of this discussion, the two can be considered identical systems.

Each address consists of ten digits in the following format: **5.RRR.NN.LL.GG**

where:

5	=	Wayside address type
RRR	=	Railroad number (see Appendix D)
NN	=	Node or routing region number
LL	=	Code-line number
GG	=	Group or location number

This addressing scheme does not have the ability to address multiple devices at each location. The node number typically follows the node number of the CC controlling the base stations for the location.

A.2.5 Wayside Equipment (Type 7)

This is the default ATCS wayside addressing scheme.

Each address consists of fourteen digits in the following format: **7.RRR.LLL.GGG.SS.DD**

where:

7	=	Wayside address type
RRR	=	Railroad number (see Appendix D)
LLL	=	Code-line or region number
GGG	=	Group or location number
SS	=	Equipment or subnode at location
DD	=	Device controlled by this equipment

The LLL fields are normally assigned by each railroad according to internal conventions, and may represent a region, district, code line, or other area designation that shows it is part of the railroad.

The GGG field must be coordinated between the CTC equipment and field equipment configuration.

For the SS field, two subnode numbers are always pre-assigned at each location. The wayside-to-office communications device is defined as number 01, and number 02 is reserved for the wayside-to-wayside communications system. Any additional equipment (e.g., the R/Link™ I/O modules), will therefore have subnode numbers starting with 03.

Device numbers (DD field) are allocated in sequence beginning at 01. Each piece of field equipment has at least one internal device, but it may have more depending on the equipment.

Examples of full ATCS addresses for a wayside code system would be as follows:

For CP Rail, code line 8, control point 1: 7.105.008.001.03.02.

For the MCP radio at the same location : 7.105.008.001.01.01.

A.2.6 Other Address Types

Other address types are defined in ATCS for future applications. Please refer to the appropriate ATCS specifications for full details.

A.3 ATCS MESSAGE FORMATS

The major fields in an ATCS message are shown in Figure A-2.



Figure A-2 Major Fields Of An ATCS Message

The **Destination** field is the address of the recipient equipment. For example, if this is an indication message coming from a wayside code unit, the destination address will be the CTC dispatching equipment (2.RRR.NN.DDDD).

The **Source** field is the sender's address (e.g., 7.RRR.LLL.GGG.SS.DD).

The number in the message number (**M#**) field is allocated by the sender in a sequential fashion so that the recipient can detect duplicate, missing, or out of order messages.

The **Label** field describes the type of data carried by the message. Many different labels have been defined in ATCS Specification 250. Additional labels are defined by suppliers to perform custom functions.

The **Data** field carries the particular data required for the type of message defined by the Label field.

A.4 ATCS RADIO NETWORK – LAYER 1

The ATCS radio network consists of pairs of UHF channels. These channels are as follows:

Channel Number	Base to Mobile Frequency	Mobile to Base Frequency
1	935.8875	896.8875
2	935.9375	896.9375
3	935.9875	896.9875
4	936.8875	897.8875
5	936.9375	897.9375
6	936.9875	897.9875

NOTE

NOTE

Transmission on the channels is baseline FSK. the deviation of the carrier to a higher frequency is interpreted as a logical 0 and to a lower frequency as a logical 1. The bit rate is 4800 bits per second. Nominal channel separation is 12.5kHz.

APPENDIX B

ATCS SPECIFICATION 250 RAILROAD CODE LIST

B. RAILROAD CODE LISTING

The following chart lists the codes assigned to all carriers in accordance with ATCS Specification No. 250 and includes the railway carrier name along with the alphabetical and numerical codes assigned to each. In the event a discrepancy exists between the information in the following list and the current AAR specification, the AAR specification shall prevail.

ID	Company Name	RR Mark	ATCS
001	Aberdeen And Rockfish Railroad Company	AR	009
002	Akron & Barberton Belt Railroad Company	ABB	002
003	Alabama & Florida Railway Co	AF(LR)	917
004	Alameda Belt Line	ABL	014
005	Alameda Corridor Transportation Authority	ACTA	015
006	Alaska Hydro-Train	AHT	039
007	Alaska Railroad Corporation	ARR	005
008	Alexander Railroad Company	ARC	049
009	Algers Winslow And Western Railway Company	AWW	004
010	Algoma Central Railroad Inc	AC	008
011	Allegheny & Eastern Railroad Inc	ALY	532
012	Alley Railroad Company		664
013	Almanor Railroad Company	AL	046
014	Alton & Southern Railway Company	ALS	032
015	Amador Central Railraod Company	AMC	019
016	Andalusia & Concecuah Railroad Company	ACRC	173
017	Angelina & Neches River Railroad Company	ANR	035
018	Anthracite Railway Inc	ATRW	176
019	Apache Railway Company	APA	011
020	Apalachicola Northern Railroad Company	AN	012
021	Appanoose County Community Railroad Inc	APNC	226
022	Arcade And Attica Railroad Corporation	ARA	013
023	Arkansas And Missouri Railroad Co	AM	906
024	Arkansas Louisiana & Mississippi (Missouri) Railro	ALM	016
025	ARTC		047
026	Ashley, Drew & Northern Railway Company	AND	020
027	Ashtabula Carson & Jefferson Railroad	ACJR	235
028	Atchison, Topeka And Santa Fe Railway Company Ats	ATSF	022
029	Atcs Shared Network	ATCS	340
030	Atcs Testing & Field Evaluation	ATCR	050
031	Atcs Testing & Field Evaluation	ATCT	620
032	Atlantic & Western Railway, L P	ATW	025
033	Austin Railroad	AUNW	924
034	Austin, Todd And Ladd Railroad Company	ATLT	514
035	Baltimore And Annapolis Railroad Company	BLA	053
036	Bangor & Aroostook Railroad Company	BAR	056
037	Bath And Hammondsport Railroad Company	BH	079
038	Batten Kill Railroad Inc	BKRR	086
039	Bauxite & Northern Railway Company	BXN	084
040	Bay Colony Railroad Corporation	BCLR	082
041	Bayside Railway Co		021
042	BC HYDRO RAIL	BCE	072
043	BC RAIL LTD	BCOL	997
044	Beaufort And Morehead Railroad Company	BMH	068
045	Beech Mountain Railroad Company	BEEM	060
046	Belfast And Moosehead Lake Railroad Company	BML	087
047	Belt Railway Company Of Chicago	BRC	083
048	Belton Railroad Company	BRR	207
049	Berlin Mills Railway	BMS	073
050	Bessemer And Lake Erie Railroad Company	BLE	061

ID	CompanyName	RR Mark	ATCS
051	Birmingham Southern Rr Co	BS	065
052	Black River & Western Corporation	BRW	066
053	Bloomer Line, The	BLOL	223
054	Blue Mountain And Reading Railroad	BMRG	256
055	Border Pacific Railroad Co	BOP	225
056	Boston And Maine Corporation	BM	069
057	Brandon Corporation	BRAN	081
058	Brandywine Valley Railroad Company	BVRY	067
059	Broken Hill Proprietary Co.		042
060	Brownsville And Rio Grande International Rr	BRG	170
061	Buffalo Southern Railroad Inc	BSOR	085
062	Burlington Junction Railway	BJRY	383
063	Burlington Northern (Manitoba) Ltd	BNML	457
064	Burlington Northern Railroad Company	BN	076
065	Burlington Northern Santa Fe	BNSF	777
066	C&J Railroad Investment Company	CJRR	565
067	Cadillac And Lake City Railway Co	CLK	093
068	Cadiz Railroad Company	CAD	092
069	Cairo Terminal	CTML	162
070	California Western	CWR	100
071	CALTRAIN	CALTRAIN	708
072	Camas Prairie Railnet Inc	CSP	952
073	Cambria And Indiana Railroad Company	CI	101
074	Canada And Gulf Terminal Railway Company, The	CGT	116
075	Canadian National Railways	CN	103
076	Caney Fork And Western Rr	CFWR	187
077	Canton Railroad Company	CTN	097
078	Cape Fear Railways Inc	CF	099
079	Carolina Rail Services Inc	CRIJ	988
080	Carrollton Railroad	CARR	113
081	Carthage Knightstown & Shirley Railroad	CKSI	396
082	Cedar Rapids & Iowa City Railway Company	CIC	111
083	Cedar Valley	CVAR	313
084	Central California Traction Company	CCT	112
085	Central Indiana & Western Railroad Co Inc	CEIW	949
086	Central Michigan Railway Co	CMGN	472
087	Central Montana Rail Inc	CM	374
088	Central New York Railroad Corporation	CNYK	151
089	Central Vermont Railway	CV	120
090	Central Western Railway Corp	CWRL	527
091	Charles City Rail Lines	CCRY	967
092	Chattahoochee Industrial Railroad	CIRR	222
093	Chattahoochee Valley	CHV	124
094	Chelatchie Praire Railraod	CCPR	155
095	Chesapeake And Ohio Railway Company	CO	125
096	Chesapeake Western	CHW	179
097	Chestnut Ridge Railway Company	CHR	117
098	Chicago And Northwestern	CNW	131
099	Chicago And West Pullman	CWP	172
100	Chicago And Western Indiana	CWI	132

ID	CompanyName	RR Mark	ATCS
101	Chicago Central & Pacific Railroad Co	CC	569
102	Chicago Heights Terminal Transfer Railroad Company	CHTT	139
103	Chicago Illinois Midland	CIM	130
104	Chicago Short Line Railway Company	CSL	147
105	Chicago Southshore & South Bend Railroad	CSS	168
106	Cimarron Valley Railroad, L C	CVR	378
107	City Of Columbia	CT	090
108	City Of Prineville Railway	COP	166
109	Claremont Concord Railroad Corporation	CCRR	188
110	Clarendon And Pittsford Railroad Company, The	CLP	169
111	Cliffaide Railroad Company	CLIF	181
112	Colonels Island Railroad Co	CISD	164
113	Colorado & Wyoming Rwy Co	CW	158
114	Colorado Springs & Eastern	CSE	319
115	Columbia & Cowlitz Railway Company	CLC	163
116	Columbia & Silver Creek Railroad Company	CLSL	165
117	Columbus And Greenville Railway	CAGY	177
118	Conemaugh & Black Lick Railroad Company	CBL	215
119	Connecticut Central	CCCL	416
120	Connecticut Department of Transportation	CDOT	007
121	Consolidated Rail Corporation	CR	190
122	Cooperstown And Charlotte Valley Rwy	CACV	114
123	Copper Basin Railway Inc	CBRY	909
124	Corinth And Counce	CCR	201
125	Corman	RJCR	970
126	Cotton Belt (St. Louis Southwestern Rwy Company)	SSW	694
127	CP RAIL SYSTEM	CP	105
128	Crab Orchard & Egyptian Railroad	COER	089
129	CSXT	CSXT	171
130	Curtin Milburn	CMER	180
131	Cuyahoga Valley Railway Company, The	CUVA	186
132	D & I Railroad Company	DAIR	211
133	Dakota Minnesota & Eastern Railroad Corp	DME	912
134	Dakota Rail Inc	DAKR	221
135	Dakota Southern Railway Company	DSRC	526
136	Dansville And Mount Morris Railroad Company, The	DMM	220
137	Dardanelle & Russellville Railroad Company,	DR	191
138	Davenport Rock Island And North Western Railway Co	DRI	192
139	Delaware & Hudson Railway Company Inc	DH	195
140	Delaware Coast Line Rr Co	DCLR	214
141	Delta Valley & Southern Railway Company	DVS	193
142	Denver Union Terminal Ry Co.	DUT	288
143	Dequeen And Eastern Railroad Company,	DQE	200
144	Des Moines Union	DMU	202
145	Detroit And Mackinac	DM	204
146	Dominion And Atlantic	DA	209
147	Doniphan Kensett & Searcy Railway	DKS	210
148	DRGW	DRGW	197
149	Duluth & Northeastern Railroad Company,	DNE	212
150	Duluth Missabe And Iron Range Railway Company	DMIR	213

ID	CompanyName	RR Mark	ATCS
151	Duluth Winnipeg And Pacific Railway Company	DWP	216
152	Dunn-Erwin Railway Corporation	DER	219
153	East Camden & Highland Rr Co	EACH	242
154	East Cooper And Berkeley Railroad Company	ECBR	229
155	East Erie Commercial Railroad	EEC	040
156	East Jersey Railroad And Terminal Company	EJR	245
157	East St. Louis Junction Rr	ESLJ	233
158	East Tennessee Railway, L P	ETRY	257
159	Eastern Shore Railroad Inc	ESHR	251
160	Edgmoor & Manetta	EM	232
161	El Dorado And Wesson Railway Company	EDW	247
162	Elgin Joliet & Eastern Railway Company	EJE	238
163	Escanaba And Lake Superior Railroad Company	ELS	241
164	Esquimalt And Nanaimo	EN	246
165	Essex Terminal Railway Company The	ETL	228
166	Eureka Southern	EUKA	368
167	Everett Railroad	EV	231
168	Falls Creek	FCRK	267
169	Farmrail Corporation	FMRC	280
170	FCA - Ferrovia Centro - Atlantica SA	??	029
171	Ferdinand & Huntingburg	FRDN	273
172	Ferrocarril De Chihuahua Al Pacifico,	CHP	284
173	Ferrocarriles Nacionales De Mexico	NDM	266
174	Ferrocarriles Nacionales De Mexico	SBC	283
175	Ferrocarriles Nacionales De Mexico -	FCP	738
176	Ferrocarriles Unidos Del Sureste, S.A.	SE	281
177	Florida Central Railroad Co	FCEN	986
178	Florida East Coast Railway Company	FEC	263
179	Florida Midland Railroad Co Inc	FMID	507
180	Fonda, Johnstown And Gloversville	FJG	264
181	Fordyce And Princeton Railroad Co	FP	265
182	Fore River	CRY	908
183	Fort Smith And Van Buren	FSVB	279
184	Fort Worth & Western Railroad	FWWR	277
185	Galveston Railroad L P	GVSR	567
186	Galveston Warves	GWF	303
187	Galveston, Houston And Henderson	GHH	293
188	Garden City Western Railway Company, The	GCW	287
189	Genesee And Wyoming Railroad Company	GNWR	320
190	Georgetown Railroad Company	GRR	302
191	Gettysburg Railway	GBRY	294
192	Gloster Southern Railroad Company	GLSR	916
193	GO TRANSIT	GOT	954
194	Goderich - Exeter Railway Company	??	027
195	Golden Triangle Railroad	GTRA	295
196	Grafton And Upton Railroad Company	GU	323
197	Grainbelt Corporation	GNBC	443
198	Grand River	GRNR	322
199	Grand Trunk Western Railroad Incorporated	GTW	308
200	Graysonia, Nashville And Western	GNA	307

ID	CompanyName	RR Mark	ATCS
201	Great River Railroad	GTR	271
202	Great Southwestern	GSWR	305
203	Great Western Railway Company, The	GWR	311
204	Green Bay And Western	GBW	312
205	Green Hills Rural Development	GHRD	980
206	Green Mountain Railroad Corporation	GMRC	314
207	Gulf And Mississippi	GMSR	392
208	Hammersley Iron (Australia)		041
209	Hampton & Branchville Railroad Company	HB	330
210	Hartford And Slocomb Railroad Company	HS	366
211	Hartwell Railway Company	HRT	334
212	Helena Southwestern Railroad Company	HSW	331
213	High Point Thomasville & Denton Railroad Company	HPTD	366
214	Hillsboro And North Eastern Railway	HLNE	338
215	Hillsdale County Railway Company, Inc.	HCRC	326
216	Hillside (Australia)		018
217	Hollis & Eastern R R Co	HE	328
218	Houston Belt & Terminal Railway Company	HBT	342
219	Huntsville & Madison County Railroad Authority	HMCR	391
220	Huron And Eastern Railway Company Inc	HESR	890
221	Hutchinson And Northern Railway Company, The	HN	332
222	Illinois Central Railroad Company	IC	360
223	Indian Creek Railroad Company	ICRK	380
224	Indiana & Ohio Rail Corp.	INOH	344
225	Indiana Hi-Rail Corporation	IHRC	352
226	Indiana Rail Road Corporation	INRD	780
227	Indianapolis Union Railway	IU	363
228	Indonesia (Indonesian State Railways)		093
229	International Bridge And Terminal Company, The	IBT	358
230	Interstate Railroad Company	SOU	381
231	Iowa Interstate Railroad Ltd	IAIS	316
232	Iowa Northern Railroad	IANR	341
233	Iowa Southern Railroad Company	ISR	272
234	Iowa Traction Railroad Company	IATR	994
235	ITS - Highway Advanced Transportation Controller		051
236	ITS - Non-ATCS Railroad		052
237	Jefferson Warrior Railroad Co Inc	JEFW	254
238	Kankakee Beaverville And Southern Railroad Company	KBSR	399
239	Kansas And Missouri Railway	KM	414
240	Kansas City Southern Railway Company	KCS	400
241	Kansas City Terminal Railway Company	KCT	401
242	Kentucky And Tennessee Railway	KT	405
243	Keokuk Junction Railway	KJRY	365
244	Kiamichi Railroad Company Llc	KRR	424
245	Knox & Kane Railroad Company	KKRR	376
246	Kwt Railway Inc	KWT	996
247	Kyle Railroad Company	KYLE	377
248	Lake Erie & Northern	LEN	421
249	Lake Erie, Franklin & Clarion Railroad Company	LEF	423
250	Lake Superior & Ishpeming Railroad Company	LSI	425

ID	CompanyName	RR Mark	ATCS
251	Lake Terminal Railroad Company, The	LT	404
252	Lamoille Valley Railroad Company	LVRC	452
253	Lancaster And Chester Railway Company	LC	426
254	Landisville Railroad Inc (Formerly Amherst Industr	AMHR	071
255	Laurinburg And Southern Railroad Company	LRS	427
256	Levin-Richmond Terminal Corporation	PRT	606
257	Lewis & Clark Railway Co	LINC	355
258	Little Rock & Western Railway, L P	LRWN	485
259	Little Rock Port Railroad	LRPA	435
260	Livonia, Avon & Lakeville Railroad Corporation	LAL	398
261	Logansport & Eel River Short-Line Co Inc	LER	304
262	Long Island Railroad Company	LIRR	436
263	Longview, Portland & Northerm Railway Company	LPN	450
264	Los Angeles Junction Railway Company	LAJ	428
265	Louisana & Arkansas Railway Company	LA	441
266	Louisiana & Delta Railroad Inc	LDRR	972
267	Louisiana And North West Railroad Company, The	LNW	442
268	Louisville And Wadley Railway Company	LW	451
269	Louisville New Albany & Corydon Railroad	LNAL	446
270	Lowville And Beaver River Railroad Company, The	LBR	447
271	Ludington & Northern Railway	LUN	430
272	Madison Railroad (A Div Of City Of Madison Port Au	CMPA	144
273	Magma Arizona Railroad Company	MAA	463
274	Mahoning Valley Railway Company, The	MVRY	504
275	Maine Central Railroad Company	MEC	456
276	Manufacturers Junction Railway Company	MJ	459
277	Manufacturers Railway Company	MRS	460
278	Marinette, Tomahawk & Western Railroad	MTW	520
279	Maryland And Delaware Railroad Company	MDDE	454
280	Maryland And Pennsylvania Railroad Company	MPA	463
281	Maryland Midland Railway Inc	MMID	495
282	Maryland Rail Commuter	MARC	003
283	Massachusetts Bay Transportation Authority	MBTA	006
284	Massachusetts Central Railroad Corporation	MCER	461
285	Massena Terminal Railroad Company, The	MSTR	471
286	Mccloud Railway Company	MCR	466
287	Mckeesport Connecting Railroad Company	MKC	583
288	Meridian & Bigbee Railroad Company	MBRR	462
289	Metra		892
290	Mexican Pacific Railroad Company, Inc.	MDP	285
291	Mg Rail Inc	MGRI	388
292	Michigan-Wisconsin Transportation Company	MWTT	512
293	Mid Atlantic Railroad Co., Inc.	MRR	877
294	Middletown & Hummelstown Railroad Company	MIDH	479
295	Middletown & New Jersey Railway Company Inc	MNRR	475
296	Midland Terminal Co, The	MDLR	385
297	Midlouisiana Rail Corporation	MDR	919
298	Midsouth Corporation	MSRC	905
299	Milwaukee Road	MILW	140
300	Minnesota Commercial Railway Co	MNNR	973

ID	CompanyName	RR Mark	ATCS
301	Minnesota Dakota & Western Railway Company	MDW	610
302	Mississippi & Skuna Valley Railroad Company	MSV	503
303	Mississippi Delta Railroad	MSDR	786
304	Mississippi Export Railroad Company	MSE	506
305	Mississippian Railway Cooperative Inc	MSRW	502
306	Missouri Pacific Railroad Company	MP	494
307	Missouri-Kansas-Texas Railroad Co.	MKT	490
308	Mobile & Gulf Railroad Company	MG	483
309	Modesto And Empire Traction Company	MET	524
310	Monongahela Connecting Rr Co.	MCRR	498
311	Monongahela Railway Company	MGA	497
312	Montana Rail Link Inc	MRL	671
313	Morristown & Erie Railway Inc	ME	511
314	Moscow, Camden & San Augustine Railroad	MCSA	548
315	MRS Logistics of South America	??	028
316	Muncie And Western Railroad Company	MWR	464
317	N D C Railroad Company	NDCR	902
318	N J Transit Rail Operations (Commuter Carrier)	NJTR	574
319	Napa Valley Railroad Co	NVRR	402
320	Nash County Railroad Corp	NCYR	776
321	Nashville And Eastern Railroad Corp	NERR	934
322	National Railroad Passenger Corporation	AMTRAK	891
323	National Railways Of Mexico (Ferrocarriles Naciona	NDM	286
324	New Hampshire Northcoast Corp	NHN	787
325	New Hope & Ivyland Rail Road	NHRR	585
326	New York & Lake Erie Railroad	NYLE	545
327	New York Cross Harbor Railroad Terminal Corp	NYCH	573
328	New York Susquehanna And Western Railway Corp	NYSW	546
329	Nicolet Badger Northern Railroad Inc	NBNR	476
330	Nittany & Bald Eagle Railroad Co	NBER	249
331	Norfolk & Portsmouth Belt Line Railroad Company	NPB	549
332	Norfolk And Western Railway Company	NW	550
333	Norfolk Southern	NS	555
334	North Carolina & Virginia Railroad Co Inc	NCVA	531
335	North Shore Railroad Co	NSHR	248
336	North Stratford Railroad Corporation	NSCR	570
337	Northwestern Oklahoma Railroad Company	NOKL	591
338	Northwestern Pacific Railroad Company	NWP	559
339	Oakland Terminal Railroad Company	OTR	586
340	Octoraro Railway, Inc.	OCTR	587
341	Ogden Union Railway And Depot Company, The	OURD	956
342	Ohi-Rail Corporation	OHIC	579
343	Oil Creek & Titusville Lines	OCTL	948
344	Okanagan Valley Railway Company	OKAN	945
345	Oklahoma Central Railroad Co	OCR	270
346	Oklahoma, Kansas And Texas Railroad	OKKT	593
347	Old Augusta Railroad Company	OAR	578
348	Omaha Lincoln And Beatrice Railway Company	OLB	598
349	Ontario Central Railroad Corporation	ONCT	589
350	Ontario Midland Railroad Corporation	OMID	588

ID	CompanyName	RR Mark	ATCS
351	Ontario Northland Railway (Ontario Northland Trans	ONT	754
352	Oregon & Northwestern Railroad Co.	ONW	596
353	Oregon Pacific & Eastern Railway Company	OPE	597
354	Oregon, California & Eastern Railway	OCE	603
355	Ottertail Valley Railroad Co Inc	OTVR	983
356	Ottumwa Terminal Railroad Co	OTT	276
357	Paducah & Illinois Railroad Company	PI	614
358	Paducah & Louisville Railroad	PAL	907
359	Panther Valley Railroad Corporation	PVAL	575
360	Patapsco & Back Rivers Railroad Company	PBR	609
361	Pearl River Valley Railroad Company	PRV	636
362	Pecos Valley Southern Railway Company, The	PVS	644
363	Pee Dee River Railroad Corp	PDRR	010
364	Peninsula Terminal Company	PT	643
365	Peoria And Pekin Union Railway Company	PPU	645
366	Philadelphia Belt Line Railroad Company, The	PBL	608
367	Philadelphia Bethlehem And New England Railroad Co	PBNE	659
368	Pickens Railway Company	PICK	624
369	Pioneer And Fayette Railroad Company	PF	630
370	Pioneer Valley Railroad Company	PVRR	611
371	Pittsburg & Shawmut Railroad Inc	PSR	627
372	Pittsburgh Chartiers & Youghioghenny Railway Compan	PCY	629
373	Pittsburgh, Allegheny & McKees Rocks Rr Co	PAM	607
374	Plymouth Short Line Ltd	PSLL	566
375	Pocono Northeast Railway, Inc.	PNER	618
376	Point Comfort & Northern Railway Company	PCN	651
377	Port Bienville Railroad	PBVR	677
378	Port Of Tillamook Bay Railroad	POTB	637
379	Port Royal Railroad	PRYL	393
380	Portland Terminal Company	PTM	619
381	Portland Traction Company	PRTD	632
382	Prescott And Northwestern Railroad Company	PNW	634
383	Providence And Worcester Railroad Company	PW	631
384	Quebec Central Railway Company	QC	658
385	Queensland Rail (Australia)		036
386	Quincy Railroad Company	QRR	656
387	Rac (Railway Association Of Canada)		033
388	Rarus Railway Company	RARW	516
389	Red River Valley & Western Railroad Co	RRVW	321
390	Renfe (National Railways Of Spain)		119
391	River Terminal Railway Company, The	RT	665
392	Robe (Australia)		044
393	Roberval And Saguenay Railway Company, The	RS	669
394	Rochester & Southern Railroad Inc	RSR	941
395	Rockdale Sandow & Southern Railroad Company	RSS	675
396	Rocky Mountain Railcar And Railroad Inc	RMRR	915
397	Roscoe Snyder & Pacific Railway Company	RSP	673
398	Sabine River & Northern Railroad Company	SRN	678
399	Saint Lawrence Railroad	SLAW	705
400	Saint Marys Railroad Company	SM	682

ID	CompanyName	RR Mark	ATCS
401	Salt Lake Garfield And Western Railway Company	SLGW	690
402	San Diego & Imperial Valley Railroad Co Inc	SDIY	315
403	San Luis Central Railroad Company	SLC	696
404	San Manuel Arizona Railroad Company	SMA	794
405	Sand Springs Railway Company	SS	707
406	Sandersville Railroad Company	SAN	691
407	Santa Maria Valley Railroad Company	SMV	741
408	Savannah State Docks Railroad Company	SSDK	679
409	Sequatchie Valley Railroad Inc	SQVR	910
410	Shore Fast Line Railroad Company Sflr 2	SFLR	255
411	Sierra Railroad Company	SERA	716
412	Singapore (Singapore)		076
413	Sisseton Southern Railway Co	SSOR	440
414	Somerset Railroad Corporation	SOM	772
415	SOO Line Rail Company	SOO	030
416	South Branch Valley Rail Road	SBVR	732
417	South Brooklyn Railway Company	SBK	718
418	South Buffalo Railway Company	SB	719
419	South Carolina Central Railroad Co Inc	SCRF	582
420	South Central Tennessee Railroad Corporation	SCTR	672
421	Southeast Kansas Railroad Company	SEKR	944
422	Southeastern Penn Transp Authority	SEPTA	024
423	Southern Indiana Railway Inc	SIND	720
424	Southern New Jersey Light Rail Transit	??	026
425	Southern Pacific Transportation Company	SP	721
426	Southern Railway Company	SOU	724
427	Southern San Luis Valley Railroad Company	SSLV	706
428	St Maries River Railroad Company	STMA	698
429	STA		048
430	Staten Island Railway Corporation	SIRY	389
431	Steelton & Highspire Railroad Company	SH	799
432	Stewartstown Railroad Co	STRT	729
433	Stockton Terminal And Eastern Railroad	STE	739
434	Strasburg Railroad Company	SRC	686
435	Strouds Creek And Muddlety Railroad	SCM	687
436	Sunset Railway Company	SUN	734
437	Tacoma Muncpal Belt Line Railway	TMBL	759
438	Tasrail		119
439	Tennessee Railway Company	SCM	767
440	Tennessee, Alabama And Georgia Railway	SOU	755
441	Tennken Railroad Company Inc	TKEN	745
442	Terminal Railroad Association Of St Louis	TRRA	757
443	Terminal Railway Alabama State Docks	TASD	758
444	Texas & Northern	TN	795
445	Texas Central Railroad Company	TEXC	750
446	Texas City Terminal Railway Company	TCT	761
447	Texas Mexican Railway Company, The	TM	762
448	Texas North Western Railway Company	TXNW	747
449	Texas South-Eastern Railroad Company	TSE	765
450	Texas, Oklahoma & Eastern Railroad Company	TOE	764

ID	CompanyName	RR Mark	ATCS
451	Thailand (Thai State Railways)		102
452	Tippecanoe Railroad Company	TIPP	753
453	Tonawanda Island Railroad Inc	TIRL	743
454	Towanda And Monroeton Shippers Lifeline, Inc.	TMSS	752
455	Transkentucky Transportation Railroad Co Inc	TTIS	773
456	Tranz Rail (Tasmania)		057
457	Trintity Railway Express		751
458	Trona Railway Company	TRC	779
459	TTCI Test Unit 1	TTCI	884
460	TTCI Test Unit 2	TTCI	885
461	TTCI Test Unit 3	TTCI	886
462	TTCI Test Unit 4	TTCI	887
463	TTCI Test Unit 5	TTCI	888
464	TTCI Test Unit 6	TTCI	889
465	Tucson, Cornelia & Gila Bend Railroad Company	TCG	783
466	Tulsa-Sapulpa Union Railway Company L L C	TSU	709
467	Turtle Creek Industrial Railroad Inc	TCKR	744
468	Tuscola And Saginaw Bay Railway Company Inc	TSBY	770
469	Union Pacific Railroad Company	UP	802
470	Union Railroad Company	URR	803
471	Union Railroad Of Oregon	UO	800
472	United South Eastern Railways Company	SE	281
473	Unity Railways Company	UNI	806
474	Upper Merion And Plymouth Railroad Company	UMP	808
475	Utah Railway Company	UTAH	811
476	Valdosta Southern Railroad	VSO	816
477	Vandalla Railroad Company	VRRC	781
478	Ventura County Railway Company	VCY	821
479	Vermont Railway Inc	VTR	817
480	Via Rail Canada Inc	VIA	818
481	Victrack (Australia)		017
482	Virginia Railway Express	VRE	023
483	Visalla Electric Railroad Company	VE	824
484	Walking Horse & Eastern Railroad Co Inc	WHOE	390
485	Warren & Saline River Railroad Company	WSR	832
486	Washington Central Railroad Company, Inc. Wcrc	WCRC	943
487	Washington County Railroad Corporation	WACR	812
488	Washington Terminal	WATC	849
489	Waterloo Railway Company	WLO	835
490	Wctu Railway Company	WCTR	844
491	Weatherford Mineral Wells & Northwestern	WMWN	837
492	West Jersey Short Line, Inc.	WJSL	387
493	West Shore Railroad Corp	WTSE	882
494	West Tennessee Railroad Corp	WTNN	258
495	West Virginia Northern Railroad	WVN	866
496	Western Railroad Company	WRRC	838
497	Westrail (Australia)		038
498	White Pass & Yukon	WPY	845
499	Willamette Valley Railway Company, Inc	WVR	863
500	Wilmington Terminal Railroad Inc	WTRY	981

ID	CompanyName	RR Mark	ATCS
501	Winchester And Western Railroad Company	WW	850
502	Winifrede Railroad Company	WNFR	852
503	Winston-Salem Southbound Railway Company (Csx Tran	WSS	854
504	Wisconsin & Calumet Railroad	WICT	382
505	Wisconsin & Southern Railroad Company	WSOR	879
506	Wisconsin Central Limited	WC	260
507	Yancey Railroad Company	YAN	876
508	Youngstown & Austintown Railroad Co	YARR	372
509	Youngstown & Southern Railway Company	YS	875
510	Yreka Western Railroad Company	YW	873
511	UK ATCS Testing and Field Evaluations	????	974
512	Network Rail - London North Eastern - UK	????	975
513	Network Rail - London North Western - UK	????	976
514	Network Rail - Scotland - UK	????	977
515	Network Rail - South East - UK	????	978
516	Network Rail - Western - UK	????	979

APPENDIX C

BCM CODEPLUG PARAMETERS

C. BCM CODEPLUG PARAMETERS

C.1 CODEPLUG PARAMETERS

Code plug parameters for Siemens Rail Automation BCM Firmware, Versions 4.01 through 4.05, are listed in Table C-1.

- For additional information regarding subsequent revisions to the firmware, contact Siemens Rail Automation Customer Service.

It is recommended that users only modify these parameters using the supplied utility program.

- However, if the parameters are manipulated directly, care should be taken that the wrong locations are not inadvertently modified.

NOTE

NOTE

- Time values are expressed in 10-millisecond increments.
 - For example, 15 seconds is expressed as 1500.
- Many values are bit-mapped.
 - Bit 0 is defined as the value 01, bit 01 as 02, bit 3 as 04, etc.
 - Actual value to be programmed is the sum of all required bits (e.g., if bits 1, 2, and 4 are set, the value is $(2+4+16) = \$16$ (22 decimal)).
- All values are in decimal, except where specifically indicated with the hexadecimal prefix (\$).
- NULL values are \$0.

Table C-1 BCM CPU II Code Plug Parameters

Location	Bytes	Description	Default Value
\$01	1	Manufacturer equipment code	\$01
\$02	1	ATCS equipment code	\$01
\$02 thru \$09	8	ATCS address of FPD. - The values are interpreted as 16 nibbles with the last nibble specifying the address length. - Used to set the FPD address when the attached equipment cannot provide the address via an XID process. Zero is coded as \$A. - Example: 7A.22.51.6A.28.A1.A1.0E	Null
\$0A thru \$11	8	ATCS address to which health and malfunction report messages should be sent. Example: 2A.22.A1.AA.AA.00.00.0A	Null

Location	Bytes	Description	Default Value
\$12	1	Local processing options bit map Bit 0 - Enable site code line application logic Bit 1 - Enable duplicate reject suppress facility Bit 2 - Enable site simulation Bit 3 - Enable site ladder logic Bit 6 - Enable AMCI Alert messages	Null
\$13	1	Maximum number of ground contact attempts per radio channel	6
\$14 thru \$17	4	Time between ground contact attempts	6000
\$18 thru \$1B	4	Layer 4 duplicate elimination timer value	1500 (15 sec.)
\$1C thru \$1F	4	Ground contact expiration timer value	Reserved
\$20 thru \$27	8	ATCS address for cluster controller time requests	Null
\$28	1	Out-of-coverage radio channel. • If this value is \$FF, no channel change is performed when entering out-of-coverage mode.	1
\$29 thru \$2A	1	Not used	Null
\$2B	1	Alarm enable bits Bit 0 - External alarm 5 Bit 1 - Port 0 contact failure Bit 2 - Port 1 contact failure Bit 3 - Port 2 contact failure Bit 4 - Port 0 hardware failure Bit 5 - Port 1 hardware failure Bit 6 - Port 2 hardware failure Bit 7 - Not used	Null
\$2C	1	Alarm enable bits Bit 0 - Mobile channel usage (COS too long) Bit 1 - Out of coverage (lost contact) Bit 2 - A/D failure Bit 3 - External alarm 0 Bit 4 - External alarm 1 Bit 5 - External alarm 2 Bit 6 - External alarm 3 Bit 7 - External alarm 4	Null
\$2D	1	Alarm enable bits Bit 0 - Radio failure Bit 1 - Radio bus failure Bit 2 - Radio power amplifier Bit 3 - Radio AC power failure Bit 4 - Code plug CRC failure Bit 5 - Carrier without data Bit 6 - Rf modulator failure Bit 7 - Ground contact failure	Null
\$2E thru \$3C	4	Not used	Null
\$3D	1	This parameter specifies the number of ground network messages that must be received within the period configured (see 'Regain contact window') for contact to be regained (\$44 thru \$47).	1

Location	Bytes	Description	Default Value
\$3E	1	Ground contact options Bit 0 - Enable ground contact procedure Bit 1 - Restrict channel cycle to default only Bit 2 - Enable passive contact if active contact fails Bit 3 - Send ground contact status to clients Bit 4 - Send ground contact status on mode change Bit 5 - Use time message exchange (Version 1 Spec.) Bit 6 - Always use code plug address for GC attempt	\$15
\$3F	1	Not used	Null
\$40 thru \$43	4	Rf poll expiration timer	\$1770 = 6000 (60 sec.)
\$44 thru \$47	4	Time within which ground contact messages are to be received (see \$3D)	\$1770 = 6000 (60 sec.)
\$48 thru \$4B	4	Not used	Null
\$4C thru \$4F	4	Channel 2 rf retry interval	\$190 = 400 (4 sec.)
\$50 thru \$53	4	Channel 4 rf retry interval	\$1EA = 490 (4.9 sec.)
\$54 thru \$57	4	Channel 6 rf retry interval	\$2F8 = 760 (7.6 sec.)
\$58 thru \$5B	4	Channel 8 rf retry interval	\$438 = 1080 (10.8 sec.)
\$5C thru \$5F	4	Channel 10 rf retry interval	\$5AA = 1450 (14.5 sec.)
\$60 thru \$63	4	Channel 12 rf retry interval	\$7D0 = 2000 (20.0 sec.)
\$64 thru \$67	4	Channel 14 rf retry interval	\$B54 = 2900 (29.0 sec.)
\$68 thru \$6B	4	Channel 16 rf retry interval	\$F3C = 3900 (39.0 sec.)
\$6C thru \$6F	4	Retry quantum time	\$5B = 91 (9.1 sec.)
\$70 thru \$73	4	Retry slope	\$1W = 30
\$74 thru \$77	4	Flow recovery time before starting recovery	\$1F4 = 500 (5 sec.)
\$78 thru \$7B	4	Flow recovery time limit	\$3E8 = 1000 (10 sec.)
\$7C thru \$7F	4	Beacon timer	\$FFFFFFFF

Location	Bytes	Description	Default Value
\$80 thru \$83	4	Cluster controller reset timer	\$3E8 = 1000 (10 sec.)
\$84 thru \$85	2	Number of fast beacons	5
\$86 thru \$87	2	Maximum number of beacon retries	6
\$88 thru \$8F	8	ATCS address to which beacons are to be sent. - The values are interpreted as 16 nibbles with the last nibble specifying the address length. - Zero is coded as \$A. - Unused bytes can be set to 0 (null). - Example: 2A.22.51.6A.28.00.00.0A	Null
\$90	1	Network layer options - Bit 0 - Enable NAK packets to ground network - Bit 1 - Enable service signals to ground network - Bit 2 - Enable emergency messages by channel group - Bit 3 - Enable lost contact when out of coverage - Bit 4 - Suppress layer 3 duplicate elimination - Bit 5 - Ignores COS test before transmit when set	Null
\$91	1	Broadcast Bit 0 - Enable wayside broadcast on zero address	Null
\$92	1	Wireline Bit 0 - Inhibits rf transmission of wayside wire line addresses	1
\$93	1	Emergency turnaround - Bit 0 - No turnaround - Bit 1 - Turnaround on trunk failure - Bit 2 - Always turnaround emergencies	1
\$94 thru \$97	4	Network address change time. If the BCM receives a local network address that is different from that of a client's current address (i.e. the BCM network address is redefined), this parameter determines the period before the BCM is reset.	\$5DC = 1500 (15 sec.)
\$98 thru \$A3	4	Not used	0
\$A4 thru \$A5	2	Number of null rf frames after each transmission. When set to \$FFFF, BCP is keyed continuously.	0
\$A6 thru \$A7	2	Maximum number of bits per non-emergency message. When set to \$FFFF, no limit applies.	\$12C0 = 4800
\$A8 thru \$A9	2	Maximum number of bits per emergency message	\$3840 = 14400
\$AA thru \$AD	4	Not used	0
\$AE thru \$B1	4	Minimum value for channel retry random access timer (channel idle)	\$82 = 130 (1.3 sec.)

Location	Bytes	Description	Default Value
\$B2 thru \$B5	4	Maximum value for channel retry random access timer (channel idle)	\$82 = 130 (1.3 sec.)
\$B6 thru \$B9	4	Minimum value for channel retry random access timer (channel receiving sync bits)	1 (0.01 sec.)
\$BA thru \$BD	4	Maximum value for channel retry random access timer (channel receiving sync bits)	\$50 = 80 (0.8 sec.)
\$BE thru \$C1	4	Minimum value for channel retry random access timer (channel receiving busy bits)	1 (0.01 sec.)
\$C2 thru \$C5	4	Maximum value for channel retry random access timer (channel receiving busy bits)	\$C8 = 200 (2.0 sec.)
\$C6 thru \$C9	4	Minimum value for channel retry random access timer (busy bit status not yet defined - less than 3 received)	1 (0.01 sec.)
\$CA thru \$CD	4	Maximum value for channel retry random access timer (busy bit status not yet defined)	\$50 = 80 (0.8 sec.)
\$CE thru \$D1	4	Maximum time before carrier-without-data alarm	\$FFFFFFFF
\$D2 thru \$D5	4	Mobile channel usage timer	\$FFFFFFFF
\$D6 thru \$D9	4	Out-of-coverage timer since last rf message	\$1770 = 6000 (60.0 sec.)
\$DA thru \$DD	4	Minimum channel idle time	\$4B = 75 (0.75 sec.)
\$DE thru \$E1	4	Maximum channel idle time	\$96 = 150 (1.5 sec.)
\$E2	1	Rf link options Bit 0 - Enable null rf link address for ground contact messages	1
\$E3 thru \$E5		Not used	0
\$E6 thru \$E9	4	Radio key-up time	4
\$EA thru \$ED	4	Radio dekey time	1
\$EE	1	Radio type 0 = None 1 = MCS 2000 2 = MSF 3 = MTR 2000	1
\$EF	1	Radio usage	5
\$F0	1	Minimum radio channel. Set to desired channel for single-channel operation or to lowest channel used in scanning.	1
\$F1	1	Maximum radio channel. Set to desired channel for single-channel operation or to highest channel used in scanning.	6
\$F2	1	Default (single-channel operation) or first (scanned operation) radio channel.	

Location	Bytes	Description	Default Value
\$F3 - \$F7	5	Remainder of radio channel scan sequence. - These parameters (including \$F2) determine the scan sequence of the ground contact process. - Location \$F2 is the channel on which the unit begins scanning. - The channels in the list must be in the range of valid channels. - If the complete list is not used, unused channels must be set to \$FF.	
\$F8	1	SSI enable. Negative value relating to BASE RSSI (dB). Normally set to -125 (\$7D)	0
\$F9	1	Minimum SSI	0
\$FA	1	SSI scaling multiplier.	0
\$FB	1	SSI scaling divisor.	0
\$FC	1	SSI simulation	0
\$FD - \$FE	1	Not used	
\$FF	1	RF transmit power. Reserved for future application. 0 = Low 1 = High 2 = Auto	
\$100 - \$103	4	Port 0 contact failure timer	6000
\$104 - \$105	2	Port 0 link (polling) address. Undefined when set to \$FFFF Start of polling range for certain emulations (WCP)	\$FFFF
\$106 thru \$107	2	Port 0 group link address	\$FFFF
\$108	1	Port 0 options Bit 0 - Inhibit XID exchange Bit 1 - Enable emergency bit in message Bit 2 - Enable time stamp Bit 3 - Enable ADM mode failure Bit 4 – Reset BCM on port contact alarm	0

Location	Bytes	Description	Default Value
\$10B	1	Port 0 mode 1 - HDLC ADM Mode 2 - HDLC ABM Mode 3 - HDLC Polled Mode 4 - HDLC UI Mode 6 - Null HDLC Mode 7 - Genisys Mode (Office) 8 - SCS-128 Local Control Panel (ECP) 9 - Not used \$A - MCS-1 Mode \$B - ASYNC port packetizer mode \$C - Spread-Spectrum Radio Protocol \$D - Not Used \$E - SCS128 Emulation \$F - Genisys mode (Field) \$10 - CN2000 A \$11 - CN2000 B \$12 - DHP \$13 - SLIP \$15 - CTK \$16 - Frame Relay \$17 - Genysis Offiice (B) \$18 - PPP \$19 - PPP Multicast \$1A - GPRS Backup \$1B - GPRS Continuous \$1C - ARES \$1D - GE Series 6	1
\$10C	1	Port 0 baud rate. Value = baud rate/300, e.g. 9600 baud = \$20	32
\$10D	1	Port 0 number of poll response information frames per poll	5
\$10E	1	Maximum poll address	0
\$10F	1	Alternate task number (special application)	\$FF
\$110 thru \$111	2	Other link address	\$FFFF
\$112 thru \$115	4	General purpose timer value. Used for either locomotive ID unit receive time-out or code line protocol poll timer. Recommended values: Port mode: Genisys, SCS-128, MCS-1 = \$000000A0 Lontalk® Mode = \$00000F00	
\$116 thru \$119	4	Port 1 contact failure timer	6000
\$11A thru \$11B	2	Port 0 baud rate. Value = baud rate/300, e.g. 9600 baud = \$20 Start of polling range for certain emulations (WCP)	\$FFFF
\$11C thru \$11D	2	Port 1 group link address	\$FFFF

Location	Bytes	Description	Default Value
\$11E	1	Port 1 options Bit 0 - Inhibit XID exchange Bit 1 - Enable emergency bit in message Bit 2 - Enable time stamp Bit 3 - Enable ADM mode failure Bit 4 - Reset BCM on port contact alarm	0
\$11F	1	Port 1 usage 5 - Ground equipment 6 - OBC equipment 18 - WIU equipment \$FF - Not used	18
\$120	1	Port 1 configuration Bit 0 - RTS/CTS handling required Bit 1 - RS232 / RS422 selection Bit 2 - RTS always asserted Bit 3 - Async port configuration Bit 4 - External modem equipped Bit 5 - Idle character enable Bit 6 - Locomotive ID unit equipped Bit 7 - External TXCLOCK port option	0
\$121	1	Port 1 mode \$1 - HDLC ADM Mode \$2 - HDLC ABM Mode \$3 - HDLC Polled Mode \$4 - HDLC UI Mode \$6 - Null HDLC Mode \$7 - Genisys Mode (Office) \$8 - SCS-128 Local Control Panel \$9 - Not used \$A - MCS-1 Mode \$B - ASYNC port packetizer mode \$C - Spread-Spectrum Radio Protocol \$D - Not used \$E - SCS128 Emulation \$F - Genisys mode (Field) \$10 - CN 2000 A \$11 - CN 2000 B \$12 - DHP \$13 - SLIP \$15 - CTK \$16 - Frame Relay \$17 - Genisys Office (B) \$18 - PPP \$19 - PPP Multicast \$1A - GPRS Backup \$1B - GPRS Continuous \$1C - ARES \$1D - GE Series 6	1
\$122	1	Port 1 baud rate. Value = baud rate/300, e.g. 9600 baud = \$20	32
\$123	1	Port 1 number of poll response information frames per poll	5

Location	Bytes	Description	Default Value
\$124	1	Maximum Poll Address	0
\$125	1	Alternate task number (special application)	\$FF
\$126 thru \$127	2	Other link address	\$FFFF
\$128 thru \$12B	4	General purpose timer value. Used for either locomotive ID unit receive time-out or code line protocol poll timer	\$FFFFFFFF
\$12C thru \$135	4	Not Used	
\$136	1	Lontalk (tm) configuration flag: 0 = not used; 1 = used	
\$137	1	DC configuration : 0 = None 1 = US&S 506 2 = US&S 514 3 = J Code 4 = K Code 5 = Alarm	
\$138 - \$13D	1	Not used	
\$13E thru \$141	4	General purpose timer value. Used for either locomotive ID unit receive time-out or code line protocol poll timer	\$FFFFFFFF
\$142 thru \$143	2	Internal entity link address	1
\$144 thru \$145	2	Link address for ground network	\$23
\$146 thru \$147	2	Link address for emergency transmission	\$25
\$148 thru \$149	2	Link address for transmission to rf user	\$27
\$14A thru \$14B	2	HDLC broadcast address	\$00FF
\$14C thru \$14D	2	HDLC control messages	\$00FF
\$14E thru \$155	8	Not used	\$0000
\$156 thru \$157	2	Rf idle frame address	\$0000
\$158 thru \$159	2	Rf link layer address for frames to locomotives	\$0001
\$15A thru \$15B	2	Rf link layer address for frames to non-locomotives	\$0004
\$15C thru \$15D	2	Rf link layer address for frames to wire line-connected waysides	\$0003
\$15E thru \$15F	2	Rf link layer address for frames to rf-connected wayside	\$0005
\$160 thru \$161	2	Rf link layer address for frames to ground network	\$0023
\$162 thru \$163	2	Rf link layer address for emergency frames to ground network	

Location	Bytes	Description	Default Value
\$164 thru \$165	2	Rf link layer address for frames to other rf users	\$0027
\$166 thru \$167	2	Rf link layer address for broadcast frames	\$00FF
\$168 thru \$174	4	Reserved for channel frequency configuration	
\$175	1	Not used	0
\$176	1	Asic - not used	
\$177	1	Asic configuration value	
\$178 thru \$17D	6	Asic frame sync pattern	\$90E0 \$2254 \$00F6
\$17F	1	Transmitter configuration analog loopback Bit 0 - Invert busy bit status Bit 1 - Hardware busy bit input Bit 2 - Enable analog loopback Bit 3 - Enable digital loopback Bit 4 - Invert transmit data Bit 5 - Invert receive data Bit 6 - Bit sync enable Bit 7 - N/A (always 0)	\$41
\$180	1	Transmitter configuration open loopback Bit 0 - Invert busy bit status Bit 1 - Hardware busy bit input Bit 2 - Enable analog loopback Bit 3 - Enable digital loopback Bit 4 - Invert transmit data Bit 5 - Invert receive data Bit 6 - Bit sync enable Bit 7 - N/A (always 0)	\$51
\$181 thru \$183	1	Not used	0
\$184 thru \$18D	2	Hardware initialization values (factory only)	
\$18E thru \$191	2	Alert initial delay time	\$FFFFFFFF
\$192 thru \$195		Alert response delay time	\$FFFFFFFF
\$196 thru \$197		Alert report rate	\$FFFF
\$198 thru \$199	2	Not used	\$FFFF
\$19A thru \$19D	2	Alert retry time	\$FFFFFFFF
\$19E thru \$1A1		Alert delivery delay time	\$FFFFFFFF
\$1A2 thru \$1A9		Alert report address	0,0,0,0,0,0, 0,0

Location	Bytes	Description	Default Value
\$1AA thru \$1AD		Not used	0
\$1B0	1	Enable version field. • This parameter determines if the version field is included in datagrams.	1
\$1B1	1	This parameter determines the format of the health and malfunction/self-test report messages. • The 89 spec. (0), 90 spec. (1) and latest spec. (3) versions are supported.	3
\$1B2	1	This parameter determines the format of the communications statistics message. • Versions 1 and 3 are supported.	3
\$1BE thru \$1BF	2	CRC of unprotected portion of code plug	\$DEAD
\$1C0 thru \$1C5	6	Encrypted password for protected portion of code plug	MCP
\$1C6 thru \$1D4	15	Serial number as 15 ASCII bytes	
\$1D5 thru \$1D7	3	Maintenance date. • Format: 3 unsigned bytes, DD/MM/YY	
\$1D8 thru \$1D9	2	Procuring railroad. • Format: Unsigned integer. • This parameter is used for the procuring railroad number for the Version 3 Health Report.	
\$1DA thru \$1DB	2	Not used	0
\$1DC thru \$1DD	2	ATCS hardware revision number. • Format: Unsigned integer. • This parameter is used for the ATCS hardware revision in the Version 3 Health Report.	
\$1DE thru \$1DF	2	ATCS software revision number. • Format: Unsigned integer • This parameter is used for the ATCS software revision in the Version 3 Health Report.	
\$1E0 thru \$1E1	2	Power-up count. • Format: Unsigned integer. • This parameter is used for recording the number of power-ups the unit has performed.	0
\$1E2 thru \$1E3	2	Rf modulator failure count. • Format: Unsigned integer. • This parameter is used for recording the number of modulator self-test failures.	0
\$1E4 thru \$1E5	2	Radio failure count. • Format: Unsigned integer. • This parameter is used for recording the number of radio self-test failures.	0
\$1E6 thru \$1E7	2	A/D converter failure count. • Format: Unsigned integer. • This parameter is used for recording the number of A/D self-test failures.	0

Location	Bytes	Description	Default Value
\$1E8 thru \$1E9	2	Client port 0 failure count. - Format: Unsigned integer. - This parameter is used for recording the number of client port self-test failures.	0
\$1EA thru \$1EB	2	Client port 1 failure count. - Format: Unsigned integer. - This parameter is used for recording the number of client port self-test failures.	0
\$1EC thru \$1ED	2	Client port 2 failure count. - Format: Unsigned integer. - This parameter is used for recording the number of client port self-test failures.	0
\$1EE thru \$1F5	8	Manufacturer hardware revision number. Format: 8 bytes, ASCII. This parameter is used for the manufacturer hardware revision in the Version 3 Health Report.	
\$1F6 thru \$1FD	4	Not used	0
\$1FE thru \$1FF	2	Restricted code plug CRC for restricted code plug area. Format: Unsigned integer.	\$DEAD

C.2 Transmitter Configuration Codeplug Parameter Descriptions

These paragraphs detail the bit state combinations that may be assigned to the transmitter configuration code-plug, position \$180, for the following systems:

- Siemens Rail Automation A53410 Base Communications Package (MTR3000)
- Siemens Rail Automation A53411 Wayside Communications Package (MDS)
- Motorola Spectra Mobile Communications Package

Within an ATCS network, the transmitter configuration codeplug parameters of the associated communications packages (figure A-1) must be compatible to ensure proper communications.

- The compatible inversion states for the Siemens Rail Automation BCP, the Siemens Rail Automation WCP and/or the Motorola MCP are summarized in Table C-2.
- The corresponding codeplug values for each inversion state are also included.

Table C-2 System Configuration Compatibility Summary

Siemens BCP		Siemens WCP		Motorola MCP	
MTR3000 Inversion	MTR3000 Loc. \$180 Codeplug Value	MDS Inversion	MDS Loc. \$180 Codeplug Value Loc. \$180	Spectra MCP Inversion	Spectra MCP Loc. \$180 Codeplug Value Loc. \$180
Rx = No Tx = No	41	TX = Yes Rx = Yes	71	TX = Yes Rx = Yes	71
Rx = Yes Tx = Yes	71	TX = No Rx = No	41	TX = No Rx = No	41
Rx = No Tx = Yes	51	TX = Yes Rx = No	51	TX = Yes Rx = No	51
Rx = Yes Tx = No	61	TX = No Rx = Yes	61	TX = No Rx = Yes	61

C.2.1 Codeplug Position \$180 Transmit/Receive Configuration

The bit assignments for position \$180 are as follows:

Bit Position	Function Assignment	Hexadecimal Position Assignment
0	Invert Busy Bit Status	16 ⁰
1	Hardware Busy Bit Input	
2	Enable Analog Loopback	
3	Enable Digital Loopback	
4	Invert Transmit Data	16 ¹
5	Invert Receive Data	
6	Bit Sync Enable	
7	No Function Assignment (always 0)	

NOTE**NOTE**

Bit state values assign options to single bits, where: 1= Yes, 0 = No.

The bit states for position \$180 are as follows:

\$51 (default) TX= YES RX = NO

Bit Position	Function Assignment	Bit State	Hexadecimal Value
0	Invert Busy Bit Status	1	1
1	Hardware Busy Bit Input	0	
2	Enable Analog Loopback	0	
3	Enable Digital Loopback	0	
4	Invert Transmit Data	1	50
5	Invert Receive Data	0	
6	Bit Sync Enable	1	
7	Bit 7	0	

\$41 TX= NO RX = NO

Bit Position	Function Assignment	Bit State	Hexadecimal Value
0	Invert Busy Bit Status	1	1
1	Hardware Busy Bit Input	0	
2	Enable Analog Loopback	0	
3	Enable Digital Loopback	0	
4	Invert Transmit Data	0	40
5	Invert Receive Data	0	
6	Bit Sync Enable	1	
7	Bit 7	0	

\$61 TX= NO RX = YES

Bit Position	Function Assignment	Bit State	Hexadecimal Value
0	Invert Busy Bit Status	1	1
1	Hardware Busy Bit Input	0	
2	Enable Analog Loopback	0	
3	Enable Digital Loopback	0	
4	Invert Transmit Data	0	60
5	Invert Receive Data	1	
6	Bit Sync Enable	1	
7	Bit 7	0	

\$71 TX= YES RX = YES

Bit Position	Function Assignment	Bit State	Hexadecimal Value
0	Invert Busy Bit Status	1	1
1	Hardware Busy Bit Input	0	
2	Enable Analog Loopback	0	
3	Enable Digital Loopback	0	
4	Invert Transmit Data	1	70
5	Invert Receive Data	1	
6	Bit Sync Enable	1	
7	Bit 7	0	

C.3 PHD2000 BCP Transmitter Config Codeplug Parameter Descriptions

The Motorola Phd2000 BCP codeplug is slightly different from the Siemens MCP codeplug.

- The Phd2000 BCP codeplug utilizes a separate address location for setting the inversion bits of its transmitter and receiver.
- In addition to setting the proper inversion bits it is necessary to change the settings of the Transmitter Configuration Analog Loopback and Digital Loopback Tests.
- Failure to set these parameters correctly will cause the Modulator self test to fail.

Within an ATCS network, the transmitter configuration codeplug parameters of the associated communications packages communications (Figure A-1) must be compatible to ensure proper communications.

- The compatible inversion states for the PHD2000 BCP, the Siemens WCP and/or the Motorola MCP are summarized in Table C-3.
- The corresponding codeplug values for each inversion state are also included.

Table C-3 Motorola PHD2000 BCP Codeplug Configuration Summary

Motorola Phd2000 BCP		Safetran WCP		Motorola MCP	
MSF5000 Inversion	MSF5000 Loc. \$178 (TX) Loc. \$183 (RX) Codeplug Values	MCS2000MDS Inversion	MCS2000MDS Loc. \$180 Codeplug Value	Spectra MCP Inversion	Spectra MCP Loc. \$180 Codeplug Value
Rx = No Tx = No	\$178 = 05 \$181 = 13 \$182 = 0B \$183 = 03	TX = Yes Rx = Yes	71	TX = Yes Rx = Yes	71
Rx = Yes Tx = Yes	\$178 = 0D \$181 = 15 \$182 = 0D \$183 = 07	TX = No Rx = No	41	TX = No Rx = No	41
Rx = No Tx = Yes	\$178 = 05 \$181 = 13 \$182 = 0B \$183 = 07	TX = Yes Rx = No	51	TX = Yes Rx = No	51
Rx = Yes Tx = No	\$178 = 0D \$181 = 15 \$182 = 0D \$183 = 03	TX = No Rx = Yes	61	TX = No Rx = Yes	61

C.3.1 Codeplug Position \$178 Receiver Configuration

The bit assignments for position \$178 are as follows:

Bit Position	Function Assignment	Hexadecimal Position Assignment
0	Number of frame sync mismatches	16 ⁰
1	Number of frame sync mismatches	
2	Number of frame sync mismatches	
3	Invert RX data	

NOTE

NOTE

Bit state values assign options to single bits, where: 1= Yes, 0 = No.

The bit states for position \$178 are as follows:

\$05

RX = NO

Bit Position	Function Assignment	Bit State	Hexadecimal Value
0	Number of frame sync mismatches	1	5
1	Number of frame sync mismatches	0	
2	Number of frame sync mismatches	1	
3	Invert RX data	0	

\$0D

RX = YES

Bit Position	Function Assignment	Bit State	Hexadecimal Value
0	Number of frame sync mismatches	1	D
1	Number of frame sync mismatches	0	
2	Number of frame sync mismatches	1	
3	Invert RX data	1	

C.3.2 Codeplug Position \$181 Transmitter Configuration Digital Loopback

The bit assignments for position \$181 are as follows:

Bit Position	Function Assignment	Hexadecimal Position Assignment
0	Invert Busy Bit	16 ⁰
1	Hardware Busy Bi	
2	Invert Transmitted Data	
3	Enable Analog Loopback	
4	Enable Digital Loopback	16 ¹
5	No Function Assignment (always 0)	
6	No Function Assignment (always 0)	
7	No Function Assignment (always 0)	

NOTE**NOTE**

Bit state values assign options to single bits, where: 1= Yes, 0 = No.

The bit states for position \$181 are as follows:

\$13		INVERT TX= NO	
Bit Position	Function Assignment	Bit State	Hexadecimal Bit Value
0	Invert Busy Bit	1	3
1	Hardware Busy Bit	1	
2	Invert Transmitted Data	0	
3	Enable Analog Loopback	0	
4	Enable Digital Loopback	1	10
5	Bit 5	0	
6	Bit 6	0	
7	Bit 7	0	

\$15		INVERT TX = YES	
Bit Position	Function Assignment	Bit State	Hexadecimal Bit Value
0	Invert Busy Bit	1	5
1	Hardware Busy Bit	0	
2	Invert Transmitted Data	1	
3	Enable Analog Loopback	0	
4	Enable Digital Loopback	1	10
5	Bit 5	0	
6	Bit 6	0	
7	Bit 7	0	

C.3.3 Codeplug Position \$182 Transmitter Configuration Analog Loopback

The bit assignments for position \$182 are as follows:

Bit Position	Function Assignment	Hexadecimal Position Assignment
0	Invert Busy Bit	16 ⁰
1	Hardware Busy Bit	
2	Invert Transmitted Data	
3	Enable Analog Loopback	

NOTE**NOTE**

Bit state values assign options to single bits, where: 1= Yes, 0 = No.

The bit states for position \$182 are as follows:

\$0B		INVERT TX= NO	
Bit Position	Function Assignment	Bit State	Hexadecimal Bit Value
0	Invert Busy Bit	1	B
1	Hardware Busy Bit	1	
2	Invert Transmitted Data	0	
3	Enable Analog Loopback	1	

\$0D		INVERT TX = YES	
Bit Position	Function Assignment	Bit State	Hexadecimal Bit Value
0	Invert Busy Bit	1	D
1	Hardware Busy Bit	0	
2	Invert Transmitted Data	1	
3	Enable Analog Loopback	1	

C.3.4 Codeplug Position \$183 Transmitter Configuration Normal (OPEN)

The bit assignments for position \$183 are as follows:

Bit Position	Function Assignment	Hexadecimal Position Assignment
0	Invert Busy Bit	16 ⁰
1	Hardware Busy Bit	
2	Invert Transmitted Data	
3	Enable Analog Loopback	

NOTE

NOTE

Bit state values assign options to single bits, where: 1= Yes, 0 = No.

The bit states for position \$183 are as follows:

\$0B		TX= NO	
Bit Position	Function Assignment	Bit State	Hexadecimal Bit Value
0	Invert Busy Bit	1	3
1	Hardware Busy Bit	1	
2	Invert Transmitted Data	0	
3	Enable Analog Loopback	0	

\$0D		TX = YES	
Bit Position	Function Assignment	Bit State	Hexadecimal Bit Value
0	Invert Busy Bit	1	7
1	Hardware Busy Bit	1	
2	Invert Transmitted Data	1	
3	Enable Analog Loopback	0	

APPENDIX D

GENERIC GROUNDING PROCEDURES

D. GENERIC GROUNDING PROCEDURES

D.1 GENERAL

With all R-Link radio applications care should be taken to prevent ground differentials between the grounding points that can cause equipment damage. Perform the following recommendations when grounding equipment and enclosures.

D.2 EXTERNAL BUILDING GROUND

(Figure D-1) Grounding electrodes should be a minimum of 8 feet in length and located approximately 2 feet away from each corner of the building with the top of each element at least 6 inches below grade. Spacing between electrodes should not exceed 15 feet. The ground elements should be bonded together with a ring of #2 AWG solid copper wire. All below grade connections shall be Cadwelded.

The following items should be connected to the ground ring using a #2 AWG solid copper conductor:

- All hydro ground elements within 6 feet of the ground ring
- All metal objects within 50 feet of the building (e.g., fuel storage tanks)
- Air gap surge protectors on the common ground side of the arrestors (as direct as possible through the floor)
- A conductor from each ground electrode to the closest corner of the building, passed up through the floor and up the inside wall to connect with an internal ground ring located 6 inches from the inside ceiling





Figure D-1 Typical Ground Connections

D.3 INTERNAL BUILDING GROUND

The internal ground ring should be #2 AWG copper, and may be stranded. The following items should be connected to the internal ground ring using a minimum #6 AWG stranded copper conductor:

- All relay racks
- AC panels
- Battery system surge protectors
- Building doors
- Cable trays

NOTE

NOTE

Bonding conductor connections to the ground ring should be made using split brass bolts (see Figure D-4).




Figure D-2 Typical Internal Building Ground

D.4 ANTENNA GROUND

A good RF ground will determine the quality of a radio antenna system. Poor grounds result in antennas not operating efficiently. It is possible to burn up between 50 and 90 percent of the RF power heating the ground losses under the antenna instead of propagating into the air. Ground resistances can vary from very low values of 5 ohms to more than 100 ohms. RF power is dissipated in the ground resistance. The following factors that affect ground resistance are:

- The conductivity of the soil
- The composition of the soil
- The water content of the soil

Note that the ideal ground depth depends on the level of the local water table; it is rarely at ground level and can be several feet below grade.

D.4.1 Antenna Ground – Roof-Mount Yagi

Roof-mounted Yagi antennae should have the pipe mast grounded to the outside grounding ring with a minimum #2 AWG solid copper conductor. The Heliac ground kit should be connected within 1 foot of the cable entry to the building and connected to the copper conductor. A lightning surge protector is not required if the Yagi antenna is less than 10 feet above the building roof. The inside terminating connector on the antenna Heliac should be bonded to the internal ground ring.

D.4.2 Antenna Ground – Towers and Poles

As with all elevated metal objects, antennas will attract lightning strikes. This necessitates the need for an adequate and effective ground to minimize electrical noise and interference. (Figure D-3) On tower and pole equipped sites, the antenna must be well grounded by means of a #2 AWG solid copper conductor connection from the ground ring to the tower or pole grounding element(s). The tower ground system must have 5 ohms or less earth resistance. The antenna cable should be grounded to the tower/pole-grounding conductor where the cable bends and leaves the tower/pole towards the building.

The messenger wire for the cable should be bonded to the tower/pole ground and the external building ground ring. The antenna cable should be grounded outside the building, within 1 foot of the building entry, to the external building ground ring via a #2 AWG solid conductor. A lightning arrestor should be installed on the Heliac cable within 1 foot of the building entrance, and bonded to the internal ground ring.

Surge arrestors or a lightning protector should be installed at the point where the antenna cable enters the building or cabinet. The lightning protector should be properly grounded at the single-point chassis ground. Connectors must be weatherproofed to prevent corrosion to enable efficient grounding.





Figure D-3 Typical Tower and Pole Ground Connections




Figure D-4 Typical Connections for Grounding and Bonding

D.5 AC POWER GROUND

AC power grounding should be to the standards set forth by the applicable local or regional electrical code. When bonding AC panels to the internal ground ring, the connection should be made to the outside surface of the panel. Hydro ground electrodes should be bonded to the building ground electrodes only if they are within 6 feet of each other. A surge protector should be installed on the main electrical panel for any ungrounded electrical feed in or out of the building, and the connection to all air gap suppressors removed.

D.6 COMMUNICATIONS GROUND

All power and telephone company grounds should be made common to the communications ground. A surge arrester such as a Polyphaser™ should be installed at the point where the cable enters the building.

D.7 CABLING

Cabling shall be installed to minimize inductive coupling that would otherwise allow surge energy to bypass the protective and isolating elements in the system. The input/output conductors entering the building shall follow a path as short as possible to the air gap surge protectors. These conductors shall not be within 3 inches of other conductors including the signal wires from the surge protectors to the relay racks. The signal wires from the surge protectors to the relay rack shall be dressed together and separated from power and other signal wires by 3 inches. The signal wires between the relay isolation and the Safetran equipment shall be dressed together and separated from power or other signal wires by 3 inches. Where physical separation is not possible, the wires should be run at right angles to each other.

D.8 SURGE PROTECTION

Surge protection should be provided on battery/charger systems to prevent the system from rising to dangerous voltages with reference to building ground. The protectors should be installed in series with a circuit breaker so if they fail in the short mode the circuit breaker will open and the system will remain isolated from ground.

This Page Intentionally Left Blank

INDEX

—A—

Advanced Trains Control System data
network, 2-1
Alphanumeric Display, 4-6
Alphanumeric Display acronyms, 4-6
application task, 4-3
ATCS destination address, 2-2
ATCS messages, 2-1
ATCS RF Message Reception, 2-2
ATCS rf network, 2-1

—B—

Base Communications Package II (BCP
II) Radio System, 1-1
Base Control Module, 1-1
Base Control Module, 3-1
BCM Configuration program, 4-11
BCM EXTERNAL CONNECTORS, 3-2
BCM, 1-1, 3-1, 3-2, 3-4
Boot Code, 4-2

—C—

Channel field, 4-26
Cluster Controller, 2-1
code plug, 4-2
Codeplug configuration, 4-17
Codeplug File, 4-17
Command List, 4-21
Communication Links, 2-2
Control Delivery field, 4-34

—D—

Date and Time function, 4-10
DC Codeline Configuration Screen
Pulldown Menus, 4-43
DC1 and DC2 Port Baud field, 4-40
debugger, 4-2
Diagnostics function display, 4-10
Duplexer, 2-2

—E—

Echelon® LonTalk® Local Area
Network,
2-1
Edit function, 4-19
Enable Code App field, 4-28
Enable Ladder Logic field, 4-30
Enable Simulation field, 4-29
event log, 5-2
executive program, 4-3, 4-43
External Frequency Reference, 2-2

—F—

FEPCC Addr field, 4-28
field-programmable data, 4-2
field port selection ranges, 4-40
File Menu, 4-17
flash EEPROM memory, 4-1
flash EEPROM, 4-2
front panel configuration, 4-3

—G—

Gaussian Mask Shift Key Modem, 2-2

—H—

Help window, 4-24

—I—

Indication Holdoff field, 4-35
Install drop-down menu, 4-35
Invert fields, 4-26

—K—

Kindis field, 4-33

INDEX

—L—

ladder logic, 4-3
LAN Controller, 2-2
Local Addr field, 4-27
log capture, 5-3
Log Event Display, 5-2
Logic File field, 4-30
Lon Port field, 4-40
LonTalk® Network Configuration, 4-31

—M—

Main Editor Screen, 4-17
Menu Bar, 4-17
Motorola Base Station, 1-1
Motorola External Frequency
 Reference, 1-1
MTR3000, 3-1

—N—

non-volatile RAM, 5-2

—O—

on-line debugging terminal, 5-1
Online drop-down menu, 4-19

—P—

Port DC function display, 4-9
Port J1 function display, 4-7
Port J2 function display, 4-9
Power field, 4-26

—R—

Radio gain, 4-27
Readback field, 4-34
Reset function display, 4-11
RF Duplexer, 1-1
RF Edit function display, 4-7
RSSI scaling and base values, 4-28

—S—

Self test, 5-1
Site Edit function display, 4-6
subfunctions, 4-5

—T—

Transceiver/Processor, 2-2
Type and Usage fields, 4-25

—U—

Usage field, 4-26

—X—

XCMMaint configuration/online utility,
4-1