

# **INSTRUCTION & INSTALLATION**

MICROPROCESSOR BASED SIMPLE GRADE CROSSING PREDICTOR 4000 / MOTION SENSOR 4000 (SGCP 4000/MS 4000), P/N A80490 & P/N A80495

**DECEMBER 2011, REVISED JANUARY 2021, APRIL 2021, & MARCH 2022** 

DOCUMENT NO. SIG-00-11-02 VERSION A.8

Siemens Mobility, Inc. One Penn Plaza Suite 1100 New York, NY 10119-1101 1-800-793-SAFE

Copyright © 2022 Siemens Mobility, Inc. All rights reserved

#### PROPRIETARY INFORMATION

Siemens Mobility, Inc., (Siemens) has a proprietary interest in the information contained herein and, in some instances, has patent rights in the systems and components described. It is requested that you distribute this information only to those responsible people within your organization who have an official interest.

This document, or the information disclosed herein, shall not be reproduced or transferred to other documents or used or disclosed for manufacturing or for any other purpose except as specifically authorized in writing by Siemens.

#### **TRANSLATIONS**

The manuals and product information of Siemens are intended to be produced and read in English. Any translation of the manuals and product information are unofficial and can be imprecise and inaccurate in whole or in part. Siemens does not warrant the accuracy, reliability, or timeliness of any information contained in any translation of manual or product information from its original official released version in English and shall not be liable for any losses caused by such reliance on the accuracy, reliability, or timeliness of such information. Any person or entity who relies on translated information does so at his or her own risk.

## WARRANTY INFORMATION

Siemens Mobility, Inc., warranty policy is as stated in the current Terms and Conditions of Sale document. Warranty adjustments will not be allowed for products or components which have been subjected to abuse, alteration, improper handling or installation, or which have not been operated in accordance with Seller's instructions. Alteration or removal of any serial number or identification mark voids the warranty.

#### SALES AND SERVICE LOCATIONS

Technical assistance and sales information on Siemens Mobility, Inc., products may be obtained at the following locations:

Siemens Mobility, Inc.

2400 NELSON MILLER PARKWAY

LOUISVILLE, KENTUCKY 40223

Siemens Mobility, Inc.

939 S. MAIN STREET

MARION, KENTUCKY 42064

TELEPHONE: (502) 618-8800 **TELEPHONE:** (270) 918-7800 (502) 618-8810 CUSTOMER SERVICE: FAX: (800) 626-2710 SALES & SERVICE: (800) 626-2710 TECHNICAL SUPPORT: (800) 793-7233 WEB SITE: https://www.mobility.siemens.com/ FAX: (270) 918-7830

## **FCC RULES COMPLIANCE**

The equipment covered in this manual has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

i

SIG-00-11-02 Version No.: A.8

# **DOCUMENT HISTORY**

Version	Release Date	Sections Changed	Details of Change
1	01/15/11		Initial draft
Α	12/02/2011		Initial Release per inspection MS4-F28
A.1	06/11//2014	All	Rebrand for Siemens and reformat
A.2	07/20/2015	All	Product renamed per PLM email 06/23/15 0831
A.3	02/09/2016	Sec 7	Add Section 7.3.9 Island Test for EZ and Z Levels
A.4	04/24/2020	All	Added information for using MS4000 with CPU III, added Low EX Safety Checkout procedure, updated 7.3.9 to differentiate bypass procedure, added GXMT error to section 8 Troubleshooting.
A.5	08/20/2020		Added Flashing info in Table 6-6 and Table 6-7
A.5.1	10/20/2020	All	Updated formatting
A.6	1/8/2021	All	Minor changes from inspection ng5–f217
A.7	4/28/2021	Sec 8	Added text in section 8.2
A.8	03/10/2022	Sec 7	Note on page 7-3 has been edited to remove incorrect statement relating to reprogramming.  Table 7-3 on page 7-4 has been updated to show accurate information for recalibration.  Tables 7-2 and 7-4 have been updated for consistency.

SIG-00-11-02 Version No.: A8

# **NOTES, CAUTIONS, AND WARNINGS**

Throughout this manual, notes, cautions, and warnings are frequently used to direct the reader's attention to specific information. Use of the three terms is defined as follows:

# **A** WARNING

## WARNING

INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY. WARNINGS ALWAYS TAKE PRECEDENCE OVER NOTES, CAUTIONS, AND ALL OTHER INFORMATION.

# **A** CAUTION

## CAUTION

REFERS TO PROPER PROCEDURES OR PRACTICES WHICH IF NOT STRICTLY OBSERVED, COULD RESULT IN A POTENTIALLY HAZARDOUS SITUATION AND/OR POSSIBLE DAMAGE TO EQUIPMENT. CAUTIONS TAKE PRECEDENCE OVER NOTES AND ALL OTHER INFORMATION, EXCEPT WARNINGS.

# NOTE

#### NOTE

Generally used to highlight certain information relating to the topic under discussion.

If there are any questions, contact Siemens Mobility Inc., Application Engineering.

## **ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS**

Static electricity can damage electronic circuitry, particularly low voltage components such as the integrated circuits commonly used throughout the electronics industry. Therefore, procedures have been adopted industry-wide which make it possible to avoid the sometimes invisible damage caused by electrostatic discharge (ESD) during the handling, shipping, and storage of electronic modules and components. Siemens Mobility, Inc. has instituted these practices at its manufacturing facility and encourages its customers to adopt them as well to lessen the likelihood of equipment damage in the field due to ESD. Some of the basic protective practices include the following:

- Ground yourself before touching card cages, assemblies, modules, or components.
- Remove power from card cages and assemblies before removing or installing modules.
- Remove circuit boards (modules) from card cages by the ejector lever only. If an ejector lever is not provided, grasp the edge of the circuit board but avoid touching circuit traces or components.
- Handle circuit boards by the edges only.
- Never physically touch circuit board or connector contact fingers or allow these fingers to come in contact with an insulator (e.g., plastic, rubber, etc.).
- When not in use, place circuit boards in approved static-shielding bags, contact fingers first.
   Remove circuit boards from static-shielding bags by grasping the ejector lever or the edge of the board only. Each bag should include a caution label on the outside indicating static-sensitive contents.
- Cover workbench surfaces used for repair of electronic equipment with static dissipative workbench matting.
- Use integrated circuit extractor/inserter tools designed to remove and install electrostaticsensitive integrated circuit devices such as PROM's (OK Industries, Inc., Model EX-2 Extractor and Model MOS-40 Inserter (or equivalent) are highly recommended).
- Utilize only anti-static cushioning material in equipment shipping and storage containers.

For information concerning ESD material applications, please contact the Technical Support Staff at 1-800-793-7233. ESD Awareness Classes and additional ESD product information are also available through the Technical Support Staff.

İ۷

# **Table Of Contents**

SECTI	ION 1 - MOTION SENSOR 4000 (SGCP 4000/MS 4000) OVERVIEW	1-1
1.1	INTRODUCTION	1-1
1.2	DESCRIPTION	1-1
1.3	MOTION SENSOR OPERATIONAL PARAMETERS	1-3
1.4	TRAIN DETECTION	1-3
	1.4.1 Track Ballast Condition	
	1.4.2 Track Ballast Changes	1-4
	1.4.3 SGCP 4000/MS 4000 Signal Frequencies	1-4
1.5	SYSTEM SPECIFICATIONS	1-4
	1.5.1 Track Card Compatibility	1-6
SECTI	ION 2 - GENERAL SGCP 4000/MS 4000 APPLICATION INFORMATION	2-1
2.1	SGCP 4000/MS 4000 TRACK SIGNALS	2-1
	2.1.1 Frequency Selection	2-1
	2.1.2 SGCP 4000/MS 4000 Frequency Range	2-1
	2.1.3 SGCP 4000/MS 4000 Signal Attenuation	
2.2	SGCP 4000/MS 4000 APPROACH FREQUENCIES	
2.3	SGCP 4000/MS 4000 FREQUENCY VERSES OPERATING DISTANCE	2-1
2.4	TRACK CIRCUIT OPERATING FREQUENCY RESTRICTIONS	
	2.4.1 Relay Coded DC Track Circuits	
	2.4.2 Electronic Coded DC Track Circuits	
	2.4.3 100 Hz Non-Coded Cab Signal Circuits	
	2.4.4 60 Hz AC Coded Track or Coded Cab Signal Circuits	
	2.4.5 100 Hz AC Coded Track or Coded Cab Signal Circuits	
2.5	TRACK CIRCUIT FREQUENCY SELECTION	
	2.5.1 Frequency Selection Restrictions	
2.6	SGCP 4000/MS 4000 APPROACH DISTANCE CALCULATIONS	
	2.6.1 Approach Distance Calculations	
	2.6.2 Approach Distance Calculation Example	2-7
2.7	USING NARROW-BAND SHUNTS AND OVERLAPPING APPROACHES	
	2.7.1 Using Narrow-Band Termination Shunts	
	2.7.2 Types of Narrow-Band Shunts	
	2.7.3 62775 Single Frequency Narrow-Band Shunt	
	2.7.4 62775 Multi-frequency Narrow-Band Shunt	
	2.7.5 62780-f Narrow-band Shunt	2-9
	2.7.6 Adjacent Frequency Use in Overlapping Bidirectional or Directionally	
	wired Approaches	
	2.7.7 Adjacent Frequency Narrow-Band Shunt Distance Example	
	2.7.8 Adjacent Frequency Use with Unidirectional Applications	
2.8	REPEATING SGCP 4000/MS 4000 OPERATING FREQUENCIES	
	2.8.1 Insulated Joints Requirements	
2.9	TERMINATION SHUNTS	
	2.9.1 Hard-Wire Shunt	
	2.9.2 Wideband Shunt	
	2.9.3 Narrow-Band Shunts	
	2.9.4 62775 Single-Frequency Narrow-Band Shunt	
	2.9.5 62775 Multi-frequency Narrow-Band Shunt	
	2.9.6 62780-f Narrow-Band Shunt	2-19

	2.9.7 62780 Multi-frequency Narrow-Band Shunt	
0.40	2.9.8 Termination Shunt Installation	
2.10	COUPLING AROUND INSULATED JOINTS	
	2.10.1 Bypassing Insulated Joints Using Wideband Shunt	
	2.10.2 Tunable Insulated Joint Bypass Coupler	2-21
2.11	INSTALLING BYPASS SHUNTS AND COUPLERS	
2.12	ISLAND CIRCUITS	
	2.12.1 Island Circuit Approach Length	2-23
	2.12.2 Track Circuit Compatibility	
	2.12.3 Island Frequencies	
	2.12.4 Island Shunting Sensitivity	
	2.12.5 Island Circuit Wiring	
2.13	TRACK CONNECTIONS	
	2.13.1 Four-Wire Connections For Bidirectional Applications	2-26
	2.13.2 Four Track Wire Unidirectional and Directionally Wired Applications Rail	
	Connections	2-27
	2.13.3 Track Lead Routing	2-27
	2.13.4 Track Lead Length	2-27
	2.13.5 Six-Wire Connections	2-27
	2.13.6 Six-Wire Transmitter and Check Receiver Track Connection Requirement	s2-27
	2.13.7 Sharing Track Wires with External Track Circuit Equipment	2-29
	2.13.8 Six-Wire Connections	
	2.13.9 Four-Wire Connections	2-29
2.14	TRACK CIRCUIT ISOLATION DEVICES	
	2.14.1 Steady Energy DC Track Circuits	2-32
	2.14.2 Battery Chokes	
	2.14.3 Siemens GEO Coded DC Track Circuit	
	2.14.4 Electronic Coded DC Track Circuit	2-34
	2.14.5 Relay Coded DC Track Circuit	
	2.14.6 Single (Fixed) Polarity Systems	
	2.14.7 GRS Trakode (Dual Polarity) Systems:	
	2.14.8 Dual Polarity (Polar) Coded Track Systems Other Than GRS Trakode	
	2.14.9 AC Code Isolation Units	
	2.14.10 CAB Signal AC:	
2.15	APPROACH CONFIGURATIONS	
2.10	2.15.1 Bidirectional Configuration	
	2.15.2 Bidirectional Approach Length Balancing	
	2.15.3 Simulated Track	
	2.15.4 Unidirectional Installations	
	2.15.5 Directionally Wired Installations	
	2.15.6 Simulated Approach	
	2.15.7 Six-Wire Directionally wired Applications Connections	
2.16	SURGE PROTECTION	
2.10	2.16.1 Primary Surge Protection for Track and I/O Wiring Between Bungalows	
	2.16.2 Battery Surge Protection and Power Wiring	
2.17	TYPICAL APPLICATION DRAWINGS	
SECT	ION 3 - SGCP 4000/MS 4000 SYSTEM PROGRAMMING	
3.1	GENERAL	
3.2	PUSH BUTTON MENU SYSTEM OVERVIEW	3-1
	3.2.1 Controls and Indicators Used in Push-Button Manu Navigation on CPU	3-1
	3.2.1.1 Four Character Alphanumeric Display	3-1

		3.2.1.2 SEL Button	-
		3.2.1.3 NAV Button	
	3.2.2	SGCP 4000/MS 4000 CPU Push-Button Main Menu	
	3.2.3	Navigating the Menus	3-2
	3.2.4	Program Menu Processes	3-3
	3.2.5	Calibration Menu Process	3-3
	3.2.6	Out of Service (OOS) Menu Processes	3-3
3.3	WEBU	I SYSTEM OVERVIEW	3-4
	3.3.1	Local User Presence	3-5
	3.3.2	System View	3-7
		3.3.2.1 Track Menu: Detail View	3-8
		3.3.2.2 Track Menu: Diagnostics	3-10
		3.3.2.3 Track Menu: Calibration	
		3.3.2.4 Track Menu: Remote Setup	3-11
		3.3.2.5 Track Menu: Out of Service	
		3.3.2.6 Check Numbers	
	3.3.3	Configuration Menu	
		3.3.3.1 Template Programming	
		3.3.3.2 MS4000 Configuration	
		3.3.3.3 CP Programming	
	3.3.4	Calibration and Adjustment	
	3.3.5	Status Monitor	
	3.3.6	Reports and Log	
	3.3.7	Software Updates	
	0.0	3.3.7.1 CP MEF	
		3.3.7.2 VLP Software Update Menu	
	3.3.8	Diagnostics	
3.4		4000/MS 4000 PUSH-BUTTON MAIN MENUS	3-21
	3.4.1	SGCP 4000/MS 4000 Program Menu Parameter Definitions and Values	
	• • • • • • • • • • • • • • • • • • • •	3.4.1.1 Approach Frequency (AFRQ)	
		3.4.1.2 Approach Directionality (DIRN)	
		3.4.1.3 Transmit Level (TLVL)	
		3.4.1.4 Approach Pickup Delay (APKU)	
		3.4.1.5 Upstream Adjacent Crossing Used (UAX)	
		3.4.1.6 Island Used (ISL)	
		3.4.1.7 Island Pickup Delay (IPKU)	
		3.4.1.8 Input 1 (IN1)	
		3.4.1.9 Input 2 (IN2)	
		3.4.1.10 Advanced Menu Settings (ADVD)	3-24
		3.4.1.11 Positive Start Level (PSTR)	3-24
		3.4.1.12 Positive Start Timer (PTIM)	
		3.4.1.13 Sudden Shunt Detection (SHNT)	
		3.4.1.14 Low EZ Detection Used (LWEZ)	
		3.4.1.15 Low EX Adjustment Level (LWEX)	
		3.4.1.16 Compensation Level (COMP)	
		3.4.1.17 SGCP 4000/MS 4000 Predictor (PRED)	
		3.4.1.18 Warning Time (WTIM)	
	3.4.2	Push-Button Program Menu	
	3.4.2	Calibration Menu	
	3.4.4	Out of Service Menu	
SECTI	ON4 -	SGCP 4000/MS 4000 APPLICATION GUIDELINES	4-1

4.1		DUCTION AND OVERVIEW	
4.2		CATION PROGRAMMING GUIDELINES	
	4.2.1	External Islands	
	4.2.2	Programming For Trains That Stop In The Approach	.4-1
	4.2.3	Positive Start (Maintains the Crossing Activated)	
	4.2.4	Sudden Shunt detection	
		4.2.4.1 Track 1, Sudden Shunt Det Level	
	4.2.5	Low EZ Detection	
		4.2.5.1 Low EZ Detection Level	
		4.2.5.2 Low EZ Detection Time	
	4.2.6	Compensation Value	
	4.2.7	SGCP 4000/MS 4000 Simple Predictor	.4-5
4.3		ENANCE CALL OUTPUT	
	4.3.1	Internal Deactivation	
4.4	TAKIN	G TRACKS "OUT OF SERVICE"	
	4.4.1	OOS Options	
		4.4.1.1 Take Approach OOS via 4-Character Display and Pushbuttons	.4-7
		4.4.1.2 Take Crossing (Approaches and Island) OOS via 4-Character	
		Display and Pushbuttons	
		4.4.1.3 Take Approach OOS via DT	.4-7
		4.4.1.4 Take Crossing (Approaches and Island) OOS via DT	.4-8
		4.4.1.5 Take Approach OOS via WebUI (CPU III)	.4-8
		4.4.1.6 Take Crossing (Approaches & Island) OOS via WebUI (CPU III)	.4-9
		4.4.1.7 Returning an OOS Function to Service	
SECT	ION 5 -	AUXILIARY EQUIPMENT	.5-1
5.0	GENE	RAL	5-1
5.1		CTIONAL SIMULATION COUPLER, 62664-MF	
5.2		UNTING ENHANCER PANEL, 80049	
J.Z	5.2.1	Track Output Voltage	
	5.2.2	Monitor Output Voltage	
	5.2.3	Track Requirements	
	5.2.4	Interface Terminal Connections.	
	5.2.4	DC Shunting Enhancer Panel Specifications	
	5.2.6	DC Shunting Enhancer Panel Configuration Options	.D-10
E 2	5.2.7	Two Track and Overlapping Crossing Applications	.D-11
5.3		DW-BAND SHUNT, 62775-F	
<b>-</b> 4	5.3.1	Narrow-band Shunt, 62775-F Specfications	
5.4		DW-BAND SHUNT, 62780-F	
	5.4.1	Narrow-band Shunt, 62780-f Specifications	.5-14
5.5		FREQUENCY NARROW-BAND SHUNT, 62775-XXXX	
	5.5.1	Physical Description	
	5.5.2	Frequency Selection	
	5.5.3	Multi-frequency Narrow-band Shunt, 62775-XXXX Specfications	
5.6		FREQUENCY NARROW-BAND SHUNT, 62780-XXXX	
	5.6.1	Multi-frequency Narrow-band Shunt, 62780-XXXX Specfications	
5.7		AND SHUNT, 8A076A	
	5.7.1	Wideband Shunt Specfications	
5.8		ATED TRACK INDUCTOR, 8V617 (USED WITH MULTI-FREQ SHUNTS)	
	5.8.1	Simulated Track Inductor Installation	
	5.8.2	8V617 Simulated Track Inductor Specifications	
5.9	ADJUS	TABLE INDUCTOR ASSEMBLY, 8A398-6	.5-27

	5.9.1 Adjustable Inductor Configuration	
	5.9.2 8A398-6 Adjustable Inductor Assembly Specifications	
5.10	TRACK CIRCUIT ISOLATION DEVICES	
	5.10.1 Steady Energy DC Track Circuits	
	5.10.1.1 62648 and 8A065A Battery Chokes Specfications	
	5.10.2 Siemens GEO Electronic DC Coded System	
	5.10.3 ElectroCode Electronic Coded System	
	5.10.4 Genrakode Electronic Coded System	
	5.10.5 Relay Coded DC Track	
	5.10.5.1 DC Code Isolation Unit, 6A342-X (6A342-1, 6A342-3, & 6A342-	
	5.10.5.2 DC Code Isolation Unit, 6A342-1 Specfications	
	5.10.5.3 DC Code Isolation Unit, 6A342-1 Applications	5-37
	5.10.5.4 Single Polarity Systems (Fixed Polarity)	
	5.10.5.5 GRS Trakode (Dual Polarity) Systems	5-38
	5.10.5.6 Dual Polarity (Polar) Coded Track Systems Other Than GRS	
	Trakode	
	5.10.6 AC Code Isolation Units	
	5.10.6.1 AC Code Isolation Unit, 8A466-3	
	5.10.6.2 AC Code Isolation Unit, 8A466-3 Specfications	
	5.10.6.3 AC Code Isolation Unit, 8A470-100	
	5.10.6.4 Code Isolation Unit, 8A470-100 AC Specfications	
	5.10.6.5 Cab Signal AC	
	5.10.6.6 Style C Track Circuits	
- 44	5.10.6.7 AC Code Isolation Unit, 8A471-180	
5.11	TUNABLE INSULATED JOINT BYPASS COUPLER, 62785-F	
	5.11.1 Field Tuning Procedure #1	5-45
	5.11.2 Field Tuning Procedure #2 for Couplers	
<b>5</b> 40	5.11.3 Tunable Insulated Joint Bypass Coupler, 62785-f Specifications	
5.12	MS/GCP TERMINATION SHUNT BURIAL KIT, 62776	
	5.12.1 Kit Contents	
	5.12.2 Kit Use	
F 40	5.12.3 Shunt Kit Assemblies Specifications	
5.13	SURGE PANELS, 80026-XX	
	5.13.1 Surge Panel Configurations	
	5.13.2 Surge Panel Arrestors	
5.14	5.13.3 Surge Panel Arresters	5-49 6 6 6
5.14	5.14.1 Rectifier Panel Assembly Nomenclature and Mounting Dimensions	
5.15	CABLE TERMINATION PANEL ASSEMBLY, 91042	5-00 5 60
SECTI	ON 6 - DETAILED CASE AND MODULE DESCRIPTION	6-1
6.1	GENERAL PHYSICAL DESCRIPTION	6-1
0.1	6.1.1 Chassis	
	6.1.2 Motherboard	
	6.1.3 Plug-In Circuit Modules	
6.2	SGCP 4000/MS 4000 ASSEMBLIES	
0.2	6.2.1 Redundant Single Track System, A80490	
	6.2.1.1 Interface Connectors	
	6.2.1.2 Modules and External Wiring Connectors	
	6.2.2 Single Track System, A80495	
	6.2.2.1 Interface Connectors	
	6.2.2.2 Modules and External Wiring Connectors	

6.3		DISPLAY UNIT, A80500	
6.4		gView Display Unit Case, A80500 Modules10DULES AND SUBASSEMBLIES	
0.4		J MODULE	
	0.4.1 CFC	1.1 CPU II+ Module, A80403	6-8
		1.2 CPU III Module, A80903	
		ck Module, A80418	
		2.1 Track Module, A80418 Front Panel	
		435 External Configuration Device (ECD)	
	6.4.4 Cha	assis Identification Chip (CIC)	6-16
	6.4.5 Inte	rface Connector Functions	6-18
		5.1 CPU Connectors	
		5.2 Track Connector	
6.5		MUNICATIONS	
SECT	ION 7 – INS	TALL, PROGRAM, CALIBRATE & CHECKOUT SGCP 4000/MS 40	000 7-1
7.1		REQUIREMENTS	
7.2		EQUIREMENTS	
		tery Wiring	
		e Wiring	
		ck Wiring	
		ernal Wiring Connectors & Wire Size	
		e Preparation	
		ew-terminal Connector Wire Insertion	
		ge-clamp Connector Wire Insertion	
7.3		CUTOVER	
		ipment Needed:	
		ipment and Site Preparation	
		calibration & Reprogramming Reqs Due To Module Replacement	
		calibration Requirements Due To Program Changes	
		calibration Requirements Due To Track Equipment Changes	
		all the SGCP 4000/MS 4000	
		figure the SGCP 4000/MS 4000 via Push-Button Menu	
		figure the SGCP 4000/MS 4000 via the WebUI (CPU III)	
		brate the SGCP 4000/MS 4000 via Push Button Menu	
	7.3.	9.1 Bypassing the Linearization	7-11
		brate the SGCP 4000/MS 4000 via the WebUI (CPU III)	
		10.1 GCP (SGCP 4000/MS 4000) Calibration	
	7.3.	10.2 Approach Distance and Linearization Calibration	7 24
		10.3 Island Calibration	
		ck Module (A80418) Internal Island Response Test (CSB 3-15)	
		iliary Equipment Calibration Proceduresiliary Equipment Calibration Procedures	
7.4		0/MS 4000 OPERATIONAL TESTS	
7. <del>4</del> 7.5		P 4000/MS 4000 HARDWARE & SOFTWARE VERSION DATA:	
7.5 7.6		RNING TIME OF THE PREVIOUS TRAIN	
SECT		OUBLESHOOTING	
8.1	OVERVIEV	V	8-1
8.2		DDES	
8.3	TESTING T	FRACKSIDE EQUIPMENT	8-9
2.0	8.3.1 Tes	ting Insulated Joint Couplers, Rail Bonds, and Termination Shunts	8-9

	8.3.2	Troubleshooting A De-energized Motion Sensor	8-10
	8.3.3	Troubleshooting A Physical SGCP 4000/MS 4000 Input	8-11
	8.3.4	Track Circuit Problems	8-11
8.4		EX	
	8.4.1	Low EX Qualification Test	8-12
8.5		ANCE ACTIVATION – RAIL PHASE CHECK	
8.6	UPGR	ADING SOFTWARE VIA WEBUI (CPU III)	8-15
	8.6.1	Local User Presence	8-15
	8.6.2	CP MEF Software Update Process	8-17
	8.6.3		
	8.6.4	Upload Module MCF / MCFCRC	8-20
	8.6.5		
	8.6.6	Vital IO Module	8-22
Appe	ndix A. I	NTERFERENCE	A-1
A.1	CHAR	ACTERISTICS	A-1
A.2	MEAS	UREMENTS AND IDENTIFICATION	A-1
	A.2.1	Measure the Track Voltage	A-1
A.3	MITIG	ATION	A-2
	A.3.1	Cab Signal Environment	A-3
	A.3.2	Power Related Environment	A-3
Appe	ndix B	- GLOSSARY	B-1
Appe	ndix C	- REMOTE CALIBRATION	
C.1	CHAR	ACTERISTICS	C-1
•	_		_
Appe	ndix D. S	SGCP 4000/MS 4000 SYSTEM CUTOVER TEST FORM	D-1
Appe	ndix E. S	SGCP 4000/MS 4000 APPLICATION HISTORY CARD	E-1
Anne	ndix F I	nstallation of Ferrite Reads	F-1

# **List of Figures**

Figure 1-1: SGCP 4000 / MS 4000, Redundant Single Track System (P/N A80490)	
& Single Track System (P/N A80495)	
Figure 1-2: Diagram of EZ Level Compared to Train Shunt Location	
Figure 2-1: Approach Distance	
Figure 2-2: Overlapping Approaches	.2-8
Figure 2-3: Adjacent Frequency 62775-f Narrow-band Shunt Placement Charts,	
Bidirectional and Directionally wired Application (Sheet 1 of 3)	.2-11
Figure 2-4: Adjacent Frequency 62775-f Narrow-band Shunt Placement Charts,	
Bidirectional and Directionally wired Application (Sheet 2 of 3)	.2-12
Figure 2-5: Adjacent Frequency 62775-f Narrow-band Shunt Placement Charts,	
Bidirectional and Directionally wired Application (Sheet 3 of 3)	.2-13
Figure 2-6: Adjacent Frequency 62780-f Narrow-band Shunt Placement Charts,	
	.2-14
Figure 2-7: Adjacent Frequency 62780-f Narrow-band Shunt Placement Charts,	
Bidirectional and Directionally wired Application (Sheet 2 of 3)	.2-15
Figure 2-8: Adjacent Frequency 62780-f Narrow-band Shunt Placement Charts,	
Bidirectional and Directionally wired Application (Sheet 3 of 3)	
Figure 2-9: Insulated Joint, Shunt, or Coupler Installation	
Figure 2-10: Determining Island Approach Length	
Figure 2-11: Track Lead Connections	
Figure 2-12: Six-Wire To Four-Wire Conversion	
Figure 2-13: Proper Connections of Track Wires	.2-30
Figure 2-14: Proper 4-Wire & 6-Wire Connections When Using Auxiliary Track Circuit	
Equipment	
Figure 2-15: Battery Choke Requirements	
Figure 2-16: Ripple Elimination Circuit	
Figure 2-17: Code Isolation Unit in a Single Polarity Code System	
Figure 2-18: Code Isolation Unit Installation In GRS Trakode System	
Figure 2-19: AC Code Isolation Unit Used in CAB Territory	
Figure 2-20: Typical Unidirectional Approach Configuration	
Figure 2-21: Bidirectional Simulation Coupler	.2-40
Figure 2-22 4-wire & 6-wire Connections Using Bidirectional Simulation Coupler on	0.40
SGCP4000/MS4000 Operating in Bidirectional Simulation mode	
Figure 2-23: Typical Unidirectional Application	
Figure 2-24: Typical Bidirectional Application	.2-45
Figure 2-25: Two Back-to-Back Unidirectional Units In Directionally wired (Simulated	0.40
Bidirectional) Application	.2-46
Figure 2-26: Two Overlapping Crossings, Using 80049-1 DC Shunting Enhancer Panels	
Figure 2-27: Typical Track Wire Surge Protection for 4 and 6 Wire Track Connections	.2-48
Figure 2-28: Typical Surge Protection Requirements When Cabling Between UAX	0.40
Unit and SGCP 4000/MS 4000	
Figure 2-29: Recommended Battery Surge Protection Wiring for SGCP 4000/MS 4000	
Figure 3-1: Unsecure Connection Warning	
Figure 3-2: WebUI Login Screen	
Figure 3-3: WebUI Tool Bar	
Figure 3-4 WebUI: Unlock	
Figure 3-5 WebUI: Confirm Local User Presence	
Figure 3-6: WebUI Local User Presence Error Messages	
Figure 3-7: WebUI Local User Presence I Authenticated	
Figure 3-8: System View	.o-1

Figure 3-9: System View Track Menu	3-8
Figure 3-10: Track Detail View	3-9
Figure 3-11: Track Diagnostics Messages	3-10
Figure 3-12: Track Calibration	3-11
Figure 3-13: Remote Setup WebUI	
Figure 3-14: Out of Service WebUI	3-12
Figure 3-15: Check Numbers	3-13
Figure 3-16: MS4000 Configuration	3-15
Figure 3-17: CP Programming	3-16
Figure 3-18: Track Calibration	3-16
Figure 3-19: Status Monitor Full Menu	3-17
Figure 3-20: Log and Report Filtering	3-18
Figure 3-21: Reports and Logs	3-18
Figure 3-22 WebUI: Event Log Text Filter	3-19
Figure 3-23 WebUI: Event Log ADVANCE Mode	
Figure 3-24 WebUI: Event Log TRACE Mode	
Figure 3-25: CP MEF	
Figure 3-26: WebUI: Software Updates	
Figure 3-27: Bidirectionally Wired Approaches	
Figure 4-1: External Island Example	
Figure 4-2: Track application	
Figure 4-3: WebUI: Out of Service Acknowledge	
Figure 4-4: WebUI: Out of Service Indications	
Figure 4-5: Island Out of Service Confirmation	
Figure 4-6: Island Out of Service Indications on WebUI	4-10
Figure 5-1: Bidirectional Simulation Coupler, 62664-Mf	
Figure 5-2 4-wire & 6-wire Connections using Bidirectional Simulation Coupler on	
SGCP 4000/MS 4000 Operating in Bidirectional Simulation mode	5-5
Figure 5-3: Bidirectional Simulation Coupler Assembly Mounting Dimensions	
Figure 5-4: DC Shunting Enhancer Panel, 80049	
Figure 5-5: DC Shunting Enhancer Panel, 80049, Interface Terminal Connections	
Figure 5-6: DC Shunting Enhancer Panel Mounting Dimensions	
Figure 5-7: DC Shunting Enhancer Panels for Two Track Crossing	
Figure 5-8: DC Shunting Enhancer Panels for Overlapping Crossings	
Figure 5-9: Siemens Narrow-band and Wide-band Termination Shunts	
Figure 5-10: Multi-frequency Narrow-band Shunt, 62775-XXXX/62780-XXXX AREMA	
Binding Posts	5-17
Figure 5-11: Simulated Track Inductor, 8V617	5-22
Figure 5-12: Simulated Track Inductor Used With Termination Shunt	
Figure 5-13: Typical Installation of 8V617 in 62775/62780 Shunt	
Figure 5-14: Adjustable Inductor Assembly, 8A398-6	
Figure 5-15: Adjustable Inductor Used With Termination Shunt	5-28
Figure 5-16: Adjustable Inductor, 8A398-6 Schematic	
Figure 5-17: Battery Choke Requirements	
Figure 5-18: Ripple Elimination Circuit	
Figure 5-19: 62648/8A065A Battery Choke With Mounting Dimensions	
Figure 5-20: DC Code Isolation Unit, 6A342-X, With Mounting Dimensions and	
Schematics	5-36
Figure 5-21: Code Isolation Unit In a Single Polarity Code System	
Figure 5-22: Code Isolation Unit Installation In a GRS Trackode System	
Figure 5-23: AC Code Isolation Unit, 8A466-3	
Figure 5-24: AC Code Unit. 8A470-100. With Mounting Dimensions	

Figure 5-25: AC Code Isolation Unit Used In CAB Territory	
Figure 5-26: AC Code Isolation Unit Used in Style C Track Circuits	
Figure 5-27: Terminal Identification, 62785-f Tunable Insulated Joint Coupler	
Figure 5-28: Typical Installation Diagrams Using the 62785-f Coupler	
Figure 5-29: MS/GCP Termination Shunt Burial Kit, 62776	
Figure 5-30: Typical 80026 Surge Panel Arrester Mounting Position	.5-50
Figure 5-31: Wall Mount Surge panels, 80026-01 -02, and -22	.5-53
Figure 5-32: Rack Mounted Surge Panels, 80026-31 and -32	
Figure 5-33: Rack Mounted Surge Panels, 80026-33 And -34	
Figure 5-34: Rack Mounted Surge Panels, 80026-35 and -36	
Figure 5-35: Rack Mounted Surge Panels, 80026-37 And -38	.5-57
Figure 5-36: Rack Mounted Surge Panels. 80026-39, -41 and -41A	.5-58
Figure 5-37: Rack Mounted Surge Panels 80026-47 and 80026-50	.5-59
Figure 5-38: Rectifier Panel assembly, 80033	.5-61
Figure 5-39: Cable Termination Panel Assembly, 91042	
Figure 6-1: SGCP 4000/MS 4000, A80490 Connectors	.6-2
Figure 6-2: SGCP 4000/MS 4000 Case, A80490 With Modules and External Wiring	
Connectors Installed	.6-3
Figure 6-3: A80495 Connectors	.6-4
Figure 6-4: SGCP 4000/MS 4000 Case, A80495 with Modules & External Wiring	
Connectors Installed	.6-5
Figure 6-5: DiagView Display Unit Case, A80500	.6-6
Figure 6-6: DiagView Display Unit, A80500	.6-7
Figure 6-7: CPU II+ Module, A80403 Front Panel	
Figure 6-8: CPU III Front Panel	
Figure 6-9: Track Module, A80418 Front Panel	
Figure 6-10: Typical ECD & CIC Locations On Backplane	
Figure 6-11: A80490 & A80495 CPU Connectors	
Figure 6-12: A80490 and A80495 Track Connectors	
Figure 7-1: Insertion of Wire into Cage-clamp Connector	
Figure 7-2: Adjust SCGP4000 / MS4000 Configuration	
Figure 7-3: Save Changed Parameters	
Figure 7-4: Start Calibration	
Figure 7-5: Please Check Overlap	
Figure 7-6: Calibration Complete	
Figure 7-7: Calibration Initializaing	
Figure 7-8: Linearization Calibration	
Figure 7-9: Midpoint Location	
Figure 7-10: Edit Button	
Figure 7-11: Linearization Steps Diaglog Box	
Figure 7-12: Computed Distance Diaglog Box	
Figure 7-13: Approach Calibration Bypass	
Figure 7-14: Linearization Calibration Bypass	
Figure 7-15: Start Island Calibration	
Figure 7-16: Tuned Joint Coupler, 62785-f	
Figure 7-17: Shunt Placement For 62785f Bypass Coupler	
Figure 8-1: MS4000 Advanced Screen	
Figure 8-2: Save Low EX Adjustment Value	
Figure 8-3: WebUI: Software Updates	
Figure 8-4: WebUI: Unlock	
Figure 8-5: WebUI: Confirm Local User Presence	
Figure 8-6: WebUI Local User Presence Error Messages	

Figure 8-7: WebUI Local UselSuccessfuly Authenticated	8-16
Figure 8-8: Select CP MEF	
Figure 8-9: CP MEF File Selected	8-17
Figure 8-10: Upload Status	
Figure 8-11: Reboot Required	8-18
Figure 8-12: Upload Successful	8-19
Figure 8-13: Vital CPU Menu	8-19
Figure 8-14: Select MCF File	8-20
Figure 8-15: Update MCF	8-21
Figure 8-16: WebUI: Reset VLP	8-21
Figure 8-17: Vital IO Module Menu	8-22
Figure 8-18: Check Serial Port Connection	8-22
Figure C-1: Connecting the VHF Communicator, A80276	
Figure C-2: WebUI Remote Setup Window	
Figure F-1: Ferrite Bead Sizes	
Figure F-2: Ferrite Bead Installation Guide	

# **List Of Tables**

Table 1-1: SGCP 4000/MS 4000 Approach Frequencies	
Table 1-2: Input Power Specifications	
Table 1-3: SGCP 4000/MS 4000 Input Current Requirements	
Table 1-4: SGCP 4000/MS 4000 General Parameters	
Table 1-5: Physical Dimension Data	1-6
Table 2-1: SGCP 4000/MS 4000 Approach Frequencies	2-1
Table 2-2: Ballast Resistance vs. Approach Distance by Frequency, Bidirectional and Directionally wired Applications	2-2
Table 2-3: Ballast Resistance vs. Approach Distance by Frequency, Unidirectional	
Applications	2-2
Table 2-4: Warning Time vs. Maximum Speed Distance Table (Imperial {MPH-FT/S})	
Table 2-5: Warning Time vs. Maximum Speed Distance Table (Metric {KPH-M/S})	
Table 2-6: 62775-f Single Frequency Narrow Band Shunt Available Frequencies	
Table 2-7: Multi-frequency Narrow-band Shunt, 62775	2-9
Table 2-8: Minimum Distance Between Termination Shunts When Repeating SGCP	0
4000/MS 4000 Operating Frequencies	2-17
Table 2-9: Narrow-band Shunt, 62775, Fixed Termination Frequencies	
Table 2-10: Multi-frequency Narrow-band Shunt, 62775	
Table 2-11: 62780-f Narrow-band Shunt Fixed Termination Frequencies	
Table 2-12: 62780 Multi-frequency Narrow-band Shunt	
Table 2-13: Minimum Distance to Insulated Joints Bypassed With The 62785-f Coupler.	
Table 2-14: SGCP 4000/MS 4000 Island Frequencies (kHz)	
Table 2-15: Maximum Transmitter Track Wire Length For 4-Wire Applications	
Table 2-16: Siemens Battery Chokes	
Table 2-17: Siemens AC Code Isolation Units	
Table 3-1: General Menu Navigation and Selection Using The Pushbuttons	3-3
Table 3-2: SGCP 4000/MS 4000 Approach Frequency Selections	
Table 3-3: SGCP 4000/MS 4000 Island Frequency Selection Values	3-23
Table 3-4: SGCP 4000/MS 4000 Program Menu	3-26
Table 3-5: SGCP 4000/MS 4000 MENU DEFAULT SETTINGS	3-27
Table 3-6: Calibration Menu Options	3-28
Table 3-7: Out of Service (OOS) Menu Options	
Table 5-1: Approach Distance Selection Strapping For Bidirectional Simulation	
Coupler, 62664-Mf	
Table 5-2: Bidirectional Simulation Coupler, 62664-Mf	5-4
Table 5-3: DC Shunting Enhancer Panel Specifications	
Table 5-4: DC Shunting Enhancer Panel Configuration Options	
Table 5-5: Frequencies Available with Narrow Band Shunt, 62775-f	5-13
Table 5-6: Frequencies Available with Narrow Band Shunt, 62780-f	5-14
Table 5-7: Multi-frequency Narrow-band Shunt, 62775-XXXX Frequency Selection	
Jumpers	
Table 5-8: Multi-frequency Narrow-band Shunt, 62780 Frequency Selection Jumpers	
Table 5-9: Simulated Track Inductor Part Number Listing	
Table 5-10: Simulated Track Inductor, 8V617, Mounting Terminals	
Table 5-11: Terminal Connections For Adjustable Inductor Assembly, 8A398-6	5-30
Table 5-12: Minimum Distance to Insulated Joints When Coupled With Tunable	
Insulated Joint Bypass Coupler, 62785-f	
Table 5-13: Wall Mount Surge Panels	
Table 5-14: Rack Mount Surge Panels	
Table 5-15: Rectifier Panel Assembly, 80033 Specifications	
Table 5-16: Cable Termination Panel Assembly, 91042 Specifications	5-60

Table 6-1:  Dual Single Track Case, A80490 Module to Interface Connector Relationship	
Table 6-2: SGCP 4000/MS 4000 Case External Wiring Connectors	.6-3
Table 6-3: Single Track Case, A80495 Module to Interface Connector Relationship	.6-4
Table 6-4: SGCP 4000/MS 4000 Case External Wiring Connectors	
Table 6-5: DiagView Display Unit Case External Wiring Connectors	
Table 6-6: CPU II+ Module, A80403 User Interface	
Table 6-7 CPU III A80903 User Interface	
Table 6-8: Track Module, A80418 User Interface	.6-15
Table 6-9: CPU Connectors	
Table 6-10: Track Connectors	.6-20
Table 7-1: Wire Preparation Standards	.7-2
Table 7-2: Recalibration & Reprogramming Requirements due to Module/Chassis	
Replacements	.7-4
Table 7-3: Recalibration Requirements Due to Program Changes	
Table 7-4: Recalibration Requirements Due to Track Equipment Changes	
Table 7-5: Island Shunt Distance in Feet/Meters	
Table 7-6: GCP (SGCP 4000/MS 4000) Calibration	.7-11
Table 7-7: Approach and Linearization Calibration 1	.7-14
Table 7-8: Approach and Linearization Calibration 2	
Table 7-9: Approach and Linearization Calibration Bypass Procedure	
Table 7-10: Calibrated Value History Form	
Table 7-11: Island Calibration Procedure	.7-21
Table 7-12: Island Shunt Distance	.7-22
Table 7-13: Tuned Joint Coupler, 62785-f Minimum Distances	.7-25
Table 7-14: Method 1 for Tuning the 62785-f Tuned Joint Coupler (See Figure 7-4 for	
Locations)	.7-27
Table 7-15: Method 2 for Tuning the 62785-f Tuned Joint Coupler (See Figure 8-2 for	
Locations)	
Table 7-16: SGCP 4000/MS 4000 Operational Tests	
Table 7-17: Train Detection, Warning Times, and Crossing Operation	
Table 8-1: SGCP 4000/MS 4000 Error Codes	
Table 8-2: Insulated Joint Coupler Test	
Table 8-3: Rail Bond Test	
Table 8-4: Termination Shunt Test	
Table 8-5: Troubleshooting a De-energized Motion Sensor	
5 I	.8-11
Table 8-7: Low EX Qualification Test Push-Button Method	
Table 8-8: Low EX Qualification Test WebUI Method (CPU III)	
Table 8-9 Ferrite Bead Ordering Information	.F-4
Table A-1 Devices Specially Designed for Interference Mitigation	
Table C-1 Remote Calibration Setup	
Table C-2: Island Shunt Distance in Feet/Meters	
Table C-3 Remote Calibration	
Table C-4 Remote Approach Calibration	
Table C-5 Remote Island Calibration	
Lania Libi Lambiatina Pamata Lalibratian	( <u>-</u> 6

# SECTION 1 – MOTION SENSOR 4000 (SGCP 4000/MS 4000) OVERVIEW

#### 1.1 INTRODUCTION

The Simple Grade Crossing Predictor 4000 / Motion Sensor 4000 (SGCP 4000/MS 4000) is a modular microprocessor-controlled motion detector system that is designed to reliably detect the motion of an approaching train and to activate the crossing warning equipment when the speed of the train exceeds the minimum motion sensitivity. In addition to motion sensor functionality, the system also provides simple predictor functionality. The SGCP 4000/MS 4000 is available as a Redundant Single-Track System (A80490) or a Single-Track System (A80495) unit.



Figure 1-1: SGCP 4000 / MS 4000, Redundant Single Track System (P/N A80490) & Single Track System (P/N A80495)

# 1.2 DESCRIPTION

Operation of the SGCP 4000/MS 4000 is based on the maximum impedance of an unoccupied track circuit. This is determined by the location of the termination shunts and the rate of change in the impedance resulting from the physical location of a train as it moves within the track circuit. The SGCP 4000/MS4000, applies a constant current AC signal to the track and measures the level of the resulting voltage. The level varies with approach track impedance, which also varies with the distance of the train from the crossing. The rate of change is sensed by the SGCP 4000/MS 4000, which then activates the crossing warning equipment provided the approaching train exceeds the minimum motion sensitivity.

A shunt is connected across the rails to terminate the SGCP 4000/MS 4000 approach circuit. This device presents a low impedance at the SGCP 4000/MS 4000 operating frequency and may consist of a wire connected between the rails (hardwire shunt) when no other signals (AC or DC) are present on the rails, or when non-coded DC track circuits only are present, a wideband shunt may be used. A narrow-band shunt is used when other AC signals are present. Insulated joints in DC coded track can be coupled using Tunable Insulated Joint Bypass Couplers, 62785-f.

The SGCP 4000/MS 4000 will respond to the approaching motion of a train and cause the crossing warning equipment to operate within approximately 5 seconds. When the train has cleared the crossing, the SGCP 4000/MS 4000 no longer senses approaching motion and the crossing warning signal system recovers.

When a train stops before reaching the crossing, or reverses direction and backs away from the crossing, the SGCP 4000/MS 4000 system will recover after a short (programmable) pickup delay as approaching motion is no longer detected. When the train resumes forward motion toward the crossing, the SGCP 4000/MS 4000 system is activated and remains in operation until the train has cleared the crossing.

The required track length becomes an integral part of the SGCP 4000/MS 4000 system and is a function of maximum train speed, warning time desired, plus an additional 5-second system response time. The 5-second interval enables the crossing warning signal equipment to activate and ensures adequate warning time when a maximum speed train enters the SGCP 4000/MS 4000 approach. At this point, the track circuit is terminated by a shunt across the rails. The track distance from the feed point to the shunt is the approach distance. Under normal conditions, the impedance of this section of track is a constant value. However, a train entering the approach shunts the track and reduces the impedance and, therefore, the effective length of the track circuit. This, in turn, causes a voltage reduction in the track signal.

The SGCP 4000/MS 4000 receiver circuits are also transformer-coupled to the track through wires connected to the rails usually on the opposite side of the crossing from the transmitter feed points. The length of track between the two sets of feed points defines the island circuit. The receiver senses the voltage level across the track impedance and the level changes as the effective impedance of the track changes with the position of the train in the approach.

When a train approaches near the crossing at 1 mile-per-hour (approximately 2 km/h) or faster, the processor module detects the train movement and activates the crossing warning signal equipment. Self-check modulation occurs every few seconds and verifies proper operation of the motion-processing circuits.

The crossing warning signal equipment recovers when the receiver circuits sense any of the following conditions:

- A zero rate of change indicating an unoccupied track, or a train stopped within the approach but not yet within the island circuit
- An increasing rate of change caused by a train moving away from the crossing

Operating parameters are programmable via buttons on the CPU II+ / CPU III module. Self-check circuits in the SGCP 4000/MS 4000 test the unit at specific intervals, ensuring safe operation. Module status LED indicators plus diagnostic messages, which are displayed on the 4-Character display, combine to permit rapid troubleshooting.

The SGCP 4000/MS 4000 island circuit is established and controlled by a high frequency island module that contains separate transmitter and receiver circuits. The length of the island circuit is established by the location of the track connections on either side of the crossing. A train located at any point within the island circuit will activate the SGCP 4000/MS 4000. The island frequency may be selected from a number of available frequencies ranging from 2.14 kHz to 20.2 kHz.

#### 1.3 MOTION SENSOR OPERATIONAL PARAMETERS

The SGCP 4000/MS 4000 supports Unidirectional track circuits, Bidirectional track circuits, and Bidirectionally Wired track circuits. The Bidirectionally Wired track circuit is one where the direction of travel may be determined by the configuration of the 6-wire track wire connections.

The SGCP 4000/MS 4000, detects the motion of an approaching train when its speed exceeds a set (programmed) motion detection threshold and activates crossing-warning devices at time of train detection.

The SGCP 4000/MS 4000, communicates with other ATCS devices via Echelon® LAN. These other devices may include the SEARII Event Analyzer/Recorder II, HD/LINK, a VHF Communicator, an iLOD, SSCC IV, and/or a second SGCP 4000/MS 4000.

#### 1.4 TRAIN DETECTION

The SGCP 4000/MS 4000, applies a constant current audio frequency (AF) signal to the track and measures the level of the resulting voltage. The approach track signal magnitude (EZ) varies with approach track impedance. The approach track impedance corresponds to the distance of the train from the crossing. When unoccupied the approach circuit has maximum impedance. When a train enters the approach and moves towards the crossing, the track circuit impedance continually decreases due to the low resistance shunt created by the train's wheels. When a train reaches the crossing, the approach circuit is reduced to minimum impedance. As a train moves away from the crossing, the track impedance continually increases. When the train exits the approach the circuit again has maximum impedance.

The EZ is proportional to the relative distance the train is from the crossing. When no train is on a calibrated approach, the EZ is approximately 100 (see Figure 1-2). The EZ value rate of change is proportional to the speed of the train. The rate of change is sensed by the SGCP 4000/MS 4000 and used predict when to activate the crossing warning devices.




Figure 1-2: Diagram of EZ Level Compared to Train Shunt Location

## 1.4.1 Track Ballast Condition

The EX value is a numerical indication of track ballast conditions. The EX corresponds to electrical leakage through track ballast. An EX value of 100 represents optimum track ballast conditions. The standard low EX operating threshold for the SGCP 4000/MS 4000 is 39. EX is nominally between 70 and 100.

# 1.4.2 Track Ballast Changes

The EX value can be affected by the presence of water, mud, salt or other contaminates deposited in the track ballast. High concentrations of these contaminates at a crossing can cause excessive leakage (lump loading). The SGCP 4000/MS 4000 provides automatic compensation of EZ for a wide range of lump loading conditions.

# 1.4.3 SGCP 4000/MS 4000 Signal Frequencies

The constant current audio frequency (AF) signal for each track can be programmed for any of 56 frequencies:

				• •	•		
86	114	156	211	285	348	430	525
645	790	970					
44	45	46	141	149	151	237	249
250	267	326	392	452	521.2	560	630
686	753	816	881	979	999		
85.5	86.5	113	113.5	114.5	115	155	115.5
156.5	157	210	212	284	286	347	349
429	431	523	527	643	647	788	792
968	972						

Table 1-1: SGCP 4000/MS 4000 Approach Frequencies

# 1.5 SYSTEM SPECIFICATIONS

**Table 1-2: Input Power Specifications** 

Parameter	Range of Values
Battery Voltage	
On CPU Connector:	9.0-16.5 VDC
On Track Card Connector:	9.0-16.5 VDC
Maximum Ripple:	1.0V p-p

Table 1-3: SGCP 4000/MS 4000 Input Current Requirements

Component	CPU Battery Connector @10V	CPU Battery Connector @13.2 V	CPU Battery Connector @16.5V		
CPU II+:	0.4 A	0.5 A	0.6 A		
CPU III	0.7 A	0.6 A	0.6 A		
Track:	1.7 A @ medium transmit power 1.90 A @ high transmit power Current increases by 200 mA when one 250 ohm relay output is energized and increases by 450 mA when two outputs are energized	1.05 A @ medium transmit power 1.15 A @ high transmit power Current increases by 80 mA when one 250 ohm relay output is energized and increases by 150 mA when two outputs are energized	800 mA @ medium transmit power 850 mA @ high transmit output Current increases by 60 mA when one 250 ohm relay output is energized and increases by 130 mA when two outputs are energized		
80490 Chassis	2.258 A (medium transmit power) 2.288 A (high transmit power)	1.685 A (medium transmit power) 1.707 A (high transmit power)	1.392 A (medium transmit power) 1.412 A (high transmit power)		
80495 Chassis	2.022 A (medium transmit power) 2.055 A (high transmit power)	1.445 A (medium transmit power) 1.465 A (high transmit power)	1.158 A (medium transmit power) 1.183 A (high transmit power)		

Table 1-4: SGCP 4000/MS 4000 General Parameters

parameter	Values
MS Response Time	5 seconds
Relay Drive Outputs (VO):	400 to 1000-ohm load
Minimum Output Current @ medium transmit power:	200 mA
Minimum Output Current @ high transmit power:	400 mA
Surge Protection:	Built-in secondary surge protection for all connections. Requires external arresters and equalizers on track wires as primary surge protection. Surge panels or their electrical equivalent are required. Refer to paragraph 2.16 for battery and external cable surge protection.
Typical Monitoring and Storage:	
IO State Changes:	CPU II+: 3000 minimum, CPU III: 250,000
Train Moves:	100 minimum
Mounting:	All SGCP 4000/MS 4000 chassis can be wall, rack, or shelf mounted
Temperature Range:	-40 °F to +160 °F (-40 °C to 70 °C)

**Table 1-5: Physical Dimension Data** 

PARAMETER	VALUES								
Chassis Dimensions:									
	Redundant Single Track (A80490)	Single Track (A80495)							
Width:	10.16 ln. (25.806 cm)	5.94 in. (15.088 cm)							
Depth:	10.86 ln. (27.584 cm)	12.38 in. (31.446 cm)							
Height:	14.25 ln. (36.195 cm)	19.09 in. (48.489 cm)							
	Chassis Weights:								
	Empty	Full Module Complement							
Redundant Single Track (A80490)	11.80 lb. (5.352 kg)	17.5 lb. (7.938 kg)							
Single Track (A80495)	8.25 lb. (3.742 kg)	10.5 lb. (4.762 kg)							
	Module Weights:								
CPU II+ (A80403)	1.25 lbs. (0.567 kg)								
CPU IIII (A80903)	1.15 lbs. (0.51 kg)								
Track (A80418)	1.00 lbs. (0.454 kg)								
Transfer (A80406) (A90490 only)	0.83 lbs. (0.567 kg)								

# 1.5.1 Track Card Compatibility

The SGCP 4000/MS 4000 will need to be fitted with the ferrite bead kits K8018-1 as described in Appendix F and CSB 3-15E if it is to be used with any hardware version of the track module A80418.



SGCP 4000/MS 4000 CHASSIS MUST HAVE FERRITE BEADS INSTALLED ON THE TRACK XMT AND RCV WIRES AS DESCRIBED IN APPENDIX F INSTALLATION OF FERRITE BEADS IN ORDER TO AVOID POSSIBLE SHUNTING ISSUES IF A REV D OR EARLIER A80418 TRACK MODULE IS INSTALLED IN CHASSIS.

# SECTION 2 – GENERAL SGCP 4000/MS 4000 APPLICATION INFORMATION

#### 2.1 SGCP 4000/MS 4000 TRACK SIGNALS

The SGCP 4000/MS 4000, applies a constant current audio frequency (AF) signal to the track.

# 2.1.1 Frequency Selection

Approach distance and track ballast resistance generally determines SGCP 4000/MS 4000 signal frequency selection. Track circuit types, track configurations, and other factors must also be taken into consideration when determining frequency. If difficulties are encountered when setting up track circuits, the generic application may not be correct for that particular site and further investigation and mitigation may be required.

# 2.1.2 SGCP 4000/MS 4000 Frequency Range

The SGCP 4000/MS 4000 application program utilizes frequencies between 44 and 999 Hz.

# 2.1.3 SGCP 4000/MS 4000 Signal Attenuation

SGCP 4000/MS 4000 transmitted frequencies are attenuated by track ballast resistance: the higher the frequency, the greater the attenuation. The useful approach distance tends to be inversely proportional to the signal frequency.

## 2.2 SGCP 4000/MS 4000 APPROACH FREQUENCIES

The SGCP 4000/MS 4000 can operate using one of 56 separate frequencies. The specific frequency chosen is dependent on approach distance requirements and track ballast conditions.

521.2 85.5 86.5 113.5 114.5 115.5 156.5 

Table 2-1: SGCP 4000/MS 4000 Approach Frequencies

#### 2.3 SGCP 4000/MS 4000 FREQUENCY VERSES OPERATING DISTANCE

SGCP 4000/MS 4000 frequency versus the operating distance at 2, 4, and 6 Ohms per 1000 ft. (304.80 meters) of ballast resistance is provided in Table 2-2 (Bidirectional and Directionally wired) and Table 2-3 (Unidirectional). The minimum distances provided are based on use of hardwire or wideband shunts.

Table 2-2: Ballast Resistance vs. Approach Distance by Frequency, Bidirectional & Directionally Wired Applications

		BIDIRECTIONAL APPROACH DISTANCE										
SGCP 4000/ MS 4000 OPERATING FREQUENCY (HZ)	DISTR BAL	000' (304.8M) RIBUTED LLAST (METERS)	DISTRIBUT	000' (304.8M) ED BALLAST (METERS)	6 OHMS/1,000' (304.8M) DISTRIBUTED BALLAST IN FEET (METERS)							
(112)	MIN.					MAX.						
86	1,000 (304.8)	5,350 (1,630.7)	1,000 (304.8)	7,950 (2,423.2)	1,000 (304.8)	9,280 (2,362.2)						
114	750 (228.6)			0 (228.6) 6,450 (1,966.0)	750 (228.6)	7,448 (2,270.2)						
156	600 (182.9)	600 (182.9) 3,925 (1,196.3) 600 (182.9) 5,55		5,550 (1,691.6)	600 (182.9)	6,349 (1,935.2)						
211	475 (144.8)	3,350 (1,021.1)	475 (144.8) 4,800 (1,463.0)		475 (144.8)	5,494 (1,674.6)						
285	400 (121.9)	2,950 (899.2)	2,950 (899.2) 400 (121.9) 4,225 (1,287.		400 (121.9)	4,762 (1,451.5)						
348	400 (121.9)	2,625 (800.1)	400 (121.9)	3,675 (1,120.1)	400 (121.9)	4,151 (1,265.2)						
430	400 (121.9)	2,300 (701.0)	400 (121.9)	3,350 (1,021.1)	400 (121.9)	3,785 (1,153.7)						
525	400 (121.9)	2,150 (655.3)	400 (121.9)	3,150 (960.1)	400 (121.9)	3,541 (1,179.3)						
645	400 (121.9) 1,950 (594.4)		400 (121.9)	2,800 (853.4)	400 (121.9)	3,175 (967.7)						
790	400 (121.9) 1,725 (525.8))		400 (121.9)			2,807 (855.9)						
970	400 (121.9)	1,550 (472.4)	400 (121.9)	2,175 (662.9)	400 (121.9)	2,472 (753.5)						

Table 2-3: Ballast Resistance vs. Approach Distance by Frequency, Unidirectional Applications

						• •						
	UNIDIRECTIONAL APPROACH DISTANCE											
SGCP 4000/ MS 4000 OPERATING FREQUENCY	(3) DIST	MS/1,000' 04.8M) RIBUTED LLAST	DIST	,000' (304.8M) RIBUTED LLAST	6 OHMS/1,000' (304.8M) DISTRIBUTED BALLAST							
(HZ)	MIN.	MAX.	MIN.	MAX.	MIN.	MAX.						
86	700 (213.4)	4,375 (1,333.5)	700 (213.4)	6,175 (1,882.1)	700 (213.4)	7,080 (2,158.0)						
114	525 (160.0)	3,850 (1,173.5)	525 (160.0)	5,550 (1,691.6)	525 (160.0)	6,360 (1,938.5)						
156	420 (128.0)	3,325 (1,013.5)	420 (128.0)	4,875 (1,485.9)	420 (128.0)	5,520 (1,682.5)						
211	400 (121.9)	2,750 (838.2)	400 (121.9) 4,100 (1,249.7)		400 (121.9)	4,680 (1,426.5)						
285	400 (121.9)	2,250 (686.8)	400 (121.9)	400 (121.9) 3,500 (1,066.8)		3,960 (1,207.0)						
348	400 (121.9)	1,925 (586.7)	400 (121.9)	3,025 (922.0)	400 (121.9)	3,420 (1,042.4)						
430	400 (121.9)	1,725 (525.8)	400 (121.9)	2,650 (807.7)	400 (121.9)	3,000 (914.4)						
525	400 (121.9)	1,500 (457.2)	400 (121.9)	2,275 (693.4)	400 (121.9)	2,580 (786.4)						
645	400 (121.9)	1,300 (396.2)	400 (121.9)			2,220 (676.7)						
790	400 (121.9)	1,125 (342.9)	400 (121.9)	1,650 (502.9)	400 (121.9)	1,860 (566.9)						
970	400 (121.9)	1,050 (320.0)	400 (121.9)	1,550 (472.4)	400 (121.9) 1,710 (521.2)							

Lumped loads in the SGCP 4000/MS 4000 approach can affect the linearity (slope) of EZ over the length of the approach.

#### 2.4 TRACK CIRCUIT OPERATING FREQUENCY RESTRICTIONS

The following track circuits are subject to the specified operating frequency restrictions:

#### NOTE



Refer to Section 2.14, Track Circuit Isolation Devices, for applicable battery isolation and AC filter requirements. Contact Siemens Mobility, Inc. for assistance as required at (800) 793-7233.

# 2.4.1 Relay Coded DC Track Circuits

#### **WARNING**



THE SINGLE POLARITY DC CODED TRACK CIRCUIT MUST BE CAREFULLY REVIEWED TO ENSURE THAT ALL TRANSMIT AND RECEIVE CODES ARE OF THE SAME POLARITY PRIOR TO INSTALLING ANY 6A342-1 UNIT.

IF THE POLARITY IS IN DOUBT, INSTALL TWO 6A342-3 ISOLATION UNITS AT EACH END OF THE TRACK CIRCUIT USING THE SAME INSTALLATION AS THE DUAL POLARITY CODED TRACK CIRCUIT.

CONTACT SIEMENS MOBILITY, INC. TECHNICAL SUPPORT AT (800) 793-7233 FOR DETAILS.

In Relay Coded DC track circuits, select frequencies of 86 Hz or higher. When using frequencies between 86 Hz and 211 Hz use high transmit level.

#### 2.4.2 Electronic Coded DC Track Circuits

In Electric Coded DC track Circuits, select frequencies of 86 Hz or higher. When using frequencies between 86 Hz and 211 Hz use high transmit level.

# 2.4.3 100 Hz Non-Coded Cab Signal Circuits

In 100 Hz Non-coded Cab Signal Circuits, select frequencies of 156 Hz or higher. Use high transmit level.

#### 2.4.4 60 Hz AC Coded Track or Coded Cab Signal Circuits

In 60 Hz AC Coded Track or Coded Cab Signal Circuits, select 86 Hz or higher. Use high transmit level.

#### 2.4.5 100 Hz AC Coded Track or Coded Cab Signal Circuits

In 100 Hz AC Coded Track or Coded Cab Signal Circuits, select 211 Hz or higher. Use high transmit level.

#### 2.5 TRACK CIRCUIT FREQUENCY SELECTION

Siemens equipment is compatible with most motion sensing and constant warning time units supplied by other manufacturers, provided audio frequency separation and compatibility are maintained.

# **A** WARNING

#### **WARNING**

WHEN SELECTING THE SGCP 4000/MS 4000 TRACK FREQUENCY, ACCOUNT FOR ANY EXISTING AUDIO FREQUENCY TRACK CIRCUIT SIGNALS.

# 2.5.1 Frequency Selection Restrictions

Before selecting the SGCP 4000/MS 4000 frequency, determine if any high-level audio frequency (AF) is present on the track. Avoid using any SGCP 4000/MS 4000 Frequency that is within fifteen percent of any AF signal present. For additional restrictions on the use of overlapping SGCP 4000/MS 4000 frequencies, see paragraph 2.8.

## 2.6 SGCP 4000/MS 4000 APPROACH DISTANCE CALCULATIONS

The approach is defined by the location of the termination shunts.

# 2.6.1 Approach Distance Calculations

#### WARNING

**A** WARNING

THE SGCP 4000/MS 4000 APPROACH DISTANCE CALCULATIONS ARE BASED ON WARNING TIME REQUIREMENTS OF TRACK SPEED TRAINS PLUS THE SYSTEM RESPONSE TIME OF APPROXIMATELY FIVE (5) SECONDS. IN AREAS WHERE POOR SHUNTING IS EXPECTED ADD FIVE (5) SECONDS OF ADDITIONAL APPROACH DISTANCE.

IN APPLICATIONS WITH SHORT APPROACHES, VERIFY THAT THE ISLAND LENGTH (MINIMUM 120 FT / 36.6 M) DOES NOT EXCEED 30 PERCENT (30%) OF THE LONGEST SGCP 4000/MS 4000 APPROACH. IF GREATER THAN 30%, INCREASE THE LENGTH. WHERE NOT POSSIBLE (E.G. INSULATED JOINTS) INCREASE THE APPROACH LENGTH WITH A DUMMY LOAD IN SERIES WITH THE TERMINATION SHUNT. ENSURE THAT THE RESULTING TOTAL LENGTH MEETS THE LENGTH VERSUS FREQUENCY REQUIREMENTS.

Table 2-4: Warning Time vs. Maximum Speed Distance Table (Imperial {MPH-FT/S})

	MAXIMUM SPEED															
N 4 F	21.1		40	45	20	٥٢	1	l			50		00	C.F.	70	7.5
MF		5	10	15	20	25	30	35	40	45	50	55	60	65	70	75
ft/s								88.0	95.3	102.7	110.0					
	I .	1												_		
	1	7	15	22	29	37	44	51	59	66	73	81	88	95	103	110
	2	15	29	44	59	73	88	103	117	132	147	161	176	191	205	220
	3	22	44	66	88	110	132	154	176	198	220	242	264	286	308	330
	4	29	59	88	117	147	176	205	235	264	293	323	352	381	411	440
	5	37	73	110	147	183	220	257	293	330	367	403	440	477	513	550
	10	73	147	220	293	367	440	513	587	660	733	807	880	953	1027	1100
	15	110	220	330	440	550	660	770	880	990	1100	1210	1320	1430	1540	1650
S	20	147	293	440	587	733	880	1027	1173	1320	1467	1613	1760	1907	2053	2200
SECONDS	25	183	367	550	733	917	1100	1283	1467	1650	1833	2017	2200	2383	2567	2750
S	30	220	440	660	880	1100	1320	1540	1760	1980	2200	2420	2640	2860	3080	3300
SE	35	257	513	770	1027	1283	1540	1797	2053	2310	2567	2823	3080	3337	3593	3850
Z	40	293	587	880	1173	1467	1760	2053	2347	2640	2933	3227	3520	3813	4107	4400
TIME IN	45	330	660	990	1320	1650	1980	2310	2640	2970	3300	3630	3960	4290	4620	4950
F	50	367	733	1100	1467	1833	2200	2567	2933	3300	3667	4033	4400	4767	5133	5500
D D	55	403	807	1210	1613	2017	2420	2823	3227	3630	4033	4437	4840	5243	5647	6050
Ž	60	440	880	1320	1760	2200	2640	3080	3520	3960	4400	4840	5280	5720	6160	6600
AR	65	477	953	1430	1907	2383	2860	3337	3813	4290	4767	5243	5720	6197	6673	7150
TOTAL WARNING	70	513	1027	1540	2053	2567	3080	3593	4107	4620	5133	5647	6160	6673	7187	7700
<del> </del>	75	550	1100	1650	2200	2750	3300	3850	4400	4950	5500	6050	6600	7150	7700	8250
0	80	587	1173	1760	2347	2933	3520	4107	4693	5280	5867	6453	7040	7627	8213	8800
-	85	623	1247	1870	2493	3117	3740	4363	4987	5610	6233	6857	7480	8103	8727	9350
	90	660	1320	1980	2640	3300	3960	4620	5280	5940	6600	7260	7920	8580	9240	9900
	95	697	1393	2090	2787	3483	4180	4877	5573	6270	6967	7663	8360	9057	9753	10450
	100	733	1467	2200	2933	3667	4400	5133	5867	6600	7333	8067	8800	9533	10267	11000
	105	770	1540	2310	3080	3850	4620	5390	6160	6930	7700	8470	9240	10010	10780	11550
	110	807	1613	2420	3227	4033	4840	5647	6453	7260	8067	8873	9680	10487	11293	12100
	115	843	1687	2530	3373	4217	5060	5903	6747	7590	8433	9277	10120	10963	11807	12650
	120	880	1760	2640	3520	4400	5280	6160	7040	7920	8800	9680	10560	11440	12320	13200

Note: Where the length of the track is known, the Total Warning Time In Seconds can be determined by dividing the length in feet by the "Feet/Sec" at the train speed selected.

Table 2-5: Warning Time vs. Maximum Speed Distance Table (Metric {KPH-M/S})

MAXIMUM SPEED																
KF	РН	5	10	15	20	25	30	40	50	60	70	80	90	100	110	120
m		1.388	2.77	4.166	5.6	6.9	8.3	11.1	13.9	16.7	19.4	22.2	25.0	27.8	30.6	33.3
DISTANCE TRAVELED IN METERS							•	•								
	1	1	3	4	6	7	8	11	14	17	19	22	25	28	31	33
	2	3	6	8	11	14	17	22	28	33	39	44	50	56	61	67
	3	4	8	13	17	21	25	33	42	50	58	67	75	83	92	100
	4	6	11	17	22	28	33	44	56	67	78	89	100	111	122	133
	5	7	14	21	28	35	42	56	69	83	97	111	125	139	153	167
	10	14	28	42	56	69	83	111	139	167	194	222	250	278	306	333
	15	21	42	63	83	104	125	167	208	250	292	333	375	417	458	500
တ	20	28	56	83	111	139	167	222	278	333	389	444	500	556	611	667
SECONDS	25	35	69	104	139	174	208	278	347	417	486	556	625	694	764	833
ဝ္ပ	30	42	83	125	167	208	250	333	417	500	583	667	750	833	917	1000
SE	35	49	97	146	194	243	292	389	486	583	681	778	875	972	1069	1167
	40	56	111	167	222	278	333	444	556	667	778	889	1000	1111	1222	1333
믵	45	63	125	188	250	313	375	500	625	750	875	1000	1125	1250	1375	1500
F	50	69	139	208	278	347	417	556	694	833	972	1111	1250	1389	1528	1667
TOTAL WARNING TIME IN	55	76	153	229	306	382	458	611	764	917	1069	1222	1375	1528	1681	1833
Į	60	83	167	250	333	417	500	667	833	1000	1167	1333	1500	1667	1833	2000
AR.	65	90	181	271	361	451	542	722	903	1083	1264	1444	1625	1806	1986	2167
>	70	97	194	292	389	486	583	778	972	1167	1361	1556	1750	1944	2139	2333
I₹	75	104	208	313	417	521	625	833	1042	1250	1458	1667	1875	2083	2292	2500
<u>6</u>	80	111	222	333	444	556	667	889	1111	1333	1556	1778	2000	2222	2444	2667
'	85	118	236	354	472	590	708	944	1181	1417	1653	1889	2125	2361	2597	2833
	90	125	250	375	500	625	750	1000	1250	1500	1750	2000	2250	2500	2750	3000
	95	132	264	396	528	660	792	1056	1319	1583	1847	2111	2375	2639	2903	3167
	100	139	278	417	556	694	833	1111	1389	1667	1944	2222	2500	2778	3056	3333
	105	146	292	438	583	729	875	1167	1458	1750	2042	2333	2625	2917	3208	3500
	110	153	306	458	611	764	917	1222	1528	1833	2139	2444	2750	3056	3361	3667
	115	160	319	479	639	799	958	1278	1597	1917	2236	2556	2875	3194	3514	3833
	120	167	333	500	667	833	1000	1333	1667	2000	2333	2667	3000	3333	3667	4000

Note: Where the length of the track is known, the Total Warning Time in Seconds can be determined by dividing the length in meters by the "Meters/Sec" at the train speed selected.

NOTE

NOTE

System response time is approximately 5 seconds.

The approach distance for a SGCP 4000/MS 4000 installation with or without an island circuit is the distance from the SGCP 4000/MS 4000 track wire connections on the rail to the termination shunt connections. Figure 2-1 provides a depiction of approach distances. The required approach distance is calculated using the following factors:

- Maximum speed of trains through the approach in feet per second/meters per second.
- Highest crossing warning time requirement in seconds. This is based on maximum train speed as well as the SGCP 4000/MS 4000 response time in seconds.

# 2.6.2 Approach Distance Calculation Example




Figure 2-1: Approach Distance

#### Given:

- Speed Conversion Factor:
- 1 mile per hour (MPH) = 1.47 feet per second (ft/s)
- 1 kilometer per hour (KPH) = 0.28 meters per second (m/s)
  - Maximum train speed = 50 MPH or 80 KPH
  - Typical SGCP 4000/MS 4000 response time = 5 seconds
  - Total warning time = 30 seconds

#### Conversion Formulas:

- Maximum train speed:
- Measured in ft/s = speed in MPH multiplied by 1.47
- Measured in m/s = speed in KPH multiplied by 0.28
  - Total approach time = Typical SGCP 4000/MS 4000 response time plus (+) Total warning time
  - Total approach distance = maximum train speed in ft/s multiplied by total approach time
  - Calculations:
  - Maximum train speed:

- 50 MPH X 1.47 = 73.3 ft/sec
- 80 KPH X 0.28 = 22.2 m/s
  - Total approach time = 5 seconds + 30 seconds = 35 seconds
  - Required approach distance:
- 73.3 ft/sec X 35 seconds = 2566.9 feet
- 22.2 m/s X 35 seconds = 778 meters



#### **NOTE**

The required approach distance is the distance from the island track wires to the termination shunt. Refer to the above figure for further information.

#### 2.7 USING NARROW-BAND SHUNTS AND OVERLAPPING APPROACHES

When crossings are close together, it may be necessary to overlap the SGCP 4000/MS 4000 approaches as well as use adjacent SGCP 4000/MS 4000 frequencies. Restrictions on the use of adjacent SGCP 4000/MS 4000 frequencies and the type of termination shunt used are covered in the following paragraphs.

# 2.7.1 Using Narrow-Band Termination Shunts

A narrow-band shunt must be used to terminate each overlapping approach as shown in Figure 2-2.




Figure 2-2: Overlapping Approaches

# 2.7.2 Types of Narrow-Band Shunts

The following sections detail the types of narrow-band shunts can be used with the SGCP 4000/MS 4000.

## 2.7.3 62775 Single Frequency Narrow-Band Shunt

Primary termination shunt for both bidirectional and unidirectional applications. The 62775-f Single Frequency Narrow Band Shunt is available in the following termination frequencies:

Table 2-6: 62775-f Single Frequency Narrow Band Shunt Available Frequencies

86	156	267	392	525	686	881
100	172	285	430	560	753	970
114	210	326	452	630	790	979
151	211	348	521.2	645	816	

Siemens standard SGCP 4000/MS 4000 frequencies are shown in **bold**.



## **WARNING**

THE 62775 NARROW-BAND SHUNT CANNOT BE USED IF A SGCP 4000/MS 4000 APPROACH OVERLAPS A MODEL 300 OR MODEL 400 GCP APPROACH. USE THE 62780 SHUNT INSTEAD.

# 2.7.4 62775 Multi-frequency Narrow-Band Shunt

The 62775 Multi-frequency Narrow Band Shunt is the primary multi-frequency termination shunt for both bidirectional and unidirectional applications. The shunts are available in the termination frequencies shown in Table 2-7.

Table 2-7: Multi-frequency Narrow-band Shunt, 62775

SHUNT PART NUMBER	FREQUENCY (HZ)	SHUNT PART NUMBER	FREQUENCY (HZ)
	86		211
	114		285
62775-8621	156	62775-2152	348
	044		430
	211		525
	156		348
	211		430
00775 4540	285	00775 0407	525
62775-1543	348	62775-3497	645
	400		790
	430		970

#### 2.7.5 62780-f Narrow-band Shunt

The 62780-f Narrow-band Shunt is used in overlapping areas where adjacent frequency narrow-band shunts produce excessive loading when used with the 62775 shunt. It produces less loading effect on adjacent frequencies than 62775-f narrow-band shunt but does not terminate as well as 62775-f narrow-band shunt. The 62780-f Narrow-band Shunt is used in installations with overlapping Model 300 and Model 400 GCP approaches and is available in the frequencies listed for the 62775-f narrow-band shunt except 172 Hz.

# 2.7.6 Adjacent Frequency Use in Overlapping Bidirectional or Directionally wired Approaches

When overlapping two or more adjacent SGCP 4000/MS 4000 frequencies in bidirectional and directionally wired applications the frequency of the overlapping narrow-band termination shunt must be selected to ensure optimum SGCP 4000/MS 4000 operation. The acceptable adjacent narrow-band shunt frequency is determined by the length of the approach, the track frequency of the approach, and the location of the overlapping termination shunts in their respective approaches.

Charts using these factors are provided to determine if the selected adjacent frequency narrow-band shunt locations are allowed for use in your application.

- Charts for 62775-f narrow-band shunt are shown in Figure 2-3, Figure 2-4, and Figure 2-5.
- Charts for 62780-f narrow-band shunt are shown in Figure 2-6, Figure 2-7, and Figure 2-8.
- A chart is provided for each SGCP 4000/MS 4000 crossing frequency with its adjacent frequency acceptance information.
- Each chart relates approach distance with the distance from the track wires to the adjacent approach narrow-band shunt
- Shading indicates the distance area near the SGCP 4000/MS 4000 track wires that adjacent frequency narrow-band shunt distances should not be used.

# 2.7.7 Adjacent Frequency Narrow-Band Shunt Distance Example

As an example, a crossing SGCP 4000/MS 4000 is operating at 114 Hz with bidirectional approaches set at 4000 feet (121.90 meters). The overlapping approach narrow-band frequency is 86 Hz. (The 62775-f Narrow Band Shunt chart for 114 Hz with adjacent frequencies of 86 and 156 Hz is shown in Figure 2-3, sheet 1).

The 114 Hz chart shows that 62775-f Narrow-band Shunts for 86 Hz should be located no closer than 1,000 feet (304.8 meters) to the 114 Hz SGCP 4000/MS 4000 track wires.

If a 62780 shunt is used at 86 Hz (see Figure 2-6) the chart shows the 62780 shunt should be located no closer than 300 feet (91.4 meters) to the 114 Hz SGCP 4000/MS 4000 track wires.


#### 2.7.8 Adjacent Frequency Use with Unidirectional Applications

When adjacent SGCP 4000/MS 4000 operating frequencies are used for overlapping unidirectional approaches, narrow-band shunts can be used in accordance with the following:

- Adjacent frequency shunts 62775 should only be located in the outer 50% of a unidirectional approach.
- When closer than 50%, change the unidirectional application to bidirectionally wired operation and use Figure 2-3 to determine the allowable shunt location.

2-10

SIG-00-11-02 Version No.: A.8



Adjacent Frequency 62775 f Narrow hand Shunt Blacement Charte

Figure 2-3: Adjacent Frequency 62775-f Narrow-band Shunt Placement Charts, Bidirectional and Directionally wired Application (Sheet 1 of 3)




Figure 2-4: Adjacent Frequency 62775-f Narrow-band Shunt Placement Charts, Bidirectional and Directionally wired Application (Sheet 2 of 3)




Figure 2-5: Adjacent Frequency 62775-f Narrow-band Shunt Placement Charts, Bidirectional and Directionally wired Application (Sheet 3 of 3)




Figure 2-6: Adjacent Frequency 62780-f Narrow-band Shunt Placement Charts, Bidirectional and Directionally wired Application (Sheet 1 of 3)

SIG-00-11-02

Version No.: A.8




Figure 2-7: Adjacent Frequency 62780-f Narrow-band Shunt Placement Charts, Bidirectional and Directionally wired Application (Sheet 2 of 3)




Figure 2-8: Adjacent Frequency 62780-f Narrow-band Shunt Placement Charts, Bidirectional and Directionally wired Application (Sheet 3 of 3)

SIG-00-11-02 REVISED MARCH 2022 Version No.: A.8

#### 2.8 REPEATING SGCP 4000/MS 4000 OPERATING FREQUENCIES

## 2.8.1 Insulated Joints Requirements

In general, do not operate two SGCP 4000/MS 4000s at the same frequency on a common track unless the units are separated by insulated joints. If necessary, frequencies can be repeated without insulated joints, provided the SGCP 4000/MS 4000 approaches do not overlap and the minimum separation distances specified in Table 2-8 exist between termination shunts, and/or one of the SGCP 4000/MS 4000s uses an offset frequency. In some cases of extremely high ballast conditions, it may not be possible to repeat the frequencies without insulated joints.

### NOTE

NOTE

The distances specified in Table 2-8 vary according to frequency and type of terminating shunt.

Use greater distances between shunts where possible. When repeating frequencies in the same block section where the approaches do not overlap, set one SGCP 4000/MS 4000 track frequency as normal and the other to the lower offset frequency.

Example: When a frequency of 285 Hz is selected, set one SGCP 4000/MS 4000 to 285 Hz and the other to 284 Hz.

Table 2-8: Minimum Distance Between Termination Shunts When Repeating SGCP 4000/MS 4000

Operating Frequencies

- Francis : reduction					
STANDARD SGCP 4000/MS 4000 FREQUENCY (HZ)	SEPARATION DISTANCE IN FT (METERS) 62775-F & 62780-F NBS / 8A076A WIDEBAND SHUNTS				
86	5200/1200 (1585.0/365.8)				
114	4500/1000 (1371.6/304.8)				
156	3500/750 (1066.8/228.6)				
211	3000/450 (914.4/137.2)				
285	2000/225 (609.6/68.6)				
348	500/150 (152.4/45.7)				
430	400/100 (121.9/30.5)				
525	350/75 (106.7/22.9)				
645	300/50 (91.4/15.2)				
790	250/25 (76.2/7.6)				
970	250/25 (76.2/7.6)				

#### 2.9 TERMINATION SHUNTS

Termination shunts are required for all SGCP 4000/MS 4000 installations. They must be connected across the rails at sufficient distances from the SGCP 4000/MS 4000 track wire connection points to provide full crossing warning system operating time (see paragraph 2.6).

#### **WARNING**



WHEN ADDING OR REPLACING TERMINATION SHUNTS, APPROPRIATE TESTS MUSTS BE MADE TO DETERMINE THAT THE TERMINATION SHUNT DID NOT ADVERSELY AFFECT OTHER HIGHWAY CROSSING WARNING SYSTEM OR WAYSIDE SIGNAL SYSTEM TRACK CIRCUITS.

#### 2.9.1 Hard-Wire Shunt

Use a hard-wire shunt only when no other signals (AC or DC) are present on the rails.

#### 2.9.2 Wideband Shunt

Use the Wideband shunt only with steady energy DC track circuits and no other AC signals present on the rails. The Siemens part number for the Wideband Shunt is 8A076A



#### NOTE

The use of dual wideband couplers, part number 8A077, is not required for SGCP 4000/MS 4000 4000 applications.

#### 2.9.3 Narrow-Band Shunts

Use a Narrow-band Shunt when other AC signals or coded AC or DC is present on the rails; this includes a shunt enhancer panel (80049) if one is being used at the crossing.

## 2.9.4 62775 Single-Frequency Narrow-Band Shunt

The 62775 Single-Frequency Narrow-band Shunt is the primary termination shunt for both bidirectional and unidirectional applications, and is available in the following fixed termination frequencies:

Table 2-9: Narrow-band Shunt, 62775, Fixed Termination Frequencies

86	151	210	285	392	521.2	630	753	881
100	156	211	326	430	525	645	790	970
114	172	267	348	452	560	686	816	979

Siemens standard SGCP 4000/MS 4000 frequencies are shown in  $\boldsymbol{bold}.$ 

525

645 790

970

## 2.9.5 62775 Multi-frequency Narrow-Band Shunt

The 62775 Multi-frequency Narrow-band Shunt is available in four multi-frequency versions (see Table 2-10). The frequency is selected by means of seven standard AREMA terminals. The Siemens part number is 62775-XXXX.

**SHUNT FREQUENCY** SHUNT **FREQUENCY PART** (HZ) PART (HZ) NUMBER NUMBER 86 211 114 285 62775-8621 156 62775-2152 348 430 211 525 156 348 211 430

62775-3497

Table 2-10: Multi-frequency Narrow-band Shunt, 62775

#### 2.9.6 62780-f Narrow-Band Shunt

62775-1543

The 62780-f Narrow-Band Shunt is used in territories where overlapping adjacent frequency 62775-f Narrow-Band Shunts produce too much loading effect. The 62780-f NBS must be used when overlapping into Model 300 and Model 400 GCP approaches. The 62780-f NBS produces less loading effect on adjacent frequencies than the 62775-f Shunt does.

The 62780-f Narrow-band Shunt is available in the following fixed termination frequencies:

285

348

430

Table 2-11: 62780-f Narrow-band Shunt Fixed Termination Frequencies

86	151	211	326	430	525	645	790	970
100	156	267	348	452	560	686	816	979
114	210	285	392	521.2	630	753	881	

Siemens standard SGCP 4000/MS 4000 frequencies are shown in **bold**.

## 2.9.7 62780 Multi-frequency Narrow-Band Shunt



#### WARNING

THE 62780 NBS MUST BE USED WHEN OVERLAPPING INTO MODEL 300 AND MODEL 400 GCP APPROACHES.

The 62780 Multi-frequency Narrow-band Shunt is used in territories where overlapping adjacent frequency 62775 Narrow-band Shunts provide too much loading effect. It is available in three multi-frequency versions, as depicted in Table 2-12. The frequency is selected by means of seven standard AREMA terminals.

Table 2-12: 62780 Multi-frequency Narrow-band Shunt

SHUNT PART NUMBER	FREQUENCY (HZ)	SHUNT PART NUMBER	FREQUENCY (HZ)
	86		156
62780-8621	114		211
	156		285
	211	00700 4540	348
	525 62780-1543	62780-1543	
62780-5297	645		430
	790		
	970		

#### 2.9.8 Termination Shunt Installation

On open track locate termination shunts near the rail with leads as short as practical. Where not at insulated joints avoid wire runs of over 25 feet (7.62 meters). Shunt wires should be 6 AWG.

To afford maximum protection from physical damage, place Wideband and Narrow-band Shunts in a protective enclosure or buried at an appropriate depth, but it is not necessary to bury shunt below the frost line. At insulated joints the termination shunt may be located within the house or signal enclosure.





The A62776 MS/SGCP 4000/MS 4000 Termination Shunt Burial Kit protects shunts while they are buried.

For additional information on Siemens shunts and the A62776 Burial Kit, refer to Section 5, Auxiliary Equipment.

## 2.10 COUPLING AROUND INSULATED JOINTS

Track separated by insulated joints can be coupled only under the specific conditions described in the following paragraphs.

## WARNING

THE FEEDPOINT INSULATED JOINTS OF A UNIDIRECTIONAL OR A DIRECTIONALLY WIRED APPROACH MUST NOT BE BYPASSED WITH ANY COUPLING DEVICE.

USE ONLY INSULATED JOINT BYPASS COUPLER, 62785 F WITH THE SGCP 4000/MS 4000.



WHEN AC TRACK CIRCUITS OR CAB SIGNALS ARE PRESENT, DO NOT COUPLE AROUND THE INSULATED JOINTS WITH ANY TYPE OF COUPLER.

LEAD WIRE LENGTH SHOULD NOT EXCEED 10 FEET (3.05 METERS) AND SHOULD NOT BE SMALLER THAN 6 AWG.

WHEN ADDING OR REPLACING INSULATED JOINT COUPLERS, APPROPRIATE TESTS MUSTS BE MADE TO DETERMINE THAT THE INSULATED JOINT COUPLER DID NOT ADVERSELY AFFECT OTHER HIGHWAY CROSSING WARNING SYSTEM OR WAYSIDE SIGNAL SYSTEM TRACK CIRCUITS.

## 2.10.1 Bypassing Insulated Joints Using Wideband Shunt

The 8A076A Wideband Shunt presents low impedance to all SGCP 4000/MS 4000 frequencies and any other audio signals present. It is only for use with steady energy DC track circuits

# **A** WARNING

#### WARNING

THE 8A076A WIDEBAND SHUNT MUST NOT BE USED TO BYPASS INSULATED JOINTS IN DC CODED TRACK CIRCUITS, AC TRACK CIRCUITS, AND/OR CODED AC TRACK CIRCUITS.

#### NOTE

The use of dual wideband couplers, part number 8A077, is not required for SGCP 4000/MS 4000 applications.



A total of five sets of insulated joints can be bypassed in an approach using a wideband shunt.

When insulated joints are located very near the crossing and are bypassed with wideband shunts, if possible, place the SGCP 4000/MS 4000 island circuit track wire connections to the rails beyond the insulated joints.

This includes the wideband shunts in the actual island circuit.

## 2.10.2 Tunable Insulated Joint Bypass Coupler

The 62785-f Tunable Insulated Joint Bypass Coupler Is available in the standard Siemens operating frequencies of 156 Hz through 970 Hz. The coupler must be located within 10 feet (3.0 meters) of the insulated joints that it is coupling. It can be used in SGCP 4000/MS 4000 applications that require using an insulated joint bypass coupler as long as:

- No CAB signals, AC, or coded AC track circuits are present.
- In DC coded track circuits, the insulated joints within an approach can be bypassed using the 62785-f coupler, provided the minimum distances specified in Table 2-13 are observed.
- As a general rule, a maximum of two sets of insulated joints in each approach can be bypassed using the 62785-f.
- The 62785-f coupler must be field adjusted to pass the SGCP 4000/MS 4000 operating frequency around the insulated joints, as field tuning enables precise frequency adjustment for proper SGCP 4000/MS 4000 operation.
- The 62785-f couplers must be adjusted in conjunction with SGCP 4000/MS 4000 calibration.
- In motion sensor applications only, you can use the 62785-f coupler when insulated joints are located in general anywhere within the approach. When used in a motion sensor application, the 62785-f couplers must be adjusted in conjunction with SGCP 4000/MS 4000 calibration

#### WARNING

THE MINIMUM DISTANCES TO THE INSULATED JOINTS SPECIFIED IN TABLE 2 13 APPLY ONLY TO SIEMENS MOBILITY, INC. SGCP 4000/

MS 4000S.



WHEN THE SGCP 4000/MS 4000 IS PROGRAMMED AS A PREDICTOR, APPLICATION RULES FOR THE 62785-F ARE SPECIFIED IN THE TABLE 2 13. WHEN APPROACH LENGTHS ARE SHORTER THAN THOSE SPECIFIED IN TABLE 2 13, THE 62785-F COUPLER MUST NOT BE LOCATED WITHIN THE INNER TWO-THIRDS OF THAT APPROACH.

USE ONLY THE INSULATED JOINT BYPASS COUPLER, 62785 F WITH THE SGCP 4000/MS 4000.

TUNED COUPLERS CANNOT BE USED TO BYPASS INSULATED JOINTS IN CAB SIGNAL OR AC TRACK CIRCUITS.

Table 2-13: Minimum Distance to Insulated Joints Bypassed With The 62785-f Coupler

FREQUENCY (HZ)	MINIMUM DISTANCE TO 1 <sup>ST</sup> SET OF INSULATED JOINTS IN FEET (METERS) <sup>*</sup>	MINIMUM DISTANCE TO 2 <sup>ND</sup> SET OF INSULATED JOINTS IN FEET (METERS) <sup>†</sup>
151 to 211	1500 (457.2)	2200 (670.6)
212 to 348	1000 (304.8)	1400 (426.7)
349 to 560	700 (213.4)	1000 (304.8)
561 to 790	500 (152.4)	800 (243.8)
791 to 979	400 (121.9)	700 (213.4)

<sup>\*</sup> Distance applies to insulated joints located on the same side of the crossing.

NOTE: Frequencies of 86 and 114 Hz are not normally used with the 62785-f coupler. Contact Siemens Mobility, Inc. Technical Support at 1-800-793-7233 for these applications.

## 2.11 INSTALLING BYPASS SHUNTS AND COUPLERS

When installing wide band shunts and tuned couplers to bypass insulated joints, connect the devices directly to the rails with leads as short as practical and encase the devices in a protective enclosure or buried at an appropriate depth as shown in Figure 2-9.




Figure 2-9: Insulated Joint, Shunt, or Coupler Installation

NOTE

## NOTE

The A62776 MS/SGCP 4000/MS 4000 Termination Shunt Burial Kit is designed to protect shunts while they are buried. For additional information, refer to Section 5, Auxiliary Equipment.

## 2.12 ISLAND CIRCUITS

The SGCP 4000/MS 4000 provides a high frequency island track circuit with excellent cutoff and shunting characteristics under varying ballast conditions.

## 2.12.1 Island Circuit Approach Length

Siemens Mobility, Inc. recommends that the minimum length of an island track circuit should be 120 feet (36.6 meters) between track connections, or longer if required to ensure island circuit shunting for the operating car fleet and to comply with the operating practices of the railroad. To ensure proper SGCP 4000/MS 4000 operation, the maximum island length (measured between the track wire connections on either side of the crossing) should be 350 feet (106.7 meters) and must not exceed 30 percent of the longest SGCP 4000/MS 4000 approach. The 30 percent figure applies to approach circuits that are 1,000 feet (304.8 meters) or shorter.




Figure 2-10: Determining Island Approach Length

For SGCP 4000/MS 4000 track approaches utilizing an internal island and with track approaches that are less than 800 feet (243.8m), it is permissible to connect the RX and RX CHK wires to the same pair of track wires from the crossing house. This activity will provide a similar benefit to making a six-wire connection for remote applications.

In applications that cannot meet either of the above guidelines, either:

- Use a standard six-wire connection where the SGCP 4000/MS 4000 RX CHK wires are connected to the TX wires adjacent to the track side connections, or
- Extend or lengthen the approach(es) to a length that meets the 30% rule. This may be accomplished either by extending the approaches or adding dummy loads in series with the termination shunts.

## 2.12.2 Track Circuit Compatibility

The SGCP 4000/MS 4000 Island is compatible with most track circuits, including DC and AC coded track.

## 2.12.3 Island Frequencies

Table 2-14: SGCP 4000/MS 4000 Island Frequencies (kHz)

2.14	3.24	4.90	7.10	10.00	13.20	17.50
2.63	4.00	5.90	8.30	11.50	15.20	20.20

#### WARNING



AT MULTIPLE TRACK INSTALLATIONS, USE DIFFERENT FREQUENCIES FOR EACH ISLAND CIRCUIT.

IN THE SAME TRACK SECTION, DO NOT REPEAT ISLAND FREQUENCIES WITHIN 5000 FEET (1524.0 METERS), UNLESS SEPARATED BY INSULATED JOINTS.

ON ADJACENT TRACKS, DO NOT REPEAT ISLAND FREQUENCIES WITHIN 1500 FEET (457.2 meters).

NOTE

## NOTE

Use frequencies of 10.0 kHz and lower when required island length is over 200 feet (61.0 meters), or lumped ballast loading at the street is anticipated.

## 2.12.4 Island Shunting Sensitivity

The island can be calibrated to respond to a shunting sensitivity of 0.12, 0.3, 0.4 or 0.5 ohms. A hardwire shunt is used for calibration.

#### NOTE

NOTE

The island circuit shunting sensitivity adjustment procedure is in Section 7.3.8, Calibrating the SGCP 4000/MS 4000.

Island track circuit calibration is generally performed using 0.12 ohm shunting sensitivity. In an area where poor shunting is experienced or anticipated, a minimum of 0.3-ohm shunting sensitivity is recommended.

In areas of passenger operation, a minimum of 0.3-ohm shunting sensitivity is recommended.

## 2.12.5 Island Circuit Wiring

Use #6 AWG for track wires. Use twisted pair wires with at least two turns per foot for connections between the track and the SGCP 4000/MS 4000 bungalow. Provide as much separation between transmit and receive wire pairs as practical. Total wire length from the bungalow to transmit wire rail connections and bungalow to receive wire connections should not exceed 600 ft. (182.9m).



### **CAUTION**

USE PROPER PRIMARY SURGE PROTECTION ON THE TRACK WIRES, SGCP 4000/MS 4000 BATTERY WIRES, AND ALL SGCP 4000/MS 4000 LINE CIRCUITS.

### 2.13 TRACK CONNECTIONS

Track wire (lead) connection requirements are based on the track circuit configuration and the distance between the SGCP 4000/MS 4000 bungalow and the transmitter lead connections at the track.

#### WARNING



WHEN ANY EXTERNAL TRACK CIRCUIT EQUIPMENT OR AUXILIARY TRACK CIRCUIT EQUIPMENT SHARES TRACK WIRES WITH A SGCP 4000/MS 4000 TRACK CIRCUIT THAT DOES NOT HAVE AN ACTIVE INTERNAL ISLAND FOR THAT TRACK CIRCUIT OR OUTPUT, SUCH AS A DAX OR PRIME PREDICTION OFFSET, THEN THE TRACK CIRCUIT EQUIPMENT MUST BE CONNECTED IN ACCORDANCE WITH PARAGRAPH 2.13.7.

## 2.13.1 Four-Wire Connections For Bidirectional Applications

In most installations where a SGCP 4000/MS 4000 is operating at a crossing, four track leads (wires) connect the SGCP 4000/MS 4000 to the track. Two transmitter leads are connected on the side of the crossing nearest the instrument bungalow. The transmitter leads must be as short as possible and not exceed the maximum lengths specified in Table 2-15. Two receiver leads are connected to the rails on the opposite side of the crossing. Two check channel receiver leads are routed to the surge panel where they are connected to the corresponding transmitter leads as shown in Figure 2-11.



### **CAUTION**

THE MAXIMUM TRANSMITTER LEAD LENGTHS SPECIFIED IN Table 2 15 ARE FOR THE TRANSMITTER PAIR OF WIRES MEASURED BETWEEN THE BUNGALOW AND THE RAILS CONNECTIONS. FAILURE TO DO SO MAY RESULT IN CHECK RECEIVER ERRORS AND FALSE ACTIVATION.




Figure 2-11: Track Lead Connections

2-26

SIG-00-11-02 REVISED MARCH 2022 Version No.: A.8

Table 2-15: Maximum Transmitter Track Wire Length For 4-Wire Applications

STANDARD SIEMENS SGCP 4000/MS 4000 FREQUENCY (HZ)	MAXIMUM TRANSMIT LEAD LENGTH IN FEET (METERS)
86	100 (30.5)
114	125 (38.1)
156	150 (45.7)
211	200 (61.0)
285-970	250 (76.2)

# 2.13.2 Four Track Wire Unidirectional and Directionally Wired Applications Rail Connections

In unidirectional or directionally wired installations, locate the transmitter leads adjacent to the insulated joints wherever possible.

## 2.13.3 Track Lead Routing

Track wires are routed between the SGCP 4000/MS 4000 track connectors on the 4000 front panel and the Surge Panel and between the Surge Panel and the rails as shown in Figure 2-11. The leads between the SGCP 4000/MS 4000 and the Surge Panel use number 16 AWG to 12 AWG wire. The transmitter and receiver leads between the Surge Panel and the rails must be twisted and have a minimum wire size of number 6 AWG





When using an island circuit, physically separate the SGCP 4000/MS 4000 transmitter pair as far as practical from the receiver pair, both below ground and within the bungalow. When splicing track wire connections, use a crimped or welded splice.

#### 2.13.4 Track Lead Length

In general, limit the total track lead length to 600 feet (182.9 meters), where possible. This includes the actual length of the transmitter and the receiver twisted pairs added together. Twist each pair of wires at least two turns per foot. Track lead length is measured from the bungalow to the rail connections.

#### 2.13.5 Six-Wire Connections

When the transmit leads must exceed the maximum lengths specified in Table 2-15, a six-wire track hookup must be used. In a six-wire hookup, the maximum wire length allowed is 3500 feet (1066.8 meters).

## 2.13.6 Six-Wire Transmitter and Check Receiver Track Connection Requirements

In a six-wire application there must be a six-wire to four- wire conversion near the rail connection so that only two transmitter wires and two receive wires are actually connected to the track. Each of the two Check wires must be connected to the corresponding Transmitter wire:

- Within 25 feet (7.62 meters) of the rail connections.
- Outside the ballast line or area damaged by track machinery.
- Both transmitter/check pairs are connected to the rail by single wires.
- A typical SGCP 4000/MS 4000 six-wire to four-wire conversion operating in unidirectional mode is shown in Figure 2-12.

#### **WARNING**



IN A SIX-WIRE APPLICATION, TWO CHECK WIRES ARE CONNECTED TO THE CORRESPONDING TRANSMITTER TRACK WIRES IN THE UNDERGROUND TO PROVIDE REMOTE SENSING OF THE TRANSMIT SIGNAL. THE CONNECTION IS MADE WITHIN 25 FEET (7.62 METERS) OF THE TRANSMITTER FEED POINTS BUT NOT AT THE RAIL CONNECTIONS AND NOT WHERE THE CONNECTION CAN BE DAMAGED BY TRACK MACHINERY OR DRAGGING EQUIPMENT.

THE CORRESPONDING XMT AND CHK WIRES MUST BE CONNECTED TOGETHER AS SHOWN IN FIGURE 2 12.

ENSURE THAT THE CORRESPONDING XMT AND RCV WIRES ARE NOT CONNECTED TOGETHER OR OPEN TRACK WIRE DETECTION WILL NOT OPERATE CORRECTLY.

THE LOCATION OF THE TRANSMITTER/CHECK CONNECTION SHOULD BE LOCATED AWAY FROM THE TRACK AND IN A MANNER THAT MINIMIZES THE RISK OF THE CHECK AND RECEIVE WIRES BEING DAMAGED SIMULTANEOUSLY BY TRACK MACHINERY OR DRAGGING EQUIPMENT.

WHEN ANY EXTERNAL TRACK CIRCUIT EQUIPMENT OR AUXILIARY TRACK CIRCUIT EQUIPMENT SHARES TRACK WIRES WITH A SGCP 4000/MS 4000 TRACK CIRCUIT THAT DOES NOT HAVE AN ACTIVE INTERNAL ISLAND FOR THAT TRACK CIRCUIT OR OUTPUT, SUCH AS A DAX OR PRIME PREDICTION OFFSET, THEN THE TRACK CIRCUIT EQUIPMENT MUST BE CONNECTED IN ACCORDANCE WITH SECTION 2.13.7.




Figure 2-12: Six-Wire To Four-Wire Conversion

## 2.13.7 Sharing Track Wires with External Track Circuit Equipment

When any external track circuit equipment or auxiliary track circuit equipment shares track wires with a SGCP 4000/MS 4000/MS track circuit that does not have an active internal island for that track circuit or output, such as a UAX or External Island, then the track circuit equipment must be connected in one of two ways:

- The external track circuit equipment or auxiliary track circuit equipment may be connected across the receiver wires directly, or
- When connected to the Transmitter/Check Receiver wires the external track circuit equipment or auxiliary track circuit equipment must be connected as identified in paragraphs 2.13.8 and 2.13.9.

#### 2.13.8 Six-Wire Connections

The external equipment must be connected to the Check Receiver wires only (refer to Figure 2-14, SGCP 4000/MS 4000 #2).



#### WARNING

FOR 6 WIRE CONNECTIONS, DO NOT CONNECT ANY EXTERNAL TRACK CIRCUIT EQUIPMENT ACROSS THE TRANSMITTER WIRES.

### 2.13.9 Four-Wire Connections

The Check Channel Receiver wires may connect either to the Transmitter wires at the same point or prior to connecting to the other track circuit equipment (refer to Figure 2-13), or the Check Channel Receiver wires may connect to the external track circuit equipment prior to connecting to the transmitter track wires (refer to Figure 2-14, SGCP 4000/MS 4000 #1)

## WARNING



DO NOT CONNECT ANY EXTERNAL TRACK CIRCUIT EQUIPMENT ACROSS THE TRANSMITTER PRIOR TO CONNECTING IT TO THE CHECK CHANNEL RECEIVER WIRES.

CONNECTIONS MUST BE ARRANGED SO THAT AN OPEN WIRE OR OPEN CONNECTION WILL NOT RESULT IN THE TRANSMITTER WIRES BEING CONNECTED TO THE AUXILIARY TRACK CIRCUIT EQUIPMENT UNLESS THE CHECK RECEIVER IS ALSO CONNECTED (REFER TO FIGURE 2-13).

#### NOTE



External track circuit equipment includes, but is not limited to, 80049 DC Exciter Panels, Electronic Coded Track, AFO Track circuits, Track batteries or relays, surge suppressors (not including air gap arresters) or Bidirectional Simulation Couplers.




Figure 2-13: Proper Connections of Track Wires




Figure 2-14: Proper 4-Wire & 6-Wire Connections When Using Auxiliary Track Circuit Equipment

#### NOTE

Customer Service Bulletin 4-94, dated 3-8-94, concerned multiple track wire failures and it recommended connecting the transmitter and check receiver track wires "at or near the bootleg connection and then running a single wire to the rails. The single wire was limited to a maximum of 50 feet (15.2 meters).

NOTE

Customer Service Bulletin 3-06B.01, dated 12-8-06, amended 12/19/06, indicates in Figures 2 and 3 that "the CHK wires are connected to the XMT wires within 25 feet (7.62 meters) of the track feed points, but not at the rail connections."

Current practice is to connect the CHK and XMT wires within 25 feet (7.62 meters) of the track feed points, which further reduces the potential for check receiver errors. Existing locations that are between 25 and 50 feet (7.62 – 15.24 meters) and do not experience check receiver errors may remain at their location.

## 2.14 TRACK CIRCUIT ISOLATION DEVICES

Several types of track circuit isolation devices are available for both DC and AC coded track applications. The following discussions are grouped by non-coded and coded track circuit type.

#### NOTE

NOTE

The recommendations listed in the following paragraphs are general in nature and no attempt is made to cover all applications. See Section 5, Auxiliary Devices, for additional information on the available track circuit isolation devices.

Battery chokes and code isolation devices described here are designed for mounting inside a weatherproof enclosure.

If there are any questions concerning these recommendations or applications, contact Siemens Mobility, Inc. Technical Support for assistance.

## 2.14.1 Steady Energy DC Track Circuits

A DC track circuit should be equipped with a battery choke when its battery is located within the SGCP 4000/MS 4000 approach or it is less than 1,000 feet (304.8 meters) beyond the approach termination.

## NOTE



If the track connections for the DC track circuit are 1,000 feet or (304.8 meters) more beyond the SGCP 4000/MS 4000 approach termination shunt, a battery choke is not required (see Section 5, Auxiliary Equipment).

## 2.14.2 Battery Chokes

#### **WARNING**



IN APPLICATIONS WHERE THE CHOKE IS LOCATED WITHIN AN ADJACENT MODEL 300 OR MODEL 400 GCP APPROACH, THE 8A065A BATTERY CHOKE MUST BE USED.

WHEN PLACING THE WIDEBAND SHUNT, 8A076A, AS SHOWN IN FIGURE 2 16 ENSURE THAT THE SHUNT IS PLACED ON THE BATTERY SIDE OF THE INDUCTOR.

#### **CAUTION**



IN LONG DC TRACK CIRCUITS, THE DC RESISTANCE OF THE 8A065A BATTERY CHOKE CAN ADVERSELY AFFECT TRACK CIRCUIT OPERATION AT LOW BALLAST. USE THE 62648 BATTERY CHOKE IN THIS TYPE OF CIRCUIT.

WHEN USING A SGCP 4000/MS 4000 OPERATING FREQUENCY OF 114 HZ IN A DC TRACK CIRCUIT WITH A RECTIFIED 60 HZ SOURCE, USE A 8A076A WIDEBAND SHUNT WITH THE BATTERY CHOKE TO ELIMINATE THE 120-HZ RIPPLE PRODUCED (SEE Figure 2 16).

NOTE

#### **NOTE**

For additional information on Siemens Battery Chokes, refer to Section 5, Auxiliary Equipment.

Two Siemens Battery Chokes can be used in DC track circuits. The part number and DC resistance for each choke is listed below.

Table 2-16: Siemens Battery Chokes

PART NUMBER	DC RESISTANCE
62648	0.10 ohm
8A065A	0.40 ohm




Figure 2-15: Battery Choke Requirements




Figure 2-16: Ripple Elimination Circuit

#### 2.14.3 Siemens GEO Coded DC Track Circuit

Standard SGCP 4000/MS 4000 frequencies of 86 Hz and higher are compatible with GEO. Isolation circuits are not required in the GEO transmitter rail connections.

Frequencies of 86, 114, 156, and 211 Hz require using maximum track drive, and installation of GEO Track Noise Suppression Filter, A53232. The GEO Filter must be installed at the signal location for the above-mentioned frequencies.

## 2.14.4 Electronic Coded DC Track Circuit

Standard SGCP 4000/MS 4000 frequencies of 86 Hz and above can normally be used with electronic DC coded track systems, e.g., ElectroCode, GenraKode™, MicroTrax®, and E-Code. All frequencies of 211 Hz and lower require using high SGCP 4000/MS 4000 track drive.

When signals from other equipment are present on the track, SGCP 4000/MS 4000 transmit level should be set to high.

#### NOTE



Under some circumstances, an external track filter may be required when electronic coded track is located within the SGCP 4000/MS 4000 approach.

As with any coded track system, the lower the transmit level, the less interference to SGCP 4000/MS 4000 units.

## 2.14.5 Relay Coded DC Track Circuit

#### WARNING

THE SINGLE POLARITY RELAY DC CODED TRACK CIRCUIT MUST BE CAREFULLY REVIEWED TO ENSURE THAT ALL TRANSMIT AND RECEIVE CODES ARE OF THE SAME POLARITY PRIOR TO INSTALLING ANY 6A341-1 UNIT. IF THE POLARITY IS IN DOUBT, INSTALL TWO 6A342 3 ISOLATION UNITS AT EACH END OF THE TRACK CIRCUIT, SAME INSTALLATIONS AS THE DUAL POLARITY CODED TRACK CIRCUIT.



ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT.

CONTACT SIEMENS MOBILITY, INC. TECHNICAL SUPPORT AT 1-800-793-7233 FOR MORE DETAILS.

Most relay coded DC track installations require DC Code Isolation units. A code isolation unit is a special battery choke that aids in preventing coded track battery and track relays from causing high interference with the SGCP 4000/MS 4000. The Siemens 6A342-1 DC Code Isolation unit is used in most single polarity code systems. The Siemens 6A342-1 DC Code Isolation unit is also used in GRS Trakode (dual polarity) relay systems, as long as the GRS TD relay is also used.

2-34

SIG-00-11-02 **REVISED MARCH 2022** 

## 2.14.6 Single (Fixed) Polarity Systems

## **A** WARNING

#### WARNING

ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT.

## NOTE

#### NOTE

To limit current losses to the track relay during low track ballast conditions, use number 6 AWG wires to terminals 1 and 2 on the Isolation units.

A fixed polarity code system must have the same received and transmitted polarities to use the 6A342-1 DC Code Isolation unit. 75, 120, 180-ppm rate code systems are generally fixed polarity systems. A typical fixed polarity code system using the 6A342-1 Code Isolation unit is shown in Figure 2-17.




Figure 2-17: Code Isolation Unit in a Single Polarity Code System

## 2.14.7 GRS Trakode (Dual Polarity) Systems:

#### **WARNING**

ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT.

**A** WARNING

TO INSTALL THE UNIT AS SHOWN IN FIGURE 2 18, A TRANSFER DELAY (TD) RELAY MUST BE USED.

DO NOT INSTALL ANY CODE ISOLATION CIRCUIT IN GRS TRAKODE WITHOUT USING THE TD RELAY.

## NOTE

## NOTE

To limit current losses to the track relay during low track ballast conditions, use #6 AWG wires to terminals 1 and 2 on the Isolation units.

The GRS Trakode (dual polarity) system is the only dual polarity system that can use the 6A342-1 code isolation unit as installed. This application requires that a GRS TD relay also be used when installing a 6A342-1 unit. Figure 2-18 shows the 6A342-1 Code Isolation unit installed in a GRS Trakode system.




Figure 2-18: Code Isolation Unit Installation In GRS Trakode System

## 2.14.8 Dual Polarity (Polar) Coded Track Systems Other Than GRS Trakode



## **WARNING**

ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT.

#### NOTE



For additional information on Siemens DC Code Isolation units, refer to Section 7, Auxiliary Equipment.

Contact Siemens Mobility, Inc. Technical Support for at 1-800-793-7233 for assistance in dual polarity code systems.

A dual polarity system is one in which the received code polarity is opposite to that of the transmitted code.

When used in a dual polarity system, two 6A342-3 Code Isolation units must be placed at each end of the circuit for proper filtering. The application depends upon the track circuit configuration.

## 2.14.9 AC Code Isolation Units

CAB signal track circuit installations require an AC Code Isolation unit. AC Code Isolation units are designed to minimize harmonic frequencies from being applied to the track and provide a higher impedance to SGCP 4000/MS 4000 frequencies. The part number and isolation frequency for each Siemens AC Code Isolation unit is listed below.

Table 2-17: Siemens AC Code Isolation Units

PART NUMBER	ISOLATION FREQUENCY
8A466-3	60 Hz
8A470-100	100 Hz

## 2.14.10 CAB Signal AC



#### WARNING

ALWAYS VERIFY PROPER CAB SIGNAL OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT.

Application of SGCP 4000/MS 4000 systems in cab territory using the 8A466-3, 60 Hz AC Code Isolation Unit or the 8A470-100, 100 Hz Isolation Unit is shown in Figure 2-19.




Figure 2-19: AC Code Isolation Unit Used in CAB Territory

#### 2.15 APPROACH CONFIGURATIONS

## 2.15.1 Bidirectional Configuration

The bidirectional configuration is the simplest of the approach applications. This configuration allows:

- a single SGCP 4000/MS 4000 track module to monitor train movement in both approaches to a crossing.
- longest approach distance for each operating frequency.
- bidirectional approach distances are less affected by low ballast resistance than unidirectional applications.

A typical bidirectional application consists of an island and two approaches (see Figure 2-2). The Island is defined by the location of the rail connections. The approach length is defined by the location of the termination shunt rail connections.

## 2.15.2 Bidirectional Approach Length Balancing

Bidirectional approach length must be balanced within  $\pm 10$  percent. Where approach distances differ by more than 10 percent, due to the presence of un-bypassed insulated joints in one of the approaches, simulated track must be added in series with the termination shunt of the shorter approach to bring it within 10% of the longer approach.

#### 2.15.3 Simulated Track

Simulated track can consist of either of the following:

- 8V617 Simulated Track Inductor of the proper value, which is normally installed within the Multifrequency Narrow-band Shunt
- 8A398-6 Adjustable Inductor

#### 2.15.4 Unidirectional Installations

**A** WARNING

#### WARNING

DO NOT BYPASS THE FEEDPOINT INSULATED JOINTS OF A UNIDIRECTIONAL OR A DIRECTIONALLY WIRED APPROACH WITH ANY COUPLING DEVICE.

- When configured for unidirectional operation:
- A Track module monitors train movements in a single approach due to insulated joints being present.
- When insulated joints are at a crossing, two Track modules are required to monitor both approaches.
- Insulated joints are sometimes used to separate crossing approaches (see Figure 2-20).
- Using insulated joints permits SGCP 4000/MS 4000 frequencies to be repeated in adjacent approaches.
- Locate insulated joints opposite each other, as close as practical.




Figure 2-20: Typical Unidirectional Approach Configuration

Unidirectional installations are generally used:

- When the signal system dictates them.
- when closely following trains are expected.
- at crossings where standing cars or trains can occupy opposite approach circuits.
- with remote SGCP 4000/MS 4000s in coded track and cab signal territory to extend crossing approaches beyond existing track circuit limits.

## 2.15.5 Directionally Wired Installations

# **A** WARNING

#### WARNING

FOR DIRECTIONALLY WIRED OPERATION, THE SGCP 4000/MS 4000 MUST BE PROGRAMMED FOR DIRECTIONALLY WIRED OPERATION.

#### NOTE

NOTE

In general, where unidirectional SGCP 4000/MS 4000 approaches longer than 2,000 feet (609.6 meters) are required, use the directionally wired application. This ensures optimum SGCP 4000/MS 4000 operation over varying ballast conditions.


The directionally wired configuration is applied to a unidirectional installation to obtain the low ballast and adjacent frequency overlap operating benefits of a bidirectional application. Bidirectional applications are less affected by low ballast (EX) than unidirectional applications. In the directionally wired configuration, a narrow-band shunt is connected in series with an adjustable inductor.

This combination is generally connected in parallel across the track connections in the bungalow and is adjusted to be electrically equal in distance to that of the actual track approach circuit. Both approach circuits appear equal in length to the SGCP 4000/MS 4000.

## 2.15.6 Simulated Approach

A directionally wired approach can consist of any of the following:

- 62664-f Bidirectional Simulation Coupler adjusted to the proper distance (Figure 2-21).
- 8V617 Simulated Track Inductor in series with a Multi-frequency Narrow-band Shunt. The inductor distance must be equal within 10% to that of the track approach.
- 8A398-6 Simulated Track Inductor in series with a Narrow-band Shunt.



11-02\_BIRDN\_SIM\_CPLR 12-22-11 (Revised 5-29-2014)

Figure 2-21: Bidirectional Simulation Coupler

The 62664-mf Bidirectional Simulation Coupler contains a Narrow-band Shunt at the SGCP 4000/MS 4000 termination frequency and an adjustable simulated track inductor that simulates a specific track length and is tapped and connected to front panel terminals.

The front panel terminals allow simulated approach distances to be selected that closely match the actual track approach. Approach distances ranging from 400 to 6,000 feet (121.9 - 1829 meters) in 400-foot (121.9 meter) increments can be selected using terminal shorting straps adjustable within  $\pm$  200 feet (61.0 meters) of the SGCP 4000/MS 4000 approach

#### WARNING



IN STANDARD FOUR-WIRE DIRECTIONALLY WIRED INSTALLATIONS, THE BIDIRECTIONAL SIMULATION COUPLER (62664-MF) MUST BE CONNECTED TO THE TWO TRANSMITTER (XMT) TRACK LEADS AS SHOWN FOR T1 IN Figure 2-22. DO NOT USE THIS COUPLER AS A STANDARD TERMINATION SHUNT ON THE TRACK.

## NOTE

#### NOTE

For additional information on the 62664-mf Bidirectional Simulation Coupler, refer to Section 5, Auxiliary Equipment.

## 2.15.7 Six-Wire Directionally wired Applications Connections

When a unidirectional SGCP 4000/MS 4000 is connected in a six-wire directionally wired configuration (see paragraph 2.15.5) the bidirectional simulation coupler must be connected to the check (CHK) wires as shown in Figure 2-14.

## WARNING



IN A STANDARD SIX-WIRE BIDIRECTIONAL CONFIGURATION THE BIDIRECTIONAL SIMULATION COUPLER (62664-MF) MUST BE CONNECTED TO THE TWO CHECK (CHK) TRACK LEADS AS SHOWN FOR T2 IN Figure 2-22 AND NOT BE CONNECTED TO THE TRANSMIT (XMT) TRACK LEADS.

IF THE COUPLER IS INCORRECTLY CONNECTED TO THE TRANSMIT (XMT) WIRES OF THIS CONFIGURATION, AN OPEN TRANSMITTER TRACK WIRE MAY NOT BE DETECTED. THIS CAN ADVERSELY AFFECT SGCP 4000/MS 4000 OPERATION.




Figure 2-22 4-wire & 6-wire Connections Using Bidirectional Simulation Coupler on SGCP4000/MS4000 Operating in Bidirectional Simulation mode

#### 2.16 SURGE PROTECTION

## 2.16.1 Primary Surge Protection for Track and I/O Wiring Between Bungalows

All 4000 track wires, output and input line or cable circuit wires that leave or enter the bungalow must have primary surge protection provided. Primary surge protection for 4 and 6 track wires requires arrestors and equalizer as shown in Figure 2-27. Primary surge protection for all I/O wiring between bungalows is shown in Figure 2-28.

## 2.16.2 Battery Surge Protection and Power Wiring

Primary battery surge protection for the SGCP 4000/MS 4000 requires careful power wiring from the charger to battery, from battery to surge arrestors and from surge arrestors to 4000 equipment. Primary arrestors, equalizers and power wiring are shown in Figure 2-29.

## 2.17 TYPICAL APPLICATION DRAWINGS

This section provides drawings to show each of the following SGCP 4000/MS 4000 applications:

- Single Track, Unidirectional (Figure 2-23)
- Single Track, Bidirectional (Figure 2-24)
- Single Track, Back-to-Back, Unidirectional, In Directionally wired Operation (Figure 2-25)
- Single Track, Two Overlapping Crossings, Using 80049-1 DC Shunting Enhancer Panels (Figure 2-26)
- Typical Track Wire Surge Protection for 4 and 6 Wire Track Connections (Figure 2-27)
- Typical Surge Protection Requirements When Cabling Between Remote UAX Unit and SGCP 4000/MS 4000 (Figure 2-28)
- Recommended Battery Surge Protection Wiring for SGCP 4000/MS 4000 (Figure 2-29)




Figure 2-23: Typical Unidirectional Application




Figure 2-24: Typical Bidirectional Application




Figure 2-25: Two Back-to-Back Unidirectional Units In Directionally wired (Simulated Bidirectional)

Application




Figure 2-26: Two Overlapping Crossings, Using 80049-1 DC Shunting Enhancer Panels





Figure 2-27: Typical Track Wire Surge Protection for 4 and 6 Wire Track Connections



# Required Surge Protection



Figure 2-28: Typical Surge Protection Requirements When Cabling Between UAX Unit and SGCP 4000/MS 4000




Figure 2-29: Recommended Battery Surge Protection Wiring for SGCP 4000/MS 4000

2-50

# SECTION 3 – SGCP 4000/MS 4000 SYSTEM PROGRAMMING

## 3.1 GENERAL

The SGCP 4000/MS 4000 differs from earlier Motion Sensor versions (MS 2000, 660, 500-550, or 350 Motion Sensors) in that its operation is completely software driven. There are only a few physical connections made within the Wayside Signal Shelter. No jumpers connected to the unit, nor are there any straps used to enable high power operation. The units come with the software pre-loaded, ready for field installation; requiring only individual unit software configuration following the railroad's approved wiring diagram to place the unit into operation.

When the SGCP 4000/MS 4000 is used with a CPU II+ module, system programming is completed via the push-button menu, described in section 3.2 below. System programming can also be done using a laptop computer with the Diagnostic Terminal (DT) program installed, connected to the SGCP 4000/MS 4000 with a serial cable.

When the SGCP 4000/MS 4000 is used with a CPU III module, system programming can still be completed via the push-button menu described in section 3.2 below, or via the Web User Interface using a PC and the Laptop/Ethernet port on the front of the CPU III module as described in section 3.3.

#### 3.2 PUSH BUTTON MENU SYSTEM OVERVIEW

The menu system allows users to implement changes without requiring a laptop computer to interface with the unit. The SGCP 4000/MS 4000 CPU has a menu system of main menus, sub-menus, parameters, and individual values. All controls and indicators used to program the SGCP 4000/MS 4000 are found on the CPU II+ or CPU III card. No programming is performed using the Track Card.

# 3.2.1 Controls and Indicators Used in Push-Button Manu Navigation on CPU

## 3.2.1.1 Four Character Alphanumeric Display

The Four Character Alphanumeric Display is located directly below the unit information written on the top of the faceplate. It displays letters, numbers, and limited symbols. Once the unit has completed the startup process, a message scrolls across the display stating: SGCP 4000/MS 4000.

## 3.2.1.2 **SEL** Button

The SEL (Select) Button is located immediately below the 4 Character Display. The major use of this button is to select the desired menu, parameter value, calibration, or diagnostics. This button can also be used to confirm onsite personnel presence when unlocking WebUI parameters (CPU III only).

## **3.2.1.3 NAV Button**

The NAV (Navigate) Button is located immediately below the SEL Button. There are two major uses of this button. The first is to scroll (move from one menu item to the next) through the menus, parameter values, etc. Each time the NAV button is momentarily pressed, the next menu item is displayed. The second use is to go up one level in the menu by pressing and holding the NAV button for a few seconds. This button can also be used to confirm onsite personnel presence when unlocking WebUI parameters (CPU III only).

# 3.2.2 SGCP 4000/MS 4000 CPU Push-Button Main Menu

The CPU has the following main menus:

- Program (PROG)
- Calibration (CAL)
- Out of Service (OOS) (when enabled)
- Version Data (VERS)
- Warning Time Data (TRWT) (from last train movement)
- Display Test (TEST)

Each of the unit main menus is discussed in Section 3.3.8. Submenu groupings and individual parameters are also discussed throughout Section 3.3.8.

# 3.2.3 Navigating the Menus

Each CPU II+ / CPU III Card has two buttons on its face: Select (SEL) and Navigate (NAV). In general, the pushbuttons are used to navigate the menus as shown in Table 3-1.

SIG-00-11-02 Version No.: A.8

Table 3-1: General Menu Navigation and Selection Using The Pushbuttons

OPTION DESIRED	ACTION TAKEN
Move to the next item at the same menu level (e.g., if in the main menu level such as PROG, move to the next main menu item such as CAL)	Press NAV momentarily
Go down a main menu level (e.g., if at the top level (SGCP 4000/MS 4000 scrolls across display), move to the MENU level (PROG, CAL, etc.) or move from the ADVD menu to the Sub-Menu PSTR, which is the first submenu of the ADVD Menu)	Press SEL momentarily
Move to the next PARAMETER value	Press NAV momentarily
To modify a PARAMETER value	Hold SEL until currently set PARAMETER appears, press NAV multiple times until desired PARAMETER value appears, then hold SEL until the set parameter message (e.g., SET DIRN=UNI?) appears. Press and hold SEL button until WAIT appears. Release the SET button. Once the parameter is saved, DONE appears, and then the menu item just saved appears (e.g., DIRN=UNI) appears in the 4-Character Display
To scroll down through PARAMETER items	Each time NAV is pressed a new PARAMETER item appears
To SAVE CHANGES to modified PARAMETER values	Hold SEL until DONE appears
Go up one level (e.g., if in the AFRQ MENU editing frequency parameters, select to return to AFRQ at MAIN Menu level)	Hold NAV until BACK appears

# 3.2.4 Program Menu Processes

The Program (PROG) Menu is used to edit parameter values. To edit an individual parameter, refer to Section 7.3.7, Configure the SGCP 4000/MS 4000.

# 3.2.5 Calibration Menu Process

Calibration is used to set signal threshold levels for the Motion Sensor Receiver and Island Receiver. To calibrate an item, refer to Section 7.3.8, Calibrate the SGCP 4000/MS 4000.

# 3.2.6 Out of Service (OOS) Menu Processes

The purpose of the Out of Service (OOS) is to take the Motion Sensor OOS regarding either the approach or the crossing (approach and island). To take a Motion Sensor OOS, refer to Section 4.4, Taking Tracks "Out of Service."

## 3.3 WEBUI SYSTEM OVERVIEW

The CPU III module provides a Web Interface which enables the user to configure the SGCP 4000/MS 4000 locally as well as remotely through the Laptop/Ethernet Port (RJ-45) on the front of the Laptop/Ethernet port on the front of the CPU III module. The DiagView Display Laptop Port default protocol is set as DHCP Server. The CPU III will default to operating as a Server as well. If they are to be connected to a network, however, they will need to be configured as Clients. The CPU III will display an IP address scrolling across the four-character display. This can be accessed by using the SEL button to move between the scrolling displayed text. The WebUI uses the HTTP Secure (https) protocol. The CPU III DHCP Server protocol will assign the laptop an IP address and connect the user to the SGCP 4000/MS 4000. The CPU III supports the following web browsers:

- IE 10 and 11 or newer
- Firefox (version 46.x) or newer
- Chrome (version 55.x) or newer

Open a web browser and type in the IP address of the CPU III. The browser may give the following screens regarding the connection.




Figure 3-1: Unsecure Connection Warning

Click the **Advanced** option and select the option to proceed to the WebUI. The WebUI will then appear. Select the username as Maintainer (default). Admin is for Siemens personnel use only.

The default password is GCP4000 (case sensitive) to open the session. If the security has not been set to enable a maintainer password, this default will allow all regular user functions of the WebUI to be accessed. If a specific maintainer password has been set, enter this. The default GCP4000 may still be used to access the WebUI, but the user will be unable to change GCP Programming parameters.




Figure 3-2: WebUI Login Screen



#### **CAUTION**

IF THE EQUIPMENT IS TO BE CONNECTED TO A NETWORK, IT WILL BE NECESSARY FOR THE USER TO SET THE ETHERNET PORT AS A CLIENT, FAILURE TO DO SO WILL CAUSE AN INTERRUPTION OF THE NETWORK SINCE TWO DHCP SERVERS WILL BE INTRODUCED ONTO THE NETWORK.

# NOTE

## NOTE

The WebUI has a session timeout (default is 1 minute). If the web browser is closed without selecting **Logout**. The user will not be able to log back in for 1 minute.

The WebUI has buttons at the top which allow the user to select the various functions.



Figure 3-3: WebUI Tool Bar

## 3.3.1 Local User Presence

Since the WebUI may be used to connect to the SGCP 4000/MS 4000 remotely, it is necessary to confirm that someone is present at the location before certain operations such as changing SGCP 4000/MS 4000 programming or re-calibration can be performed.

To enable the SGCP 4000/MS 4000 programming or calibration, first unlock the screen from the WebUI by pressing the **Unlock** button.




Figure 3-4 WebUI: Unlock

The WebUI will show the message below on the left, asking for confirmation to continue. Select **OK** and the WebUI will show the message below on the right.




Figure 3-5 WebUI: Confirm Local User Presence

At this point, the onsite personnel will need to press the SEL or NAV button on the front of the CPU III to confirm user presence.

If the local user denies access to the remote user, the WebUI will show the **Failed** message in the figure below on the left. If there is no confirmation by the local user, the WebUI will show the timeout message in the figure below on the right.



Figure 3-6: WebUI Local User Presence Error Messages

If the unlock parameters action is successful, the WebUI will display the message shown in Figure 3-7.



Figure 3-7: WebUI Local User Presence I Authenticated

# 3.3.2 System View

The System View is the main screen that shows an overview of the SGCP 4000/MS 4000 status. If there are diagnostic messages present, the System View will show the red exclamation mark in the top right.



Figure 3-8: System View

If a SGCP 4000/MS 4000 is not fully calibrated, the required calibrations are indicated in System View.

The Island status is indicated as

- Up unoccupied
- Down occupied
- Not Used not used
- Cal Req calibration required.

The Track menu can be expanded to show the following options for the Track modules:




Figure 3-9: System View Track Menu

## 3.3.2.1 Track Menu: Detail View

The track **Detail View** shows more detailed information about the track module. This screen is primarily used to see the information shown in Figure 3-10 (highlighted with yellow boxes) as this is not available elsewhere on the WebUI:

- Check EZ value of EZ on the check wires,
- Island Z Level the island signal level, where 100 or lower indicates occupancy,
- Track Check Number (TCN) and date and time it was last changed.

The Island Z level represents the normalized signal level on the island. When the value is below 100 the island becomes occupied, the island will start its pickup delay timer running when the Z level goes back over 110. The display does not show values over 250, even though the island level will generally be much higher.

The track detail screen also shows the user the EZ/EX limits information consisting of:

- the highest EZ value the track has recorded since this screen was last reset and the EX value at that time. The time/date this occurred is shown.
- the lowest EX value the track has recorded since this screen was last reset and the EZ value at that time. The time/date this occurred is shown.

The values can be reset by clicking the **Reset** button.



Figure 3-10: Track Detail View

# 3.3.2.2 Track Menu: Diagnostics

When **Diagnostics** is selected, the WebUI shows any diagnostic messages present in the system. When a specific diagnostic message is selected, the WebUI will show the **Cause** and **Remedy** of this at the bottom of the screen as shown in Figure 3-11.

To show diagnostic messages for just a specific module in the system, select the module from the drop-down menu labeled **Select slot**.




Figure 3-11: Track Diagnostics Messages

## 3.3.2.3 Track Menu: Calibration

When **Calibration** is selected, the WebUI will show a screen that allows the user to calibrate the SGCP 4000/MS 4000 approach, linearization, or island. Before options can be selected on the screen, it has to be unlocked and local user presence confirmed (section 3.3.1).




Figure 3-12: Track Calibration

# 3.3.2.4 Track Menu: Remote Setup

When **Remote Setup** is selected, the WebUI shows the following screen that allows the user to obtain the remote setup password when the system is used with a VHF communicator and DTMF radio that allow remote setup operations to be performed. Before options can be selected on the screen, it has to be unlocked and local user presence confirmed (section 3.3.1).




Figure 3-13: Remote Setup WebUI

#### 3.3.2.5 Track Menu: Out of Service

When **Out of Service** is selected, the WebUI shows the following screen that allows the user to take the SGCP 4000/MS 4000 approach or island out of service. Before options can be selected on the screen, it has to be unlocked and local user presence confirmed (section 3.3.1).



Figure 3-14: Out of Service WebUI

#### 3.3.2.6 Check Numbers

The check numbers screen will show the following check numbers:

MCF Name – the name/version of t–e MCF

CCN - Configuration Check number, a check number that covers every configuration parameter that is part of the SGCP 4000/MS 4000 programming and can be used to check whether anything in the vital programming has been changed.

OCCN – Office Configuration Check number, used to verify configuration settings prescribed by design office are correct. The Web UI will indicate if the value is out of date, if it is to obtain the new value select the Recalculate OCCN option on the screen.

FCN - Field Check Number.

TCN - Track Check Number (shown as Track 1 on Web UI).

The MS4000 provides a Track Check Number (TCN) for the track. The TCN provides a way for the Maintainer to know if any track calibration changes have been made since they recorded the TCN value. This check number changes whenever any of the following are performed:

- The main and standby track cards will have different TCNs as they are calibrated at different times.
- The main and standby will have different FCNs if any TCN changes or the SSCC lamp voltages
  are adjusted will cause the FCN to change. The Field Check Number (FCN) is a combination of

3-12

**REVISED MARCH 2022** 

- all the track check numbers and the SSCC lamp voltage settings, so for the MS4000 this provides same information as the TCN as there is only 1 track and no SSCC IIIi modules
- The check numbers screen has been improved in display versions after 1.5.7r to show the main and standby TCNs and FCNs.




Figure 3-15: Check Numbers

The TCN and FCN will show a value of 0 if the track card is not fully configured and calibrated and in session with the CPU (for the powered side).

If a parameter is changed which causes the GCP to require calibration, then the TCNs for both main and standby will show zero. When the main is then fully calibrated its values will be non-zero, the standby TCNs will still be at zero, thus providing an indication that the unpowered standby side has not yet been calibrated (refer to the following figure).



#### NOTE

If a parameter that affects the TCN is changed, so calibration is required, but then it is changed back to its original value, the GCP will no longer require calibration, but the TCN is updated to a new value, as the TCN is recalculated when the GCP goes from an uncalibrated to a calibrated state.

NOTE

#### NOTE

The main/standby TCNs and FCN, and OCCN out of date indication are only available on the Display if the Display Software version is later than 1.5.7r AND the CPU II+ version is ncg05\_30.mef or later or if the CPU III is used it has version 9VC72-V3H01\_10.mef or later.

The main/standby TCNs and FCN, and OCCN out of date indication are available on the CP WebUI for CP versions after 1.1.61r.

# 3.3.3 Configuration Menu

The **Configuration** menu allows the user to view and change the SGCP 4000/MS 4000 programming and configuration parameters.

NOTE

#### NOTE

If the Security Enabled is set to Maintainer, the correct Maintainer password has to be entered in the WebUI in order to edit parameters. If the default password is used, the programming parameter will remain locked.

# 3.3.3.1 Template Programming

This menu should not be used in MS4000 applications as it will already be set to the MS4000 option.

# 3.3.3.2 MS4000 Configuration

When **MS4000** programming is selected, the WebUI shows the following screen that allows the user to take change configuration parameters. Before options can be selected on the screen, it has to be unlocked and local user presence confirmed (Section 3.3.1).




Figure 3-16: MS4000 Configuration

# 3.3.3.3 CP Programming

This menu item contains the following sub-menus:

- Laptop Port
- Router Settings
- Log Setup
  - Security
  - Web Server
  - Set to Default

These menus can be used to adjust parameters relating to the WebUI settings.




Figure 3-17: CP Programming

# 3.3.4 Calibration and Adjustment

The calibration screen can be accessed from the **System View Track Calibration** menu or from the **Calibration & Adjustment** icon on the tool bar.

The calibration screen shows the state of the calibration for the specified track. If the calibrations are complete, these are marked with a green check mark as shown in Figure 3-18.




Figure 3-18: Track Calibration

If the calibrations are required, these are marked with a red check box.

To select which calibration to perform, either click on a specific calibration in the menu bar, for example, GCP shown in the yellow box above, or select the calibration from the drop-down menu shown in green box.

When the island calibration is selected, the WebUI will show the distance at which the hardwire shunt should be placed. The distances shown are automatically calculated for the island frequency that has been configured.

See section 7 for the detailed instructions on performing calibrations.

#### 3.3.5 Status Monitor

The **Status Monitor** screen enables the user to view the status of the MS4000 and its systems from different perspectives and connection points. This menu item is for visibility and troubleshooting and not used for any system programming activities.



Figure 3-19: Status Monitor Full Menu

# 3.3.6 Reports and Log

The **Reports and Logs** menu provides the user with access to the following different submenus:

- CP Status Log
- Diagnostic Log
- Train History Log
- Maintenance Log
- Reports
- EZ/EX Recording
- CP Diagnostic Log
- VLP/IO Card Logs

Most of the logs have filtering options located at the top of the viewing screen allowing the user to filter the log entries for a smaller subset.



Figure 3-20: Log and Report Filtering

All log and report types will have the option to **Download** as shown in Figure 3-21.




Figure 3-21: Reports and Logs

Use the buttons as follows:

- First show the oldest page of events in the log
- Last show the newest page of events in the log
- Previous move back a page in the log
- Next– move forward a page in the log

50 events are shown per page, use the scroll bar on the right to see all the events on the page.

The Download button provides the following selections:

- Displayed download the current page displayed
- Last 24 hours downloads the events that occurred in the last 24hrs
- All downloads the whole event log

The screen provides a filter box so events that contain the entered text are the only shown. Enter the text to be filtered, then press enter.



Figure 3-22 WebUI: Event Log Text Filter

To clear the filter, either delete the text in the box and press **Enter** or press the red **X**.

The events log contains both the CPU events and also the Diagnostic events. To see the Diagnostic events, either change the log filter to Diagnostic, or select the Diagnostic Log menu item from the left menus.

If **ADVANCE** is selected, the WebUI allows the user to choose a range of dates to view. Enter the required date range. The **First** button will now show events from the start date and time. The **Last** button will now show events up to the selected end date and time. The **Download** button now has the option to download a selected range.




Figure 3-23 WebUI: Event Log ADVANCE Mode

If **TRACE** is selected, the WebUI will go into Trace mode and add events to a text buffer as they are received in real time. To pause the trace, press the **Stop** button. To restart tracing, press the **Start** again. To clear the trace buffer press the **Clear** button. Press the back button to exit **TRACE** mode and return to the **BASIC** mode.




Figure 3-24 WebUI: Event Log TRACE Mode

# 3.3.7 Software Updates

When the software updates icon is selected, the WebUI will show the menu options illustrated in Figure 3-25.

## 3.3.7.1 CP MEF

The **CP MEF** page can be used to update the non-vital MEF of the SGCP 4000/MS 4000. This process is detailed in section 8.3.2. Before options can be selected on the screen, it has to be unlocked and local user presence confirmed (section 3.3.1).



Figure 3-25: CP MEF

## 3.3.7.2 VLP Software Update Menu

The **VLP** menu option enables the user to update the vital MEF, MCF, and MCFCRC. The options to clear the ECD, CIC and reset the VLP module are also available under the VLP menu. Before options can be selected on the screen, it has to be unlocked and local user presence confirmed (section 3.3.1).




Figure 3-26: WebUI: Software Updates

## 3.3.8 Diagnostics

The **Diagnostics** menu tab contains the same diagnostic information available under the WebUI System View – see section 3.3.2.2 for more information.

## 3.4 SGCP 4000/MS 4000 PUSH-BUTTON MAIN MENUS

Each of the unit menus differs from the others. While many values are common across the units, care must be taken so that proper selections are made. Default entries are shown in **bold** type. The following menu systems are depicted:

- Program Menu
- Calibration Menu
- Out of Service (OOS)

## 3.4.1 SGCP 4000/MS 4000 Program Menu Parameter Definitions and Values

The following sections provide information regarding the purpose and values of each parameter in the PROG (Program) Menu.

# 3.4.1.1 Approach Frequency (AFRQ)

The AFRQ menu provides a listing of all approach frequencies that may be used by the SGCP 4000/MS 4000, whether the frequency is a Siemens Mobility standard frequency, a frequency used by other vendors, or an offset frequency. There are a total of 56 different frequencies available and those frequencies are depicted in Table 3-2.

Not Set	86	114	156	211	285	348	430	525	645
790	970	44	45	46	151	250	267	326	392
452	522	560	630	686	753	816	881	979	999
85.5	86.5	87	113	113.5	114.5	115	155	155.5	156.5
157	210	212	284	286	347	349	429	431	523
527	643	647	788	792	968	972			

Table 3-2: SGCP 4000/MS 4000 Approach Frequency Selections

# 3.4.1.2 Approach Directionality (DIRN)

The Approach Directionality (DIRN) menu parameter determines whether the approach is Unidirectional (UNI), Bidirectional (BI), or Bidirectionally-Wired (BIWD). The default is UNI.




Figure 3-27: Bidirectionally Wired Approaches

In this configuration, a six-wire connection, one where the Check wires are physically separated from the Transmit wires, is required in order to allow the system to determine train direction. The wires are separated by between 75 – 100 feet (see Figure 3-27. The orientation of the wiring is specified in the Railroad's or Agency's approved wiring diagram.

The parameter value "Bidirectionally-Wired" that appears on the menu enables the system to determine train direction. As an example, as the train passes through the crossing, it crosses the Receive wire, then the Transmit wire followed by the Check wire. The system notes this as the train direction.

# 3.4.1.3 Transmit Level (TLVL)

The Transmit Level (TLVL) parameter range of values are Medium and High. The default setting is Medium.

# 3.4.1.4 Approach Pickup Delay (APKU)

The Approach Pickup Delay (APKU) is the length of time from the point at which motion ceases in the approach until the gates pickup. The range is 8 – 99 seconds, and the default is 15 seconds.

# 3.4.1.5 Upstream Adjacent Crossing Used (UAX)

The Upstream Adjacent Crossing (UAX) parameter is used when the SGCP 4000/MS 4000 receives an input from another unit (another motion sensor, a GCP, a PSO, etc.) and the pickup delay set for that input. The default setting is Not Used with no chassis input enabled. The UAX is enabled when:

- A non-zero-time value is set,
- An input is set to UAX
- The input is energized.
- The UAX activates when the input de-energizes.

The range of values is from 0-99 seconds. The value entered is the length of time from when the UAX input energizes until the system will allow the XR to be energized (assuming no other detection/error is keeping the XR down). The default value is Not Set.

# 3.4.1.6 Island Used (ISL)

The SGCP 4000/MS 4000 may be configured to use an internal island or an external island. When a frequency value is selected, the internal island is enabled. When the parameter value EXT (external) is selected, the external island is enabled and an external input is used in lieu of the internal island.

The SGCP 4000/MS 4000 will not allow the XR output to recover if the island is not used. The Island Used parameter values depicted in Table 3-3 are available on the SGCP 4000/MS 4000.

External (EXT)	Not Used	4.9kHz	11.5kHz
2.14kHz	5.9kHz	13.2kHz	2.63kHz
7.1kHz	15.2kHz	3.24kHz	8.3kHz
17.5kHz	4.0kHz	10.0kHz	20.2kHz

Table 3-3: SGCP 4000/MS 4000 Island Frequency Selection Values

# 3.4.1.7 Island Pickup Delay (IPKU)

The Island Pickup Delay (IPKU) is the time from the island energizing to the system recognizing the island is up (island pickup delay). When the Internal Island is enabled, the range of values is 0-6 seconds, and the default setting is 0 seconds. The Internal Island also has a built-in two second pickup delay in addition to the value of the IPKU parameter. When the External Island is enabled, the range of values is 0-99 seconds, and the default is 1 second.

## 3.4.1.8 Input 1 (IN1)

The IN1 parameter is used to set the type of function activated when the input is activated. The options are None, Out of Service (OOS), UAX (if UAX has a time selected), and ISL (if the External Island is selected). The default setting is Not Used.

# 3.4.1.9 Input 2 (IN2)

The IN1 parameter is used to set the type of function activated when the input is activated. The options are Not Used, Out of Service (OOS), UAX (if UAX has a time selected), and ISL (if the External Island is selected). The default setting is Not Used.

# 3.4.1.10 Advanced Menu Settings (ADVD)

The Advanced Menu parameter contains the sub-menus that pertain to the SGCP 4000/MS 4000.

## 3.4.1.11 Positive Start Level (PSTR)

When enabled, the Positive Start level immediately activates the crossing when EZ is less than the programmed Positive Start EZ Level. There is no 5-second reaction delay time. Once Positive Start occurs, the crossing is continuously activated until either the train clears the island circuit, the EZ value rises to a number 5 greater than the programmed positive start EZ level, or the Positive Start timer has exceeded the programmed timer delay of 1 to 99 minutes. A new Positive Start sequence may be initiated once EZ exceeds the programmed Positive Start EZ level by 5. The range of values is 1-80, the default is OFF.

# 3.4.1.12 Positive Start Timer (PTIM)

The Positive Start Timer parameter value allows a continuous positive start to either not time out (PTIM=0) or to timeout after the programmed delay. Range of values is 0 – 99 minutes. The default value is NONE. This parameter is only visible when PSTR is enabled.

## 3.4.1.13 Sudden Shunt Detection (SHNT)

This parameter is used when a signal is located close to a crossing, Sudden Shunt can activate the crossing immediately when the first wheels of the train pass the remote UAX insulated joints into the crossing approach. The range of values is OFF, 5-75. The default setting is OFF.

# 3.4.1.14 Low EZ Detection Used (LWEZ)

Low EZ Detection is used to detect a significant reduction of EZ. The valid range of settings are OFF, 50 – 80. The default value is Off.

# 3.4.1.15 Low EX Adjustment Level (LWEX)

The Low EX Adjustment Level (LWEX) enables the SGCP 4000/MS 4000 to operate at EX levels as low as 34. The range of values is 34 – 39. The default setting is 39. Prior to adjusting for Low EX follow the Low EX Qualification Test (Table 8-7) listed in section 8.

SIG-00-11-02 Version No.: A.8

## 3.4.1.16 Compensation Level (COMP)

The compensation value is a correction factor used to fine tune the system for unusual ballast conditions. The range of values is 1000 – 2000. The default setting is 1300.

# 3.4.1.17 SGCP 4000/MS 4000 Predictor (PRED)

The SGCP 4000/MS 4000 Predictor provides simple prediction functionality when programmed. The range of values is No or Yes. The default value is No.

# 3.4.1.18 Warning Time (WTIM)

The warning time value is the amount of warning time desired for the crossing measured in seconds. The default values is 23 – 99 seconds. The default setting is 35 seconds. This parameter is only used and only visible if PRED is set to Yes.

# 3.4.2 Push-Button Program Menu

The SGCP 4000/MS 4000 has four top level menus, one sub-menu, and one data report:

- PROG Top level menu used to program the SGCP 4000/MS 4000
- ADVD The Advanced parameter is a programming sub-menu of the PROG main menu
- CAL Top level menu used to calibrate the SGCP 4000/MS 4000
- OOS Top level menu used to place the SGCP 4000/MS 4000 in Out of Service (OOS) status
- VERS Top level menu that depicts software and hardware information of the SGCP 4000/MS 4000
- TRWT Top level data report that depicts information regarding most recent train movement
- TEST Top level menu used to run the Display Test on the SGCP 4000/MS 4000.

The menu for the SGCP 4000/MS 4000 is as depicted in Table 3-4.

Table 3-4: SGCP 4000/MS 4000 Program Menu

ITEM	VALUE
PROG	Top Level Program Menu
AFRQ	<b>NOT SET</b> , 86, 114, 156, 211, 285, 348, 430, 525, 645, 790, 970, 44, 45, 46, 141, 149, 151, 237, 239, 249, 250, 267, 326, 392, 452, 522, 560, 630, 686, 753, 816, 881, 979, 999, 85.5, 86.5, 87, 113, 113.5, 114.5, 115, 155, 115.5, 156.5, 157, 210, 212, 284, 286, 347, 349, 429, 431, 523, 527, 643, 647, 788, 792, 968, 972 Hz
DIRN	UNI, BI, BIWD
TLVL	MED, HI
APKU	8 – 99 SEC (DEFAULT = <b>15</b> )
UAX	NOT USED, 0-99 SEC (UAX + UAX Pickup Delay)
ISL	<b>NOT USED</b> , EXT, 2.14, 2.63, 3.24, 4.0, 4.9, 5.9, 7.1, 8.3, 10.0, 11.5, 13.2, 15.2, 17.5, 20.2 kHz
IPKU	<b>0</b> -6 SEC (Internal) 0 – 99 SEC (External)
IN1	NOT USED, OOS, UAX (if time is programmed), EXT (if External Island is selected)
IN2	NOT USED, OOS, UAX (if time is programmed), EXT (if External Island is selected)
<u>ADVD</u>	Sub-menu Program Label
PSTR	<b>OFF</b> , 1-80
PTIM	<b>0</b> -99 MIN
SHNT	<b>OFF</b> , 5 – 75
LWEZ	<b>OFF</b> , 50 – 80
LTIM	2 – 99 MIN
LWEX	34 <b>-39</b>
COMP	1000 – 2000 (DEFAULT = <b>1300</b> )
PRED	No, Yes
WTIM	23 – 99 SEC (DEFAULT = <b>35</b> )
<u>008</u>	Out of Service (OOS) Menu
APPR	Take Approaches only OOS
XNG	Take Approaches and Island OOS
CAL	Calibration Menu
MCAL	Approach Calibration
ICAL	Island Calibration
ACAL	Approach Distance Calibration
LCAL	Linearization Calibration
<u>VERS</u>	Software and Hardware Information
TRWT	Warning Time of previous train
<u>TEST</u>	SGCP 4000/MS 4000 Display Test

On Table 3-4, Main Menu titles are underlined. Default values are in BOLD text

When the Set Default parameter is selected, the values in Table 3-5 are set.

Table 3-5: SGCP 4000/MS 4000 MENU DEFAULT SETTINGS

PARAMETER	VALUE
Track Frequency (AFRQ)	NOT SET
Directionality, to include directionality of wiring (DIRN)	UNI
Transmit Level (TLVL)	MED
Pickup Delay (APKU)	15 SEC
Upstream Adjacent Crossing (UAX) Time	NOT USED
Island Frequency (ISL)	NOT USED
Island Pickup Delay (IPKU) (Internal Island selected)	0 SEC
Island Pickup Delay (IPKU) (External Island selected)	1 SEC
IN1	NOT USED
IN2	NOT USED
Positive Start EZ Value (PSTR)	OFF
Positive Start Time (PTIM)	0 MIN
Sudden Shunt Level (SHNT)	OFF
Low EZ Level (LWEZ)	OFF
Low EZ Time (LTIM)	2 MIN
Low EX Level (LWEX)	39
Compensation Value (COMP)	1300
Predictor Used (PRED)	No
Warning Time (WTIM)	30 SEC

# 3.4.3 Calibration Menu

**Table 3-6: Calibration Menu Options** 

MENU ITEM	DESCRIPTION
MCAL	Select the approach calibration when unit is in Motion Sensor Mode
ICAL	Selects island calibration
ACAL	Selects approach distance calibration when unit is in Predictor Mode
LCAL	Selects linearization calibration when unit is in Predictor Mode

# 3.4.4 Out of Service Menu

Table 3-7: Out of Service (OOS) Menu Options

MENU ITEM	DESCRIPTION
OOS TIME	The amount of time in hours (1-23) that the unit shall remain OOS once activated
APPR	Takes the approaches OOS but leaves the Island in service.
XNG	Takes the motion sensor (approaches and island) OOS

# SECTION 4 – SGCP 4000/MS 4000 APPLICATION GUIDELINES

## 4.1 INTRODUCTION AND OVERVIEW

The Simple Grade Crossing Predictor 4000 / Motion Sensor 4000 (SGCP 4000/MS 4000) allows many application functions to be configured in software, reducing the equipment and wiring needed to install and maintain a crossing. Extensive reduction in the number of relays utilized by crossings is achieved through the use of various software routines.

## 4.2 APPLICATION PROGRAMMING GUIDELINES

#### 4.2.1 External Islands

NOTE

## **NOTE**

There are only two inputs available on the SGCP 4000/MS 4000. If an application plan specifies both OOS and UAX inputs, there is no input available for assignment as an External Island. Planners must keep this fact in mind when creating SGCP 4000/MS 4000 applications.

When an input is required from an island circuit external to the SGCP 4000/MS 4000, such as a DC island as shown in Figure 4-1, the LOS pickup delay for an external island is set using the IPKU.




Figure 4-1: External Island Example

## 4.2.2 Programming For Trains That Stop In The Approach

When trains have a normal stop in a MS/GCP approach such as a station stop or at a signal location, it is important to consider the following:

- How close to the crossing does the stop occur
- Will trains accelerate fast enough from the stop to affect warning time

Station stops are generally for short commuter trains that have brief stops at a station and when leaving, accelerate fast. Station stops unlike stops at signal (near track wires), may be located anywhere within a SGCP 4000/MS 4000 approach.

When a station stop is located in the crossing or remote approach, it may be desirable to maintain the crossing activated during the stop. Motion sensing provides the fastest train detection possible when trains begin accelerating from a station stop toward the crossing.

# 4.2.3 Positive Start (Maintains the Crossing Activated)

If the station stop is very close to a crossing, (generally less than 1000 feet {305 meters}), it may be desirable to maintain the crossing activated. This may be implemented by means of the Positive Start feature. Positive Start holds the XR relay in the de-energized state when EZ is less than the programmed value. Positive start recovers when the:

- Train passes the island circuit
- Train backs up 5 points higher than the EZ Positive Start level value.
- Positive Start timed mode is selected and the timer exceeds its programmed value
- The Positive Start function depends on the operating mode selected (ON or TIMED).

When in the ON (non-timed) mode:

- The XR Relay deenergizes when EZ drops below its configured level without any reaction time delay
- If the train stops, XR Relay stays deenergized as long as EZ is below its configured level
- The XR Relay recovers when train passes the island circuit or EZ rises 5 points above its configured level and the programmed pickup time expires.

When in the timed mode:

- the XR Relay deenergizes when EZ drops below its configured level
- the positive start timer starts when EZ drops to a value that is less than its configured level
- the XR Relay recovers when train passes the island circuit or both the programmed Positive Start timer and the prime Pickup delay timer have elapsed, provided no other prediction processes are in process

A Positive Start timer value of 1 to 99 minutes may be specified.

## NOTE

NOTE

When Positive Start is used, slow trains may cause a long warning time if the Positive Start EZ level activation point is located well out in the approach.

If bidirectional approaches are used, Positive Start is active for both directions of train traffic

If movement through a trailing switch causes EZ to be below the Positive Start threshold, crossing activation will result.

## 4.2.4 Sudden Shunt detection

When a signal is located close to a crossing, Sudden Shunt can activate the crossing immediately when the first wheels of the train pass the remote UAX insulated joints into the crossing approach. See the application in Figure 4-2. Sudden Shunt will activate the crossing on all inbound trains (slow or fast) that pass the signal location so care should be taken in the application of this option.




Figure 4-2: Track application

The sudden shunt option allows the user to configure the crossing unit so that the XR relay deenergizes when a sudden shunt is detected. Sudden Shunt when enabled operates as follows:

- Sudden Shunt is detected when EZ drops instantaneously from above 80 to below a configured Sudden Shunt EZ level
- EZ drops due to the termination shunt having simulated track in series with it to balance or extend the approach distance
- Once Sudden Shunt has activated the crossing, if the train stops short of the island, any
  active timers will run their programmed pickup delays and the crossing will then recover
- When the crossing is unidirectional and has Sudden shunt enabled, a reverse move train although providing the Sudden Shunt detection conditions will not trigger Sudden Shunt operation

# 4.2.4.1 Track 1, Sudden Shunt Det Level

To determine the Sudden Shunt Detector EZ Level value:

- A hardwire shunt is placed on the track on the crossing side of the remote UAX insulated joints and the EZ value noted.
- The Sudden Shunt Det Level should be set 5 EZ point higher than the EZ value noted with the hardwire shunt
- The EZ value noted with the hardwire shunt must not be less than 5 for Sudden Shunt to be detected.
- The detector EZ level configuration setting is from an EZ of 5 to 75

# NOTE

NOTE

When Sudden Shunt is used, ensure there are no trailing switches that are close enough on either side of the crossing (if bidirectional) to cause EZ to drop below the programmed Sudden Shunt EZ level. If so, this would cause a crossing activation each time a train comes out of the trailing switch.

## 4.2.5 Low EZ Detection

Low EZ Detection is used to detect a significant reduction of EZ. The valid range of settings are No and Yes. The default value is No.

- The EZ signal may decrease for various reasons including a false shunt
- Low EZ detection occurs when the EZ level drops below the programmed EZ level threshold (default is 70) for a period of time exceeding the low EZ detection timer value.
- Once low EZ detection occurs and depending on user selection, the crossing is continuously activated until EZ rises 5 points above the EZ level threshold.

When Low EZ Detection Used is set to Yes, it provides two submenus:

- Low EZ Detection Level Valid range is an EZ between 50 and 80. Default setting is 70.
- Low EZ Detection Time Valid range is between 2 and 99 minutes. Default setting is 10 minutes.

#### 4.2.5.1 Low EZ Detection Level

• This sets the threshold level for low EZ detection. It is generally set at the default level of 70 for most applications.

## 4.2.5.2 Low EZ Detection Time

- The valid range of entry is between 2 and 99 minutes. The default is 10 minutes.
- The low EZ detection timer is generally programmed for a time interval longer than trains would normally remain in the approach.

# 4.2.6 Compensation Value



#### WARNING

THE COMPENSATION VALUE IS AUTOMATICALLY SELECTED BY THE SYSTEM WHENEVER THE FREQUENCY IS CHANGED. THE COMPENSATION VALUE CAN BE CHANGED MANUALLY VIA THIS MENU ITEM; HOWEVER, THE COMPENSATION VALUE SHOULD NOT BE CHANGED UNLESS SPECIFICALLY INSTRUCTED BY SIEMENS APPLICATION ENGINEERING TO DO SO. CALIBRATE THE CROSSING IF THE COMPENSATION VALUE IS CHANGED.

The compensation value is a correction factor used to fine tune the system for unusual ballast loads on the track. This value is selected automatically to maintain a stable EZ value over changing ballast conditions. The EZ value can be monitored using the Status Mode (see Section IV, Diagnostics). The valid range of entries is 1000 to 2000; however, 1300 is generally used.

4-4

## 4.2.7 SGCP 4000/MS 4000 Simple Predictor



#### CAUTION

THE SGCP4000/MS4000 IS NOT A GCP 4000! WHILE IT CAN RECEIVE UAX INPUT, IT CANNOT DAX NOR CAN IT PERFORM TRAFFIC PREEMPTION OR ANY OTHER ADVANCED PROGRAMMING OPTIONS (ANDING, ADVANCED APPROACH PREDICTION, WRAP CIRCUITS, APPROACH OVERRIDES, ETC.) DESCRIBED IN SECTION 6 OF SIEMENS MICROPROCESSOR BASED GRADE CROSSING PREDICTOR 4000 FAMILY APPLICATION GUIDELINES, SIG-00-08-06.

The SGCP 4000/MS 4000 provides a simple predictor to allow users to set up crossing applications with programmable warning times. When programmed to PRED=YES (or \*Prime MS/GCP Mode=Pred on the DT), the SGCP 4000/MS 4000 will perform as a very simple predictor, activating the crossing in accordance with its programmed warning time. The predictor is not capable of performing any advanced programming actions (DAXing, ANDing, Traffic Preemption, etc.) as described in Section 6 of the GCP 4000 Application Guidelines Manual.

## 4.3 MAINTENANCE CALL OUTPUT

The maintenance call output may be controlled by the SGCP 4000/MS 4000, an external SSCC, or other equipment at the crossing connected via ECHELON LAN.

#### 4.3.1 Internal Deactivation

When equipped with an external SEAR, the maintenance call output is deactivated if:

- The CPU detects a low battery condition
- The SEAR detects that POK (power off indicator) is low
- Communication with the external SEAR is lost
- Unit is taken Out-of-Service (OOS)
- During any transfers from MAIN to STBY or STBY to MAIN, until the active side is fully recovered.

## 4.4 TAKING TRACKS "OUT OF SERVICE"

## **WARNING**

THE RAILROAD PROCEDURES GOVERNING HOW TO TAKE A TRACK CIRCUIT OUT OF SERVICE (OOS) SHALL BE FOLLOWED. THE INSTRUCTIONS IN THIS SECTION MAY BE FOLLOWED ONLY IF ALLOWED BY THE RAILROAD.



OUT OF SERVICE TRACKS WILL NOT RESPOND TO TRAIN OPERATION. TAKE ALTERNATE MEANS TO WARN VEHICULAR TRAFFIC, PEDESTRIANS, AND EMPLOYEES.

REQUIRED OPERATIONAL TESTS SHOULD BE PERFORMED IN ACCORDANCE WITH RAILROAD PROCEDURES WHEN RESTORING TRACKS TO SERVICE.

DO NOT USE TEST TERMINALS OR SWITCHES THAT CAN VIBRATE CLOSED TO ENERGIZE OOS INPUTS. .

## NOTE

## NOTE

There are only two inputs available on the SGCP 4000/MS 4000. If an application plan specifies both External Island and UAX inputs, there is no input available for assignment as an OOS. Planners must keep this fact in mind when creating SGCP 4000/MS 4000 applications.

When an approach is out of service, the message "APPR OOS" OR "XNG OOS" scrolls across the 4-Character Display and if a Diagnostic Terminal (DT) is connected, its display will remain ON and not go into the sleep mode. The track module outputs remain energized (no crossing activation). Module motion and island LEDs remain ON during train movements. External inputs are ignored (UAX and External Island). Most OOS Track module failures and all corresponding rail failures are ignored. Failure types and causes can be reviewed by selecting the DIAG button. The Island is ignored when the approach and the island are selected OOS. Maintenance call light is turned off when the input is energized, and lights when the input is de-energized. Status log shows OOS EZ changes and EX on train moves but XR Relay does not de-energize nor are warning times displayed.

If the SGCP 4000/MS 4000 switches over between MAIN and STANDBY modules, OOS tracks will be placed in-service and will remain in-service until user selects tracks OOS again.

## 4.4.1 OOS Options

#### NOTE

If the approaches (APPR) or the approaches and the island together (XNG) are Out of Service and one of the following occurs, the component is put back In Service:

NOTE

- The Out of Service Timer expires
- Transfer occurs
- The user puts the component back into service using the user interface
- The Unit reboots
- The Unit detects a health error (not including Island or motion sensor component errors).

The approaches (APPR), or the approaches and the island together (XNG) may be taken out of service. When the Out of Service option XNG is activated, the unit does not command the crossing to activate and only logs the train activity.

## NOTE

NOTE

The Maintenance Call light is de-energized whenever the OOS input is energized. Ensure that the input is only energized only when the unit is to be taken OOS.

To enable Out of Service on the SGCP 4000/MS 4000:

Scroll down the main menu to PROG and select either IN1.1 or IN1.2.

- 1. When IN1.X=XXXX appears, press and hold the SEL button until NONE appears.
- 2. Press the NAV button until OOS appears.
- 3. Press and hold the SEL button until SET IN1.X=OOS?
- 4. Press and hold the SEL button until DONE appears. IN1.X=OOS appears.
- 5. Verify IN1.X. is de-energized.

## 4.4.1.1 Take Approach OOS via 4-Character Display & Pushbuttons

To take only the approaches Out of Service:

Scroll down the main menu to OOS and select OOS.

- 1. Energize IN1.X.
- 2. When SET OOS TIME appears, either select NONE (for permanent OOS) or the length of time required, set in hourly increments (01 23 hours, in 1-hour increments).
- 3. Press and hold the SEL button until DONE appears. OOS TIME=XXHR (e.g., OOS TIME=4HR) appears.
- 4. When APPR appears, press the Select button for approximately 2 seconds.
- 5. Select "TAKE APPR OOS?" as it appears in the window.
- 6. The 4-Character Display scrolls APPR OOS REM TIME XX:XX (e.g., APPR OOS REM TIME 03:59). This message scrolls as the top-level description until the timer expires.

# 4.4.1.2 Take Crossing (Approaches & Island) OOS via 4-Character Display & Pushbuttons

To take the Crossing (XNG), Out of Service:

Scroll down the main menu to OOS and select OOS.

- 1. Energize IN1.X.
- 2. When SET OOS TIME appears, either select NONE (for permanent OOS) or the length of time required, set in hourly increments (01 23 hours, in 1-hour increments).
- 3. Press and hold the SEL button until DONE appears. OOS TIME=XXHR (e.g., OOS TIME=4HR) appears.
- 4. When APPR appears, the NAV button until XNG appears in the 4-Character Display
- 5. Press the Select button for approximately 2 seconds.
- 6. Select "TAKE XNG OOS?" as it appears in the window.
- 7. The 4-Character Display scrolls XNG OOS REM TIME XX:XX (e.g., XNG OOS REM TIME 03:59). This message scrolls as the top-level description until the timer expires.

#### 4.4.1.3 Take Approach OOS via DT

To take only the approaches Out of Service:

Scroll down the main menu to OOS and select OOS.

- 1. Energize IN1.X.
- 2. Right click the DT and select OOS
- 3. If required, select the EDIT button by the upper OOS Timeout and select YES if the approach is to be OOS for a set number of hours (01 23) or NO if OOS is to be permanent.
- 4. If required and the OOS Timeout value is set to YES, select the EDIT button by the lower OOS Timeout and set the timer to the desired period (01 23 hours).
- 5. Select the TAKE GCP OUT OF SERVICE button.
- Select Yes when the message "Are you sure you want to take GCP Out Of Service?"

## 4.4.1.4 Take Crossing (Approaches and Island) OOS via DT

To take the Crossing (XNG) (both Approaches and the Island) Out of Service:

Scroll down the main menu to OOS and select OOS.

- 1. Energize IN1.X.
- 2. Right click the DT and select OOS
- 3. If required, select the EDIT button by the upper OOS Timeout and select YES if the approach is to be OOS for a set number of hours (01 23) or NO if OOS is to be permanent.
- 4. If required and the OOS Timeout value is set to YES, select the EDIT button by the lower OOS Timeout and set the timer to the desired period (01 23 hours).
- 5. Select the TAKE ISL OUT OF SERVICE button.
- 6. Select Yes when the message "Are you sure you want to take GCP Out Of Service?"

## 4.4.1.5 Take Approach OOS via WebUI (CPU III)

To take only the approaches Out of Service:

- 1. Access the Out Of Service page on the WebUI using under System View > Track menu.
- 2. Select the option to Take GCP Out of Service

First, enter the **Out of Service Timeout** that is required, and press **Save**. The timer cannot be changed once a track is out of service, so it needs to be set first. The valid values are 0 to 23 hours, where the value 0 means that the timeout is not being used.

3. The WebUI will ask for confirmation as shown below.



Figure 4-3: WebUI: Out of Service Acknowledge

4. Select **OK** if required. The WebUI will now show: **GCP Out of Service** as shown in Figure 4-4 on the left. The System View will show the GCP OOS icon flashing between blue and white.




Figure 4-4: WebUI: Out of Service Indications

The track module will also display the message GOFS on its four-character display. The maintenance call output on the SGCP 4000/MS 4000 will turn off, causing the maintenance call lamp to go off, if it is wired. The maintenance call light is illuminated when running properly, if it goes dark, that indicates a problem at the location.



#### NOTE

When a GCP is OOS but the island remains in service, the crossing will activate when the island is occupied.

## 4.4.1.6 Take Crossing (Approaches and Island) OOS via WebUI (CPU III)

To take the Crossing (XNG) (both Approaches and the Island) Out of Service:

- To take the island out of service, first take the GCP out of service (SGCP 4000/MS 4000), then select the **Take ISL Out of Service** button shown in Figure 4-4 above.
- 2. This will bring up the following confirmation screen. Select **OK** to continue.





Figure 4-5: Island Out of Service Confirmation

The **Out of Service** screen will now show the Island as **Out of Service**, and the top system level screen will show the message **GCP-ISL OOS** that will alternate between blue and white. The track module will display the messages **GOFS** and **IOFS** on its four-character display. As before, the maintenance call output on the SGCP 4000/MS 4000 will turn off, this will cause the maintenance call lamp to go off, if it is wired.



Figure 4-6: Island Out of Service Indications on WebUI



## 4.4.1.7 Returning an OOS Function to Service

Deenergizing the OOS input causes the approach or crossing to be returned to service. Another method to return an OOS approach or crossing is as follows:

Scroll down the main push-button menu to OOS and select OOS.

- 1. When PUT APPR IN SERV? Or PUT XNg IN SERV? appears, press and hold the SEL button until DONE appears.
- 2. OOS TIME=00:00 appears, then the menu scrolls SGCP 4000/MS 4000 (e.g., OOS TIME=4HR) appears

When returned to service, the 4-digit display returns to normal configuration, (e.g., SGCP 4000/MS 4000). Ensure the Input is de-energized when the OOS period is complete.

On the DT, simply select either Put GCP Back in Service to return the entire unit to service or select Put ISL Back in Service to leave the approaches Out Of Service.

On the WebUI (for CPU III) select the Put GCP Back in Service.

## SECTION 5 - AUXILIARY EQUIPMENT

#### 5.0 GENERAL

The equipment described in this section can be used with the SGCP 4000/MS 4000. Where applicable, installation and adjustment information is provided. The following equipment is covered:

<u>Section</u>	Equipment Covered	<u>Page</u>
5.1	Bidirectional Simulation Coupler, 62664-Mf	5-1
5.2	DC Shunting Enhancer Panel, 80049	5-7
5.3	Narrow-band Shunt, 62775-f	5-13
5.4	Narrow-band Shunt, 62780-f	5-14
5.5	Multi-frequency Narrow-band Shunt, 62775-XXXX	5-15
5.6	Multi-frequency Narrow-band Shunt, 62780-XXXX	5-19
5.7	Wideband Shunt, 8A076A	5-20
5.8	Simulated Track Inductor, 8V617	5-21
5.9	Adjustable Inductor Assembly, 8A398-6	5-27
5.10	Track Circuit Isolation Devices	5-31
5.10.1	Steady Energy DC Track Circuits	5-31
5.10.1.1	Battery Chokes, 62648 & 8A065A	5-33
5.10.2	Siemens GEO Electronic DC Coded System	5-34
5.10.3	ElectroCode Electronic DC Coded System	5-34
5.10.5	Relay Coded DC Track	5-34
5.10.5.1	DC Code Isolation Unit, 6A342-1	5-35
5.10.6	AC Code Isolation Units	5-39
5.10.6.1	60 Hz AC Code Isolation Unit, 8A466-3	5-39
5.10.6.2	100 Hz AC Code Isolation Unit, 8A470-100	5-40
5.10.6.7	180 Hz AC Code Isolation Unit, 8A471-180	5-42
5.11	Tunable Insulated Joint Bypass Coupler, 62785-f	5-42
5.12	MS/GCP Termination Shunt Burial Kit, 62776	5-48
5.13	Surge Panels, 80026-XX	5-49
5.14	Rectifier Panel Assembly, 80033	5-60
5.15	Cable Termination Panel Assembly, 91042	5-60

## 5.1 BIDIRECTIONAL SIMULATION COUPLER, 62664-MF

When a SGCP 4000/MS 4000 is connected in a six-wire configuration (two receiver wires, two transmit wires, and two check wires) as shown in Figure 5-3, the bidirectional simulation coupler must be connected to the check (CHK) wires, not to the transmit (XMT) wires. If the coupler is connected to the transmit wires, an open transmitter track wire cannot be detected and can, therefore, adversely affect motion sensor operation. However, in standard four-wire bidirectionally-wired (simulated bidirectional) installations; it is permissible to connect the coupler to the two-transmitter track leads as shown.

This condition exists for six wire applications using bidirectional simulation equipment which is located in the case/bungalow (not at the tracks) regardless of which of the following types of simulated track load is used:

- (1) bidirectional simulation coupler (62664 mf),
- (2) single-frequency narrowband shunt (62775 mf) used in conjunction with adjustable inductor (8a398 6), or

(3) multi-frequency narrow band shunt (62775 or 62780) equipped with simulated track inductor (8v617 distance).

In standard four track wire bidirectionally-wired (simulated bidirectional) installations, it is permissible to connect the simulated bidirectional load to the two transmitter track leads in the bungalow as shown in Figure 5-3.




Figure 5-1: Bidirectional Simulation Coupler, 62664-Mf

Low ballast resistance effectively reduces approach distances to a greater degree in unidirectional SGCP 4000/MS 4000 installations than in bidirectional installations.

## WARNING



THE 62664 BIDIRECTIONAL SIMULATION COUPLER <u>MUST NOT</u> BE USED AS A TERMINATION SHUNT.

THE 62664 PLUG-IN MODULE FREQUENCY MUST BE THE SAME AS THE MOTION SENSOR FREQUENCY.

In a simulated bidirectional configuration, a narrow-band shunt is connected in series with an adjustable inductor. This combination is:

- Connected in parallel across the track connections.
- Electrically equal to that of the actual track approach circuit.

Both approach circuits appear equal in length to the SGCP 4000/MS 4000, even though one of the circuits consists of the shunt and inductor located in the instrument housing/bungalow.

The 62664 Bidirectional Simulation Coupler (Figure 5-1) is a convenient, compact, shelf- or backboard-mounted unit containing:

- A narrow-band Shunt of the same frequency as the motion sensor
- An adjustable inductor (simulated track).

The Bidirectional Simulation Coupler is housed in a brushed aluminum case and consists of:

- A single plug-in-type printed circuit board that is available in 12 fixed frequencies (Hz)
- Four series-connected, toroid-wound inductors. Each inductor simulates a specific track length and is tapped and connected to the front panel terminals.

The front panel terminals allow simulated approach distances to be selected that closely match the actual track approach:

- Approach distances ranging from 400 to 6,000 feet (122 1829 meters) may be selected using terminal shorting straps.
- The available simulated approach distances and the corresponding shorting strap terminal positions for the 62664 are shown in Table 5-1.

Table 5-1: Approach Distance Selection Strapping For Bidirectional Simulation Coupler, 62664-Mf

DISTANCE FEET/METERS	STRAP TERMINALS	DISTANCE FEET/METERS	STRAP TERMINALS
400/122	B-C, C-D, D-E	3,600/1098	B-C, C-D
800/244	A-B, C-D, D-E	4,000/1220	A-B, C-D
1,200/366	C-D, D-E	4,400/1342	C-D
1,600/488	A-B, B-C, D-E	4,800/1464	A-B, B-C
2,000/610	B-C, D-E	5,200/1585	B-C
2,400/732	A-B, D-E	5,600/1707	A-B
2,800/854	D-E	6,000/1829	No Straps
3,200/976	A-B, B-C, C-D		

When a SGCP 4000/MS 4000 is connected in a six-wire configuration the bidirectional simulation coupler must be connected to the check (CHK) wires as shown in Figure 5-2.

When a SGCP 4000/MS 4000 is connected in a standard four-wire configuration, the bidirectional simulation coupler is connected to the two transmit leads as shown in Figure 5-2.

Mounting dimensions for the bidirectional simulation coupler are provided in Figure 5-3. Specifications for the bidirectional simulation coupler are as depicted in Table 5-2:

Table 5-2: Bidirectional Simulation Coupler, 62664-Mf

PARAMETER	VALUE
Environmental	-40°F to +160°F (-40°C to +71°C)
Dimensions	8.75 inches (22.225 centimeters) high
	8.50 inches (21.590 centimeters) wide
	9.25 inches (23.495 centimeters) deep
Weight	5 pounds (2.27 kilograms) (approximate)
Adjustment Range	400 to 6,000 feet (122 – 1829 meters)
Loading Effect	Loading effects of the internal narrow-band Shunt are equivalent to that of the 62775 narrow-band Shunt.

# NOTE

## NOTE

The adjustment range must be within ±10% of actual approach distance.




Figure 5-2 4-wire & 6-wire Connections using Bidirectional Simulation Coupler on SGCP 4000/MS 4000 Operating in Bidirectional Simulation mode

5-5




Figure 5-3: Bidirectional Simulation Coupler Assembly Mounting Dimensions

## 5.2 DC SHUNTING ENHANCER PANEL, 80049

Intermittent poor shunting can result just about anywhere due to numerous causes, but generally occurs due to:

- infrequent track usage
- lightly weighted cars
- passenger and transit operation
- spillage from rail cars
- rail contamination

Lack of any shunting generally occurs in dark territory where no DC or AC track circuits exist and few trains run. Track shunting in dark territory can be easily improved using methods similar to those employed in style-C track circuits (but without the need for so many insulated joints). This involves the use of one insulated joint at the far end of each approach and the application of a DC voltage to the track at the crossing.

These measures improve shunting, thus allowing the SGCP 4000/MS 4000 Enhanced Detection software to function optimally.




Figure 5-4: DC Shunting Enhancer Panel, 80049

## 5.2.1 Track Output Voltage

The Siemens 80049 DC Shunting Enhancer Panel, Figure 5-4, applies a nominal 6 volts DC to the track at the crossing to break down any insulating film that may develop on the rails. This DC voltage is isolated from battery and is generated from a 110-volt AC step-down transformer when AC is present or utilizes battery powered DC-to-DC converter when AC is off. The panel switches automatically to the DC-to-DC converter output if AC fails.

## 5.2.2 Monitor Output Voltage

The Monitor Output voltage is applied to a SGCP 4000/MS 4000 vital input programmed as a UAX. Loss of the Monitor Output voltage will activate the crossing. The UAX input enable must be programmed with a minimum of 5 second pickup delay.

## 5.2.3 Track Requirements

Installation of the Siemens 80049 DC Shunting Enhancer Panel requires the placement of at least one joint at the far end of each approach. The insulated joints are required to confine the DC track voltage to the crossing. The insulated joints can be located beyond the approach narrow-band shunt termination as desired.

The 80049 panel can be rack, wall, or shelf mounted. See Figure 5-4 for mounting dimensions.

**A** WARNING

#### WARNING

THE TERMINATION SHUNTS MUST BE 62775-F OR 62780-F NARROW-BAND SHUNTS. SOME FAILURE MODES CANNOT BE DETECTED IF HARDWIRE OR WIDEBAND SHUNTS ARE USED. MOTION SENSOR TRANSMIT WIRES MUST FIRST BE ROUTED TO THE ENHANCER PANEL TRACK CONNECTIONS AND THEN ON TO THE TRACK; IF NOT, SOME FAILURES CANNOT BE DETECTED BY THE SYSTEM. (SEE Figure 5-7)

**A** CAUTION

#### CAUTION

WHEN TWO OR MORE DARK TERRITORY CROSSINGS OVERLAP, ENSURE THAT EACH SGCP 4000/MS 4000 CROSSING HAS AN 80049 PANEL IN OPERATION AND THAT THE POLARITY OF THE TRACK VOLTAGE TO THE RAIL FROM ALL 80049 PANELS IS THE SAME AT EACH CROSSING.

NOTE

#### NOTE

The DC Shunting Enhancer Panel can be used with applications involving overlapping approaches from two or more crossings without the use of additional insulated joints.

A typical DC Shunting Enhancer Panel application drawing for a two track application is provided in Figure 5-7 and for two overlapping crossings is provided in Figure 5-8.

## 5.2.4 Interface Terminal Connections

The DC Shunting Enhancer Panel is equipped with eight user interface terminals. These terminals are connected as shown in Figure 5-5.




Figure 5-5: DC Shunting Enhancer Panel, 80049, Interface Terminal Connections

# 5.2.5 DC Shunting Enhancer Panel Specifications

Table 5-3: DC Shunting Enhancer Panel Specifications

PARAMETER	VALUES		
Input Power:			
AC Voltage:	95 to 130 VAC		
DC Voltage:	11 to 16 VDC		
DC Current (AC present):	0 amps		
DC Current (AC not present):	0.25 amps with no train and high ballast resistance 2.5 amps with train shunting track		
Environmental Temperature Range:	-40 °F to +160 °F (-40 °C to +71 °C)		
UAX Output:	+15.0 ± 0.2 VDC		
Surge Protec8tion:	Primary protection required for AC input and battery		
	Secondary protection provided internally		
Humidity:	95%, non-condensing		
-1 unit:	6.97 inches (17.704 centimeters) high		
	23.0 inches (58.420 centimeters) wide		
	10.75 inches (27.305 centimeters) deep		
-5 unit:	6.97 inches (17.704 centimeters) high		
	23.0 inches (58.420 centimeters) wide		
	5.75 inches (14.605 centimeters) deep		
Weight:	-1 unit: 32 pounds (14.4 kilograms) (approximate)		
	-5 unit: 17 pounds (7.65 kilograms) (approximately)		
Mounting Dimensions	The DC Shunting Enhancer Panel can be rack, wall, or shelf mounted. The Panel mounting dimensions are provided in Figure 5-6.		




Figure 5-6: DC Shunting Enhancer Panel Mounting Dimensions

# 5.2.6 DC Shunting Enhancer Panel Configuration Options

Two DC Shunting Enhancer Panel configuration options are available. These configurations are described in Table 5-4.

**Table 5-4: DC Shunting Enhancer Panel Configuration Options** 

PART NUMBER	OPTION DESCRIPTION	
8000-80049-0001	Panel with CXP-3 DC-to-AC Inverter	
8000-80049-0005	Panel without CXP-3 DC-to-AC Inverter Used in two track applications	

# 5.2.7 Two Track and Overlapping Crossing Applications

When two 80049 Panels are required with applications involving two tracks at a crossing, the first panel is an 80049-0001 and the second panel may be an 80049-0001 or 80049-0005.



## NOTE

When the -5 panel is used, it must be connected to the isolated 6.3 VAC inverter output of the first panel as shown in Figure 5-7.

When there are two crossings that have overlapping approaches, this application may be implemented as shown in Figure 5-8.




Figure 5-7: DC Shunting Enhancer Panels for Two Track Crossing

SIG-00-11-02 Version No.: A.8




Figure 5-8: DC Shunting Enhancer Panels for Overlapping Crossings

#### 5.3 NARROW-BAND SHUNT, 62775-F

#### **CAUTION**

WHEN ADDING OR REPLACING TERMINATION SHUNTS, APPROPRIATE TESTS MUSTS BE MADE TO DETERMINE THAT THE TERMINATION SHUNT DID NOT ADVERSELY AFFECT OTHER HIGHWAY CROSSING WARNING SYSTEM OR WAYSIDE SIGNAL SYSTEM TRACK CIRCUITS.



THE SHUNT SHOULD BE CONNECTED AS CLOSE AS PRACTICABLE TO THE RAILS (WITHIN THE #6 AWG WIRE LEAD LENGTH OF 10 FEET {3.05 METERS}) AND, TO AFFORD MAXIMUM PROTECTION FROM PHYSICAL DAMAGE, BE ENCASED IN A PROTECTIVE ENCLOSURE OR BURIED (EITHER VERTICALLY OR HORIZONTALLY) AT AN APPROPRIATE DEPTH (SEE PARAGRAPH 5.12). IT IS NOT NECESSARY TO BURY THE SHUNT BELOW THE FROST LINE.

The 62775-f Narrow-band Shunt (Figure 5-9) is intended for use in areas where other AC frequencies or DC coded track circuits are present, but where only the SGCP 4000/MS 4000 frequency should be terminated.

The Shunt requires no special tuning and is generally preferred for most applications.

The 62775-f Narrow-band Shunt is housed in a hermetically sealed, cylindrical case with a pair of 10-foot leads extending from one end.

The Shunt is available in any fixed frequency (Hz) listed in the chart below (Siemens frequencies are shown in **boldface** type).

Table 5-5: Frequencies Available with Narrow Band Shunt, 62775-f

86	151	285	522	753
100	156	326	525	790
114	172	348	560	816
134	210	392	630	881
141	211	430	645	970
149	267	452	686	979

## 5.3.1 Narrow-band Shunt, 62775-F Specifications

Dimensions 16 inches (40.640 centimeters) long

5 inches (12.700 centimeters) in diameter

Weight 10 pounds (4.54 kilograms) (approximate)

Frequencies See Table 5-5 above.

Leads 10 feet (3.05 meters); number 6 AWG, stranded, black PVC

## 5.4 NARROW-BAND SHUNT, 62780-F

#### CAUTION

WHEN ADDING OR REPLACING TERMINATION SHUNTS, APPROPRIATE TESTS MUSTS BE MADE TO DETERMINE THAT THE TERMINATION SHUNT DID NOT ADVERSELY AFFECT OTHER HIGHWAY CROSSING WARNING SYSTEM OR WAYSIDE SIGNAL SYSTEM TRACK CIRCUITS.



THE SHUNT SHOULD BE CONNECTED AS CLOSE AS PRACTICABLE TO THE RAILS (WITHIN THE #6 AWG WIRE LEAD LENGTH OF 10 FEET {3.05 METERS}) AND, TO AFFORD MAXIMUM PROTECTION FROM PHYSICAL DAMAGE, BE ENCASED IN A PROTECTIVE ENCLOSURE OR BURIED (EITHER VERTICALLY OR HORIZONTALLY) AT AN APPROPRIATE DEPTH (SEE PARAGRAPH 5.12). IT IS NOT NECESSARY TO BURY THE SHUNT BELOW THE FROST LINE.

The Narrow-band Shunt, 62780-f (Figure 5-9) is intended for use in areas where other AC frequencies or DC coded track circuits are present, but where only the SGCP 4000/MS 4000 frequency should be terminated.

Similar to the Narrow-band Termination Shunt, 62775 (paragraph 5.3).

The 62780 Shunt produces less loading effect on adjacent frequencies (10 ohms reactance) than the 62775 Shunt:

This shunt can be used in territories with overlapping Model 300 and Model 400 GCP approaches.

The 62780 Narrow-band Shunt is compatible with all Siemens Motion Sensors and GCP's.

This shunt is available in any one of 26 frequencies ranging from 86 Hz to 979 Hz as shown in the following chart (Siemens frequencies are shown in **boldface** type).

Table 5-6: Frequencies Available with Narrow Band Shunt, 62780-f

86	;	151	211	326	430	525	645	790	970
10	0	156	267	348	452	560	686	816	979
11	4	210	285	392	522	630	753	881	1

The Narrow-band Shunt, 62780 is housed in a cylindrical case with a pair of 10-foot leads extending from one end.

#### 5.4.1 Narrow-band Shunt, 62780-f Specifications

Dimensions 14.125 inches (35.9 centime

**F.1** 4.125 inches (10.5 centimeters) in

diameter

Weight 7 pounds (3.18 kilograms) (approximate)

Frequencies See Table 5-6 above.

Leads 10 feet (3.05 meters); number 6 AWG, stranded, black PVC




Figure 5-9: Siemens Narrow-band and Wide-band Termination Shunts

## 5.5 MULTI-FREQUENCY NARROW-BAND SHUNT, 62775-XXXX

## **WARNING**



THE 62775-XXXX MULTI-FREQUENCY NARROW-BAND SHUNT MUST NOT BE USED ANYWHERE WITHIN A MODEL 300 OR 400 GCP APPROACH; NARROW-BAND SHUNT 62780-XXXX IS RECOMMENDED FOR THESE APPLICATIONS.

CAREFULLY TIGHTEN ALL NUTS ON ALL FREQUENCY JUMPERS, AND THEN INSTALL A SECOND NUT TO SECURELY LOCK THE ASSEMBLY.

## CAUTION

WHEN ADDING OR REPLACING TERMINATION SHUNTS, APPROPRIATE TESTS MUSTS BE MADE TO DETERMINE THAT THE TERMINATION SHUNT DID NOT ADVERSELY AFFECT OTHER HIGHWAY CROSSING WARNING SYSTEM OR WAYSIDE SIGNAL SYSTEM TRACK CIRCUITS.



THE SHUNT SHOULD BE CONNECTED AS CLOSE AS PRACTICABLE TO THE RAILS (WITHIN THE #6 AWG WIRE LEAD LENGTH OF 10 FEET {3.05 METERS}) AND, TO AFFORD MAXIMUM PROTECTION FROM PHYSICAL DAMAGE, BE ENCASED IN A PROTECTIVE ENCLOSURE OR BURIED (EITHER VERTICALLY OR HORIZONTALLY) AT AN APPROPRIATE DEPTH (SEE PARAGRAPH 5.12). IT IS NOT NECESSARY TO BURY THE SHUNT BELOW THE FROST LINE.

#### NOTE

NOTE

The Shunt is shipped with no factory jumpers installed and is, therefore, electrically open and does not load any frequency on the track. Install jumpers for the desired frequency before placing the unit in service.

The Multi-frequency Narrow-band Shunt, 62775-XXXX, like its single single-frequency counterpart (paragraph 5.3), is designed to terminate specific track frequencies in areas where other audio frequencies or DC coded track circuits are present.

## 5.5.1 Physical Description

The Multi-frequency Narrow-band Shunt, 62775-XXXX, (Figure 5-10) is slightly longer than its single-frequency counterpart (Section 5.3) but exhibits the same electrical characteristics as the basic single-frequency unit.

## 5.5.2 Frequency Selection

The Multi-frequency Narrow-band Shunt is available in eight frequency ranges.

The Shunt is housed in a hermetically sealed, cylindrical case with a pair of 10-foot (3.048 meter) leads extending from one end and seven standard AREMA terminals extending from the other.

The terminals are labeled A through G and are jumpered to select the desired shunting frequency (Table 5-7).




Figure 5-10: Multi-frequency Narrow-band Shunt, 62775-XXXX/62780-XXXX AREMA Binding Posts

## NOTE

#### NOTE

Terminal jumper hardware is supplied with each Shunt. The Shunt is shipped with no factory jumpers installed and is therefore electrically open and does not load any frequency on the track. Install jumpers for the desired frequency before placing the unit into service. A label located inside the removable end cap identifies the terminal jumpering for each frequency.

The pliable end cap covering the terminal end of the Shunt is secured in place by a sturdy stainless steel clamp for protection against moisture.

## 5.5.3 Multi-frequency Narrow-band Shunt, 62775-XXXX Specifications

Dimensions 22 inches (55.880 centimeters) long

5 inches (12.700 centimeters) in diameter

Weight 10 pounds (4.54 kilograms) (approximate)

Frequencies See Table 5-7

Leads 10 feet (3.048 meters); number 6 AWG, stranded, black PVC

Table 5-7: Multi-frequency Narrow-band Shunt, 62775-XXXX Frequency Selection Jumpers

SHUNT PART NUMBER	FREQUENCY (HZ)	JUMPER SHUNT TERMINALS
	86	A-F, G-D, D-E, E-F
00775 0004	114	B-G, G-D, D-E
62775-8621	156	C-D, D-G
	211	C-D
	156	A-F, G-C, C-D, D-E, E-F
	211	A-G, G-C, C-D, D-E
62775-1543	285	B-C, C-D, D-G,
	348	B-C, C-D
	430	B-C
	211	A-F, G-C, C-D, D-E, E-F
	267	B-G, G-C, C-D, D-E
62775-2132*	285	B-C, C-D, D-G
	313	B-C, C-D
	326	B-C
	211	A-F, G-C, C-D, D-E, E-F
	285	B-C, C-D, D-E, E-G
62775-2152	348	B-C, C-D, D-G
32 3 2.02	430	B-C, C-D
	525	B-C
	348	A-B, B-C, C-D, D-E, E-F, F-G
	389	A-B, B-C, C-D, D-E, E-F
	392	A-B, B-C, C-D, D-E
62775-3448*	430	A-B, B-C, C-D
	452	A-B, B-C
	483.5	A-B
	348	A-B, B-C, C-D, D-E, E-F, F-G
	430	A-B, B-C, C-D, D-E, E-F
	525	A-B, B-C, C-D, D-E
62775-3497	645	A-B, B-C, C-D
	790	A-B, B-C
	970	A-B
	522	A-B, B-C, C-D, D-E, E-F, F-G
	525	A-B, B-C, C-D, D-E, E-F
	560	A-B, B-C, C-D, D-E
62775-5274*	645	A-B, B-C, C-D
	669.9	A-B, B-C
	746.8	A-B
	790	A-B, B-C, C-D, D-E, E-F, F-G
	816	A-B, B-C, C-D, D-E, E-F
	832.5	A-B, B-C, C-D, D-E
62775-7910*	970	A-B, B-C, C-D
	979	A-B, B-C
	1034	A-B
*Available for appoint applies		/ ·-U

<sup>\*</sup>Available for special applications only

## 5.6 MULTI-FREQUENCY NARROW-BAND SHUNT, 62780-XXXX

# **A** WARNING

#### WARNING

CAREFULLY TIGHTEN ALL NUTS ON ALL FREQUENCY JUMPERS, AND THEN INSTALL A SECOND NUT TO SECURELY LOCK THE ASSEMBLY.

#### CAUTION

WHEN ADDING OR REPLACING TERMINATION SHUNTS, APPROPRIATE TESTS MUSTS BE MADE TO DETERMINE THAT THE TERMINATION SHUNT DID NOT ADVERSELY AFFECT OTHER HIGHWAY CROSSING WARNING SYSTEM OR WAYSIDE SIGNAL SYSTEM TRACK CIRCUITS.

# **A** CAUTION

THE SHUNT SHOULD BE CONNECTED AS CLOSE AS PRACTICABLE TO THE RAILS (WITHIN THE #6 AWG WIRE LEAD LENGTH OF 10 FEET {3.05 METERS}) AND, TO AFFORD MAXIMUM PROTECTION FROM PHYSICAL DAMAGE, BE ENCASED IN A PROTECTIVE ENCLOSURE OR BURIED (EITHER VERTICALLY OR HORIZONTALLY) AT AN APPROPRIATE DEPTH (SEE PARAGRAPH 5.12). IT IS NOT NECESSARY TO BURY THE SHUNT BELOW THE FROST LINE.

#### NOTE

## NOTE

The Multi-frequency Narrow-band Shunt is shipped with no factory jumpers installed and is, therefore, electrically open and does not load any frequency on the track. Install jumpers for the desired frequency before placing the unit in service.

The Multi-frequency Narrow-band Shunt, 62780-XXXX Figure 5-10, can be used in territories with overlapping Model 300 and Model 400 GCP approaches.

#### This shunt:

- Produces less loading effect on adjacent frequencies (10 ohms reactance) than the 62775-xxxx Shunt (paragraph 5.6)
- Is compatible with all Siemens GCP's and Motion Sensors.
- Is available in four Multi-frequency versions (see Table 5-8).
- Is housed in a cylindrical case:

A pair of 10-foot leads extends from one end of the case. Seven standard AREMA terminals extend from the opposite end of the case.

- AREMA terminals use jumpers to select the desired shunt frequency.
- AREMA terminals are labeled A through G
- Terminal jumper hardware is supplied with each Multi-frequency Shunt:
- A label located inside the removable end cap identifies the terminal jumpers required for each frequency.

The pliable end cap covers the terminal end of the Shunt is secured in place by a sturdy stainless steel clamp for protection against moisture.

Table 5-8: Multi-frequency Narrow-band Shunt, 62780 Frequency Selection Jumpers

SHUNT PART NUMBER	FREQUENCY (HZ)	JUMPER SHUNT TERMINALS
	86	A-F, G-D, D-E, E-F
60700 0604	114	B-G, G-D, D-E
62780-8621	156	C-D, D-G
	211	C-D
	156	A-F, G-C, C-D, D-E, E-F
	211	A-G, G-C, C-D, D-E
62780-1543	285	B-C, D-G, C-D
	348	B-C, C-D
	430	B-C
	211	A-F, G-C, C-D, D-E, E-F
	285	B-C, C-D, D-E, C-G
62780-2152*	348	B-C, C-D, D-G
	430	B-C, C-D
	525	B-C
	525	A-B, B-C, C-D, D-E
60700 5007	645	A-B, B-C, C-D
62780-5297	790	A-B, B-C
	970	A-B

<sup>\*</sup>Available for special applications only

## 5.6.1 Multi-frequency Narrow-band Shunt, 62780-XXXX Specifications

Dimensions 22 inches (55.880 centimeters) long

5 inches (12.700 centimeters) in diameter

Weight 10 pounds (4.54 kilograms) (approximate)

Frequencies See Table 5-8 above

Leads 10 feet (3.048 meters); number 6 AWG, stranded, black PVC

# 5.7 WIDEBAND SHUNT, 8A076A



### WARNING

THE 8A076A OR 8A077 WIDEBAND SHUNTS MUST NOT BE USED TO BYPASS INSULATED JOINTS IN DC CODED TRACK CIRCUITS OR WHERE AC OR CODED AC CIRCUITS EXIST.

## CAUTION

WHEN ADDING OR REPLACING TERMINATION SHUNTS, APPROPRIATE TESTS MUSTS BE MADE TO DETERMINE THAT THE TERMINATION SHUNT DID NOT ADVERSELY AFFECT OTHER HIGHWAY CROSSING WARNING SYSTEM OR WAYSIDE SIGNAL SYSTEM TRACK CIRCUITS.

# **A** CAUTION

THE SHUNT SHOULD BE CONNECTED AS CLOSE AS PRACTICABLE TO THE RAILS (WITHIN THE #6 AWG WIRE LEAD LENGTH OF 10 FEET {3.05 METERS}) AND, TO AFFORD MAXIMUM PROTECTION FROM PHYSICAL DAMAGE, BE ENCASED IN A PROTECTIVE ENCLOSURE OR BURIED (EITHER VERTICALLY OR HORIZONTALLY) AT AN APPROPRIATE DEPTH (SEE PARAGRAPH 5.12). IT IS NOT NECESSARY TO BURY THE SHUNT BELOW THE FROST LINE.

## NOTE

## NOTE

The use of dual wideband couplers, part number 8A077, is not recommended for SGCP 4000/MS 4000 applications.

The Wideband Shunt, 8A076A (Figure 5-9) provides an effective short circuit to AC but presents an open circuit to DC. This shunt may be used as a termination shunt where no other frequencies (other than the motion sensor) are present or to bypass existing insulated joints required for DC signaling purposes within the track circuit.

The Wideband Shunt is housed in a cylindrical case with a pair of 10-foot leads extending from one end.

## 5.7.1 Wideband Shunt Specifications

Dimensions 7.5 inches (19.050centimeters) long

3.35 inches (8.509 centimeters) in diameter

Weight 7 pounds (3.18 kilograms) (approximate)

Leads 10 feet (3.048 meters); number 6 AWG, stranded, black PVC

# 5.8 SIMULATED TRACK INDUCTOR, 8V617 (USED WITH MULTI-FREQUENCY SHUNTS)

The Simulated Track Inductor, 8V617 (Figure 5-11) is intended for use with Siemens's Multi-frequency Narrow-band Shunts (62775/62780).

In bidirectional motion sensor and grade crossing predictor installations, insulated joints located in one approach frequently prevent both termination shunts from being installed at equal distances from the MS/GCP feed point as required.

The 8V617 Simulated Track Inductor is used with the Shunt in the shorter approach to compensate for the reduced distance (Figure 5-12).

### Each Inductor:

 Consists of an insulated, toroid-wound coil with a pair of 4-inch number 18 AWG stranded wire leads with 1/4-inch ring terminals attached.

- Is supplied in 21 configurations to simulate track lengths ranging from 200 to 4,000 feet (61 1220 meters) in 200-foot (61 meter) increments plus 4,400 feet (1342 meters.
- Is identified with the basic part number followed by a dash number indicating the simulated distance in feet as listed in Table 5-9.




Figure 5-11: Simulated Track Inductor, 8V617

Table 5-9: Simulated Track Inductor Part Number Listing

BASIC PART NO.	DASH NUMBER = DISTANCE IN FEET (METERS)		
	-0200 (61)	-1600 (488)	-3000 (450)
	-0400 (122)	-1800 (549)	-3200 (976)
	-0600 (183)	-2000 (610)	-3400 (1037)
	-0800 (244)	-2200 (671)	-3600 (1098)
8V617	-1000 ((309)	-2400 (732)	-3800 (1159)
	-1200 (366)	-2600 (793)	-4000 (1220)
	-1400 (427)	-2800 (854)	-4400 (1342)




Figure 5-12: Simulated Track Inductor Used With Termination Shunt

## 5.8.1 Simulated Track Inductor Installation

## **A** WARNING

#### **WARNING**

BEFORE INSTALLING, VERIFY THAT THE 8V617 INDUCTOR IS THE CORRECT DISTANCE VALUE FOR THE APPLICATION.

ALWAYS WRAP THE INDUCTOR IN THE FOAM INSULATION (INCLUDED WITH THE INDUCTOR) THAT PROVIDES INSULATION FROM THE TERMINAL POSTS (AS SHOWN IN FIGURE 5-13).

#### NOTE

#### **NOTE**

Refer to the small chart inside the end cap for terminal strapping information. If the chart is missing or illegible, refer to Table 5-7 (62775) or Table 5-8 (62780) in this manual.

Position the inductor with the leads extending horizontally toward the side (not upward) to prevent interference with the Shunt end cap.




Figure 5-13: Typical Installation of 8V617 in 62775/62780 Shunt

- Step 1: Determine the Shunt frequency and compensating distance required.
- Step 2: Loosen the clamp and remove the end cap from the Shunt to gain access to the frequency-selection terminals.
- Step 3: Refer to Table 5-10 and note the inductor mounting terminals for the applicable shunt and frequency.
- Step 4: Remove the nuts, washers, and shorting link from the shunt terminals indicated. Discard the shorting link.
- Step 5: Install the inductor in its place by connecting the inductor leads to the two terminals. Install the washers and nuts and tighten securely.
- Step 6: Wrap the inductor in the foam insulation (included with the inductor) as shown in Figure 5-13 and carefully insert into the Shunt housing between the terminals and case at the approximate location shown.
- Step 7: Return the end cap to its original position on the Shunt and tighten the clamp securely.

## 5.8.2 8V617 Simulated Track Inductor Specifications

Diameter 1.875 inches (4.763 centimeters)
Thickness 0.875 inches (2.223 centimeters)

Weight 5 ounces (141.75 grams)

Table 5-10: Simulated Track Inductor, 8V617, Mounting Terminals

Table 5-10: Simulated Track Inductor, 8V617, Mounting Terminals				
NARROW-BAND SHUNT PART NO.	FREQUENCY (HZ)	REMOVE SHORTING LINK AND CONNECT INDUCTOR LEADS BETWEEN SHUNT TERMINALS		
	86	A and F		
00775/00700 0004	114	B and G		
62775/62780-8621	156	C and D		
	211	C and D		
	156	A and F		
	211	A and G		
62775/62780-1543	285	B and C		
	348	B and C		
	430	B and C		
	211	A and F		
	267	B and G		
62775-2132*	285	B and C		
	313	B and C		
	326	B and C		
	211	A and F		
	285	B and C		
62775/62780-2152*	348	B and C		
	430	B and C		
	525	B and C		
	348	A and B		
	389	A and B		
	392	A and B		
62775-3448*	430	A and B		
	452	A and B		
	483.5	A and B		
	211	A and F		
	267	B and G		
62775-2132*	285	B and C		
	313	B and C		
	326	B and C		
	211	A and F		
	285	B and C		
62775/62780-2152*	348	B and C		
	430	B and C		
	525	B and C		
	348	A and B		
	389	A and B		
20775 2 / / 2 *	392	A and B		
62775-3448*	430	A and B		
	452	A and B		
	483.5	A and B		
0	348	A and B		
62775-3497	430	A and B		
		•		

NARROW-BAND SHUNT PART NO.	FREQUENCY (HZ)	REMOVE SHORTING LINK AND CONNECT INDUCTOR LEADS BETWEEN SHUNT TERMINALS
	525	A and B
	645	A and B
	790	A and B
	970	A and B
	790	A and B
	816	A and B
60775 7040*	832.5	A and B
62775-7910*	970	A and B
	979	A and B
	1034	A and B
	522	A and B
	525	A and B
00775 507.15	560	A and B
62775-5274*	645	A and B
	669.9	A and B
	746.8	A and B
	525	A and B
	645	A and B
62780-5297	790	A and B
	970	A and B
	211	A and F
	285	B and C
62775/62780-2152*	348	B and C
02770702700 2102	430	B and C
	525	B and C
	348	A and B
	389	A and B
	392	A and B
62775-3448*	430	A and B
-	452	A and B
 	483.5	A and B
	348	A and B
 	430	A and B
<u> </u>	525	A and B
62775-3497	645	A and B
 	790	A and B
 	970	A and B
	790	A and B
  -		
<del> </del>	816	A and B
62775-7910*	832.5	A and B
  -	970	A and B
  -	979	A and B
00775 5074*	1034	A and B
62775-5274*	522	A and B

NARROW-BAND SHUNT PART NO.	FREQUENCY (HZ)	REMOVE SHORTING LINK AND CONNECT INDUCTOR LEADS BETWEEN SHUNT TERMINALS	
	525	A and B	
	560	A and B	
	645	A and B	
	669.9	A and B	
	746.8	A and B	
62780-5297	525	A and B	
	645	A and B	
	790	A and B	
	970	A and B	

<sup>\*</sup>Available for special applications only

## 5.9 ADJUSTABLE INDUCTOR ASSEMBLY, 8A398-6

The Adjustable Inductor Assembly, 8A398 is intended for use with Siemens's Single-frequency Narrow-band Shunts (62775-f/62780-f) to balance the approaches of a bidirectional application when the approaches differ by more than 10%. Insulated joints located in one approach frequently prevent both termination shunts from being installed at approximately equal distances from the SGCP 4000/MS 4000 feed point as required.

Adjustable Inductor Assembly, 8A398-6 (Figure 5-14), may be used along with the Shunt in the shorter approach to compensate for the reduced distance as shown in Figure 5-15.

The Adjustable Inductor Assembly consists of a 3-inch diameter ABS plastic enclosure with mounting brackets at the base and seven AREMA terminals extend from the top of the assembly.

Terminals accommodate connections to six inductors that are connected in series and housed within the sealed unit.

NOTE

## **NOTE**

When configuring the 8A398-6 Adjustable Inductor, simulated track length is selectable in 50-foot (15.2 meter) increments ranging from 50 to 3150 feet (15.2 - 960.1 meters).




Figure 5-14: Adjustable Inductor Assembly, 8A398-6




Figure 5-15: Adjustable Inductor Used With Termination Shunt

5-28

## 5.9.1 Adjustable Inductor Configuration

- Step 1: Refer to Table 5-11 and locate the desired simulated track length (column 1).
- Step 2: Read across the table to determine which inductors (indicated by terminal pairs in column 2) are required to simulate that length (i.e., for a simulated track length of 1,000 feet, terminals C and F are indicated).
- Step 3: Connect the track wire and the shunt wire (see Figure 5-15) to the two terminals indicated in column 2.
- Step 4: Install a strap between the terminal pairs indicated in column 3. [This shorts the inductor(s) located between the track and shunt wire connecting terminals (Figure 5-16) which are not required for the desired length. To continue the example given in Step 2, when the track and shunt wires are connected to terminals C and F, a simulated track length of 1400 feet (800 + 400 + 200) is selected. Placing a strap between terminals D and E shorts the 400-foot inductor, removing it from the series circuit].

5-29

Table 5-11: Terminal Connections For Adjustable Inductor Assembly, 8A398-6

COLUMN 1	COLUMN 2	COLUMN 3	COLUMN 1	COLUMN 2	COLUMN 3
SIMULATED TRACK LENGTH FEET/ METERS	SET TRACK & SHUNT WIRES TO TERMINALS	CONNECT SHORTING STRAP(S) TO THESE TERMINALS	SIMULATED TRACK LENGTH FEET/ METERS	CONNECT TRACK AND SHUNT WIRES TO TERMINALS	CONNECT SHORTING STRAP(S) BETWEEN THESE TERMINALS
50/16	A-B		1650/503	A-G	B-C, C-D, D-E, E-
100/31	B-C				F
150/46	A-C		1700/519	B-G	C-D, D-E, E-F
200/61	C-D		1750/134	A-G	C-D, D-E, E-F
250/77	A-D	B-C	1800/549	C-G	D-E, E-F
300/92	B-D		1850/564	A-G	B-C, D-E, E-F
350/107	A-D		1900/580	B-G	D-E, E-F
400/122	D-E		1950/595	A-G	D-E, E-F
450/137	A-E	B-C, C-D	2000/610	D-G	E-F
500/153	B-E	C-D	2050/625	A-G	B-C, C-D, E-F
550/168	A-E	C-D	2100/640	B-G	C-D, E-F
600/183	C-E		2150/656	A-G	C-D, E-F
650/199	A-E	B-C	2200/671	C-G	E-F
700/214	B-E		2250/686	A-G	B-C, E-F
750/229	A-E		2300/701	B-G	E-F
800/244	E-F		2350/717	A-G	E-F
850/259	A-F	B-C, C-D, D-E	2400/732	E-G	
900/275	B-F	C-D, D-E	2450/747	A-G	B-C, C-D, D-E
950/282	A-F	C-D, D-E	2500/762	B-G	C-D, D-E
1000/305	C-F	D-E	2550/778	A-G	C-D, D-E
1050/320	A-F	B-C, D-E	2600/793	C-G	D-E
1100/336	B-F	D-E	2650/808	A-G	B-C, D-E
1150/351	A-F	D-E	2700/823	B-G	D-E
1200/366	D-F		2750/839	A-G	D-E
1250/381	A-F	B-C, C-D	2800/854	D-G	
1300/397	B-F	C-D	2850/869	A-G	B-C, C-D, D-E
1350/412	A-F	C-D	2900/884	B-G	C-D
1400/427	C-F		2950/899	A-G	C-D
1450/442	A-F	B-C	3000/914	C-G	
1500/458	B-F		3050/930	A-G	B-C
1550/473	A-F		3100/945	B-G	
1600/488	F-G		3150/961	A-G	




Figure 5-16: Adjustable Inductor, 8A398-6 Schematic

#### 5.9.2 8A398-6 Adjustable Inductor Assembly Specifications

Diameter 3.375 inches (8.573 centimeters)

Height 9 inches (22.860 centimeters) (to top of AREMA terminals)

Weight 5 pounds, 12 ounces (2.59 kilograms)

#### 5.10 TRACK CIRCUIT ISOLATION DEVICES

Several types of track circuit isolation devices are available for both DC and AC coded track applications. The following discussions are grouped by coded track circuit type.

#### NOTE

#### NOTE

The recommendations presented in the following paragraphs are general in nature and no attempt has been made to cover all applications.

Battery chokes and code isolation devices described here are designed for mounting inside a weatherproof enclosure.

If there are any questions concerning these recommendations or applications, contact Siemens Technical Support for assistance.

#### 5.10.1 Steady Energy DC Track Circuits

#### NOTE

#### NOTE

If the track connections for the DC track circuit are 1,000 feet (305 meters) or more beyond the approach termination shunt, a battery choke is not required (see Figure 5-17).

A DC track circuit should be equipped with a battery choke when its battery is located:

- Within the GCP 3000/GCP 4000/MS 2000/SGCP 4000/MS 4000 approach
- Less than 1,000 feet (305 meters) beyond the approach termination.




Figure 5-17: Battery Choke Requirements

Either of the following Battery Chokes may be used: (see limitations in the following paragraphs):

- Part number 8A065A
- Part number 62648.

The use of battery chokes is subject to the following limitations:

Operation of long DC track circuits with very low ballast conditions may be affected by the DC resistance (DCR) of the 8A065A Battery Choke (DCR of 8A065A is 0.40 ohm). Such track circuits should use the 62648 Battery Choke, which has a DCR of 0.10 ohm.

In applications where the Choke is located within a Model 300 or Model 400 GCP approach, the 8A065A Battery Choke must be used.

When a rectified track circuit is used and the motion sensor is operating at 114 Hz, an 8A076A Wideband Shunt (paragraph 5.7) should be used together with the Battery Choke to eliminate 120 Hz ripple. This application is illustrated in Figure 5-18.

The 62648 and 8A065A Battery Chokes each consist of a large inductance coil with two top mounted AREMA terminals and a mounting base (see Figure 5-19).

SIG-00-11-02 Version No.: A.8

**REVISED MARCH 2022** 




Figure 5-18: Ripple Elimination Circuit

#### 5.10.1.1 62648 and 8A065A Battery Chokes Specifications

Dimensions 4.5 inches (11.430 centimeters) wide

5.0 inches (12.700 centimeters) deep

8.5 inches (21.590 centimeters) high

(to top of terminal studs)

Weight 17 pounds (7.72 kilograms) (approximate)




Figure 5-19: 62648/8A065A Battery Choke With Mounting Dimensions

5-33

#### 5.10.2 Siemens GEO Electronic DC Coded System

The standard Siemens SGCP 4000/MS 4000 frequencies of 86 Hz and above are compatible with GEO. Isolation circuits are generally not required in the GEO transmitter rail connections. Frequencies of 86, 114, 156, and 211 Hz require use of high current, track devices, and the GEO Track Noise Suppression Filter, A53252. The GEO Filter must be installed at the signal location for the above-mentioned frequencies.

#### 5.10.3 ElectroCode Electronic Coded System

SGCP 4000/MS 4000 frequencies of 86 Hz and above can normally be used with Electro Code.

- All frequencies of 211 Hz and lower require use of high current track drive.
- In certain instances, 285 Hz may also require high current.
- For frequencies of 211 Hz and lower, an Electro Code track filter (TF-freq) may be required when the Electro Code transmitter is located within the SGCP 4000/MS 4000 approach.

#### 5.10.4 Genrakode Electronic Coded System

SGCP 4000/MS 4000 frequencies of 86 Hz and above can normally be used with Genrakode when used in conjunction with a 6A342-5 DC Code Isolation Unit.

- All frequencies of 211 Hz and lower require use of high current track drive.
- In certain instances, 285 Hz may also require high current.
- For frequencies of 211 Hz and lower, a 6A342-5 DC Code Isolation Unit may be required when the Genrakode transmitter is located within the SGCP 4000/MS 4000 approach.

#### NOTE

#### NOTE

Under some circumstances, an external track filter may be required when electronic coded track is located within the SGCP 4000/MS 4000 approach. As with any coded track system, the lower the transmit level, the less interference to motion sensor units.

#### 5.10.5 Relay Coded DC Track

Most relay coded DC track installations require use of DC Code Isolation units. A code isolation unit is a special battery choke that aids in preventing coded track battery and track relays from causing high interference with the SGCP 4000/MS 4000. There are two Siemens DC Code Isolation units: the 6A342-1 DC Code Isolation Unit, used in single polarity systems and the 6A342-3 DC Code Isolation Unit, which is used in dual polarity systems.

#### 5.10.5.1 DC Code Isolation Unit, 6A342-X (6A342-1, 6A342-3, & 6A342-5)

There are three versions of the DC Code Isolation Unit, 6A342-X: the 6A342-1, the 6A342-3, and the 6A342-5 (see Figure 5-20). The 6A342-1 is used in most single polarity code systems. The 6A342-1 unit consists of filter components (L1, C1, R1, and CR1) and three AREMA binding posts on a mounting base. The 6A342-3 DC Code Isolation Unit is used in GRS Trakode (dual polarity) relay systems. The 6A342-3 unit consists of filter components (L1, C1, and R1) and three AREMA binding posts on a mounting base. The 6A342-5 DC Code Isolation Unit is used in GRS Genrakode (dual polarity) relay systems. The 6A342-5 unit consists of filter components (L1 and C1) and three AREMA binding posts on a mounting base.



#### **WARNING**

THE SINGLE POLARITY CODED TRACK CIRCUIT MUST BE CAREFULLY REVIEWED TO ENSURE THAT ALL TRANSMIT AND RECEIVE CODES ARE OF THE SAME POLARITY PRIOR TO INSTALLING ANY 6A341-1 UNIT. IF THE POLARITY IS IN DOUBT, INSTALL TWO 6A342-3 ISOLATION UNITS AT EACH END OF THE TRACK CIRCUIT. SAME INSTALLATION AS THE DUAL POLARITY CODED TRACK CIRCUIT.

CONTACT SIEMENS TECHNICAL SUPPORT AT 800-793-7233 FOR DETAILS.




Figure 5-20: DC Code Isolation Unit, 6A342-X, With Mounting Dimensions and Schematics

**A** WARNING

#### WARNING

ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF THE ISOLATION UNIT.

#### NOTE

#### NOTE

All wiring to terminals 1 and 2 on the Isolation units should be number 6 AWG. This significantly reduces current losses to the track relay during low track ballast conditions. Frequencies below 211 Hz require high track drive current.

#### 5.10.5.2 DC Code Isolation Unit, 6A342-1 Specifications

Dimensions 5.0 inches (12.700 centimeters) wide

9.0 inches (22.860 centimeters) deep

5.75 inches (14.605 centimeters) high

Weight 15 pounds (6.81 kilograms) (approximate)

#### 5.10.5.3 DC Code Isolation Unit, 6A342-1 Applications

Three applications for the 6A342-1 DC Code Isolation Units are discussed in the following paragraphs.

#### 5.10.5.4 Single Polarity Systems (Fixed Polarity)

## **A** WARNING

#### WARNING

ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF THE ISOLATION UNIT.

#### NOTE



To limit current losses to the track relay during low track ballast conditions, use number 6 AWG wires to terminals 1 and 2 on the isolation units.

The 6A342-1 Code Isolation unit can be used in most single (fixed) polarity code systems. A single polarity code system must have the same received and transmitted polarities to use this Code Isolation unit. Most rate code systems (75, 120, 180 ppm) are of this type. Figure 5-21 illustrates a typical 6A342-1 Code Isolation unit installation in a single polarity code system.

The 6A342-5 Code Isolation unit can be used in Genrakode single (fixed) polarity code systems. A single polarity code system must have the same received and transmitted polarities to use this Code Isolation unit. Most rate code systems (75, 120, 180 ppm) are of this type.




Figure 5-21: Code Isolation Unit In a Single Polarity Code System

#### 5.10.5.5 GRS Trakode (Dual Polarity) Systems

### WARNING TO INSTALL THE UNIT AS SHOWN, A TRANSFER DELAY (TD) RELAY MUST BE USED. DO NOT INSTALL ANY CODE ISOLATION **A** WARNING CIRCUIT IN GRS TRAKODE WITHOUT USE OF THE TD RELAY. ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT. NOTE To limit current losses to the track relay during low track ballast conditions,

NOTE

use number 6 AWG wires to terminals 1 and 2 on the isolation units.

Figure 5-22 illustrates the 6A342-1 Code Isolation unit installed in a GRS Trakode system.




Figure 5-22: Code Isolation Unit Installation In a GRS Trackode System

#### 5.10.5.6 Dual Polarity (Polar) Coded Track Systems Other Than GRS Trakode



#### WARNING

## ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT.

A dual polarity system is one in which the received code polarity is opposite to that of the transmitted code.

The 6A342-3 Code Isolation unit can be used in a dual polarity system; however, two 6A342-3 units must be specifically placed at each end of the circuit for proper filtering. The application will depend upon the track circuit configuration. Contact Siemens Technical Support for assistance in dual polarity code systems.

#### 5.10.6 AC Code Isolation Units



#### **WARNING**

ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF AN ISOLATION UNIT.

CAB signal and style C track circuit installations require the use of an AC Code Isolation unit such as the 8A466-3 (Figure 5-23) or the 8A470-100 (Figure 5-24). Both of these units should be used only with frequencies of 790 Hz and higher in style C track circuit installations. Contact Siemens Technical Support for specific information.

#### 5.10.6.1 AC Code Isolation Unit, 8A466-3

The 8A466-3 AC Code isolation unit is used in 60 Hz CAB signal track circuit installations to reduce 60 Hz harmonics from being applied to the track. It is used with frequencies 156 Hz and higher. It is housed in a steel case with top mounted AREMA binding posts provided for track connections.

#### 5.10.6.2 AC Code Isolation Unit, 8A466-3 Specifications

Dimensions 10.15 inches (25.781 centimeters) wide

11.78 inches (29.921 centimeters) deep 7.62 inches (19.355 centimeters) high

Weight 26 pounds (11.8 kilograms) (approximate)

5-39

SIG-00-11-02 Version No.: A.8




Figure 5-23: AC Code Isolation Unit, 8A466-3

#### 5.10.6.3 AC Code Isolation Unit, 8A470-100

The 8A470-100 AC Code isolation unit is used in 100 Hz CAB signal track circuit installations to reduce 100 Hz harmonics from being applied to the track. It is used on with frequencies 211 Hz and higher. It is mounted on an aluminum case with two top mounted AREMA binding posts provided for track connections.

#### 5.10.6.4 Code Isolation Unit, 8A470-100 AC Specifications

Dimensions 5.0 inches (12.700 centimeters) wide

9.4 inches (23.876 centimeters) deep 9.0 inches (22.860 centimeters) high

Weight 5 pounds (2.27 kilograms) (approximate)

#### 5.10.6.5 Cab Signal AC



#### WARNING

ALWAYS VERIFY PROPER CODE SYSTEM OPERATION FOLLOWING INSTALLATION OF A CAB SIGNAL UNIT.

Application of SGCP 4000/MS 4000 systems in cab territory using the 8A466-3, 60 Hz AC Code Isolation Unit or the 8A470-100, 100 Hz Isolation Unit is shown in Figure 5-25.

For other installations, contact Siemens Technical Support for assistance.




Figure 5-24: AC Code Unit, 8A470-100, With Mounting Dimensions




Figure 5-25: AC Code Isolation Unit Used In CAB Territory

#### 5.10.6.6 Style C Track Circuits

The 60 Hz AC Code Isolation unit (8A466-3) is used with style C track circuits as shown in Figure 5-26.




Figure 5-26: AC Code Isolation Unit Used in Style C Track Circuits

#### 5.10.6.7 AC Code Isolation Unit, 8A471-180

For special applications, 180 Hz AC Code Isolation Unit (8A471-180) is also available. Contact Siemens Technical Support for specific information.

#### 5.11 TUNABLE INSULATED JOINT BYPASS COUPLER, 62785-F

The Tunable Insulated Joint Bypass Coupler, 62785-f is the only tuned bypass coupler to be used with the SGCP 4000/MS 4000 for bypassing insulated joints in DC coded track.

The 62785-f Bypass Coupler is used in all SGCP 4000/MS 4000 applications requiring the use of an insulated joint bypass coupler.

The 62785-f Coupler is available in standard Siemens frequencies of 156 Hz through 970 Hz.



#### WARNING

INSULATED JOINT BYPASS COUPLERS, 62531-F AND 62631-F, MUST NOT BE USED WITH THE SGCP 4000/MS 4000.

THE MINIMUM DISTANCES TO THE INSULATED JOINTS SPECIFIED IN TABLE 5-12 APPLY TO THE SGCP 4000/MS 4000 ONLY.

62785-F TUNED BYPASS COUPLERS MUST ONLY BE USED TO BYPASS INSULATED JOINTS IN CODED DC TRACK CIRCUITS.

The application guidelines for Tunable Insulated Joint Bypass Coupler, 62785-f when used only with the SGCP 4000/MS 4000 have been expanded as follows:

In DC coded track circuits, the insulated joints within an approach may be bypassed using the Siemens 62785-f Tunable Insulated Joint Bypass Coupler, provided the minimum distances specified in Table 5-12 are observed.

- The 62785-f Coupler must be field tuned to pass the SGCP 4000/MS 4000 operating frequency (f) around insulated joints in DC or coded DC track circuits.
- Field tuning of the Coupler enables precise frequency adjustment for track and joint parameters.
- The Coupler must be located within 10 feet (3 meters) of the insulated joints that it is coupling.
- The minimum distance to the insulated joints is generally a function of the SGCP 4000/MS 4000 operating frequency, i.e., the lower the operating frequency, the longer the minimum distance.

Two sets of insulated joints may be coupled in any single approach, provided the minimum operating distances specified in Table 5-12 are observed. Table 5-12 indicates the minimum operating distances (in feet/meters) to the first and second set of insulated joints that are coupled with 62785-f couplers for SGCP 4000/MS 4000 operation.

Table 5-12: Minimum Distance to Insulated Joints When Coupled With Tunable Insulated Joint Bypass Coupler, 62785-f

FREQUENCY (HZ)	MINIMUM DISTANCE TO FIRST SET OF INSULATED JOINTS (FEET/METERS)	MINIMUM DISTANCE TO SECOND SET OF INSULATED JOINTS (FEET/METERS)*
151 – 211	1500/458	2200/671
212 – 348	1000/305	1400/427
349 – 560	700/214	1000/305
561 – 790	500/153	800/244
791 – 979	400/122	700/214

<sup>\*</sup>Distance applies to insulated joints located on the same side of the crossing.

The Coupler is housed in a hermetically sealed, 6-inch (15.240 cm) diameter case

- A pair of 10-foot (3.048 meter), number 6 AWG leads extend from one end
- Nine AREMA terminals extend from the other end (see Figure 5-27).
- Five of the terminals (labeled A through E) are equipped with special gold test nuts that are used to tune the Coupler.

#### **WARNING**



AT THE COMPLETION OF FIELD TUNING THE 62785-F BYPASS COUPLERS ENSURE THAT A STANDARD AREMA NUT IS TIGHTENED SECURELY AGAINST <u>EACH</u> GOLD NUT ON TERMINALS A THROUGH E, INCLUDING THE TERMINALS THAT ARE NOT TIGHTENED DOWN.

#### NOTE

NOTE

While field tuning the 62785-f Bypass Coupler, tightening the nut on terminal E produces maximum change in EZ value. Tightening the nut on terminal A produces minimum change.




Figure 5-27: Terminal Identification, 62785-f Tunable Insulated Joint Coupler

The Coupler is tuned in the following sequence:

- The gold nut on terminal E is tightened first.
- Calibrate the SGCP 4000/MS 4000 so that the EZ value is 100.
- Next, a hardwire shunt is placed across the tracks, first on one side of the coupler and then on the other, tightening one or more of the remaining nuts in sequence to obtain the minimum change in EZ value across the joint.

#### NOTE

#### NOTE

Tightening the nut on terminal E produces maximum change in EZ value and tightening the nut on terminal A produces minimum change.

- When the adjustment is complete, a second (standard) AREMA nut is tightened on each
  of the terminals to lock the gold adjusting nuts firmly in position.
- Next, an equalizer and a gas tube for capacitor protection are connected to the remaining AREMA terminals to provide complete surge protection.
- Finally, a pliable end cap is secured in place over the terminal end of the coupler by a sturdy stainless steel clamp to provide protection against moisture and dust.

There are two different tuning procedures to tune the Tunable Insulated Joint Bypass Coupler depending on where the coupler(s) is/are located in the approach. Use the procedure outlined in paragraph 5.11.1 primarily. Use the procedure outlined in paragraph 5.11.2 as an alternate. Refer to Figure 5-28 when performing either of the following tuning procedures.

#### CAUTION



THE COUPLER SHOULD BE CONNECTED WITHIN 10 FEET (3.048 METERS) OF THE RAILS. TO AFFORD MAXIMUM PROTECTION FROM PHYSICAL DAMAGE, IT SHOULD BE ENCASED IN A PROTECTIVE ENCLOSURE OR BURIED (EITHER VERTICALLY OR HORIZONTALLY) AT AN APPROPRIATE DEPTH (SEE PARAGRAPH 5.12). IT IS NOT NECESSARY TO BURY THE COUPLER BELOW THE FROST LINE.

#### NOTE



Multiple couplers often require the procedures in paragraph 5.11.2 for proper setup.

Tightening the nut on terminal E produces maximum change in EZ value and tightening the nut on terminal A produces minimum change.

#### 5.11.1 Field Tuning Procedure #1

Refer to the appropriate installation diagram Figure 5-28 for the following tuning procedure.

- Step 1: Tighten the gold nut securely on terminal E of each coupler.
- Step 2: Calibrate the SGCP 4000/MS 4000 so that the EZ value is 100.
- Step 3: Place a hardwire test shunt across the track at location A (refer to Figure 5-28.
- Step 4: Make note of the EZ value appearing on the SGCP 4000/MS 4000 display.
- Step 5: Move the test shunt to location B.
- Step 6: Tune the Tunable Insulated Joint Bypass Coupler #1 to the same EZ value noted in Step 4.
  - Tighten the gold nut on the Coupler **#1** terminals labeled D, C, B, and A, in sequence beginning with terminal D.
  - If tightening a nut results in an EZ value that is lower than the value recorded in step 4, loosen the nut and tighten the next nut in sequence.
  - If, after tightening a nut, the EZ value remains higher than the value recorded in step 4, leave the nut tightened and tighten the next nut in sequence.
  - Continue to tighten nuts D through A as necessary to obtain an EZ value that is approximately the same as that recorded in step 4.

Step 7: Move the test shunt to location C.




Figure 5-28: Typical Installation Diagrams Using the 62785-f Coupler

Step 8: Tune the No. 2 Tunable Insulated Joint Bypass Coupler to the EZ value noted in step 4.

- Tighten the gold nut on the Coupler #1 terminals labeled D, C, B, and A, in sequence beginning with terminal D.
- If tightening a nut results in an EZ value that is lower than the value recorded in step 4, loosen the nut and tighten the next nut in sequence.
- If, after tightening a nut, the EZ value remains higher than the value recorded in step 4, leave the nut tightened and tighten the next nut in sequence. Continue to tighten nuts D through A as necessary to obtain an EZ value that is approximately the same as that recorded in step 4.

Step 9: Remove the test shunt and tighten a standard AREMA nut against each gold nut to ensure all nuts are securely locked in position.



#### WARNING

ENSURE THAT A STANDARD AREMA NUT IS TIGHTENED SECURELY AGAINST <u>EACH</u>. GOLD NUT ON TERMINALS A THROUGH E, INCLUDING THE TERMINALS THAT ARE NOT TIGHTENED DOWN.

Step 10: Completely recalibrate the SGCP 4000/MS 4000 and perform all operational checks while observing the smooth change in the EZ value across the couplers during a train move.

#### 5.11.2 Field Tuning Procedure #2 for Couplers

- Step 1: Tighten the gold nut securely on terminal E of each coupler.
- Step 2: Calibrate the SGCP 4000/MS 4000 EZ value to 100.
- Step 3: Place a hardwire test shunt across the track at location A (refer to Figure 5-28).
- Step 4: Make a note of the EZ and EX values on the SGCP 4000/MS 4000 display.
- Step 5: Move the test shunt to location B.
- Step 6: Tune the Tunable Insulated Joint Bypass Coupler **#1 EX** value to above 75. The **EZ** value may be as much as 8 points above the value noted in Step 4.
- Step 7: Move the test shunt to location C.
- Step 8: Tune the Tunable Insulated Joint Bypass Coupler **#2** so the **EX**-value stays above 75. The **EZ** value may be as much as 16 points above the value note in Step 4.
- Step 9: Remove the test shunt and tighten a standard AREMA nut against each gold nut to ensure all nuts are securely locked in position.



#### WARNING

ENSURE THAT A STANDARD AREMA NUT IS TIGHTENED SECURELY AGAINST <u>EACH</u> GOLD NUT ON TERMINALS A THROUGH E. TERMINALS THAT ARE NOT USED FOR TUNING THE COUPLER <u>MUST HAVE THEIR GOLD NUTS REMOVED</u>.

Step 10: Completely recalibrate the SGCP 4000/MS 4000 and perform all the operational checks while observing the relatively smooth change in the EZ value across the couplers during a train move.

#### 5.11.3 Tunable Insulated Joint Bypass Coupler, 62785-f Specifications

Dimensions 18 inches (45.720 centimeters) long

6 inches (15.240 centimeters) in diameter

Weight 12 pounds (5.45 kilograms) (approximate)

Leads 10 feet (3.048 meters); #6 AWG, stranded, black PVC Surge Suppresser Equalizer, 022700-21X, Siemens No. Z803-00052-0001 Gas Tube Arrester, Siemens No. Z803-00053-0001

5-47

#### 5.12 MS/GCP TERMINATION SHUNT BURIAL KIT, 62776




Figure 5-29: MS/GCP Termination Shunt Burial Kit, 62776

The MS/GCP Termination Shunt Burial Kit, 62776, is designed to protect Narrow-band Termination Shunts while they are buried in the space between adjacent railroad ties.

#### 5.12.1 Kit Contents

The MS/GCP Termination Shunt Burial Kit, 62776, consists of a 26-inch (66 cm) length enclosure of 6-inch (15.2 cm) diameter black PVC tubing, a 7x24-inch (17.8 1/41cm), a 1/4-inch (6.4 mm) thick steel plate, a pliable rubber cap with an adjustable stainless steel clam1/4 and two 1/4 X 3-inch (7 X 77mm) lag bolts (not shown).

One end of the tubing is fitted with a pliable rubber cap that is secured in place by an adjustable stainless steel clamp. Two 5/8-inch (16 mm) diameter holes located near the capped end of the tube accommodate the shunt leads.

#### 5.12.2 Kit Use

The enclosure is normally buried in a vertical position between the ties.

- The Termination Shunt is lowered into the enclosure and the two leads routed through the holes in the enclosure wall and connected to the rails using standard procedures.
- The cap is then secured over the top of the enclosure using the stainless steel clamp.
- The steel plate is centered over the buried enclosure/shunt and securely fastened to each tie usi1/4 the two 1/4 X 3-inch lag bolts provided.

#### **5.12.3 Shunt Kit Assemblies Specifications**

Dimensions:

Enclosure (PVC) 24 inches (60.960 centimeters) long (w/o end cap)

6 inches (15.240 centimeters) in diameter (inside)

Cover Plate (Steel) 24 inches (60.960 centimeters) long

7 inches (17.780 centimeters) wide 0.25 inch (0.635 centimeters) thick

Weight:

Enclosure 5 pounds (2.27 kilograms) Cover Plate 12 pounds (5.44 kilograms)

#### **5.13 SURGE PANELS, 80026-XX**

The 80026-XX Surge Panels are available in a combination of equalizers and arresters to provide protection for battery and/or track circuits.



#### **WARNING**

ANY ALTERNATIVE SURGE PROTECTION DEVICE MUST BE ANALYZED TO ENSURE THAT FAILURE MODES OF DEVICE DO NOT COMPROMISE SAFETY OF SGCP 4000/MS 4000 SYSTEM. FOR EXAMPLE, BUT NOT LIMITED TO, UNINTENTIONAL EARTH GROUNDS ON CONTROL CIRCUITS OR SHORTS ON TRACK CIRCUITS.

#### 5.13.1 Surge Panel Configurations

Surge Panel units are provided in a variety of configurations to meet specific customer requirements. Wall mounted Surge Panel applications are listed in Table 5-13. Rack mount Surge Panel applications are in Table 5-14.



#### NOTE

For surge protection requirements not listed or for custom designed Surge Panels, contact Siemens Technical Support.

#### **5.13.2 Surge Panel Nomenclature and Mounting Dimensions**

Surge panel nomenclature and mounting dimensions are provided on the figures identified in Table 5-13 and Table 5-14.

#### **5.13.3 Surge Panel Arresters**



#### WARNING

DO NOT MOUNT ARRESTER WITH ELECTRODES POINTED IN THE DOWN POSITION TO MINIMIZE THE POTENTIAL OF SHORT CIRCUIT.

A typical Surge Panel arrester is shown in Figure 5-30.




Figure 5-30: Typical 80026 Surge Panel Arrester Mounting Position

**Table 5-13: Wall Mount Surge Panels** 

PART NO.	FIG.	DESCRIPTION	DIMENSIONS	WEIGHT
80026-01	3-35	Protects 1 battery and 1 track circuit.	Height: 13.5 in (34.290 cm) Width: 5.69 in (14.453 cm) Depth: 3.625 in (9.208 cm)	6.00 lb. (2.72 kg) (approximate)
80026-02	3-35	Protects 1 track circuit.  Use with –1 panel for subsequent track protection.	Height: 8.75 in (22.23 cm) Width: 5.69 in (14.453 cm) Depth: 3.625 in (9.208 cm)	4.00 lb. (1.82 kg) (approximate)
80026-22	3-35	Protects 1 track circuit. Use for six-wire applications.	Height: 5.44 in (13.82 cm) Width: 5.69 in (14.453 cm) Depth: 3.625 in (9.208 cm)	3.00 lb. (1.36 kg) (approximate)

Table 5-14: Rack Mount Surge Panels

PART NO.	FIG.	DESCRIPTION	DIMENSIONS	WEIGHT
80026-31	3-36	Protects 1 track and 1 battery circuit.	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	5.00 lb. (2.26 kg) (approximate)
80026-32	3-36	Protects 1 track and 1 battery circuit.  Use with –31 panel for subsequent track and battery circuit protection.	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	6.00 lb. (2.72 kg) (approximate)
80026-33	3-37	Protects 1 battery circuit.  Use with –31 panel for subsequent battery circuit protection.	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	7.00 lb. (3.18 kg) (approximate)
80026-34	3-37	Protects 1 track circuit.  Use with –31 panel for subsequent track circuit protection.	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	6.00 lb. (2.72 kg) (approximate)
80026-35	3-38	Protects 2 track circuits.	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	7.00 lb. (3.18 kg) (approximate)
80026-36	3-38	Protects 1 track circuit.  Use with –31 panel for subsequent track circuit protection.  Used with six-wire applications for transmit, receive, and check receive lead protection	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	6.00 lb. (2.72 kg) (approximate)
80026-37	3-39	Protects 1 battery circuit.	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	6.00 lb. (2.72 kg) (approximate)
80026-38	3-39	Protects 2 track circuits.  Used in applications with six wires on one track and four on the other	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	8.00 lb. (3.64 kg) (approximate)
80026-39	3-40	Protects 4 battery circuits.  Battery input/output line protection for two DAX start or two UAX circuits.  Normally used with second battery when line circuit protection is required	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	6.00 lb. (2.72 kg) (approximate)

PART NO.	FIG.	DESCRIPTION	DIMENSIONS	WEIGHT
80026-41	3-40	Protects 110 VAC circuits.  Used when 20-ampere solid- state crossing controller (91070A) is used in conjunction with SGCP 4000/MS 4000  Includes four 15-ampere resettable circuit breakers and one 15-ampere GFCI duplex outlet	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	9.00 lb. (4.09 kg) (approximate)
80026- 41A	3-40	Protects 110 VAC circuits.  Used when 40-ampere solid- state crossing controller (91075A) is used in conjunction with SGCP 4000/MS 4000  Includes three 15-ampere and one 25-ampere resettable circuit breakers and one 15- ampere GFCI duplex outlet	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	9.00 lb. (4.09 kg) (approximate)
80026-47	3-41	Protects 2 battery circuits and 1 track circuit. Used with motion sensor battery and second battery	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	7.00 lb. (3.18 kg) (approximate)
80026-50	3-41	Protects 4 vital Input/output circuits  Generally used for UAX inputs or DAX start outputs	Height: 4.96 in (12.598 cm) Width: 23.00 in (58.420 cm) Depth: 4.535 in (11.519 cm)	7.00 lb. (3.18 kg) (approximate)




Figure 5-31: Wall Mount Surge panels, 80026-01 -02, and -22




Figure 5-32: Rack Mounted Surge Panels, 80026-31 and -32




Figure 5-33: Rack Mounted Surge Panels, 80026-33 And -34




Figure 5-34: Rack Mounted Surge Panels, 80026-35 and -36




Figure 5-35: Rack Mounted Surge Panels, 80026-37 And -38




Figure 5-36: Rack Mounted Surge Panels. 80026-39, -41 and -41A




Figure 5-37: Rack Mounted Surge Panels 80026-47 and 80026-50

#### 5.14 RECTIFIER PANEL ASSEMBLY, 80033

The 80033 Rectifier Panel Assembly is equipped with equalizers and arresters to provide surge protection on the B (+) and N (-) connections to the battery and the motion sensor. Mounting holes are provided for a battery charger, as required.

#### 5.14.1 Rectifier Panel Assembly Nomenclature and Mounting Dimensions-

Rectifier Panel Assembly, 80033 nomenclature and mounting dimensions are provided on Figure 5-38.

Table 5-15: Rectifier Panel Assembly, 80033 Specifications

PARAMETER	VALUE
Height	10.46 in. (26.568 cm)
Width	23.00 in. (58.420 cm)
Depth	2.75 in. (6.985cm)
Weight	7 pounds (3.18 kg) (approximate)

#### 5.15 CABLE TERMINATION PANEL ASSEMBLY, 91042

The Cable Termination Panel Assembly, 91042 is a universal-mounting panel that can be ordered with from 1 to 19 pairs of strapped AREMA binding posts.

Cable Termination Panel Assembly Mounting Dimensions-91042 Cable Termination Panel Assembly mounting dimensions are provided on Figure 5-39.

Table 5-16: Cable Termination Panel Assembly, 91042 Specifications

PARAMETER	VALUE
Height	3.96 in. (10.058 cm)
Width	23.00 in. (58.420 cm)
Depth	2.25 in. (5.715cm)
Weight	7 pounds (3.18 kg) (approximate)




Figure 5-38: Rectifier Panel assembly, 80033




Figure 5-39: Cable Termination Panel Assembly, 91042

# SECTION 6 – DETAILED CASE AND MODULE DESCRIPTION

#### 6.1 GENERAL PHYSICAL DESCRIPTION

Each SGCP 4000/MS 4000 consists of a case assembly, a motherboard, and plug-in circuit modules that come equipped with plug-in external wiring connectors.

#### 6.1.1 Chassis

Each chassis consists of a powder-coated steel case with a backplane-mounted motherboard.

#### 6.1.2 Motherboard

The Motherboard for each assembly provides:

- SGCP 4000/MS 4000 unit wiring
- Circuit module connectors
- External Configuration Device Connector(s)
- Chassis Identification Chip socket(s)
- DIAG (diagnostic) port connector
- Interface connectors for external wiring connectors
- Echelon LONTALK® PROTOCOL LAN connector (See Siemens's Echelon Configuration Handbook, COM-00-07-09).

#### 6.1.3 Plug-In Circuit Modules

Each SGCP 4000/MS 4000 plug-in circuit module is equipped with:

A dual 43-pin connector on one edge which plugs into a corresponding edge connector on the motherboard.

Locking ejector levers at the top and bottom of each module to facilitate removal from the case.

# 6.2 SIMPLE GRADE CROSSING PREDICTOR 4000 / MOTION SENSOR 4000 (SGCP 4000/MS 4000) ASSEMBLIES

The SGCP 4000/MS 4000 is available in two configurations:

- Redundant Single Track System (A80490)
- Single Track System (A80495)

#### **NOTE**

NOTE

The module slot allocations shown below the module connectors are assigned for discussion purposes only and do not appear on the actual case assembly.

#### 6.2.1 Redundant Single Track System, A80490

#### 6.2.1.1 Interface Connectors

The A80495 case is shown in Figure 6-1. The relationships between the Single Case modules and the interface connectors are described in Table 6-1.

Table 6-1: Dual Single Track Case, A80490 Module to Interface Connector Relationship

MODULE	SLOT POSITION	INTERFACE CONNECTOR
A80403/A80903	M1	CPU
A80418	M2	TRACK
A80406	M3	TRANSFER
A80403/A80903	M4	CPU
A80418	M2	TRACK




Figure 6-1: SGCP 4000/MS 4000, A80490 Connectors

6-2

**REVISED MARCH 2022** 

#### **6.2.1.2 Modules and External Wiring Connectors**

The SGCP 4000/MS 4000, A80495 with modules and external wiring connectors installed is shown in Figure 6-2. The case contains FIVE modules:

- Two Central Processor Units, A80403 (CPU II+) or A80903 (CPU III), in slot positions M1 and M4.
- Two Track Modules, A80418 in slot positions M2 and M5.
- Transfer Module, A80406 in slot position M3.

The SGCP 4000/MS 4000 Case, A80495 has four external wiring connectors (see Table 6-2).




Figure 6-2: SGCP 4000/MS 4000 Case, A80490 with Modules & External Wiring Connectors Installed

Table 6-2: SGCP 4000/MS 4000 Case External Wiring Connectors

REF. NO.	CONNECTOR DESCRIPTION	CONNECTOR DESIGNATION	SIEMENS PART NUMBER
1	4-pin cage clamp, female	LONTALK® PROTOCOL	Z715-09099-0000
2	10-pin screw lock, female	CPU	Z715-02101-0007
3	Keyed 10-pin cage clamp,	INPUT/OUTPUT	Z715-02101-0001
4	female	TRACK	Z715-02101-0008

6-3

#### 6.2.2 Single Track System, A80495

#### 6.2.2.1 Interface Connectors

The A80495 case is shown in Figure 6-3. The relationships between the Single Case modules and the interface connectors are described in Table 6-1.




Figure 6-3: A80495 Connectors

Table 6-3: Single Track Case, A80495 Module to Interface Connector Relationship

MODULE	SLOT POSITION	INTERFACE CONNECTOR
A80403	M1	CPU
A80418	M2	TRACK

## **6.2.2.2 Modules and External Wiring Connectors**

The SGCP 4000/MS 4000, A80495 with modules and external wiring connectors installed is shown in Figure 6-4. The case contains two modules:

- Central Processor Unit, A80403 (CPU II+) or A80903 (CPU III) module in slot position M1.
- Track Module, A80418 in slot position M2

The SGCP 4000/MS 4000 Case, A80495 has four external wiring connectors (see Table 6-2).




Figure 6-4: SGCP 4000/MS 4000 Case, A80495 with Modules & External Wiring Connectors Installed

Table 6-4: SGCP 4000/MS 4000 Case External Wiring Connectors

REF. NO.	CONNECTOR DESCRIPTION	CONNECTOR DESIGNATION	SIEMENS PART NUMBER
1	4-pin cage clamp, female	LONTALK® PROTOCOL	Z715-09099-0000
2	10-pin screw lock, female	CPU	Z715-02101-0007
3	Keyed 10-pin cage clamp,	INPUT/OUTPUT	Z715-02101-0001
4	female	TRACK	Z715-02101-0008

6-5

## 6.3 DIAGVIEW DISPLAY UNIT, A80500

The DiagView Display Unit Case, A80500 is shown in Figure 6-5.




Figure 6-5: DiagView Display Unit Case, A80500

## 6.3.1 DiagView Display Unit Case, A80500 Modules

The DiagView Display Unit Case along with the Display II Panel, A80485-01, installed is shown in Figure 6-6.

Table 6-5: DiagView Display Unit Case External Wiring Connectors

REF. NO.	DESCRIPTION	DESIGNATION	SIEMENS PART NUMBER
1	DB9 connector	Port 1	Z715-09099-0000
2	DB9 connector	Port 2	Z715-02101-0007
3	10-pin screw clamp connector, female	Power	Z715-02101-0007




Figure 6-6: DiagView Display Unit, A80500

The DiagView Display Unit is used with either SGCP 4000/MS 4000 Case, A80490 or A80495, to provide the user with a visual cue of track status as well as a Display Terminal.

The DiagView Display Unit is connected to the Single Track Case through the use of Serial Cable, P/N Z706-00280-0000. This cable has a male DB9 connector on each end of the cable. The cable is connected between the Diag Port located on the upper portion of the Single Track Case between the Echelon LAN connector and the power connector and Port 2 on the DiagView Display Unit case.

## NOTE

NOTE

The DiagView Display Unit may take up to 10 minutes to power up and connect after being plugged in. It is recommended to wait the allotted time prior attempting other troubleshooting methods.

## 6.4 PLUG-IN MODULES AND SUBASSEMBLIES

#### 6.4.1 CPU MODULE

The CPU Module is a central processing unit that provides all vital logic processing functions for all SGCP 4000/MS 4000 chassis, controls ECHELON LAN, and vital and non-vital serial communications interfaces with front panel CPU connectors.

#### 6.4.1.1 CPU II+ Module, A80403

The CPU II+ front panel is shown in Figure 6-7. The CPU II+ user interface is described in Table 6-6.




Figure 6-7: CPU II+ Module, A80403 Front Panel

Table 6-6: CPU II+ Module, A80403 User Interface

COMPONENT	FUNCTION				
4-Character Display	Displays alphanumeric representation of currently selected function menu item. (Refer to SGCP 4000/MS 4000 Field Manual for diagnostic messages.)				
Select Push Button (SEL)	Used to	select menu item display	ect menu item displayed on 4-Character Display.		
Navigate Push Button (NAV)	Used to s	select an available funct	ion menu.		
16 MCF DEFINED LEDS	COLOR	FUNCTION	INDICATION		
1 (MAINT CALL)	Red	Maintenance Call see maintenance call logic section	On – maintenance call output on. Off – maintenance call output off.		
			On – transfer signal is being generated transfer card should not be counting down.		
2 (TRANSFER HEALTH)	Red	Transfer Output see transfer output section	Flashing – indicates transfer time extended by CPU due to same error on main and standby side.		
		section	Off – transfer signal is not being generated If transfer card is in AUTO it should be counting down.		
3 (XR OUTPUT)	Red	XR OUTPUT	On – XR Output is energized Off – XR Output is Deenergized		
4 (AND 2)*	Red	AND 2	Not Used in this application		
5 (AND 3)*	Red	AND 3	Not Used in this application		
6 (AND 4)*	Red	AND 4	Not Used in this application		
7 (AND 5)*	Red	AND 5	Not Used in this application		
8 (AND 6)*	Red	AND 6	Not Used in this application		
9 (AND 7)*	Red	AND 7	Not Used in this application		
10 (AND 8)*	Red	AND 8	Not Used in this application		
11 (REMOTE SETUP)	Red	Remote Setup Session	On – the SGCP 4000/MS 4000 has been primed for a remote, one-person setup. See section 6-10. Off – No remote setup is in progress		
12 (SSCC IV COMM)*	Red	SSCC IV Communication link	Not Used in this application		
13 (RADIO DAX LINK A)*	Red	Radio DAX Link A	Not Used in this application		

COMPONENT			FUNCTION	
14 (RADIO DAX LINK B)*	Red	Radio DAX Link B	Not Used in this application	
15 (VITAL COMM1)*	Red	Vital Comm 1	Not Used in this application	
16 (VITAL COMM2)*	Red	Vital Comm 2	Not Used in this application	
ECH LAN LEDs	TX flashe		transmitting an ATCS message via the	
EOIT LAIV EEDS	RX flashe		is receiving an ATCS message via the	
DSPL COMM LEDs	TX flash	es red when the CPU II+	is transmitting data to the Display Panel.	
DOI E CONNIN EEDS	RX flash	es green when the CPU	II+ is receiving data from the Display Panel.	
DIAG COMM (CP) LEDs		es red when the CPU II+ or diagnostic (DIAG CP)	- is transmitting data on the communications serial port.	
DIAG COMM (CF) LEDS	RX flashes green when the CPU II+ is receiving data from the communications processor diagnostic (DIAG CP) serial port.			
VILDIOD COMM LED-	TX flashes red when the Vital Logic Processor (VLP) is transmitting data to the Communications Processor (CP).			
VLP/CP COMM LEDs	RX flashes green when the Vital Logic Processor (VLP) is receiving data from the Communications Processor (CP).			
BACKPLANE COMM LEDs	TX flashes red when the Vital Logic Processor (VLP) is sending data onto the serial bus.			
	RX flashes green when the Vital Logic Processor (VLP) is receiving data from the serial bus.			
BACKPLANE COMM LEDs	TX flashes red when the Vital Logic Processor (VLP) is sending data onto the serial bus.			
BACKPLANE COMINI LEDS	RX flashes green when the Vital Logic Processor (VLP) is receiving data from the serial bus.			
VLP HEALTH LED	Flashes yellow to indicate that the Vital Logic Processor is functioning normally.			
CP HEALTH LED	Flashes yellow to indicate that the Communications Processor is functioning normally.			
POWER LED	Lights gr	een to indicate that pow	er is applied to the CPU II+ module.	
VLP Serial Port	9-pin diagnostic serial port for Vital Logic Processor.			
DIAG (CP) Serial Port	9-pin diagnostic serial port for Communications Processor.			

<sup>\*</sup> LED not used in Motion Sensor application

## 6.4.1.2 CPU III Module, A80903

The CPU III front panel is shown in Figure 6-8. The CPU III user interface is described in Table 6-7.




Figure 6-8: CPU III Front Panel

Table 6-7 CPU III A80903 User Interface

Table 6-7 CPU III A80903 User Interface						
Component	Function					
4-Character Display	Displays alphanumeric representation of currently selected function menu item. (Refer to Table 8-1 for diagnostic messages.)					
Select Push Button (SEL)	Used to	Used to select menu items displayed on 4-Character Display.				
Navigate Push Button (NAV)	Used to select an available function menu.					
16 MCF Defined LEDs	Color	Function	Indication			
1 (MAINT CALL)	Red	Maintenance Call:	On – maintenance call output on Off – maintenance call output off			
2 (TRANSFER HEALTH)	Red	Transfer Output:	On – transfer signal is being generated, transfer cards should not be counting down Flashing – indicates transfer time extended by CPU due to same error on main and standby side. Off- transfer signal is not being generated, if transfer card is in AUTO it should be counting down			
3 (XR Output)	Red	Red XR Output On – XR Output is energized Off – XR Output is de-energized				
4 - 10 (AND 2 through AND 8)*	Red	AND 2 through AND 8	Not used in this application			
11 (REMOTE SETUP)	Red	Remote Setup Session	On – The SGCP 4000/MS 4000 has been primed for a remote, one-person setup Flashing – Remote setup in progress Off – No remote setup is in progress			
12 (SSCC IV COMM)*	Red	SSCCIV Echelon Active	Not used in this application			
13 (RADIO DAX LINK A)*	Red	Radio DAX Link A	Not used in this application			
14 (RADIO DAX LINK B)*	Red	Radio DAX Link B	Not used in this application			
15 (VITAL COMM1)*	Red	Vital Comm 1	Not used in this application			
16 (VITAL COMM2)*	Red	Vital Comm 2	Not used in this application			
Component	Functi	on				
ECH LAN LEDs	<b>TX</b> flashes red when the CPU is transmitting an ATCS message via the <b>LONTALK® LAN</b> .					
LOIT LAIN LEDS	RX flashes green when the CPU is receiving an ATCS message via the LONTALK® LAN.					
DSPL COMM LEDs	TX flashes red when the CPU is transmitting data to the Display Panel.					

Component	Function			
	<b>RX</b> flashes green when the CPU is receiving data from the Display Panel.			
DIAC COMM (CD) I FDo	<b>TX</b> flashes red when the CPU is transmitting data on the communications processor diagnostic ( <b>DIAG CP</b> ) serial port.			
DIAG COMM (CP) LEDs	<b>RX</b> flashes green when the CPU is receiving data from the communications processor diagnostic ( <b>DIAG CP</b> ) serial port.			
PACKELANE COMMILEDO	<b>TX</b> flashes red when the Vital Logic Processor (VLP) is sending data onto the serial bus.			
BACKPLANE COMM LEDs	<b>RX</b> flashes green when the Vital Logic Processor (VLP) is receiving data from the serial bus.			
VLP HEALTH LED	Flashes yellow to indicate that the Vital Logic Processor is functioning normally.			
CP HEALTH LED	Flashes yellow to indicate that the Communications Processor is functioning normally.			
POWER LED	Illuminates green to indicate that power is applied to the CPU module.			
LAPTOP	Ethernet port for WebUI access, or for communication via Ethernet cable from Display Laptop port.			
RS-232 (DTE)	9-pin serial port for configuration management of modules via WebUI.			

<sup>\*</sup>LED not used in Motion Sensor application.

## 6.4.2 Track Module, A80418

The Track Module, A80418 performs the predictor and island train detection functions. The Vital I/O functions found on the Track Module, A80418 are:

- 2 isolated vital inputs
- 2 isolated vital outputs

## 6.4.2.1 Track Module, A80418 Front Panel

The Track module front panel is shown in Figure 6-9. The PRIME LED depicts the XR Relay. The DAX LEDs are not used on the SGCP 4000/MS 4000 application. The user interface is described in

Table 6-8.




Figure 6-9: Track Module, A80418 Front Panel

Table 6-8: Track Module, A80418 User Interface

COMPONENT	FUNCTION
4-Character Display	Displays module and track status and diagnostic messages. Refer to Section 7, Troubleshooting, for diagnostic message information.
S1 Push Button Switch	Pressing the S1 button on the track module will stop the display rotating around the different values so that one particular value can be seen. Press the S1 button again to scroll round the different values.
PRIME LED {XR Relay} (red)	On – XR Relay is energized Off – XR Relay is de-energized or not used Flashing – XR Relay is running the programmed pickup delay
DAX A – DAX G LEDS (red)	Not Used in SGCP 4000/MS 4000 application
PRE-EMPT LED (red)	Not Used in SGCP 4000/MS 4000 application
MOTION LED (red)	On – Motion Sensor has not detected motion Off – Motion Sensor has detected motion
ISLAND LED (red)	On – Island is unoccupied Off – Island is occupied Flashing – Island is running its pickup delay
OUT 1 LED (red)	On – output energized Off – output de-energized or not used
OUT 2 LED (red)	On – output energized Off – output de-energized or not used
IN 1 LED (red)	On – input energized Off – input de-energized or not used
IN 2 LED (red)	On – input energized Off – input de-energized or not used
HEALTH LED (yellow)	Slow (1Hz) – module is healthy and communicating with CPU Fast (2Hz) – module is healthy but not communicating with CPU Very Fast (4Hz) – module is unhealthy and communicating with CPU
POWER LED (green)	LED is on steady when power is applied to the module
DIAG Serial Port	9-pin diagnostic serial port for Track module.

## 6.4.3 A80435 External Configuration Device (ECD)

The ECD is a factory installed plug-in device on the SGCP 4000/MS 4000 backplane (see Figure 6-10). The ECD stores the module configuration file (MCF) and the application program for the SGCP 4000/MS 4000. Both the Main and the Standby CPU Modules copy the MCF from the ECD, as it is used for vital system operation.

# **A** WARNING

## **WARNING**

IF AN ECD IS REPLACED WITH AN ECD CONTAINING A DIFFERENT MCF, THE SGCP 4000/MS 4000 WILL COPY THE NEW MCF INTO THE FLASH ON THE CPU MODULES AND SET THE SYSTEM BACK TO DEFAULT VALUES.

## 6.4.4 Chassis Identification Chip (CIC)

The CIC is a non-volatile memory chip that is installed adjacent to the ECD on the SGCP 4000/MS 4000 backplane (see Figure 6-10). Each CIC stores site specific information for both Main and Standby vital operations.



#### **WARNING**

IF THE CIC IS REPLACED, THE USER MUST SET THE SYSTEM BACK TO DEFAULTS AND REPROGRAM THE SYSTEM. FAILURE TO DO THIS COULD RESULT IN THE SYSTEM RUNNING WITH THE WRONG CONFIGURATION FOR THE SITE.

6-16

SIG-00-11-02 Version No.: A.8




Figure 6-10: Typical ECD & CIC Locations On Backplane

## 6.4.5 Interface Connector Functions

The CPU interface connector functions are illustrated in Figure 6-11 and are described in Table 6-9; the SGCP 4000/MS 4000 Track Connector interface functions are illustrated in Figure 6-12 and are described in Table 6-10.




Figure 6-11: A80490 & A80495 CPU Connectors

## 6.4.5.1 CPU Connectors

Table 6-9: CPU Connectors

CONNECTOR	PINOUT	FUNCTION
LONTALK®	ECH1	LAN Twisted pair
PROTOCOL	ECH2	LAN Twisted pair
	2	DT_TX
DIAG	3	DT_RX
	5	GROUND
	В	Battery B input to SGCP 4000/MS 4000
CPU	N	Battery N input to SGCP 4000/MS 4000
	MAINT CALL	Battery power to Maint Call Light




Figure 6-12: A80490 and A80495 Track Connectors

## 6.4.5.2 Track Connector

**Table 6-10: Track Connectors** 

CONNECTOR	PINOUT*		FUNCTION	
	+		Vital output to crossing relay	
	ı	XR	(XR)	
	+		Vital output to island relay (ISL	
	ı	ISL	RLY)	
	+	IN1.1	Vital input 1	
	-		·	
TRACK	+ IN1.2	Vital input 2		
	TRK RCV1		Receiver input from track	
	TRK RVC2		rteceiver input from track	
	TRK CHK1		Chook input from trook	
	TRK CHK2		Check input from track	
	TRK XMT1			
	TRK XMT2		Transmit output to track	

#### 6.5 LAN COMMUNICATIONS



## **CAUTION**

BECAUSE THE ECHELON® INTERFACE IS NOT SURGE PROTECTED, NETWORK CONNECTIONS MUST BE RESTRICTED TO THE EQUIPMENT CONTAINED INSIDE A SIGNAL CASE OR BUNGALOW.

## NOTE

#### NOTE

For additional information concerning the Echelon<sup>®</sup> LAN, contact Siemens Technical Support.

Each SGCP 4000/MS 4000 may communicate with other Siemens equipment via LONTALK® LAN (Echelon®) For further information, see Siemens's Echelon Configuration Handbook, COM-00-07-09.

# SECTION 7 - INSTALL, PROGRAM, CALIBRATE & CHECKOUT SGCP 4000/MS 4000

#### 7.1 GENERAL REQUIREMENTS

It is recommended that the following wiring and installation requirements be read before the starting installation.

#### WARNING



VERIFY THAT THE SGCP 4000/MS 4000 SOFTWARE, AND PROGRAMMING DATA ARE AS SPECIFIED BY THE RAILROAD'S OR AGENCY'S APPROVED DESIGN. FAILURE TO DO SO MAY LEAD TO INCORRECT OR UNSAFE OPERATION OF THE WARNING DEVICES.

FAILURE TO FOLLOW THE RAILROAD'S OR AGENCY'S APPROVED DESIGN REGARDING MOTION SENSOR SETTINGS AND CALIBRATION MAY LEAD TO POSSIBLE UNSAFE OPERATION OF THE WARNING DEVICES.

FOLLOWING INSTALLATION OR AFTER ANY MENU CHANGES HAVE BEEN MADE, RECALIBRATE THE MOTION SENSOR AND TEST FOR PROPER OPERATION PER THE REQUIREMENTS SPECIFIED IN TABLES 8-1 THRU TABLE 8-3 OF SIG-00-11-02, SGCP 4000/MS 4000 INSTRUCTION & INSTALLATION MANUAL.

## **CAUTION**



IF ANY MOTION SENSOR IS CALIBRATED IN POOR BALLAST CONDITIONS, IT MUST BE RE-CALIBRATED WHEN BALLAST CONDITIONS IMPROVE.

## 7.2 WIRING REQUIREMENTS

## 7.2.1 Battery Wiring

Battery wiring to the SGCP 4000/MS 4000 equipment should be #16 AWG stranded minimum and twisted in pair. The wires are connected to at the shelter battery surge suppression panel. For proper battery surge protection, the battery surge suppression panel should be wired as shown in Figure 2-29.

## 7.2.2 Case Wiring

Case wiring to the SGCP 4000/MS 4000 equipment should be #16 AWG stranded. See individual application drawings in Section 2 for additional information.

## 7.2.3 Track Wiring

Equipment connections to the rails should be as short as practical (preferably less than a 100-foot {30.5 meter} pair) and should be #9 AWG or #6 AWG.

## 7.2.4 External Wiring Connectors & Wire Size

All external wiring to a SGCP 4000/MS 4000 Assembly is by means of plug-in connectors. The orange cage-clamp connectors for the signal circuits should use 16 to 12 AWG wire. The orange cage-clamp connector for the Echelon Lon Talk should use communication grade twisted wires of at least 20. The green Screw-Lock connectors for the CPU should use 10 AWG wire.

## NOTE

#### NOTE

Generic spare connectors that are not keyed for specific modules may be ordered. Refer to the catalog for ordering information.

## 7.2.5 Wire Preparation

Strip insulation from the end of the wire as follows:

**Table 7-1: Wire Preparation Standards** 

Connector Type	Strip Length
Screw terminal	0.28" (7 mm)
Cage clamp	0.32" - 0.35" (8 - 9 mm)

## NOTE

#### NOTE

Use a stripping tool to accurately set the strip length. The addition of ferrules is not required.

#### 7.2.6 Screw-terminal Connector Wire Insertion

Wires are secured to the screw-terminal connector as follows:

- Insert the stripped end of a wire into the wire receptor of the connector until it stops
- Tighten the screw to a torque of 4.5 inch pounds (0.508 Newton meters).




Figure 7-1: Insertion of Wire into Cage-clamp Connector

## 7.2.7 Cage-clamp Connector Wire Insertion

Wires are secured to the cage-clamp connector as follows:

- Place a flat bladed screwdriver in the rectangular slot in the connector next to the wire receptor (see Figure 7-1).
- Use a screwdriver blade 0.10 in. wide and 0.020 in. thick (2.5mm x 0.5mm)
- Lever the wire cage clamp open by pressing straight down on the screwdriver
- Insert the stripped end of a wire into the fully open wire receptor until it stops
- Hold the wire in place and release the screwdriver blade pressure
- The wire receptor closes on the stripped end of the wire

## 7.3 SYSTEM CUTOVER

The cutover test procedure should be used when initially installing, modifying, or after disarrangement of a SGCP 4000/MS 4000 system.



#### NOTE

This procedure does not supersede procedures of the maintaining railroad. This procedure is designed to supplement railroad procedures. In case of conflicts between procedures, the most restrictive procedure should govern.

Results of the tests may be documented on the SGCP 4000/MS 4000 System Cutover Test Form, which is found in Appendix D of this document.

## 7.3.1 Equipment Needed:

- Hardwire test shunt
- Test shunt
- Stopwatch
- PC with Diagnostic Terminal, (DT) software, or if using CPU III PC web browser.

NOTE

#### NOTE

It is not necessary to remove power from the motion sensor case before installing or removing modules.

## 7.3.2 Equipment and Site Preparation



## **WARNING**

IF ISLAND STATUS IS CHANGED FROM EXTERNAL TO INTERNAL, ISLAND RECALIBRATION IS REQUIRED.



#### NOTE

If the CPU module MCF is changed, requisite programming and recalibration will be required.

## 7.3.3 Recalibration & Reprogramming Requirements Due To Module Replacement

The recalibration requirements due to the replacement of a module are shown in the following table.

 Table 7-2: Recalibration & Reprogramming Requirements due to Module/Chassis Replacements

Part Number	Module	Approach Calibration	Island Calibration	Complete Reprogramming Required
A80403 A80903	CPU	No	No	No
A40418	Track	Yes	Yes	No
A80406	Transfer	No	No	No
A80500 A80485	Display Unit	No	No	No
A80438-2	ECD <sup>1</sup>	No	No	Yes
A80495 A80490	Chassis	Yes	Yes	Yes

#### Notes:

1. – Plug-in located on chassis behind CPU module. Requires same MCF as previously in use.

## 7.3.4 Recalibration Requirements Due To Program Changes

The program changes that require track recalibration are indicated in the following table.

Table 7-3: Recalibration Requirements Due to Program Changes

	Calibratio	_				
Program Changes	Approach Calibration	Island Calibration	Reprogramming Required			
Approach Frequency Change	Yes	No	No			
Island Frequency Change	No	Yes	No			
Directionality changed: UNI to BI/BWD, or BI/BWD to UNI	Yes	No	No			
Transmit Level Changed	Yes	No	No			
Ballast Compensation Value Changed	Yes	No	No			
Island Operation: Changed from EXT to INT or INT to EXT	Yes - Notes 1 & 2	Yes - Note 2	No			
Template Set to Default Selected	Yes	Yes	Yes - Note 3			
New Software Installed:	New Software Installed:					
Track MEF Changed:	No - Notes 4 & 5	No - Notes 4 & 5	No			
Other MEFs Changed:	No	No	No			
System MCF Changed:	Yes	Yes	Yes - Note 3			
Notes:						

- 1. If EZ varies by more than 2.
- 2. If changed to INT.
- 3. Complete reprogramming is required.
- 4. In general GCP and ISL calibration is not required when software is updated. However, in some cases due to the nature of the change, it may be necessary to force a recalibration. In this case the module will show that calibration is required after the new software has been loaded. Approach and Linearization can be bypassed after GCP calibration has been performed (Predictor Mode only).
- 5. Calibration may be needed, check Product Release Bulletin (PRB) associated with release for specific conditions, for example an update to GCP04\_80.mef, requires recalibration, see PRB0539. Approach and Linearization can be bypassed after GCP calibration has been performed (Predictor Mode only).

**NOTE:** Uploading a new PAC file may require recalibration.

## 7.3.5 Recalibration Requirements Due To Track Equipment Changes

Changes made to the existing track equipment that require track recalibration are shown in the following table.

Table 7-4: Recalibration Requirements Due to Track Equipment Changes

Track Equipment Changes	Approach Calibration	Island Calibration
Termination Shunts Changed	Yes	No
Termination Shunts moved to new location	Yes	No
Change of shunt or frequency in overlapping territory	Yes	No
Termination Shunts of other frequencies added, removed from, or moved within the SGCP 4000/MS 4000 approaches)	Yes	No
Wide band Insulated Joint Couplers (8A076 or 8A077) replaced in SGCP 4000/MS 4000 approaches	Yes	No
Tuned Insulated Joint Couplers (62785-f) replaced in SGCP 4000/MS 4000 approaches)	Yes	No
SGCP 4000/MS 4000 Track Wire(s) replaced, disarranged, and/or modified	Yes	Yes
Change of Insulate Joint Bypass Coupler (Tuned) 7A422-f	Yes	No

## 7.3.6 Install the SGCP 4000/MS 4000

- 1. Install and connect all SGCP 4000/MS 4000 equipment per the railroad's or agency's approved design.
- 2. Connect all required wiring per the railroad's or agency's approved design.

## 7.3.7 Configure the SGCP 4000/MS 4000 via Push-Button Menu

- 1. Observe the face of the CPU Card. SGCP 4000/MS 4000 scrolls in the 4-Character Display (Figure 7-3).
  - Press and release the SEL button. PROG appears in the 4-Character Display.
  - Press and release the SEL button. AFRQ appears in the 4-Character Display.
    If the desired parameter value is displayed, proceed to step 6. Otherwise,
    press and hold the SEL until the currently programmed value flashes on the
    display.
  - To move down the menu, press and release the NAV button to scroll through the menu until the desired frequency value appears. To move back up the menu, press and release the SEL button until the desired frequency value appears.

#### NOTE

#### NOTE

Typically, the SEL button is used to select desired parameter values. However, when setting parameters in the AFRQ (approach frequency) and ISL (island frequency) portions of the menu, pressing the SEL button moves the parameter value back up the value list, eliminating the need to scroll all the way through the menu if a mistake in made in parameter value selection.

- Press and hold the SEL button until SET AFRQ = XXXX? (e.g., SET AFRQ=4000?) appears in the 4-Character display. Press and hold the SEL until WAIT appears. Release the SEL button. After the parameter value is saved, AFRQ=XXXX (e.g., AFRQ=4000 HZ) appears.
- Continue programming the values per the railroad's or agency's approved design until all main menu items have been programmed. If no values from the Advanced (ADVD) menu require programming, proceed to step 8.
- Press and release the SEL value when the ADVD sub-menu appears and begin programming with the Positive Start EZ Value (PSTR) and program per the railroad's or agency's approved design until all sub-menu items have been programmed.
- 2. Once all required parameters have been programmed, proceed to Section 7.3.9, Calibrate the SGCP 4000/MS 4000.

## 7.3.8 Configure the SGCP 4000/MS 4000 via the WebUI (CPU III)

To configure the SGCP 4000/MS 4000 via the WebUI, Login to the WebUI as detailed in Section 3, then access the **Configuration** menu and navigate to the **MS4000 programming** screen. The user can then select the appropriate values from the drop-down menu or enter values where appropriate.




Figure 7-2: Adjust SCGP4000 / MS4000 Configuration

Once a parameter is changed, the **Save** button will need to be selected, as shown in Figure 7-3.




Figure 7-3: Save Changed Parameters

The user can also select the **Discard** button to discard a change to the value. After the desired parameters have been changed and saved, the MS4000 is ready to be calibrated.

## 7.3.9 Calibrate the SGCP 4000/MS 4000 via Push Button Menu

When possible, all SGCP 4000/MS 4000 Calibration procedures should be done when ballast is dry. If calibration is done when ballast is wet, recalibration may be required later when the ballast is dry.

## NOTE

NOTE

Refer to Section 7.3.12. If there are TJCs in an approach, they must be tuned before the rest of the calibration is completed.

The MS 4000 may operate using an internal island (ISL frequency is set) or an external island (EXT is set). The calibration process differs depending upon whether the internal or external island is selected.

- 1. Observe face of Track Card. The display scrolls GCAL, ICAL, the EZ value, the EX value and the Island value (e.g., I250).
- 2. Observe face of the CPU Card. To calibrate the approach (GCAL):
  - Navigate to the CAL menu. Press and release the SEL button. MCAL appears in the display.
  - Press and hold the SEL Button. Release the SEL Button when \*CAL appears, as
     \*CAL alternating with MCAL signifies that the calibration process has begun.
  - PASS or FAIL appears for twenty (20) seconds when calibration is complete.

#### WARNING



IF "FAIL" APPEARS ON THE DISPLAY, THE CALIBRATION PROCESS DID NOT COMPLETE.

SHOULD THIS HAPPEN, CYCLE THE UNIT POWER AND THEN REPEAT THE APPROPRIATE STEP.

IF THE UNIT FAILS TO COMPLETE THE CALIBRATION PROCESS, FURTHER TROUBLESHOOTING IS REQUIRED. REFER TO SECTION 8, TROUBLESHOOTING, IN THIS MANUAL.

• If FAIL appears, perform the measures directed in the WARNING immediately above. If Pass appears, proceed to Step 3.

The island can be calibrated to respond to a shunting sensitivity of 0.12, 0.3, 0.4, or 0.5 ohms. A hardwire shunt is used for calibration.

#### NOTE

NOTE

Island track circuit calibration is generally performed using 0.12 ohm shunting sensitivity. In an area where poor shunting is experienced or anticipated, a minimum of 0.3 ohm shunting sensitivity is recommended.

In areas of passenger operation, a minimum of 0.3 ohm shunting sensitivity is recommended.

If the internal island is enabled, proceed to Step 4. If the external island is enabled, proceed to Step 6.

Table 7-5: Island Shunt Distance in Feet/Meters

Island Frequency	0.12 ohm Sensitivity	0.3 ohm Sensitivity	0.4 ohm Sensitivity	0.5 ohm Sensitivity	
2.14	20/6.10	50/15.24	67/20.42	84/25.60	
2.63	17/5.18	43/13.11	58/17.68	72/21.95	
3.24	13/3.96	33/10.06	44/13.41	55/16.76	
4.0	10.5/3.20	27/8.23	36/10.97	45/13.72	
4.9	9.0/2.74	23/7.01	31/9.45	39/11.89	
5.9	7.5/2.29	19/5.79	26/7.92	32/9.75	
7.1	6.5/1.98	17/5.18	23/7.01	29/8.84	
8.3	6.0/1.82	15/4.57	20/6.10	25/7.62	
10.0	5.0/1.50	13/3.96	18/5.49	22/6.71	
11.5	4.5/1.37	12/3.66	16/4.88	20/6.10	
13.2	4.0/1.22	10/3.20	14/4.27	17/5.18	
15.2	3.5/1.07	9/2.74	12/3.66	15/4.57	
17.5	3.0/0.91	8/2.44	11/3.35	14/4.27	
20.2	3.0/0.91	8/2.44	11/3.35	14/4.27	

- Observe face of the CPU Card. To calibrate the island:
  - Connect a hardwire shunt at the distance beyond the receiver track connections specified in Table 7-5 for the desired sensitivity. Verify solid connections of the shunt to each rail.
  - ICAL appears in the display. Press the SEL Button until \*CAL appears alternating with ICAL. Release the SEL Button. The calibration process begins.
  - \*CAL and ICAL alternately flash during the calibration process.
  - PASS or FAIL appears for twenty (20) seconds when calibration is complete. When PASS appears, continue to Step 5. If FAIL appears, refer to the WARNING above.
- 4. Remove the test shunt.
- 5. LEDs #2 & #3 on the CPU card should light following calibration (when in MS mode, in PRED mode approach and linearization have to be completed too). If the LEDs do not light, proceed to Section 8 Troubleshooting this manual.
- 6. If the unit is programmed as a motion sensor (PRED=NO / \*Prime MS/GCP Mode=NO), proceed to Step 12. If the unit is programmed as a simple predictor (PRED=YES / \*Prime MS/GCP Mode=YES), proceed to Step 8.
- 7. Observe the face of the CPU Card. To calibrate the approach distance (ACAL):
  - Place a hardwire shunt on the termination shunt.
  - Press and release the NAV button. ACAL appears in the display.
  - Press and hold the SEL Button. Release the SEL Button when \*CAL appears, as \*CAL alternating with ACAL signifies that the calibration process has begun.
  - PASS or FAIL appears for twenty (20) seconds when calibration is complete.
  - If PASS appears, proceed to Step 10. If FAIL appears, proceed to Step 9 to manually enter the approach EZ.
- 8. Press and release the NAV button until APPEZ=100 appears.

- Press and hold the SEL Button. Use the NAV to increase the numerical value depicted on the 4-Character Display and the SEL button to navigate between the columns on the display.
- When the desired EZ value is displayed, press and hold the SEL button until SET APPEZ= XXX? (e.g., SET APPEZ=100?) appears in the 4-Character Display. Press and hold the SEL until WAIT appears. Release the SEL button. After the parameter value is saved, APPEZ=XXXX (e.g., APPEZ=100) appears.
- 9. Accurately (within 1%) locate the midpoint of the approach and move the hardwire shunt to that point on the rails.
- 10. Navigate down the menu until LCAL appears.
  - Press and release the NAV button. LCAL appears in the display.
  - Press and hold the SEL Button. Release the SEL Button when \*CAL appears, as
     \*CAL alternating with LCAL signifies that the calibration process has begun.
  - PASS or FAIL appears for twenty (20) seconds when calibration is complete.
  - If PASS appears, calibration is complete. If FAIL appears, refer to section 8 for troubleshooting. Remove the hardwire shunt.
- 11. Press and hold the SEL button until DONE appears.
  - Press and hold the NAV button until "SGCP 4000/MS 4000" appears in the display.

## 7.3.9.1 Bypassing the Linearization

Press and release the NAV button until LIN=100 appears.

- Press and hold the SEL Button until the "100" begins to flash. Hold the SEL button to bypass LIN.
- When complete "SET LIN=XXX" (e.g., SET LIN=100) appears. Bypass is now complete.

Press and hold the SEL button until DONE appears.

Press and hold the NAV button until "SGCP 4000/MS 4000" appears in the display.

## 7.3.10 Calibrate the SGCP 4000/MS 4000 via the WebUI (CPU III)



#### NOTE

Refer to Section 7.3.12. If there are TJCs in an approach, they must be tuned before the rest of the calibration is completed.

## 7.3.10.1 GCP (SGCP 4000/MS 4000) Calibration

When possible, all SGCP 4000/MS 4000 Calibration procedures should be done when ballast is dry. If calibration is done when ballast is wet, recalibration may be required later when the ballast is dry.

#### Table 7-6: GCP (SGCP 4000/MS 4000) Calibration

If a 60 or 100 Hz Cab Signal is in use, turn it off at this time.

Step 1

From the System View WebUI menu, select **Track > Calibration**. When a system needs calibration, instead of a box with a green checkmark it will have a red box icon beside it.

After unlocking the screen, select GCP from the **Select calibration** drop-down menu to calibrate the SGCP 4000/MS 4000, then select **Start Calibration**.




Figure 7-4: Start Calibration

Step 2 The WebUI may prompt the user during calibration to check overlapping crossings if present. Once the user confirms the check with **OK** the calibration process will complete.




Figure 7-5: Please Check Overlap

Step 3 EZ should be 98 to 102 and the 1) GCP line has a green checkmark next to it. If calibration is not successful, the display shows a Failed message.




Figure 7-6: Calibration Complete

Step 4 If the cab signal was turned off in Step 2, turn it on.

## 7.3.10.2 Approach Distance and Linearization Calibration

NOTE

#### NOTE

The Approach Distance and Linearization Calibration procedure is only needed if **PRED** is set to **Yes**.

NOTE

## **NOTE**

- 1. The setup for approach distance and setup for linearization procedures are combined into a single procedure to simplify track-shunting requirements.
  - a. The combined procedure calculates a modified approach distance based on actual approach distance (distance to the termination shunt from the crossing track wires) plus the electrical characteristics of the termination shunt and any simulated track impedance placed in series with the shunt.
  - b. This procedure is essential to improving warning time accuracy, especially for DAX and prime prediction offset circuits.
- 2. The linearization procedure compensates for lumped loads in the MS4000 approach that can affect the linearity of EZ over the length of the approach as a train approaches the crossing.
  - SECTION 1 The linearization is essential to improving warning time accuracy.
- 3. The types of loads that can affect the linearity of the approach circuit include:
  - a. Narrow-band shunts of other frequencies in the SGCP 4000/MS 4000 approach circuits, which may occur when other GCP approaches overlap the GCP approach circuit.
  - b. Other track equipment in the SGCP 4000/MS 4000 approaches such as audio frequency overlay track circuits, coded track circuits, etc.
  - c. Missing or incorrect track battery chokes.

Table 7-7: Approach and Linearization Calibration 1

Step 1	Record the EZ and EX values for the track (before installing the hardwire shunt) in the Step 1 column (Calibrated Values) on the CALIBRATION VALUES HISTORY form (Table 7-10). Then, temporarily place a hardwire shunt across the termination shunt. For bidirectional installation, use the termination shunt farthest from the crossing.
Step 2	Record the EZ and EX values for the track in the First Approach, Step 2 column on the CALIBRATION VALUES HISTORY form (Table 7-10).
Step 3	On the WebUI Calibration screen, select APP from the WebUI drop-down window, then select Start Calibration.



Figure 7-7: Calibration Initializaing

	The WebUI reports <b>Initializing</b> (Figure 7-7), then <b>In Progress</b> during the calibration.
Step 4	If calibration is successful, the WebUI will display the message <b>Calibration Success</b> in the <b>Status</b> window.
	If calibration is not successful, the display shows a Failed message.
Step 5	Record the computed approach distance in feet for the track in First Approach, Step 5 column (Comp Dist) on CALIBRATION VALUES HISTORY form (Table 7-10).
Step 6	Accurately (within 1%) locate the midpoint of the longest approach and move the hardwire shunt to that point on the rails (see Figure 7-9).
Step 7	On the WebUI Calibration screen, select LIN from the WebUI drop-down window, then select Start Calibration.




Figure 7-8: Linearization Calibration

	The WebUI reports Initializing, then In Progress during the calibration.
Step 8	If calibration is successful, the WebUI will display the message <b>Calibration Success</b> in the <b>Status</b> window.
	If calibration is not successful, the display shows a Failed message.
Step 9	Record the linearization step value for the track in the First Approach, Step 9 column (Linearization Steps) on the CALIBRATION VALUES HISTORY form (Table 7-10).
	The value should be between 68 and 132. If not, refer to Troubleshooting, found in SECTION 1.
Step 10	Verify that the computed approach distance in feet/meters (Comp Dist, Step 5) and the linearization steps (Linearization Steps, Step 9) values recorded on the CALIBRATION VALUES HISTORY form (Table 7-10) are the same as the values displayed on the Track "N" window.
Step 11	Remove the hardwire shunt from the track.




Figure 7-9: Midpoint Location

Table 7-8: Approach and Linearization Calibration 2

	••
Step 12	If the approach is unidirectional or simulated bidirectional, go to step 31.
	If the track is bidirectional go to step 13.
Step 13	Temporarily place a hardwire shunt across the termination shunt of the other approach.
Step 14	Record the EZ and EX values for the track in the Second Approach, Step 14 column on the CALIBRATION VALUES HISTORY form (Table 7-10).
Step 15	On the WebUI <b>Calibration</b> screen, select APP from the WebUI drop-down window, then select <b>Start Calibration</b> .
	The WebUI reports Initializing, then In Progress during the calibration.
Step 16	If calibration is successful, the WebUI will display the message <b>Calibration Success</b> in the <b>Status</b> window.
Step 17	Record the computed approach distance in feet for the track in the Second Approach, Step 16 column (Comp Dist) on the CALIBRATION VALUES HISTORY form (Table 7-10)
Step 18	Accurately (within 1%) locate the midpoint of this approach and move the hardwire shunt to that point on the rails (see Figure 7-9)
Step 19	On the WebUI <b>Calibration</b> screen, select <b>LIN</b> from the WebUI drop-down window, then select <b>Start Calibration</b> .
	The WebUI reports Initializing, then In Progress during the calibration.
Step 20	If calibration is successful, the WebUI will display the message <b>Calibration Success</b> in the <b>Status</b> window.
	If calibration is not successful, the display shows a Failed message.

Step 21	Record the linearization (Linearization Steps) for the track in the Second Approach, Step 21 column (Linearization Steps) on the CALIBRATION VALUES HISTORY form (Table 7-10).
	Value between 68 and 132.
	Verify that the computed approach distance in feet (Computed Distance, Step 17) and the linearization steps (Linearization Steps, Step 21) values recorded are the same as the values displayed on the Calibration Select window.
Step 22	Remove the hardwire shunt from the track.
Step 23	If the Linearization Steps value for the second approach, Step 21, is greater than or the same as the Linearization Steps value recorded for the First Approach (Table 7-10), Step 9, go to Step 31.
	If the Linearization Steps value for the second approach (Table 7-10), Step 21, is less than the value recorded for the First Approach, Step 9, go to Step 24.
Step 24	With <b>LIN</b> selected from the drop-down menu, click the <b>Edit</b> button from the WebUI Calibration screen




Figure 7-10: Edit Button

Step 25	The <b>Linearization Steps</b> dialog box, Figure 7-11, appears.
---------	--



Figure 7-11: Linearization Steps Diaglog Box

Step 26	Enter the Linearization Step Value (Linearization Steps) recorded for the First Approach, Step 9, (see CALIBRATION VALUES HISTORY form (Table 7-10) into the New Value field and select <b>Update</b> .  The entered value appears under the <b>Lin Steps</b> field.
Step 27	With <b>APP</b> selected from the drop-down menu, click the <b>Edit</b> button from the WebUI Calibration screen
Step 28	The Computed Distance dialog box, Figure 7-12, appears.




Figure 7-12: Computed Distance Diaglog Box

Step 29	Enter the computed approach distance (Computed Distance) value (in feet/meters) recorded for the First Approach (Table 7-10), Step 5, into the <b>Computed Distance</b> field and select <b>Update</b> .  The entered value appears under the <b>Comp. Dist</b> field.
Step 30	Verify that the computed approach distance (Comp Dist, Step 5) and the linearization steps (Linearization Steps, Step 9) values recorded on the CALIBRATION VALUES HISTORY form for the First Approach are the same as those displayed on the Track "N" window (see Table 7-10).
Step 31	To record the reason for the Calibration and store it in the event log, select <b>Add Comment</b> . Type any notes about the calibration and select <b>Add</b> to save the entry.

This completes Approach and Linearization Calibration. Proceed to Paragraph 7.3.10.3 for Island calibration.

Table 7-9: Approach and Linearization Calibration Bypass Procedure

Step 1 Once GCP Calibration is completed, bypass the approach calibration by selecting APP from the drop-down menu, then select the **By-Pass** key. Once approach calibration has been bypassed the WebUI will display the message: **Calibration bypassed successfully**.




Figure 7-13: Approach Calibration Bypass

Step 2

Bypass the linearization calibration by selecting LIN from the drop-down menu, then select the **By-Pass** key. Once linearization calibration has been bypassed the WebUI will display the message: **Calibration bypassed successfully**.



Figure 7-14: Linearization Calibration Bypass

NOTE

## NOTE

Calibration Distance and Linearization Steps values are site historical data and must be recorded as specified in Table 7-10 in this manual as well as on both the History Card and the Site Cutover form.

**Table 7-10: Calibrated Value History Form** 

1	CALIBRATION VALUES HISTORY FORM (APPROACH AND LINEARIZATION CALIBRATION)											
GCP#:				_								
Date of C	Calibration: Name:											
Location Information:								· · · · · · · · · · · · · · · · · · ·				
CALIBRA	NOIT	VALUE	S HIST	ORY								
	Fir			First Approach E/W( )N/S			Second Approach E/W ( ) N/S					
	Calibrated Values (Step 1)		Values		Hardy Acros Term Shun (Step	ss t	Computed Approach Distance (Comp Dist) (Step 5)	Linearizatio n Step Value (Linearizatio n Steps) (Step 9)	Across Term.		Computed Approach Distance (Comp Dist) (Step 17)	Linearization Step Value (Linearization Steps) (Step 21)
	EZ	EX	EZ	EX			ÈΖ	ΕX				
Track 1												
Track 2												
Track 3												
Track 4												
Track 5												
Track 6												

This completes Approach and Linearization Calibration. If the system includes an internal island, proceed to Island Calibration.

### 7.3.10.3 Island Calibration

The island can be calibrated to respond to shunting sensitivities: 0.12, 0.3, 0.4, or 0.5 ohms. A hardwire shunt is used for calibration.

# NOTE

#### NOTE

Island track circuit calibration is generally performed using 0.12 ohm shunting sensitivity. In an area where poor shunting is experienced or anticipated, a minimum of 0.3 ohm shunting sensitivity is recommended. In areas of passenger operation, a minimum of 0.3 ohm shunting sensitivity is recommended.

### NOTE

### NOTE

Be sure to follow all railroad, agency, or regulatory policies regarding the type and application of jumpers. Siemens recommends the use of jumper wires that are 18 AWG or larger.

**Table 7-11: Island Calibration Procedure** 

Step 1

From the **System View** WebUI menu, select **Track > Calibration**. After unlocking the screen, select **ISL** from the **Select calibration** drop-down menu.



Figure 7-15: Start Island Calibration

Temporarily install a hardwire shunt beyond the island receiver rail connections at the appropriate distance specified in the **Shunt (ft)** row.

Step 2

Shunt distances for island frequencies are provided in the table following the Island Calibration procedure. The appropriate ones for the configured island frequency are also shown on the calibration screen as shown in Figure 7-15.

Ensure EZ value is less than or equal to 5, confirming that the calibration shunt has a good connection to the rail.

	Select <b>Start Calibration</b> (Figure 7-15). The display reports <b>Initializing</b> , then <b>In Progress</b> during the calibration.				
Step 3	If calibration is successful, the WebUI will display the message <b>Calibration Success</b> in the <b>Status</b> window.				
	If calibration is not successful, the display shows a Failed message.				
Step 4	Remove the hardwire shunt.				

Table 7-12: Island Shunt Distance

Island Frequency	Shunt Distance Feet (Meters)					
(kHz)	0.12 ohm Sensitivity	0.3 ohm Sensitivity	0.4 ohm Sensitivity	0.5 ohm Sensitivity		
2.14	20 (6.1)	50 (15.2)	67 (20.4)	84 (25.6)		
2.63	17 (5.2)	43 (13.1)	58 (17.7)	72 (22)		
3.24	13 (4)	33 (10.1)	44 (13.4)	55 (16.8)		
4.0	10.5 (3.2)	27 (8.2)	36 (11)	45 (13.7)		
4.9	9.0 (2.7)	23 (7.0)	31 (9.5)	39 (12)		
5.9	7.5 (2.3)	19 (5.8)	26 (7.9)	32 (9.8)		
7.1	6.5 (2)	17 (5.2)	23 (7.0)	29 (8.8)		
8.3	6.0 (1.8)	15 (4.6)	20 (6.1)	25 (7.6)		
10.0	5.0 (1.5)	13 (4)	18 (5.5)	22 (6.7)		
11.5	4.5 (1.4)	12 (4)	16 (4.9)	20 (6.1)		
13.2	4.0 (1.2)	10 (3.2)	14 (4.3)	17 (5.2)		
15.2	3.5 (1.1)	9 (2.7)	12 (3.7)	15 (4.6)		
17.5	3.0 (0.9)	8 (2.4)	11 (3.4)	14 (4.3)		
20.2	3.0 (0.9)	8 (2.4)	11 (3.4)	14 (4.3)		

# 7.3.11 Track Module (A80418) Internal Island Response Test (CSB 3-15)

# NOTE

### NOTE

Perform the procedure in this section if the SGCP/MS4000 track circuit contains an internal island circuit.

After calibration, check the Track Module response using the following procedure:

- 1. Observe face of Track Card. The display scrolls the EZ value, the EX value and the Island value (e.g., I250). On the CPU card, after calibration is complete and all the shunts are lifted, LED #3 should be lit
- 2. Following railroad policies concerning the use of jumpers, place a jumper wire across the RCV1 and RCV2 receiver wires at the main terminal board and verify the EZ value is less than or equal to 5. If the EZ value is greater than 5 and the jumper is confirmed to be securely connected, use additional jumper wires in parallel until an EZ less than or equal to 5 is achieved. Note the Island Z value (e.g. I020) and verify the value is less than or equal to 40.
- 3. Remove the jumpers and allow the unit to recover.
- 4. Following railroad policies concerning the use of jumpers, place a jumper wire across the XMT1 and XMT2 receiver wires at the main terminal board and verify the EZ value is less than or equal to 5. If the EZ value is greater than 5 and the jumper is confirmed to be securely connected, use additional jumper wires in parallel until an EZ less than or equal to 5 is achieved. Note the Island Z value (e.g. l020) and verify the value is less than or equal to 40.
- 5. Remove the jumpers and allow the unit to recover.
- 6. If either the Island Z value is greater than 40, perform a full island calibration as detailed in Section 7.3.9 and repeat the Response Test in Section 7.3.11.
- 7. If, after performing the Response Test and Recalibration, the Island value remains greater than 40, remove the Track Module from service and contact Siemens Mobility Technical Support at (800) 793-7233, Option 1, inform the operator you have a Track Module that failed the functional checks as described in this procedure. Be prepared to provide the following:
  - Your Contact Information
  - Part Number
  - Serial Number
  - The EZ and Island Z values recorded during the test.

# 7.3.12 Auxiliary Equipment Calibration Procedures

### WARNING



TRACKS MUST BE VERIFIED TO BE FREE OF ANY AND ALL TRACK RELATED ISSUES PRIOR TO BEING PLACED IN SERVICE. ANY TRACK RELATED ISSUES THAT ARE IDENTIFIED MUST BE CORRECTED AND VERIFIED TO BE CORRECT PRIOR TO FINAL CALIBRATION AND LINEARIZATION.

NOTE

### NOTE

If the outlined procedures fail, they should be repeated once. If the error repeats, refer to the Troubleshooting section.

SGCP 4000/MS 4000 calibration is divided into the following procedures:

- Tuning the Tuned Joint Coupler (TJC)
- Approach Calibration (MCAL)
- Island Calibration (ICAL)

# **A** WARNING

# WARNING

PERFORM THE FOLLOWING TUNING PROCEDURES ON THE TUNED JOINT COUPLER PRIOR TO BEGINNING THE CALIBRATION PROCESS.




Figure 7-16: Tuned Joint Coupler, 62785-f

7-24

# 7.3.13 Tuning the 62785-f Tuned Joint Coupler

The Tunable Insulated Joint Bypass Coupler, 62785-f is the only tuned bypass coupler to be used with the SGCP 4000/MS 4000 for bypassing insulated joints in DC coded track.

The application guidelines for Tunable Insulated Joint Bypass Coupler, 62785-f when used only with the SGCP 4000/MS 4000 have been expanded as follows:

- In DC coded track circuits, the insulated joints within an approach may be bypassed using the Siemens 62785-f Tunable Insulated Joint Bypass Coupler, provided the minimum distances specified in Table 7-13 are observed.
- The 62785-f Coupler must be field tuned to pass the SGCP 4000/MS 4000 operating frequency (f) around insulated joints in DC or coded DC track circuits.
- The Coupler must be located within 10 feet (3.048 meters) of the insulated joints that it is coupling.

Two sets of insulated joints may be coupled in any single approach, provided the minimum operating distances specified in Table 7-13 are observed.

 Table 7-13 indicates the minimum operating distances (in feet & meters) to the first and second set of insulated joints that are coupled with 62785-f couplers for SGCP 4000/MS 4000 operation.

Table 7-13: Tuned Joint Coupler, 62785-f Minimum Distances

Frequency (Hz)	Minimum Distance To 1 <sup>st</sup> Set Of Insulated Joints (Feet/Meters)*	Minimum Distance To 2 <sup>nd</sup> Set Of Insulated Joints (Feet/Meters)*
151 to 211	1500/458	2200/671
212 to 348	1000/305	1400/427
349 to 560	700/214	1000/305
561 to 790	500/153	800/244
791 to 979	400/122	700/214

<sup>\*</sup> Distance applies to insulated joints located on the same side of the crossing.




Figure 7-17: Shunt Placement For 62785f Bypass Coupler

### WARNING

**A** WARNING

AT THE COMPLETION OF FIELD TUNING THE 62785-F BYPASS COUPLERS ENSURE THAT A STANDARD AREMA NUT IS TIGHTENED SECURELY AGAINST EACH GOLD NUT ON TERMINALS A THROUGH E, INCLUDING THE TERMINALS THAT ARE NOT TIGHTENED DOWN.

### NOTE

NOTE

While field tuning the 62785-f Bypass Coupler, tightening the nut on terminal E produces maximum change in EZ value. Tightening the nut on terminal A produces minimum change. The 62785-f Coupler is tuned by means of five standard AREMA binding posts.

- AREMA binding posts are labeled A through E (see Figure 7-16).
- AREMA binding posts are equipped with special gold AREMA adjustment nuts.

Table 7-14: Method 1 for Tuning the 62785-f Tuned Joint Coupler (See Figure 7-4 for Locations)

Step 1	Tighten the gold nut securely on terminal E of each coupler.							
Step 2	Calibrate the SGCP 4000/MS 4000, setting the EZ value to 100.							
Step 3	Place a hardwire test shunt across the track at location A.							
Step 4	Note the EZ value appearing on the SGCP 4000/MS 4000 display.							
Step 5	Move the test shunt to location B.							
Step 6	<ul> <li>Tune the Tunable Insulated Joint Bypass Coupler #1 to the same EZ value noted in Step 4.</li> <li>Tighten the gold nut on the Coupler #1 terminals labeled D, C, B, and A, in sequence beginning with terminal D.</li> <li>If tightening a nut results in an EZ value that is lower than the value recorded in step 4, loosen the nut and tighten the next nut in sequence.</li> <li>If, after tightening a nut, the EZ value remains higher than the value recorded in step 4, leave the nut tightened and tighten the next nut in sequence.</li> <li>Continue to tighten nuts D through A as necessary to obtain an EZ</li> </ul>							
	value that is approximately the same as that recorded in step 4.							
Step 7	Move the test shunt to location C.							
Step 8	<ul> <li>Tune the No. 2 Tunable Insulated Joint Bypass Coupler to the EZ value noted in step 4.</li> <li>Tighten the gold nut on the Coupler #2 terminals labeled D, C, B, and A, in sequence beginning with terminal D.</li> <li>If tightening a nut results in an EZ value that is lower than the value recorded in step 4, loosen the nut and tighten the next nut in sequence.</li> <li>If, after tightening a nut, the EZ value remains higher than the value recorded in step 4, leave the nut tightened and tighten the next nut in sequence.</li> <li>Continue to tighten nuts D through A as necessary to obtain an EZ value that is approximately the same as that recorded in step 4.</li> </ul>							
Step 9	Remove the test shunt.							
Step 10	Tighten a standard AREMA nut against each gold nut of both couplers to ensure all nuts are securely locked in position.							
Step 11	Secure the end caps over the terminal end of both couplers.							
Step 12	Completely recalibrate the SGCP 4000/MS 4000 and perform all operational checks.							
Step 13	Verify that a smooth change in the EZ value occurs across the couplers during a train move.							

Table 7-15: Method 2 for Tuning the 62785-f Tuned Joint Coupler (See Figure 8-2 for Locations)

Step 1	Tighten the gold nut securely on terminal E of each coupler.					
Step 2	Calibrate the SGCP 4000/MS 4000, setting the EZ value to 100.					
Step 3	Place a hardwire test shunt across the track at location A.					
Step 4	Note the EZ and EX values appearing on the SGCP 4000/MS 4000 display.					
Step 5	Move the test shunt to location B.					
Step 6	Tune the Tunable Insulated Joint Bypass Coupler #1 <b>EX</b> value to above 75. The <b>EZ</b> value may be as much as 8 points above the value noted in Step 4.					
Step 7	Move the test shunt to location C.					
Step 8	Tune the Tunable Insulated Joint Bypass Coupler #2 <b>EX</b> value to above 75. The <b>EZ</b> value may be as much as 16 points above the value noted in Step 4.					
Step 9	Remove the test shunt.					
Step 10	Tighten a standard AREMA nut against each gold nut of both couplers to ensure all nuts are securely locked in position.					
Step 11	Secure the end caps over the terminal end of both couplers.					
Step 12	Completely recalibrate the SGCP 4000/MS 4000 and perform all operational checks.					
Step 13	Verify that a smooth change in the EZ value occurs across the couplers during a train move.					

### WARNING



AT THE COMPLETION OF FIELD TUNING THE 62785-F BYPASS COUPLERS ENSURE THAT A STANDARD AREMA NUT IS TIGHTENED SECURELY AGAINST EACH GOLD NUT ON TERMINALS A THROUGH E. TERMINALS THAT ARE NOT USED FOR TUNING THE COUPLER MUST HAVE THEIR GOLD NUTS REMOVED.

# 7.4 SGCP 4000/MS 4000 OPERATIONAL TESTS

Prior to placing a system in service, tests must be performed to verify proper system operation and I/O wiring. Proceed to next step if a feature is not used.

### WARNING

**A** WARNING

AFTER INITIAL PROGRAMMING OR PROGRAMMING, MODULE, TRACK, OR WIRING CHANGES, TESTS MUST BE PERFORMED TO VERIFY PROPER OPERATION OF THE MOTION SENSOR PRIOR TO PLACING A SYSTEM IN SERVICE.

IF A RAPID CHANGE OCCURS IN THE VALUE OF EZ AT ANY TIME THE TRAIN IS MOVING WITHIN THE TERMINATION SHUNTS, TRACK DISCONTINUITY CAUSED BY A HIGH RESISTANCE BOND OR A DEFECTIVE COUPLER IS INDICATED. LOCATE AND CORRECT THE PROBLEM IMMEDIATELY.

THE RAILROAD PROCEDURES GOVERNING HOW TO TAKE A TRACK CIRCUIT OUT OF SERVICE SHALL BE FOLLOWED. THE INSTRUCTIONS IN THIS SECTION MAY BE FOLLOWED ONLY IF ALLOWED BY THE RAILROAD.

Table 7-16: SGCP 4000/MS 4000 Operational Tests

Step 1	Check tracks for:  Open transmit wire Crossing activates EZ = 0  Or Open receive wire Crossing activates EZ = 0					
Step 2	UAX, if used: Crossing activates when each remote line circuit that controls a UAX is de-energized or opened from the far end of the circuit. Pickup Delay time is correct when input closes.					
Step 3	Out of Service, OOS, if this feature is used: 4-Character Display reflects time remaining in OOS					
Step 5	If Positive Start, and/or Sudden Shunt Detection are used:					

Finishing Step 5 completes the SGCP 4000/MS 4000 operational checks / tests. Now verify proper Train Detection, Warning Time, and Crossing Activation.

Table 7-17: Train Detection, Warning Times, and Crossing Operation

Step 1	<ul> <li>EZ continuity check on train moves:</li> <li>Crossing devices activate and EZ value decreases smoothly (without rapid change) for an approaching train.</li> <li>Crossing devices turn off when island recovers after train move and the EZ rises smoothly (without rapid change) as the train recedes.</li> </ul>	
Step 2	Check warning times for inbound train moves on each approach including UAX operation.	

### 7.5 VIEW SGCP 4000/MS 4000 HARDWARE & SOFTWARE VERSION DATA:

To view SGCP 4000/MS 4000 Hardware and Software Data:

- 1. Observe the face of the CPU Card. SGCP 4000/MS 4000 scrolls in the 4-Character Display (Figure 7-3).
- Press and release the SEL button. PROG appears in the 4-Character Display.
- 3. Press the NAV button to scroll down the menu until VERS appears.
- 4. Press and release the SEL button. Press the NAV button to scroll to the desired submenu (CP, VLP, TRK, or CFG).
- 5. On the desired sub-menu (e.g., CP), press and release the SEL button. The first parameter appears.
- 6. Review the parameter values by pressing the NAV to scroll through each value.
- 7. Move back up the menu by pressing and holding the NAV button for approximately 2 sec.

### 7.6 VIEW WARNING TIME OF THE PREVIOUS TRAIN

To view the Warning Time (measured in seconds) of the previous train:

- 1. Observe the face of the CPU Card. SGCP 4000/MS 4000 scrolls in the 4-Character Display (Figure 7-3).
- 2. Press and release the SEL button. PROG appears in the 4-Character Display.
- 3. Press the NAV button to scroll down the menu until TRWT appears.
- 4. Press and release the SEL button. The Warning Time appears in the 4-Character Display.

SIG-00-11-02

Version No.: A.8

# SECTION 8 - TROUBLESHOOTING

### 8.1 OVERVIEW

The 4-character display on the front of the CPU module allows the user to diagnose and remedy system errors by identifying the diagnostic code, cause, and remedy. The **Diagnostics** menu on the CPU III WebUI can also be used to identify system errors. See section 3.3.2.2 for more information on the CPU III WebUI Diagnostics menu.

### 8.2 ERROR CODES



# WARNING

IF APPROACH LENGTH IS REDUCED, MAXIMUM TRAIN SPEED MUST ALSO BE CORRESPONDINGLY REDUCED.

NOTE

### NOTE

Throughout Table 8-1, any reference to GCP includes the Simple Grade Crossing Predictor 4000 / Motion Sensor 4000 (SGCP 4000/MS 4000).

Disp. Code refers to the codes being displayed in the 4-Character Display on the CPU Card or Track Card.

The following table provides a listing of the error codes used with the SGCP 4000/MS 4000:

Table 8-1: SGCP 4000/MS 4000 Error Codes								
<u>Diag</u> Code	Disp. Code	Card	Error Name	<u>Cause</u>	Remedies_			
Diag1000	RECV	Track	GCP Recovering	The GCP runs a 30s recovery timeout after an error has cleared	None			
Diag1001	GSTB	Track	GCP Stabilizing	On startup GCP is output stabilizes for 20s before normal operation	None			
Diag1002	HIEZ	Track	High EZ	A High EZ is caused by:  a) high resistance bond b) broken rail c) defective termination shunt d) high resistance connection to termination shunt e) defective insulated joint coupler f) ballast has increased since calibration	a) check for high resistance bond b) check for broken rail c) check for defective termination shunt d) check for high resistance connection to termination shunt e) check for defective insulated joint coupler f) recalibrate the GCP only after verifying that none of the other causes above exist			
Diag1003	LWEX	Track	Low EX	Low EX is caused by low ballast resistance possibly due to:  a) salted crossing b) poor drainage at the crossing c) mud between rails	If above signs of poor ballast are present, consider:  a) using a lower GCP frequency b) temporarily shortening the approach c) check if low EX Adjust is applicable as directed in the manual			
Diag1004	LWEZ	Track	Low EZ Detected	a) A train sitting on the approach for longer than the configured Low EZ detection timer b) A false shunt on the track c) Broken receive track wire	a) If the cause is a train sitting on the approach, turn off the low EZ detection temporarily until the train has left b) Check for false shunts on the track, and ensure EZ has gone back to it normal value after the shunt is removed. c) if the above shunts are not found, see other diagnostics messages for broken receive wire			
Diag1005	RXEX	Track	Receive Wire EX Error	Generally, occurs at cutover, and means that the receive wires and transmit wires are misphased.	Check the receive wires for proper phasing			
Diag1006	CKEX	Track	Check Wire EX Error	Generally, occurs at cutover with 6 wire installations, and means that the check wires and transmit wires are misphased.	Check the check wires for proper phasing			
Diag1007	CHK2	Track	Gain Check -Check Wire Error	The error generally occurs when there is a high resistance or open connection in the check wire	Check for high resistance or open connection in check wire			
Diag1008	CHK1	Track	Gain Check - Receive Wire Error	The Gain Check Receive Error is caused when the receiver wires have a low reading and the check wires have a high reading	Check the receive and check wires			

	Table 8-1: SGCP 4000/MS 4000 Error Codes							
<u>Diag</u> Code	<u>Disp.</u> Code	Card	Error Name	Cause	Remedies			
Diag1009	СНКЗ	Track	Gain Check Island Error	The Gain Check Island Error is caused when the receiver and check wires have a low reading indicating that the train is at EZ zero, but the island has not become occupied. Note: this check is only done when the GCP and island share the same pair of transmit wires.	a) Check the receive and check wires b) check the island shunting and calibration			
Diag1010	CHCK4	Track	Gain Check Error	The Gain Check Error is caused when the receiver and check wires have a reading that differs by a significant amount. This could be due to: a) High resistance or open connection (if no train is present) b) high resistance in transmitter (if a train is present)	a) Check for high resistance or open connections in check and receive wires b) check for high resistance in transmitter			
Diag1011	GMAX	Track	GCP Transmitter	The GCP Transmitter Error is caused when the card detects either:  a) high resistance or open track wire or track wire rail connection or b) Unidirectional installation: open termination; open coupler; or open bond,	a) Check that transmit wires are connected properly b) Check for open termination, open coupler, open bond,			
Diag1012	GFRQ	Track	No GCP frequency	This message indicates that Ms/GCP Operation has been requested but no GCP frequency has been selected	Select a GCP frequency from the Program menu			
Diag1013	GIPS	Track	IPS Mode	IPS Mode is shown when the card has been configured with the Enhanced Detection option On and the card has detected in bound poor shunting.	None.			
Diag1014	GRCV	Track	Receiver Error 1	Receiver Error 1 is caused by an unacceptable difference between the redundant receivers on the module	Replace the track module			
Diag1015	GRCV	Track	Receiver Error 2	Receiver Error 2 is caused by an unacceptable difference between the redundant receivers on the module	Replace the track module			

			Table 8-1: So	GCP 4000/MS 4000 Error	Codes
<u>Diag</u> Code	<u>Disp.</u> Code	Card	Error Name	Cause	Remedies
Diag1016	GEXP	Track	EX Process Prediction	An EX Process Prediction is possibly caused by: a) poor shunting b) a high resistance bond or c) coupler	Check that no high resistance bonds are present
Diag1017	UCFG	Track	No Communications	No Communications indicates that the track card is not communicating with the CPU	a) Check that there is a module in the appropriate slot, b) Check to see if the module is continuously rebooting (Boot shows on the 4 character display every minute or so), if it is replace the module. c) If the module is not continuously rebooting, then check to see if the module says UCFG on its display. If only this module is shows UCFG, then replace it, if all Track modules show UCFG then replace the CPU
Diag1018	GLCK	Track	Power Up Lockout Error	This occurs when the EZ or check EZ values are below three after a power up. This could be caused by a) a train shunting the tracks or b) open receive or check wires	a) Check to see if a train is present, if it is the lockout can be cleared using the diagnostic terminal b) if no trains are present verify that the check and receive wires are connected properly
Diag1019	GHWR	Track	Track Hardware Error	This occurs when the track card detects that its hardware is not operating correctly	Replace the hardware
Diag1020	GCAL	Track	GCP Calibration Required	The GCP requires calibration if the: a) module was replaced b) MCF was changed c) the program was set to defaults or if one of following has changed: i) frequency ii) approach distance iii) compensation value iv) transmit level v) bi/uni directional	Check that the module is programmed correctly then go to the Setup Track GCP Calibration screen, and calibrate the GCP as described in the manual
Diag1021	GAPP	Track	GCP Approach Calibration Required	The GCP requires approach calibration if the: a) GCP calibration was performed b) module was replaced c) program was set to defaults d) programmed approach distance has changed e) MCF was changed	Go to the Setup Track Approach Calibration screen. If the computed approach distance is correct, hit the bypass button. If the computed approach distance is known for this track from a previous calibration, enter the correct value by hitting the edit button. If the computed approach distance is incorrect and not known, perform an approach calibration as described in the manual.

	Table 8-1: SGCP 4000/MS 4000 Error Codes								
<u>Diag</u> Code	<u>Disp.</u> Code	Card	Error Name	Cause	Remedies				
Diag1022	GLIN	Track	GCP Linearization Required	The GCP requires linearization if the: a) GCP calibration was performed b) GCP approach calibration was performed c) module was replaced d) program was set to defaults e) programmed approach distance has changed f) MCF was changed	Go to the Setup Track Linearization Screen. If the linearization value is correct, hit the bypass button. If the linearization value is known for this track from a previous calibration, enter the correct value by hitting the edit button. If the linearization value is incorrect and not known, perform a linearization as described in the manual.				
Diag1200	VOER OUT	Track	OUT Correspondence Check Error	OUT Correspondence Check Error is caused by the module detecting a state on its output that is not in correspondence with the commanded state of the OUT.	a) check that the output is not shorted     b) replace the module				
Diag1201	GSWR	Track	Software Compatibility Error	The software (MEF) in the track module is incompatible with the MCF running in the CPU	a) install the latest track module MEF     b) install the latest MCF				
Diag1202	GMAX	Track	GCP Transmit Level	This version of GCP module does not support the MAX transmit level	a) set transmit level to Medium or High     b) change A80418 module to rev     newer than rev D				
Diag1202	GPRM	Track	Prime Offset Error	The track module is configured to expect an island and the prime has a non-zero offset value	a) set the prime to zero offset if applicable b) if island is used at remote location, use a DAX not the prime c) set the Island Connection to No Islands if no island is intended				
Diag1011	GXMT	Track	Transmitter Error	All installations: High resistance or open transmit track wire High resistance or open track wire rail connection	Locate and repair open transmit wires or high resistance transmit wires connections				
Diag1011	GXMT	Track	Transmitter Error	Unidirectional installations only: Open termination, open coupler, or open bond	Locate and repair: Open termination, open coupler, or open bond				
Diag1203	ICON	Track	Island Connect Error	The GCP Island Connection indicates an island is connected, but no island is turned on	a) turn the island on, if applicable     b) set the island connection to No     Islands if no island is intended				
Diag1300	IFRQ	Track	No Island Frequency Selected	This message indicates that Island Operation has been requested but no island frequency has been selected	Select an island frequency from the Program menu				
Diag1301	ISTB	Track	Island Stabilizing	On startup the island output stabilizes for about 10s	None				
Diag1302	ITST	Track	Island Self-Test Error	Island Self-Test Error is caused when an interfering signal causes large variation in the Island receive signal.	a) Check for interfering signals on the track b) Change IPI frequencies c) Replace the module				

			Table 8-1: S	GCP 4000/MS 4000 Error	Codes
<u>Diag</u> Code	<u>Disp.</u> Code	Card	Error Name	Cause	Remedies
Diag1303	RECV	Track	Island Recovering	The Island runs a 30s recovery timeout after an error has cleared	None
Diag1304	IXMT	Track	Island Transmitter Error	The Island Transmitter Error is caused when the card detects either: a) high resistance or open track wire or track wire rail connection b) Unidirectional installation: open termination, open coupler, open bond	a) Check that transmit wires are connected properly     b) Check for open termination, open coupler, open bond,
Diag1305	ICAL	Track	Island Calibration Required	The Island requires calibration if the: a) module was replaced b) MCF was changed c) the program was set to defaults or if the frequency has changed	Check that the module is programmed correctly then go to the Setup Track Island Calibration screen and calibrate the island as described in the manual
Diag3001	DFT	CPU	Operating Parameters set to default	New MCF has been loaded	Set the operating parameters to the required values
Diag3002	DFT	CPU	Vital Cfg Params set to default	New MCF has been loaded or UCN changed	Set the vital CFG parameters to the required values
Diag3003	CRPT	CPU	MCF checksum incorrect	MCF is corrupt	Reload the MCF
Diag3004	CRC	CPU	MCF CRC incorrect	a) incorrect MCF CRC has been entered for this MCF b) the MCF is corrupt	a) reload MCF CRC b) reload MCF
Diag3005	MCF	CPU	MCF Checks failed	the MCF is invalid	obtain and load a valid MCF
Diag3006	MOD	CPU	Module type error	The MEF is incompatible with this hardware	Reload a valid MEF for this hardware
Diag3007	VERS	CPU	Hardware compatibility error	The software (MEF) is incompatible with this revision of hardware	a) reload compatible software     b) obtain later compatible release of     hardware
Diag3008	VERS	CPU	MCF Compatibility incorrect	The MCF is incompatible with the software (MEF)	Obtain compatible MCF or software (MEF)
Diag3009	SIN	CPU	SIN Error	The ATCS address of System is incorrect, due to: a) address not set b) address has an illegal value	Set SIN to valid value using ATCS Site ID Menu
Diag3010	UCN	CPU	UCN Error	The UCN has not been entered correctly or is not the correct one for this location	a) Obtain and enter the correct UCN or b) check that the UCN is for this location and check that the vital options and ATCS address are set correctly
Diag3013	MCF	CPU	MCF Compatibility incorrect	The MCF is incompatible with the software (MEF)	Obtain compatible MCF or software (MEF)
Diag3014	CRC	CPU	MEF CRC incorrect	The software (MEF) is corrupt	Reload the MEF
Diag3015	ADR	CPU	ATCS Session address invalid	The ATCS address of the session is invalid	Reenter the SIN for this location

	Table 8-1: SGCP 4000/MS 4000 Error Codes				
<u>Diag</u> Code	<u>Disp.</u> Code	Card	Error Name	Cause	Remedies
Diag3016	CAP	CPU	MCF Capability Error	The CPU is not capable of running this MCF	a) Purchase a CPU with a higher capability or     b) Obtain and MCF requiring lower a capability CPU
Diag3017	DFT	CPU	Configuration Set to Default	The configuration parameters have been setback to defaults due to either: a) an MCF change b) a template change c) user setting default	Wait. This message will clear after the defaults have been set.
Diag3018	UCFG	CPU	VLP Unconfigured	The VLP is unconfigured, as thus does not communicate with any I/O modules. This is usually due to UCN, MCF CRC, SIN errors.	Check other diagnostic message for the exact cause of the VLP being unconfigured
Diag3019	UCFG	CPU	Configuration Invalid	The VLP has found that the configuration is either corrupt or invalid for this MCF or MTF.	If a new MCF loaded or MTF selected, do a Set To Default. Otherwise repower the CPU, if this does not fix the problem, do a Set To Default and reprogram the unit.
Diag3020	INIT	CPU	No VLP Comms	The VLP is rebooting or is in its Initial State and performing its initial checks. This may occur after a VLP reset, or after changing templates.	Wait for a minute for the VLP to power up. If the VLP does not power up, check to see if it is continuously rebooting by checking the VLP Health LED.
Diag3021	CCN	CPU	CCN Incorrect	After loading a configuration file the CCN is incorrect	Reload the configuration file and repower the CPU card. If you still get a CCN error, do a Set to Default and reprogram the unit.
Diag3021	N/A	SEAR	SEAR Health	SEAR not in session	1. Verify that Power light on SEAR is lit. Verify that the first 10 digits (7.RRR.LLL.GGG) of the ATCS address match between the MS/GCP and the SEAR.

	Table 8-1: SGCP 4000/MS 4000 Error Codes				
<u>Diag</u> Code	<u>Disp.</u> Code	Card	Error Name	<u>Cause</u>	<u>Remedies</u>
Diag3022	CIC	CPU	CIC Access Error	The CPU cannot access the configuration data stored in the CIC.	1. If CIC access error is on the Main CPU:  a) remove the Standby card, and repower the Main CPU, b) if CIC error clears then the Standby CPU card is faulty, replace the Standby CPU with a good CPU. c) if error does not clear, remove the Main CPU and insert the original Standby CPU, and switch to Standby, d) if the error clears, the Main CPU is faulty, replace with a good CPU module e) if the error does not clear, the CIC chip is likely to be the problem, replace the chassis. 2. If CIC access error is on the Standby CPU: a) remove the Main card, and repower the Standby CPU, b) if CIC error clears then the Main CPU card is faulty, replace the Main CPU with a new module. c) if error does not clear, remove the Standby CPU and insert the original Main CPU, and switch to Main, d) if the error clears, the Standby CPU is faulty, replace with a good CPU module e) if the error does not clear, the CIC chip is likely to be the problem, replace the chassis.
Diag3023	UCFG	CPU	CP Unconfigured	The CP is unconfigured.	The probable cause of this is failure to the read the CIC, see other diagnostic messages for more information.
Diag3024	UCU	CPU	Unconfigured due to	The CPU is unconfigured to a due request to upload a configuration file.	Reset the VLP2 or repower the CPU card.

The normal sequence of messages seen on the four character display when a CPU III is booting up is shown below:

CPU3 > Boot > Init > E087 > ICHK > CP MEF > VLP MEF > GCP 4k MCF

If a CPU III is inserted into a system that does not have the MCF loaded it will need to load the MCF from the ECD, in this case the boot up message sequence is shown below:

CPU3 > Boot > Init > E087 > ICHK > CRC UCFG > NRBT > Loading MCF > Burning MCF > DONE > Boot > IP : Laptop > Init > ICHK > CP MEF > VLP ME > GCP 4k MCF

Note the E087 may or may not be present in the sequence above.

If the CPU III has been unpowered for more than a week and then it is inserted into a system,-the boot up sequence may show the following:

CPU3 > Boot > Init > E087 > ICHK > CRC.. UCFG.. ERR ..ECD

In this case, leave the CPU III installed in the system with power on for 1 minute, then remove the CPU III module and reinsert it and it should boot up normally showing one of the first two sequences shown above.

# 8.3 TESTING TRACKSIDE EQUIPMENT

# 8.3.1 Testing Insulated Joint Couplers, Rail Bonds, and Termination Shunts

**Table 8-2: Insulated Joint Coupler Test** 

Step 1	Connect a hardwire shunt on the crossing side of the joint coupler.	
Step 2	Note the EZ value:	
Step 3	Move the hardwire shunt to the termination side of the joint coupler.	
Step 4	Note the EZ value:	
Step 5	Remove the hardwire shunt.	
Step 6	Note the difference in EZ values in steps 2 and 4.	
	Wideband shunt coupler - if the difference in EZ is more than 2, the wideband shunt is defective.	
	Tuned Insulated Joint Coupler, TIJC - (located in the outer half of the approach), if the EZ difference is more than 3, the TIJC is mistuned or defective.	

# Table 8-3: Rail Bond Test

Step 1	Note the EX value with no shunt:		
Step 2	Place a hardwire shunt at the 50% point of the approach.		
Step 3	Note the EX value:		
Step 4	Note the difference in EX values in steps 1 and 3.		
	An EX value <b>always</b> increases as a shunt is placed closer to the crossing.		
	If the EX value recorded in step 3 is greater than the EX value in step 1, the bad bond is between the hardwire shunt and the termination.		
	If the EX value recorded in step 3 is lower than the EX value in step 1, the bad bond is between the hardwire shunt and the crossing.		
Step 5	Continue placing the hardwire shunt closer or further away from the starting point, based on the value in step 3. When the EX value increases, the last bond passed is the bad bond.		

EZ must be greater than 15 for this test to work.

**Table 8-4: Termination Shunt Test** 

Step 1	Note the EZ value:
Step 2	Install a hardwire shunt across the termination.
Step 3	Note the change in EZ:
	If termination is hardwire, no EZ change occurs.
	If termination is wideband, an EZ change of no more than $\pm$ 2 occurs.
	If termination is NBS, EZ can decrease up to 30.
	Lower frequencies and shorter approaches produce a greater change.
	If termination is NBS and an increase in EZ is noted, then the NBS is defective.

# 8.3.2 Troubleshooting A De-energized Motion Sensor

This subsection describes the method of troubleshooting a problem in a system that has previously been in service. The first step in troubleshooting a problem is to determine whether the track circuit continuity and components of a SGCP 4000/MS 4000 system are healthy.

When the SGCP 4000/MS 4000 system is healthy, Power LEDs on all modules are on and steady.

Table 8-5: Troubleshooting a De-energized Motion Sensor

REASON	HOW
The track module senses that EZ is decreasing at a rate that is fast enough to trigger the motion sensor.	An approaching train.
Positive Start is enabled and the EZ level is below the programmed Positive Start EZ Level	Positive start is de-energizing the motion sensor.  Enabled in the menu.  Predictor remains de-energized while the EZ is less than the positive state level plus 5.  The current Track Module EZ is shown on the module's 4-character display.
An UAX input is deenergized	A UAX input is programmed for the Track Module and the input is not energized or is running UAX Pickup delay.
Interference is causing large EZ fluctuations which appear to be an approaching train	The rapid fluctuation of the displayed track EZ level by 5 to 10 points (or more) indicates the presence of interference.

# 8.3.3 Troubleshooting A Physical SGCP 4000/MS 4000 Input

After it is determined that a problem is caused by a de-energized physical input, use the following procedure to isolate the cause.

Table 8-6: Troubleshooting Inputs

Step 1	Determine the connections to the physical inputs by referring to the circuit plans for the location. These inputs may include:		
	a UAX circuit from a remote site.		
	an external island.		
	other external inputs.		
Step 2	If the input is connected to other equipment that is not in this bungalow, go to step 5.		
Step 3	Verify that the output of the other equipment is energized using either the indications from that equipment or a meter.		
Step 4	If the output of the other equipment is energized but the motion sensor input is not, check the wiring between the equipment and the motion sensor.		
Step 5	Using a meter, check the remote connection input at the point it enters the bungalow.		
	If the input is energized, go to the remote site and check the output.		
	If the input is de-energized, check the wiring from this point through to the motion sensor terminals.		

### 8.3.4 Track Circuit Problems

When a failure occurs in a bi-directional track circuit, the EZ and CHECK EZ on the Detailed Status View will generally change in relationship to the normal range and possibly to each other as follows:

If EZ and Check EZ move higher or lower than normal, but remain relatively equal to each other, the track circuit problem lies on the transmitter side of the crossing.

If EZ and Check EZ move higher or lower than normal, but their values differ by more than 5, the track circuit problem most likely lies on the receiver side of the crossing.

### 8.4 **LOW EX**

If a low EX condition is occurring at a cutover of a new installation, check the following:

- 1. Defective Bonds
- 2. Defective insulated joint couplers
- 3. Missing battery choke in approaches
- 4. Defective gauge rods or switch rods
- 5. Open termination shunt
- 6. Improper application of other frequency NBS in the approaches.

When low EX occurs at an in-service crossing, follow the steps shown in Table 8-7 to determine whether the Low EX Adjustment can safely be lowered below 39.

Low EX condition commonly occurs at an in-service crossing when track conditions are extremely wet and possibly salted.

### 8.4.1 Low EX Qualification Test



### WARNING


DO NOT LOWER THE LOW EX ADJUSTMENT BELOW 39 IF THERE IS NOT A 5 POINT DROP IN EZ.

Table 8-7: Low EX Qualification Test Push-Button Method

Step 1	With EX below 39, connect a hardwire shunt at the termination shunt of the longest approach.		
Step 2	Record the EZ value:		
Step 3	Move the hardwire shunt in to the 90% point of the approach.		
Step 4	<ul> <li>Record the EZ value:</li></ul>		
Step 5	Scroll with the SEL button to get to PROG:  SEL button to get into options (AFRQ)  NAV button down to ADVD  SEL button to get into options (PSTR)		
Step 6	Press NAV button down to LWEX     Hold SEL button to change option		
Step 7	<ul> <li>Enter a new EX value between 34 and 39. Use SEL and NAV to change the 2 digits of the value</li> <li>Hold SEL when the desired value is displayed (SET LWEX=3X?)</li> </ul>		
Step 8			

Table 8-8: Low EX Qualification Test WebUI Method (CPU III)

Step 1	With EX below 39, connect a hardwire shunt at the termination shunt of the longest approach.			
Step 2	Record the EZ value:			
Step 3	Move the hardwire shunt in to the 90% point of the approach.			
Step 4	<ul> <li>Record the EZ value:</li></ul>			
Step 5	Access the Configuration menu on the WebUI (see Section 3.3 for information on the WebUI):  • Select the MS4000 programming menu, then use the Next button to scroll (2X) to MS4000 Advanced screen.  Configuration  MS4000 Advanced  TEMPLATE programming  MS4000 programming  MS4000 Programming  MS4000 Advanced  • Prev • Next  MS4000 Advanced  • Prositive Start  • Sudden Shnt Det Used			
		Inbound PS Sensitivity	High ▼ *	
		Speed Limiting Used	Yes ▼ *	
		Outbound False Act LvI	Normal *	
	Figure 8-1: MS4000 Advanced Screen			
	<ul> <li>After confirming local user presence via the Unlock button, use the Low EX Adjustment field to enter a new EX value between 34 and 39.</li> </ul>			



### 8.5 NUISANCE ACTIVATION – RAIL PHASE CHECK

In situations where EZ shifting between 5 to 20 points concurrently with EX is shifting from 2 to 5 points, checking the rail to ground voltage is required. From within the enclosure, measure the AC voltage from RCV1 to ground, and then measure the AC voltage from RCV2 to ground. The ideal measurement is identical. If  $V_{RCV1}$  differs from  $V_{RCV2}$  by approximately 0.75V or higher, nuisance activations may occur. Typically, the cause of this problem is a failing insulating joint or arrestor in the signal block.



### WARNING

DO NOT USE A NARROW BAND SHUNT TO REPLACE A DEFECTIVE COUPLER.



### **CAUTION**

FOLLOWING INSTALLATION OF COUPLERS AROUND INSULATED JOINTS, VERIFY PROPER OPERATION OF THE TRACK CIRCUIT PRIOR TO PLACING IT INTO OPERATION.

# 8.6 UPGRADING SOFTWARE VIA WEBUI (CPU III)

When the software updates icon is selected, the WebUI will display all the software update screens available on the left side of the screen as illustrated in Figure 8-3.



Figure 8-3: WebUI: Software Updates

Using the WebUI, the user can upload the vital and non-vital MEF, the MCF, and enter the MCFCRC. The **Software Updates** menu also allows the user to clear the ECD, CRC, and reset the VLP Module.

#### 8.6.1 Local User Presence

Since the WebUI may be used to connect to the SGCP 4000/MS 4000 remotely, it is necessary to confirm that someone is present at the location before certain operations such as changing SGCP 4000/MS 4000 programming or re-calibration can be performed.

To enable the SGCP 4000/MS 4000 programming or calibration, first unlock the screen from the WebUI by pressing the **Unlock** button.




Figure 8-4: WebUI: Unlock

The WebUI will show the message below on the left, asking for confirmation to continue. Select **OK** and the WebUI will show the message below on the right.




Figure 8-5: WebUI: Confirm Local User Presence

At this point, the onsite personnel will need to press the SEL button to acknowledge the request and allow removal of access. If NAV is pressed, it will deny access and report "User Presence is failed" as shown below in Figure 8-6.

If the local user denies access to the remote user, the WebUI will show the Failed message shown in the figure below. If there is no confirmation by the local user, the WebUI will show the timeout message in the figure below on the right.



Figure 8-6: WebUI Local User Presence Error Messages

If the unlock parameters action is successful, the WebUI will display the message shown in Figure 8-7.



Figure 8-7: WebUI Local UselSuccessfuly Authenticated

# 8.6.2 CP MEF Software Update Process

Using the **Software Updates** menu, access the CP MEF screen. First unlock the screen using the procedure outlined in section 3.3.1, then select the **Browse** button. This will open a file explorer window from which the user can navigate to the desired CP MEF file.




Figure 8-8: Select CP MEF

Select the desired file and then click **Open**. The file will then be displayed in the **Select CP MEF** field as shown below in Figure 8-9. To begin the software update process, select the **Update** button.



Figure 8-9: CP MEF File Selected

The software will then begin uploading to the CPU, and the WebUI will display an upload status bar, as shown below in Figure 8-10.



Figure 8-10: Upload Status

Once the software has uploaded to 90% it will prompt the user to confirm they are okay with a system reboot. The user must select **OK** to continue.




Figure 8-11: Reboot Required

Once the user has confirmed permission to reboot, the software upload will complete and the WebUI will display the confirmation message shown in Figure 8-12. The user should then expect to lose connection to the equipment as it goes through the reboot process. Once the system reboot is complete, the WebUI can be used to log back into the system.




Figure 8-12: Upload Successful

INC

NOTE

The same steps for loading the CP MEF apply when updating the VLP MEF and MCF, the MCF will just also require the MCFCRC to be entered.

### 8.6.3 Vital CPU Software

The Vital CPU menu (VLP) enables the user to load the MEF, MCF, and enter the MCFCRC. Follow the software loading steps described in section 8.6.2 to update the VLP MEF using the screen shown below in Figure 8-13.



Figure 8-13: Vital CPU Menu

# 8.6.4 Upload Module MCF / MCFCRC

To update the MCF, select the **Browse** button and navigate to the desired MCF file. Select **Open**.




Figure 8-14: Select MCF File

Once the desired MCF file is selected, the MCFCRC for that file must be entered in the field below. This can be obtained from the release notes for that version of software.




Figure 8-15: Update MCF

After MCFCRC is entered, select **Update** to complete the installation.

### 8.6.5 Reset VLP Module

This menu is used to reset the VLP module. This may be necessary if an attempt has been made to load a new configuration as described in section 4.5 and the process cancelled before complete. Unlock the screen as described in section 3.3.1, then press the **Reset VLP** button and the WebUI will ask for confirmation first.



Figure 8-16: WebUI: Reset VLP

### 8.6.6 Vital IO Module

To update the software on the Track module, select the Vital IO Module option. Unlock the screen as per section 3.3.1 then use the **Install Software** button as shown below in Figure 8-17.



### **NOTE**

In order to load new software into a track module (A80418) from the CPU III, a serial cable with null modem needs to be connected between the serial port on the front of the CPU III and the DIAG port on the module whose software is to be updated.




Figure 8-17: Vital IO Module Menu

Once the **Install Software** button is selected, the WebUI will prompt the user to confirm that the serial cable has been installed between the CPU III and the module requiring a software update.




Figure 8-18: Check Serial Port Connection

After this has been confirmed the user can proceed with installing the software.

# Appendix A. INTERFERENCE

### A.1 CHARACTERISTICS

In general terms there are two basic types of interference, which are characterized by voltage amplitude. The first and usually the most common is 'Low Voltage' amplitude and the second is 'High Voltage' amplitude.

Symptoms for the first case include a moving EZ and EX. Typically this is only a few points at a time (less than 10). This movement can happen in either jumps (step changes) or a slow drift over time (30 secs to several minutes). In many situations the changes in EZ and EX can result in occasional false activations or nuisance operations.

The High Voltage symptoms include both EZ and EX changing great amounts over time. This change may include frequent errors such as Hi EZ, Frequency, and Self Check.

Many times, the system will not operate normally for any extended time; having almost constant false activations.

### A.2 MEASUREMENTS AND IDENTIFICATION

In order to address the interference issue, the actual problem needs to be identified. Use of a Spectrum Analyzer (Velleman or Equivalent) can often be an extremely valuable tool in this effort of identifying interfering fundamental and harmonic frequencies.

### A.2.1 Measure the Track Voltage

This is a rail-to-rail measurement for AC voltage with the SGCP 4000/MS 4000 and island turned off. If the problem is present and the AC value is 2.5 VRMS or smaller, the interference falls into the low voltage category. If the value is greater than 5VRMS with the problem present, it falls into the High Voltage category.

If the spectrum analyzer is available, take a sample of frequencies within 100 HZ of the SGCP 4000/MS 4000 frequency being analyzed. If any frequencies are found to be within 1 channel of the SGCP 4000/MS 4000 in question or within 20 dBm, they could be a potential concern.

### NOTE



In High Voltage situations frequencies may be much higher in value than the frequency set by the SGCP 4000/MS 4000.

When looking for low voltage problems check other AC track circuits. Especially look for other SGCP 4000/MS 4000's of the same frequency. Overlay Track circuits can also be a source.

The investigation should also include adjacent tracks, particularly when switches are in the area. When conducting these checks think in terms of Signal Blocks not just Approaches. Sources are often found outside of the in-question approach limits.

The power company can also be a source. Check the area for load balancing capacitors mounted on poles.

Other problems can result from improper or failed equipment, such as Isolation/filter units, Surge protection, battery chokes, or other track appliances.

High Voltage problems are typically somewhat easier to identify since any mitigation results in large observable changes. Sources typically include cab signal/ AC track circuits and power company related sources.

### WARNING



BE VERY CAREFUL WHEN INVESTIGATING POWER COMPANY ISSUES. IN SOME AREAS VOLTAGES CAN BE OVER 50VRMS WITH SIGNIFICANT CURRENT. THIS CAN BE A HAZARD TO BOTH PERSONNEL AND EQUIPMENT.

The power company issues usually will involve transmission line situations. Typically, a power line or large industry is in or near the crossing. There may also be substations and/or power plants as well. The history of the location can be important. The local personnel probably know an area which has always had a power related issue.

Another major cause can be related to bad insulated joints. A shorted joint can cause a major electrical imbalance which can result in conduction of power company signals and their harmonics on to the track.

As stated above, other items can come into play, such as Isolation/filter units, Surge protection, battery chokes, or other track appliances. In this situation be especially watchful for damage due to surge protection issues.

# A.3 MITIGATION

Generally, two basic approaches are followed to mitigate interference problems. One is to minimize the interference effects by changing the SGCP 4000/MS 4000 frequency. The other, which is typically more difficult, is to identify the source of the interference and reduce or eliminate it.

The simple approach is most often used in 'Low voltage' situations. Looking at the simple approach, a rule of thumb applies find a frequency for the SGCP 4000/MS 4000 that is 15% or more from that of the interference. The Spectrum Analyzer is a real aide in identifying the new frequency. Conversely, one could change the frequency of the interfering unit.

### NOTE



If two SGCP 4000/MS 4000 systems are operating at the same frequency and a slow drift of EZ is observed, a shift of one of the two SGCP 4000/MS 4000 frequencies (using a SGCP 4000/MS 4000 offset frequency) could be accomplished rather than changing to a new frequency

For 'High Voltage' situations where elimination or reduction of the voltage is attempted try the following. Repair or replace insulated joints, surge protection as necessary. Look for bad grounds and also note the phasing of local power lines.

If these initial steps do not reduce the interference to workable levels (less than 5 volts RMS), then working on identifying and minimizing the voltage must be attempted. There are two categories- Cab Signal Environment and Power related environment.

### A.3.1 Cab Signal Environment

In the Cab Signal Environment of course there is little flexibility to reduce amplitudes. One needs to consider the following options:

- A. Change the SGCP 4000/MS 4000 Frequency.
- B. For Frequencies 211 Hz and lower use 62770 Shunts with Max SGCP 4000/MS 4000 transmit current.
- C. For Frequencies above 211Hz use 62780 Shunts.
- D. Ensure that the appropriate cab signal filters are being used (if required) in the cab signal feeds to the track.

#### A.3.2 Power Related Environment

In the power related environment:

- When the option exists to reduce amplitudes of 60 and 180 Hz harmonics typically a shunt is used. In addition to reducing amplitude this often balances the track circuit which can also improve conditions.
- Use a 62780-60 or 62780-180 Hz shunts for filtering of lower track current interference situations.
- For those where more than 2 amps are suspected use a 62765 for 60 or 180 Hz.
- For severe situations use a 62760 for 60 hertz applications.

Start with using these shunts rail to rail within the approach of interest as close to the crossing as possible. If this does not help, check rail to rail at the next set of joints. At times two or more of these shunts may be required. Some situations may require these shunts to be applied across the joints. There is no magic combination here- use whatever combination works out best for your situation.

After determining the amplitude remaining after using one of the above shunts and the problem still persists, options A through C from above will still need to be accomplished. Again, the spectrum analyzer can be a good tool to use.

It may take a combination of actions to arrive at a solution. Due to the variability of these issues, solutions for one location may not work at a different location.

Table A-1 Devices Specially Designed for Interference Mitigation

Part Number	Rating	Application
62780	Low Current	60 Hz and 180 Hz Shunt
62770	Medium and High Currents	86Hz – 211Hz Termination shunts

62765	Medium and Higher Currents- 3 amps	60Hz and 180 Hz Shunts
62760	High Currents- 10 amps	60 Hz Shunt
8A470-100	High Cab 100 Hz filter	100 Hz Cab Signal
8A466-3	Low Cab 60 Hz filter	60 Hz cab signal

SIG-00-11-02 Version No.: A.8

## Appendix B. - GLOSSARY

AF Audio Frequency

AFO Audio Frequency Overlay

AREMA American Railway Engineering and Maintenance-of-way Association

ATCS: Advanced Train Control System – An industry standard used in the SGCP

4000/MS 4000 for communications.

CCN: Configuration Check Number – The 32 bit CRC of the configuration data.

CHK: CHECK receiver on a track module connected to transmit wires that perform

track wire integrity checks.

CHK EZ: Check EZ is a signal value compared to main receiver EZ that is useful in

troubleshooting.

CIC: Chassis Identification Chip – A non-volatile memory chip that is installed

adjacent to the ECD on the SGCP 4000/MS 4000 backplane. Stores site

specific information for both Main and Standby operations.

Computed Approach

Distance:

The track approach length calculated by the MS. The calculated distance

between the wire connections on the rail and the termination shunt

connections.

CP: Communications Processor – One of two microprocessors on the CPUII+

module, processes external communications for the SGCP 4000/MS 4000.

CRC: Cyclical Redundancy Check - Used to determine that data has not been

corrupted.

DAX: Acronym for Downstream Adjacent Crossing (Xing). DAX outputs are used to

send prediction information from an upstream SGCP 4000/MS 4000 to a downstream SGCP 4000/MS 4000 when insulated joints are in the approach

circuit.

dB Decibels
DIAG: Diagnostic

Directionally Wired Setting used to enable a bidirectional SGCP 4000/MS 4000 to determine train

direction.

DOT Number: Department Of Transportation crossing inventory number assigned to every

highway-railroad crossing that consists of six numbers with an alpha suffix.

DT: Diagnostic Terminal – The Diagnostic Terminal (DT) is an Siemens developed

Windows® based software that can run on the Display Module or on a PC,

which allows the user to perform programming, calibration, and

troubleshooting.

DTMF: Dual—Tone Multi-Frequency - The tones on a telephone or radio keypad.

ECD: External Configuration Device – The non-volatile memory device on the

SGCP 4000/MS 4000 backplane used for storing the module

configuration file.

Echelon: A Local Area Network, LAN, used by the SGCP 4000/MS 4000.

Enhanced Detection: User selectable process that detects nonlinear fluctuations in track signal due

to poor shunting and temporarily switches the track module from predictor to

motion sensor.

EX: The EX value is a numerical indication of track ballast conditions relative to the

leakage resistance between the rails. A value of 100 represents very good

ballast. A value of 39 represents very poor ballast.

EZ: The track signal value that varies with approach track impedance that indicates

the relative train position within an approach. 100 represents nominal value with no train in the approach, 0 represents nominal value for a train occupying

the island.

Field Password The password set that allows field maintenance personnel access to field

editable parameters.

Flash Memory A type of non-volatile memory that can be reprogrammed in-circuit via

software.

GCP: Grade Crossing Predictor – A train detection device used as part of a highway-

railroad grade crossing warning system to provide a relatively uniform warning

time.

GCP APP SGCP 4000/MS 4000 Approach length calibration into a hardwire shunt

located at the termination shunt.

GCP CAL SGCP 4000/MS 4000 Calibration into a termination shunt.

GCP LIN Approach Linearization Calibration into a hardwire shunt located at the 50%

point on the approach.

Healthy: The SGCP 4000/MS 4000 system, modules and track circuit are operating as

intended. Health is generally indicated by a yellow LED flashing at 1 Hz (approximately the same flash rate as the FLASH SYNC on a controller or a flashing light signal). Unhealthy conditions are indicated by faster flash rates (2)

Hz and 4 Hz) or a dark Health LED.

Hz: Hertz – Common reference for cycles per second or flashes per second.

IO or I/O: Input/Output

ISL: Island

ISL CAL: Island calibration

kHz: Kilohertz – 1000 Hz or 1000 cycles per second.

LAN: Local Area Network – A limited network where the data transfer medium is

generally wires or cable.

Linearization: The linearization procedure compensates for lumped loads in the SGCP

4000/MS 4000 approach that affects the linearity (slope) of EZ over the length

of the approach.

Linearization Steps: A calibration value that allows the SGCP 4000/MS 4000 to compensate for

non-linear EZ values within the approach circuit.

LOS: Loss of Shunt – Commonly due to rust and / or rail contamination. LOS timers

provide a pick up delay function.

Lumped Load: A section of track that has a lower ballast resistance than the rest of the

approach because of switches, crossings, contamination, etc.

MAIN: The primary SGCP 4000/MS 4000 Modules (CPU, Track, and RIO Modules)

that are in a dual SGCP 4000/MS 4000 chassis.

B-2

MCF: Module Configuration File – The SGCP 4000/MS 4000 application logic file.

MEF: Module Executable File – The SGCP 4000/MS 4000 executive software

program.

Module Physical package including PCBs and input/output terminals for connecting to

external devices and equipment.

MS: Motion Sensor – A train detection device used as part of a highway-railroad

grade crossing warning system to provide a detection of a train approach.

OCCN: Office Configuration Check Number – The 32 bit CRC of the configuration

data, excluding items that are protected by the Field Password.

OCE: Office Configuration Editor – The PC version of the DT that can be used to

create configuration package files (Pac files) for the SGCP 4000/MS 4000

system.

Out Of Service: The process for taking one or more SGCP 4000/MS 4000 approach circuits

and / or approach and island circuits out of service.

Pac File: A SGCP 4000/MS 4000 configuration Package File that can either be created

in the office using the OCE, or downloaded from a SGCP 4000/MS 4000

system via the CP.

PCB Printed Circuit Board

Pick Up Delay: An internal delay time between when an input receives the signal to pick up

and when it actually responds.

Positive Start: Activate crossing devices when EZ level is less than a programmed value.

PRIME: PRIME may be de-energized by a Track's prime predictor, UAX, advance

preempt, and/or island, if zero offset is selected.

RIO: Relay Input Output Module

RS232: Industry standard serial port.

RX: Receive

SIN: Site (Subnode) Identification Number - A twelve-digit ATCS address

representing the module as a subnode on the network.

Standby: The SGCP 4000/MS 4000 Backup Modules (e.g., CPU, Track, and RIO

modules) that are in a dual SGCP 4000/MS 4000 chassis.

Supervisor Password The password set that allows application design personnel access to office

editable parameters.

TCN Track Check Number (TCN) is used to track changes due to re-calibration and

adjustments made to key Track Modules specific setup variables.

True RMS AC+DC: A scale on a multimeter that measures the effective combined AC and DC

portions of the total voltage. Measured as VRMS.

TX: Transmit

UAX: Acronym for Upstream Adjacent Crossing (Xing). UAX inputs are used to

receive prediction information from an upstream SGCP 4000/MS 4000 as inputs to a downstream SGCP 4000/MS 4000 when insulated joints are in the

approach circuit.

USB Port: Universal Serial Bus Port

USB Drive: Types of memory devices that plug into a USB port. These devices are

commonly called flash drives or memory sticks.

VHF Communicator: Communications device used for remote operations and calibration as well as

data communications.

VLP: Vital Logic Processor – One of two microprocessors on the CPUII+ module,

processes SGCP 4000/MS 4000 vital system logic.

VRMS Volt Root Mean Square – See True RMS AC + DC above.

Z Level: An Island calibration value. A calibrated island will have a nominal Z Level of

approximately 250. The Z Level approaches 0 when shunted.

**REVISED MARCH 2022** 

# Appendix C. - REMOTE CALIBRATION

### C.1 CHARACTERISTICS

Optional remote MS/GCP calibration may be used as needed. The remote calibration is the same as the other procedures, except that the person doing the adjustment or calibration communicates directly with the MS/GCP via VHF radio and a Display Terminal (either a A80500 DiagView unit or a laptop-based DT) or WebUI (if using CPU III) is required to generate a password. The MS/GCP sends voice options and the person performing the operation replies via a DTMF keypad on a VHF radio.




Figure C-1: Connecting the VHF Communicator, A80276

C-1

To perform remote calibration and/or lamp adjustment the following are required:

- 1. Siemens VHF Communicator (A80276) programmed and connected to the MS/GCP Echelon LAN.
- VHF Communicator is a VHF Radio interface to the MS/GCP that sends setup and calibration options to remote radio.
- VHF Communicator set to a railroad VHF frequency.
- Hand-held VHF radio with DTMF keypad.
- Person doing remote calibration responds to options and sends commands to MS/GCP.
- Set to same frequency as VHF communicator.
- Hardwire test shunt for calibration and appropriate voltmeter for lamp adjustments.
- Obtain a one-time password from the MS/GCP for remote operation.
- Password expires in 60 minutes unless another setting is selected by user.

Previously during the programming stage, the DOT Crossing Number must be entered in the Location Information on the SITE INFO screen. During remote calibration, the DOT number is used to identify that the proper location is being calibrated.

This section includes flow charts for the commands and choices used in setup and calibration:

- Remote calibration setup
- Remote MS/GCP calibration
- Remote approach calibration (Not Applicable in Motion Sensor application)
- Remote linearization calibration (Not Applicable in Motion Sensor application)
- Remote crossing lamp voltage adjustment (Not Applicable to MS4000/SGCP)
- Remote calibration termination



### NOTE

The MS/GCP sends and receives commands via the VHF Communicator which includes a half-duplex radio. The radio cannot receive a reply until it is finished transmitting. DO NOT send back responses until the message is completed.

After using the **Unlock** button, the WebUI can be used to obtain a remote password by using the **Get** button.




Figure C-2: WebUI Remote Setup Window

**Table C-1 Remote Calibration Setup** 

Step 1	Select the <b>Setup</b> button from the DT Buttons at the top of the status Screen.
Step 2	From the menu that appears, select <b>REMOTE SETUP</b> . The <b>Remote Setup</b> dialog box displays.
Step 3	Select the <b>GET PASS</b> button.  A <b>Push button</b> message appears in the message box at the bottom of the window.
Step 4	Press the SEL pushbutton on the front panel of the CPU module:  The Remote Setup dialog box changes.  A four-digit password appears in the Remote Password value field (see Figure C-2).  Check boxes for each used track module and the SSCC appear below the Remote Password value field.
Step 5	Record the four-digit password.
Step 6	If the default 60-minute timeout is not long enough, select the <b>EDIT TIMER</b> button. The Set Timer dialog box displays.
Step 7	Using the keypad numbers, enter the required Setup Timeout value (range 1 – 120 minutes) into the <b>New Value</b> field.
Step 8	Select the <b>Update</b> button. The dialog box closes and the <b>Remote Setup</b> dialog box appears. The new Remote Setup Timeout value displays.
Step 9	Individually select each field of the Track to be calibrated.  A check appears in the check box of each selected field.
<u>Step 10</u>	Select the <b>CLOSE</b> button. The Status Screen displays.
<u>Step 11</u>	To perform an Island Calibration, go to the Island Calibration screen and record the shunt placement distance for shunting sensitivity.

### WARNING



AFTER PERFORMING REMOTE MS/GCP CALIBRATION USING THE VHF COMMUNICATOR, RETURN TO THE SGCP 4000/MS 4000 AND VERIFY THAT EACH CALIBRATION IS PROPERLY IMPLEMENTED. REVIEW THE MAINTENANCE LOG OR THE CPU STATUS LOG AS PART OF THE VERIFICATION PROCESS.

Table C-2: Island Shunt Distance in Feet/Meters

Island Frequency	0.12 ohm Sensitivity	0.3 ohm Sensitivity	0.4 ohm Sensitivity	0.5 ohm Sensitivity
2.14	20/6.10	50/15.24	67/20.42	84/25.60
2.63	17/5.18	43/13.11	58/17.68	72/21.95
3.24	13/3.96	33/10.06	44/13.41	55/16.76
4.0	10.5/3.20	27/8.23	36/10.97	45/13.72
4.9	9.0/2.74	23/7.01	31/9.45	39/11.89
5.9	7.5/2.29	19/5.79	26/7.92	32/9.75
7.1	6.5/1.98	17/5.18	23/7.01	29/8.84
8.3	6.0/1.82	15/4.57	20/6.10	25/7.62
10.0	5.0/1.50	13/3.96	18/5.49	22/6.71
11.5	4.5/1.37	12/3.66	16/4.88	20/6.10
13.2	4.0/1.22	10/3.20	14/4.27	17/5.18
15.2	3.5/1.07	9/2.74	12/3.66	15/4.57
17.5	3.0/0.91	8/2.44	11/3.35	14/4.27
20.2	3.0/0.91	8/2.44	11/3.35	14/4.27

**Table C-3 Remote Calibration** 

Step 1	Press and Hold the Transmit button of the hand-held VHF radio.		
Step 2	Enter *# followed by the password recorded in step 5 of Table C-1.		
Step 3	Release the Transmit button of the hand-held VHF radio: An assigned Department Of Transportation (DOT) number (XXX) is verbally announced.  The Root menu options are announced:  "For location press 1"  "For MS/GCP press 2"  "For SSCC press 3"  "For Help press 4"		
Step 4	Press and Hold the Transmit button then Press 2. MS/GCP is selected.		
Step 5	Release the Transmit button. An "Enter track number" message is announced		
Step 6	Press and Hold the Transmit button. Enter the number 1 (one) to calibrate the motion sensor track.		
Step 7	Release the Transmit button. The Track Menu options are announced:  • "For MS/GCP calibration press 1"  • "For island calibration press 4"  • "To monitor EZ EX press 5"  • "To monitor island press 6"		

**Table C-4 Remote Approach Calibration** 

Step 1	<ul> <li>To perform the MS/GCP Calibration:</li> <li>Press and Hold the Transmit button then press 3.</li> <li>MS/GCP calibration is selected.</li> </ul>		
Step 2	Release the Transmit button. The Calibration Menu options are announced:  • "To start track N MS/GCP calibration press 1"  • "To monitor EZ EX press 2"		
Step 3	Press and Hold the Transmit button then Press 1.		
Step 4	Release the Transmit button. "Enter password for DOT XXX" is announced.		
Step 5	Press and Hold the Transmit button then enter the password recorded in step 5 Table C-1.		
Step 6	Release the Transmit button. The following information messages are sequentially announced:  • "Initiating track N MS/GCP calibration"  • "Track N MS/GCP calibration in progress"  If MS/GCP calibration passes the information messages are concluded with:  • "Track N MS/GCP calibration passed"  • "EZ is"  • "EX is"  If MS/GCP calibration fails:  • The information messages conclude with:  • "Track N MS/GCP calibration failed"  • The calibration menu of step 2 is repeated.  • Refer to Section 8 for troubleshooting procedures.  When the cause of the failure is corrected, repeat this procedure starting at step 3.  If the Remote Setup Timeout selected in 5 Table C-1. step 6 expires, start again from Step 1 of Table C-1.		

### **Table C-5 Remote Island Calibration**

Stop 1	Temporarily install a hardwire shunt beyond the island receiver rail connections.			
Step 1	Place the shunt at the distance recorded in Table C-2, step 11.			
Cton 0	Press and Hold the Transmit button then press 6.			
Step 2	Island calibration is selected.			
Step 3	Release the Transmit button. The Calibration Menu options are announced:  • "To start track N island calibration press 1"			
Step 3	"To monitor island signal level press 2"			
Step 4	Press and Hold the Transmit button then press 1.			
Chair F	Release the Transmit button.			
Step 5	An "Enter password for DOT" message is announced			
Step 6	Press and Hold the Transmit button and enter the password recorded in step 5 of 5 Table C-1.			
Step 7	Release the Transmit button. The following information messages are sequentially announced:  • "Initiating track N island calibration" • "Track N island calibration in progress"  If island calibration passes: • The information messages conclude with: • "Track N island calibration passed" • "Island signal level n" (where n is around 100).  If island calibration fails: • The information messages conclude with: • "Track N island calibration failed" • Release the Transmit button. • The calibration menu from step 3 is repeated.  Refer to the Maintenance and Troubleshooting section for troubleshooting procedures.  When the failure is corrected, repeat the procedure starting at step 2.			
Step 8	Remove the hardwire shunt.			
C top 0	. toe. to the arm o offerin			

### **Table C-6 Completing Remote Calibration**

Step 1	Repeat all remote procedures for each track module selected in the Remote Calibration steps.
Step 2	To terminate the remote session, press and hold the Transmit button then press *##.
Step 3	Release the Transmit button. The remote setup is finished
Step 4	Return to the bungalow and check the Status log to ensure that the tracks were correctly calibrated. To access the Status Log, press the History Button on the display, then select Status Log.

# Appendix D. SGCP 4000/MS 4000 SYSTEM CUTOVER TEST FORM

Case Serial Number: Track Module Serial Number: Crossing Name: DOT Number: ATCS Number:Sign  Use the SGCP 4000/MS 4000 Instruction and In Cutover Test.	CPU Card Serial Number:  External SEAR Serial Number:  Date:  Milepost:  med:  Installation Manual (SIG-00-11-02) to perform the
Place a check in the appropriate space when the proce n/a if procedure is not applicable. Verify wiring and prog diagram. Verify polarity and voltage with a meter. If as-l plans, explain in remarks area.	ramming in accordance with the approved installation
	0 or chassis outputs to warning devices until
Test Procedure 10.1.2 Preliminary SGCP4000/MS4000 modules in correct slots and inserted properlyCPU battery voltage and polaritySGCP 4000/MS 4000 programmingATCS SINWiring to SGCP 4000/MS 4000 & Surge equipmentWiring to TrackWiring to Warning DevicesWiring to other cablesConnect remainder of connections on SGCP 4000/MS 4000 system	10.4 Procedure 10-3 GCP Operational Tests  Open Transmit. wire Open Receive wire Open UAX circuits UAX pickup time Open External Island Input 10.4 GCP Train Detection
Connect other equipment to battery buss  10.2 Procedure 10-1 Approach Calibration  Approach Calibration  10.3 Procedure 10-2 Island Calibration  Island Cal.  Shunt Island	Crossing Recovery Out of Service  10.5 Maintenance Call (MC) Light Maint. Call light output on Maint Call light output turns off Remarks:

APPENDIX D - SGCP4000 / MS4000 SYSTEM CUTOVER TEST FORM

This Page Intentionally Left Blank

D-2

# Appendix E. SGCP 4000/MS 4000 APPLICATION HISTORY CARD

Case Serial Number: Track Module Serial Numb Crossing Name: DOT Number: ATCS Number:		Date:		
		tion Diagram to program		
Parameter	Value Initial Setup	Value reprogram 1 Date:	Value reprogram 2 Date:	
AFRQ				
DIRN				
TLVL				
APKU				
UAX				
ISL				
IPKU				
	Advanced	(ADVD) Menu		
PSTR				
PTIM				
SHNT				
LWEZ				
LTIM				
LWEX				
COMP				
PRED				
WTIM				
software data	SOFTWARE VERSION Initial Setup	SOFTWARE VERSION reprogram 1	SOFTWARE VERSION reprogram 2	
MOTION SENSOR MCF				
CPU MEF				
VLP MEF				

TRACK MODULE MEF

APPENDIX E - SGCP4000 / MS4000 APPLICATION HISTORY CARD

This Page Intentionally Left Blank

E-2

### Appendix F. Installation of Ferrite Beads

## **A** WARNING

### WARNING

IF THE MS4000/SGCP TRACK CIRCUIT HAS AN ACTIVE INTERNAL ISLAND, THE MS4000/SGCP CHASSIS MUST HAVE FERRITE BEADS INSTALLED ON THE TRACK XMT AND RCV WIRES AS DESCRIBED IN BELOW IN ORDER TO AVOID POSSIBLE SHUNTING ISSUES IF A REV D OR EARLIER A80418 TRACK MODULE IS INSTALLED IN CHASSIS.

### **CAUTION**



PRIOR TO INSTALLATION OF THE FERRITE BEADS, RECORD EZ/EX AND ISLAND Z VALUES FOR THE ACTIVE TRACK MODULES WHERE FERRITE BEADS ARE TO BE INSTALLED; THESE VALUES SHOULD BE RECORDED WITH THE GCP APPROACH CLEAR.

The following guidelines are for the application of Ferrite Beads to the transmitter (XMT1/XMT2) and receiver (RCV1/RCV2) wires [not the check wires] of an affected GCP that incorporates an internal island circuit. The ferrite beads shall be installed on all track slots at the termination point of the XMT1/XMT2 and RCV1/RCV2 wires on the GCP chassis as shown in Figure F-1. There are two different sizes of ferrite beads. The smaller of the two is to be installed on the transmitter [XMT1/XMT2] wires. The larger of the two is to be installed on the receiver [RCV1/RCV2] wires.




Figure F-1: Ferrite Bead Sizes

The ferrite beads require a single wrap of the wires **[XMT1/XMT2] [RCV1/RCV2]** around the ferrite bead before securing the transmitter or receiver wires to the Wago connector as shown in Figure F-2. The ferrite beads should be installed within two to three inches of the Wago connector. The sleeve tag can be used as a reference to determine this distance as shown in Figure F-2. Close the ferrite bead, ensuring the securing tabs have properly seated and have snapped into the locked position. Once ferrite bead is installed, a zip tie can be used to secure the ferrite bead and wires in place, preventing movement and the unintentional opening of the ferrite bead.




Figure F-2: Ferrite Bead Installation Guide

# **A** CAUTION

### **CAUTION**

WITH FERRITE BEADS INSTALLED, AGAIN RECORD EZ/EX AND ISLAND Z VALUES OF ACTIVE TRACK MODULES [WITH APPROACH CLEAR] AND COMPARE TO READINGS RECORDED PREVIOUSLY. VALUES SHOULD DIFFER NO GREATER THAN 3 POINTS BETWEEN THE TWO RECORDED VALUES.

The installation of ferrite beads on the GCP does not require any re-calibration of the track circuits and has no effect in the GCP's ability to detect trains.

The installation of ferrite beads is compatible with all hardware revisions of the 80418 Track Module.

## **Ferrite Bead Kit Ordering Information**

A Ferrite Bead Kit for the 80418 Track Card will be provided by Siemens.

Table 8-9 Ferrite Bead Ordering Information

Part Number	Revision	Description
K80418-1	А	Kit, CSB 3-15E, 80418 Track Card

For additional kits contact Siemens Customer Service at (800) 626-2710.