

Installation, Maintenance & Troubleshooting Guide For RAJA⁺ Agriculture Starters & Controllers



SIEMENS



Contents:

1. Automatic Direct ON Line Starter:

- 1.1 Product description
- 1.2 Wiring diagram
- 1.3 Technical Details
- 1.4 Installation
- 1.5 Operating procedure in normal condition
- 1.6 Troubleshooting guidelines in case any incoming fault is present before switching ON the motor
- 1.7 Troubleshooting guidelines in fault condition when motor stops while it is in running condition
- 1.8 Troubleshooting guidelines in case any fault is at the load side

Product: Automatic Direct ON Line Starter

1.1: Product Description



- 1: Door Knob
- 2: Amber LED
- 3: Metal enclosure
- 4: ON Push button (Green)
- 5: OFF/RESET push button (Red)
- 6: Mechanical Latch (OFF push button)
- 7: Door
- 8: Earthing screw
- 9: Name Plate

- For screwing & unscrewing the door
- For indicating the incoming power supply availability & healthiness.
- Metallic enclosure of ADOL starter
- For switching ON the motor
- For switching OFF the motor / Reset the overload relay
- For preventing undesired ON operation of motor
- Door of ADOL starter
- Earthing screw of ADOL starter for Customer
- Name plate with technical details of ADOL



- 1: Amber LED
- 2: Starter Mode selecting switch
- 3: LMRA
- 4: LMRA On delay dial
- 5: Contactor
- 6: Thermal overload relay
- 7: Relay setting dial
- 8: Green NO Aux.contact
- 9: Red NC Aux.contact
- 10: Relay Red test button
- 11: Relay reset button
- 12: Incoming terminal block (TB1)
- 13: Outgoing terminal block (TB2)
- 14: Earthing screw
- 15: Mounting hole
- 16: Links
- 17: Gasket
- 18: Grommet
- 19: Wiring diagram label

- For indicating the healthiness of incoming power supply
- For the selection of starter operating mode (Auto, Manual, Bypass)
- For checking the healthiness of incoming power supply
- On delay setting dial (0.5-5min)
- Dial which can be set according to the motor current
- For switching ON the motor if starter enclosure is open
- For switching OFF the motor if starter enclosure is open
- For checking the relay trip circuit
- For resetting the relay
- For connecting the incoming supply cables
- For connecting the outgoing supply cables to motor
- Starter earthing provision
- 4x holes for mounting the starter
- Links of ON & OFF push buttons

- For the incoming & outgoing cable passage

1.2: Wiring Diagram



Control logic diagram



Power circuit diagram



1.3: Technical details

Table: 1 Technical details of ADOL Starter

Туре	(HP / kW)	le (A)	Contactor	Relay	Range (A)	Line Monitoring Relay	Recomm- ended Max. Back-up HRC Fuse rating, SIEMENS Make type 3NA7 – 500V*	Max. Recomm ended Cu cable size (sq:mm)
3TE7111-25C18-14vv	7.5/5.5	11.4	3TS3210-0Ax x-08K	3UW5102-2A	10-16	7UG0613-0yy20	32A	2.5
512/111-23C10-1AXX	7.5/5.5	14.5	3TS3210-0Axx-08K	3UW5102-2A	10-16	7UG0613-0yy20	32A	2.5
3TE7111-2BC21-1Axx	10/7.5	15.4	3TS3311-0Axx-08K	3UW5102-2B	10-16	7UG0613-0yy20	32A	2.5
3TE7111-20021-14vv	10/7.5	19.5	3TS3311-0Axx-08K	3UW5202-2C	12.5-20	7UG0613-0yy20	32A	2.5
512/111-20021-1444	12.5/9.3	19.5	3TS3311-0Axx-08K	3UW5202-2C	16-25	7UG0613-0yy20	32A	4.0
3TE7111-2DC23-1AZ8	12.5/9.3	25	3TS3511-0AZ8-08K	3US5600-2D	20-32	7UG0613-0yy20	63A	4.0
3TE7111-2CC24-1Axx	15/11	23	3TS3411-0Axx-08K	3UW5202-2C	16-25	7UG0613-0yy20	32A	4.0
3TE7111-2QC24-1AZ8	15/11	29	3TS3511-0AZ8-08K	3US5600-2Q	25-36	7UG0613-0yy20	63A	10
3TE7111-2RC25-1AZ8	17.5/13	34	3TS3611-0AZ8-08K	3US5600-2R	32-40	7UG0613-0yy20	80A	10

Note: xx: Coil voltage; Z6:200-400V AC; Z8: 260-460V AC yy: Coil voltage; FE:200-400V AC; FF: 260-460V AC

*Type 1 coordination as per IS/IEC 60947-4-1 Standard.



1.4: Installation

- 1. Open the door by unscrewing the door knob.
- 2. Fix the starter enclosure vertically on a rigid surface free from vibration.
- 3. Remove the rubber grommets for incoming and outgoing cable connections. (Fig: 2)
- 4. Connect incoming and outgoing cables as follows (Fig: 2)
 -Select correct size of cable from Table 1.
 -Remove approx. 10mm of insulation.
 -Pass the cable through proper cable gland to avoid ingress of material.
 -Connect the incoming supply cables to terminal block TB1 and tighten the screws firmly
- (ref.tightening torque from Table 3).
- 5. NOTE: LMRA is set in Manual mode (Factory setting).
- 6. Set the overload relay scale (Fig: 2) using proper screw driver as per the procedure given below.
- 7. Set the overload relay to rated current mentioned on motor name plate.
- 8. Press green button of the Aux.contact block (Fig: 2) to start the motor and wait till it reaches to normal speed.
- 9. Reduce the overload relay settings till it trips.
- 10. Set the overload relay at slightly higher value.
- 11. Allow a reset time approx 4min. and reset the overload relay manually (Fig: 2)
- 12. Restart the motor. If the relay does not trip, consider the overload relay as properly set. If it trips, set it at little higher value and recheck.
- 13. Press the red knob (Fig: 2) on the overload relay to stop the motor
- 14. Fix the door by screwing the knob

Table: 2 Mounting Torque Values

Sr. No	Location	Size	Torque
1	Earthing screw (cover to body)	M5	2.5-3.0Nm
2	Contactor 3TS3036	M4	0.8-1.4Nm
3	LMR-A	M4	0.8-1.4Nm
4	Terminal block 30A	M4	0.8-1.4Nm
5	Terminal block 60A	M4	0.8-1.4Nm
6	ON& OFF /Rest link	ST4.2x9.5	0.8-1.2Nm

Table: 3 Terminal Torque Values

Sr. No	Location	Size	Torque
1	3TS3032	M3.5	0.8-1.4Nm
2	3TS33/34 (Power wiring)	M4	1.0-1.5Nm
3	3TS35/36 (Power wiring)	M5	2.5-3.0Nm
4	Terminal block 30A	M4	0.8-1.4Nm
5	Terminal block 60A	M5	1.5-2.1Nm
6	Contact block 3SB5	M3.5	0.8-1.2Nm
7	Aux terminal (side add on) of 3TS35/36, 3TS33/34	M3.5	0.8-1.4Nm
8	Coil Terminals A1/A2	M3.5	0.8-1.2Nm
9	Aux. terminals of all Relays	M3.5	0.8-1.2Nm
10	3UW51/52	M4	1.0-1.5Nm
11	3US56	M5	2.5-3.0Nm
12	Indicating light - Amber	M3	0.8Nm

1.5: Operating procedure in normal condition

1A	1B	1C	1D	1E	1F	1G	1H	11	1J	1K	1L
LMR-A Mode	Зф main supply	Amber LED indication	On- Delay	Amber LED	'ON' Push button	Starter Operation	'OFF' Push button	Starter Operation	Amber LED	Зф main supply	Amber LED indication
Manual	ON	Blink (On-delay duration)	0.5- 5min	ON	ON	ON	OFF	OFF	ON	OFF	OFF
Auto	ON	Blink (On-delay duration)	0.5- 5min	ON	ON	ON	Lock	OFF	ON	OFF	OFF
Bypass	ON	Blink (On-delay duration)	0.5- 5min	ON	ON	ON	OFF	OFF	ON	OFF	OFF
ON operation								0	FF opera	tion	

Table: 4 ADOL operating sequence in normal condition

Starter operation:

LMR-A: Manual mode

- 1A : Keep the LMR-A in Manual mode.
- 1B : Switch ON 3-Phase incoming main supply.
- 1C : Amber LED will start blinking for a period of min 0.5 min.
- 1D : 0.5 min is the default setting which can vary from min 0.5 min to max.5min.
- 1E : After the ON-delay duration, amber LED will ON continously indicating that the incoming supply is Healthy (Assuming incoming supply is healthy).
- 1F : Press the green push putton for switching ON the starter.
- 1G : Starter gets switched ON.
- 1H : Press the red push button for switching OFF the starter.
- 11 : Starter gets switched OFF.
- 1J : Amber LED indication remains continous ON.
- 1K : Switch OFF the 3-phase incoming main supply.
- 1L : Amber LED indication gets turned OFF indicating that there is no incoming main supply.

LMR-A: Auto mode

- 1A : Keep the LMR-A in Auto mode.
- 1B : Switch ON the 3-Phase incoming main supply.
- 1C : Amber LED will start blinking for a period of min 0.5 min.
- 1D : 0.5 min is the default setting which can vary from min 0.5 min to max.5min.
- 1E : After the ON-delay duration, amber LED will ON continously indicating that the incoming supply is healthy(Assuming incoming supply is healthy).
- 1F : Not applicable (No need to press ON push button)
- 1G : Starter gets switched ON automatically.
- 1H : Press the red push button and lock by mechanical latch for switching OFF the starter.
- 11 : Starter gets switched OFF.
- 1J : Amber LED indication remains continous ON.
- 1K : Switch OFF the 3-phase incoming main supply.
- 1L : Amber LED indication gets turned OFF indicating that there is no incoming main supply.

LMR-A: Bypass mode

- 1A : Keep the LMR-A in Bypass mode.
- 1B : Switch ON the 3-Phase incoming main supply.
 (*Customer may switch ON the starter directly after switching ON the 3 phase incoming supply irresepctive of Blinking status as there is only indication for incoming supply faults and no Protection in Byapass mode.)
- 1C : Amber LED will start blinking for a period of min 0.5 min.
- 1D : 0.5 min is the default setting which can vary from min 0.5 min to max.5min.
- 1E : After the ON-delay duration, amber LED will ON continously indicating that the incoming supply is healthy(Assuming incoming supply is healthy).
- 1F : Press the green push putton for switching ON the starter.
- 1G : Starter gets switched ON.
- 1H : Press the red push button for switching OFF the starter.
- 11 : Starter gets switched OFF.
- 1J : Amber LED indication remains continous ON.
- 1K : Switch OFF the 3-phase incoming main supply.
- 1L : Amber LED indication gets turned OFF indicating that there is no incoming main supply.



1.6: Troubleshooting Guidelines in case any incoming supply fault is present before switching ON the Starter

2A	2B	2C	2D	2E	2F	2G	2H	21	2J
LMR-A Mode	Зф main supply	Amber LED indication	On- Delay	Amber LED indication	Possible causes of fault	Corrective action	Amber LED indication	'ON' Push button	Starter operation
Manual	ON	Blink	0.5- 5min	Blink	#	1)	ON	ON	ON
Auto	ON	Blink	0.5- 5min	Blink	#	2)	ON	NA	ON
Bypass	ON	Blink	0.5- 5min	Blink	NA	NA	ON	ON	ON

Table: 5 ADOL operating sequence in fault condition

#: Phase loss¹, Phase reversal², Under voltage³, Over voltage⁴, Phase unbalance⁵

NA – Starter is unprotected from incoming power supply faults, only protection from load side faults. In this mode, amber LED will continously ON if incoming power supply is healthy and will blink if the incoming power supply is unhealthy–Refer 1.8

Starter Fault conditon:

1) LMR-A: Manual mode

- 2A : Check the mode of LMR-A, if it is manual mode, please follow the below steps.
- 2B : Switch ON the 3-Phase incoming main supply.
- 2C : Amber LED will start blinking
- 2D : Amber LED will blink for a duration of min 30sec.
- 2E : After the On-delay duration, amber LED remains blinking indicating that the incoming supply is unhealthy.
- ¹2F : Check the rated operational voltage of the starter in incoming terminal block (TB1) between L1-L2, L2-L3, L1-L3 with suitable equipment e.g. multimeter.
 - Check for the phase loss in any phase (L1,L2,L3) with suitable equipment e.g. multimeter.
- ¹2G : After resuming incoming main supply to normal condition, repeat the steps from 2A to 2D and then go to step no.2H

If fault still exists, then

- ²2F : Check the phase sequence of all the phases of incoming main supply at terminal block TB1.
 - Identify the wrong sequence of phase connected in any of the incoming terminal.
- ²2G : Connect the phase sequence of all the phases correctly (R phase to L1, Y phase to L2, B phase to L3) to the incoming main supply terminals of Terminal block TB1.
 - Repeat the steps from 2A to 2D and then go to step no.2H

If fault still exists, then

- ³2F : Check the rated operational voltage of the starter in incoming terminal block (TB1) between L1-L2,
 - L2-L3, L1-L3 with suitable equipment e.g. multimeter.
 - Check whether the 3-phase voltage in the incoming terminals of terminal block TB1 is less than minimum required voltage (Refer table no.6).
- ³2G : Starter will be operational only if the 3-phase incoming supply voltage is between min.required voltage & max.voltage allowed (Refer table no.6).
 - Repeat the steps from 2A to 2D and then go to step no.2H

If fault still exists, then

- ⁴2F : Check the rated operational voltage of the starter in incoming terminal block (TB1) between L1-L2, L2-L3, L1-L3.
 - Check whether the 3-phase voltage in the incoming terminals of terminal block TB1 is >Maximum voltage allowed. (Refer table no.6).
- ⁴2G : Starter will be operational only if the incoming supply voltage is between min.required voltage & Max.voltage allowed (Refer table no.6).
 - Repeat the steps from 2A to 2D and then go to step no.2H
- If fault still exists, then
- ⁵2F : Check the rated operational voltage of the starter in incoming terminal block (TB1) between L1-L2, L2-L3, L1-L3.
 Check whether the operational line voltage difference between any 2 phase in the incoming. terminals of terminal block TB1 is >50V.
- ⁵2G : Starter will be operational only if the incoming supply voltage difference between any 2 phase in the incoming terminal block TB1 of the starter is <= 50V.

- Repeat the steps from 2A to 2D and then go to step no.2H

- 2H : Amber LED will remain ON continously indicating that the fault is cleared
- 21 : Press the Green ON push button to switch ON the starter.
- 2J : Starter gets switched ON.

Table: 6 Range of Undervoltage & Over voltage

C to at ou	Undervol	tage fault	Overvoltage fault			
Starter Voltage Range (V)	Trip voltage for undervoltage fault (V)	Trip voltage for undervoltage fault (V)	Trip voltage for Overvoltage fault (V)	Max.voltage allowed (V)		
(Z6) 200-400	≤ 195	205	≥ 400	390		
(Z8) 260-460	≤ 250	260	≥ 455	445		

2) LMR-A: Auto mode

- 2A : Check the mode of LMR-A, if it is Auto mode, please repeat the steps from 2B to 2H.
- 21 : No need to press ON push button.
- 2J : Starter gets switched ON automatically.

* LMR-A: Bypass mode

As in Bypass mode there is no protection from the inconing supply faults, however there may some conditions, example mentioned below where Starter may not ON –

- 1. Phase loss
- 2. Incmoing supply voltage less than the minimum required operational voltage of the Starter.
- 3. Incoming supply voltage is very high etc......

In the above conditions check the Starters as explained in Auto & Manual Mode.

1.7: Troubleshooting Guidelines in fault condition when motor stops while it is in running condition

3A	3B	3C	3D	ЗE	3F	3G	ЗH	31	3J	ЗК	3L
Motor conditon	LMR Mode	Amber LED indication	Possible causes of fault	Corrective action	Зф main supply	Amber LED indication	Waiting duration	Amber LED indication	'ON' Push button	Starter operation	Motor conditon
Not Running	Manual	Blink	#	1)	ON	Blink	0.5-5min	ON	ON	ON	Running
Not Running	Auto	Blink	#	2)	ON	Blink	0.5-5min	ON	NA	ON	Running
Not Running	Bypass	Blink**	NA	NA	ON	Blink	0.5-5min	ON	ON	ON	Running

Table: 7 ADOL operating sequence in fault condition

#: Phase loss¹, Phase reversal², Under voltage³, Over voltage⁴, Phase unbalance⁵

NA – Starter is unprotected from incoming power supply faults, only protection from load side faults. In this mode, amber LED will continously ON if incoming power supply is healthy and will blink if the incoming power supply is unhealthy– Refer 1.8

Starter Fault conditon:

1) LMR-A: Manual mode

- 3A : Motor suddenly stops after running for some time.
- 3B : Check the mode of LMR-A, if it is Manual mode.
- 3C : Amber LED will start blinking 3D,
- 3E : Follow steps from 2F to 2G of manual mode (Refer Table no.5 ; Corrective action 1))
- 3F to 3K : Follow steps from 1B to 1G of manual mode (Refer Table no.4)
- 3L : Motor starts running again.

1) LMR-A: Auto mode

- 3A : Motor suddenly stops after running for some time.
- 3B : Check the mode of LMR-A, if it is Auto mode.
- 3C : Amber LED will start blinking
- 3D ,3E : Follow steps from 2F to 2G of Auto mode (Refer Table no.5; Corrective action 2))
- 3F to 3K : Follow steps from 1B to 1G of Auto mode (Refer Table no.4)
- 3L : Motor starts running again.

**LMR-A: Bypass mode

As in Bypass mode there is no protection from the inconing supply faults, however there may some conditions, example mentioned below where Starter may not ON –

- 1. Phase loss
- 2. Incoming supply voltage less than the minimum required operational voltage of the Starter.
- 3. Incoming supply voltage is very high etc.....

In the above conditions check the Starters as explained in Auto & Manual Mode.

1.8: Troubleshooting Guidelines in case any fault is at load side

Steps to be followed

Thermal overload relay provide protection from:

a) overload condition at Motor

b) single phasing at load side

a) overload condition at Motor : check the suitable Motor current rating and adjust the overload relay setting dial as per the requirement.

b) Single phasing at load side – Overload relay tripped as inbuilt feature to protect from single phase faults. Check the single phasing condition at Motor side terminal TB2,TB3 to Motor.

For both conditions restart the Starter after proper reset time of approx. 4 min.



Smart Infrastructure intelligently connects energy systems, buildings and industries, enhancing the way we live and work to significantly improve efficiency and sustainability.

We work together with customers and partners to create an ecosystem that both intuitively responds to the needs of people and helps customers achieve their business goals.

It helps our customers to thrive, communities to progress and supports sustainable development to protect our planet for the next generation.

Creating environments that care. siemens.com/smart-infrastructure

Published by Siemens Ltd

Smart Infrastructure Electrical Products R&D Building, 48, Thane-Belapur Road Thane 400708, India

Article no. SI EP CC RajaSM1 042021

Subject to changes and errors. The information given in this document only contains general descriptions and/or performance features which may not always specifically reflect those described, or which may undergo modification in the course of further development of the products. The requested performance features are binding only when they are expressly agreed upon in the concluded contract.