


1 Set Up




Insert CD

Put the software media in the CD drive of a laptop or desktop PC.



Install Software


Complete the TrafficDOT software setup wizard.



Set IP Address

Set up a static IP Address of **192.168.2.211** on the local LAN port.

Note: any IP address in the 192.168.2.xxx range may be used except **192.168.2.100**.



Connect Cables

Cable the devices together with Cat5 Ethernet cables. Plug into power source.


2 Connect



TrafficDOT 1.6


Run TrafficDOT

Click the icon to start the Sensys configuration program.




Type in IP Address

Complete the form as shown above and click **Connect**.



Open Preference Window

Click **Preference** from the **Configure** menu.



Set Advanced Mode


Fill check box (a), click **Apply and Save** (b), close window (c).




3 Run




Open AP Config Window
From the **Configure** menu, click **Access Point**.



Set Master Mode
Fill check box (a), click **Apply** (b), close window (c).




Save Changes
From the **Configure** menu, click **Save**.




Start AP
From the **Control** menu, click **Run**.


4 Manage



Open System Config Window
From the **System** menu, click **Configuration**.



Set Time Zone
Specify Time Zone (d), click **Save** (e), close window (f).



Main Window
The default radio channel of the Access Point and Sensors is Channel 0 (zero).
All Sensors or Repeaters on the Access Point's channel are found on the Main window.
Green icons in the first column indicate normal, expected operation.
Use the menu options to further configure the system.
See the **Sensys Wireless Vehicle Detection System Reference Guide** for more information