

**SIEMENS**

SLD4

# User Manual

Aug 16

Issue 7

667/HB/45200/000  
V24763-A82-B4-

# Contents

<b>Contents</b>	<b>2</b>
<b>List of Figures</b>	<b>5</b>
<b>List of Tables</b>	<b>6</b>
<b>Health and Safety Protection</b>	<b>7</b>
<b>Handling Precautions</b>	<b>8</b>
<b>1. Introduction</b>	<b>9</b>
1.1. Purpose	9
1.2. Document References	9
1.3. Key Terms and Abbreviations	10
<b>2. General Description</b>	<b>11</b>
2.1. Introduction	11
2.2. SLD4 Loop Detector Variants	13
2.3. Interface Description	14
2.3.1. LED's and push button	14
2.4. Functional Description	15
2.4.1. Loop Input	16
2.4.2. Detection processing	16
2.4.3. Channel processing	17
2.4.4. Lane Data Processing	19
2.4.5. Output mapping	21
<b>3. General Installation Guidance</b>	<b>22</b>
3.1. Tools Required	22
3.2. Loop Installation Guidance	22
3.3. Detector Card Installation	23
3.3.1. Auto-Configuration	23
<b>4. Basic Operation</b>	<b>24</b>
4.1. Reset (LED Enable) Button	24
4.2. LED Indicators	25
4.3. Switch and Link Operation	26
4.3.1. Default Configuration	27
4.3.2. Sensitivity selection	28

4.3.3.	Frequency Selection	29
4.3.4.	Presence time selection	30
4.3.5.	Loop Mode configuration	31
4.3.6.	Loop connection range	32
<b>5.</b>	<b>Advanced Operation and Configuration</b>	<b>34</b>
5.1.	General	34
5.2.	Main Window	35
5.3.	Connection Status	36
5.4.	Configuration	37
5.5.	Status	44
5.6.	System Log	45
5.7.	Monitoring & Simulation	46
5.7.1.	Vehicle Simulation	48
5.8.	Tools	49
5.8.1.	Firmware Update	49
5.8.2.	Reboot Device [Reboot]	50
5.8.3.	Restore Factory Defaults [Restore]	50
5.8.4.	Revert to Switch Settings [Delete Configuration]	50
<b>6.</b>	<b>Maintenance</b>	<b>51</b>
6.1.	Modifications	51
6.2.	Routine Maintenance Visits	51
6.3.	First Line Maintenance	51
6.4.	Second Line Maintenance	52
<b>A</b>	<b>Appendix</b>	<b>53</b>
A.1	SLD4 Loop Detector Specification	53
A.2	SLD4 Loop Detector Variant Features	55
A.3	Backplane Connector	56
A.4	Backplane Connections	57
A.5	Link Ranges for Example Loop Configurations	61
A.6	Impact of Long Loop Feeder Lengths	62
A.6.1.	Summary	62
A.6.2.	Effect of feeder length	62
A.6.3.	Maximum inductance	63

## Contents

A.7	Installing USB Drivers	64
A.8	Command Line Operation	69
A.9	Installation of Configuration Tool	73

## List of Figures

Figure 1 : SLD4 Detector	11
Figure 2 : SLD4 Internal Processing for Each Loop Pair	15
Figure 3 : SLD4 Lane and channel processing in the default mode	16
Figure 4 : Channel output mode examples	18
Figure 5 : Output Pulse, Delay & Extension	21
Figure 6 : Loop Dimensions	31
Figure 7 : SLD4 Configuration Tool - Main Window	35
Figure 8 : Connection Status	36
Figure 9 : Configuration Window	37
Figure 10 : Blue colour indicates configuration changed	38
Figure 11 : Configuration changed in the blue coloured tab	39
Figure 12 : Select Target device	40
Figure 13 : Configuration of Digital Outputs	42
Figure 14 : Output Pulse, Delay & Extension	43
Figure 15: Status Window	44
Figure 16 : Monitoring & Simulation Window	46
Figure 17 : UK Backplane Connections	56
Figure 18 : Loss of Sensitivity due to Feeder	63

## List of Tables

Table 1 : External Document References	9
Table 2 : Terms and Abbreviations	10
Table 3 : SLD4 Loop Detector Variants	13
Table 4 : Additional Items	13
Table 5 : Channel output modes - single and unidirectional	18
Table 6 : LED Output Mapping Table	21
Table 7 : Reset (LED Enable) Button	24
Table 8 : Status LED	25
Table 9 : Power and Mode LED	25
Table 10 : Link and Switch Function	26
Table 11 : Sensitivity Selection	28
Table 12 : Suggested Sensitivity Settings	28
Table 13 : Manual Frequency Selection	29
Table 14 : Manual Presence Time Selection	30
Table 15 : Manual Loop Mode Selection	31
Table 16 : Loop Connection Range	32
Table 17 : Toolbar Options - Configuration	39
Table 18 : SLD4 Outputs	43
Table 19 : Toolbar Options - System Log	45
Table 20 : Toolbar Options - System Log	47
Table 21 : SLDS4 Loop Detector Specification	53
Table 22 : Recommended Power Supply Operation	54
Table 23 : SLD4 Loop Detector Feature Set	55
Table 24 : Inductance of Standard Sized Loops	61
Table 25 : Fault Table	71

## Health and Safety Protection



### Installation and Maintenance Personnel

In the interests of health and safety, when installing, using or servicing this equipment the following instructions must be noted and adhered to:

- (1) Only skilled or instructed personnel, with relevant technical knowledge and experience, who are also familiar with the safety procedures required when dealing with modern electrical/electronic equipment, are to be allowed to use and/or work on this equipment. All work shall be performed in accordance with the local regulations<sup>1,2</sup>.
- (2) Such personnel must take heed of all relevant notes, cautions and warnings in this Handbook and any other Document or Handbook associated with the equipment including, but not restricted to, the following:
  - i. The equipment must be correctly connected to the specified incoming power supply.
  - ii. Only trained / competent persons should work on this equipment.
  - iii. Any power tools must be regularly inspected and tested.
  - iv. Any personnel working on site must wear the appropriate protective clothing, e.g. reflective vests, etc.



### Road Users

It is important that all personnel are aware of the dangers to road users that could arise during repair and maintenance of traffic control equipment.

Ensure that the junction area is coned and signed as necessary to warn motorists and pedestrians of any dangers and to help protect the personnel working on the site.

---

<sup>1</sup> For UK this refers to Electricity at Work Regulations 1989.

<sup>2</sup> For DE this refers to GV A3, DIN EN 50110-1 (VDE 0105-1) and VDE 0832 and the work-safety leaflet ASM 0099-01

# Handling Precautions



### Handling

- Take care when handling these modules as they can be easily damaged.
- Observe anti static precautions at all times



### Damage through electric fields or electrostatic discharge

Electric fields or electrostatic discharge can cause malfunctions through damaged individual components, integrated circuits, modules or devices.

- Only pack, store, transport electronic components, modules or devices in their original packaging or in other suitable materials, e.g. conductive foam or anti-static bags.
- Ensure that users are discharged prior to handling modules. This can be achieved by touching an earthed surface such as a control cabinet, for example.

# 1. Introduction

## 1.1. Purpose

This handbook gives a general description and specification for the SLD4 detector. It outlines the general procedures for installation, commissioning and maintenance.

Detailed installation instructions can be found in this document and in addition, the appropriate installation guides.

## 1.2. Document References

External Document References	
667/HE/20663/000	Loop detector and cable terminations installation and commissioning handbook (UK)
667/HE/20664/000	Installation and Testing (General)
667/HE/31699/000	Loop Inductance Calculator
667/HQ/45200/000	SLD4 Users Quick Start Guide
667/HQ/45200/001	SLD4 Intelligent Detector Backplane QS Guide
667/HQ/45200/101	SLD4 Application Notes

**Table 1 : External Document References**

## 1.3. Key Terms and Abbreviations

Key Terms and Abbreviations	
BMS	Business Management System (Siemens Electronic Document Storage Tool for Process Documents)
CPU	Central Processing Unit
DIP	Dual In-Line Package
EEPROM	Electrically Erasable and Programmable Memory
GSPI	Generic Serial Peripheral Interface Protocol
HE	Highways England
LED	Light Emitting Diode
MOL	Mobility
MOTION	Method for the Optimization of Traffic Signals In On-line controlled Networks
MOVA	Microprocessor Optimised Vehicle Actuation
N/A	Not Applicable
NC	No Connection
O.C.	Open Collector
PCB	Printed Circuit Board
SCOOT	Split Cycle Offset Optimisation Technique
SITOS	Siemens Traffic Communications Protocol
ITS	Intelligent Transportation Systems (Mobility)
UART	Universal Asynchronous Receiver Transmitter

**Table 2 : Terms and Abbreviations**

## 2. General Description

### 2.1. Introduction

The Siemens SLD4 is an inductive loop detector for 4 loops (L1 to L4). Most important operator control functions are accessible by switches. More detailed features and additional functions can be set using the PC configuration program. The detector features:

- Four detection channels with various output options (digital and/or serial)
- Fully automated set-up optimized for VA operation
- Self-tuning operation
- High detection accuracy
- Low power operation
- Standard 3U card format
- Enhanced processing features including vehicle classification and speed measurement (variant dependant)




Figure 1 : SLD4 Detector

The SLD4 uses the latest inductive loop detection algorithms to provide exceptional detection performance in a wide range of applications. The detectors interface with all popular traffic control equipment and the automated set-up features ensures optimal performance is always achieved.

The SLD4 loop detector is a self-tuning unit in a 3U format with various pin-out options including the standard defined in TR2512. Providing four separate detection channels, the SLD4 offers fully solid state output variants designed for maximum reliability. SSR relay variants offer both normally open (n/o) and normally closed (n/c) configurations.

The detector may be powered from either AC or DC supplies and offers both low power and full operation down to 10V DC, which makes support within battery powered equipment a viable option where needed.

A range of LED's on the front panel provide indication of loop detection and faults. The LED's are disabled after a preset time to reduce power consumption. These can be activated when

## General Description

an Engineer is present by means of a push button on the front panel, which also provides a reset facility.

The SLD4 offers a unique feature that, when it is installed in a rack with other SLD4 detectors, all units are able to communicate with each other so as to automatically set critical parameters. The automatic setup has been optimized for VA applications.

Manual set-up is also possible, with sensitivity level, presence time and frequency, loop mode and size selection being offered via DIP switches or advanced PC configuration.

For special/advanced applications a PC configuration tool is also available. This tool allows access to a wide range of detection parameters allowing detectors to be individually set up for specialist applications. A dedicated USB cable is required to access the detector using the front panel serial connector.

2.2. SLD4 Loop Detector Variants

SLD4 Loop Detector Variants		
	Part Number	Product Description
	667/1/45200/001	UK Isolated SSR O/P TR2512A
	667/1/45200/002	UK Non Isolated Open Collector output
	667/1/45200/003	UK Serial output integrated
	667/1/45200/504 S24763-A82-A1-01	DE Advanced - Non-Isolated, Parallel and serial connection to equipment in the same cabinet, with full 8+1 classification enhanced firmware features and silver front panel
	667/1/45200/505 S24763-A82-A2-01	As /504 (-A3) without front panel
	667/1/45200/506 S24763-A82-A5-01	DE Non-Isolated - Parallel and serial connection to equipment in the same cabinet, with enhanced firmware features and silver front panel
	667/1/45200/507 S24763-A82-A6-01	As /506 without front panel
	667/1/45200/011	UK Advanced – as /001 with enhance f/w features

Table 3 : SLD4 Loop Detector Variants

Additional Items		
	Part Number	Product Description
	702/4/08535/000 A8D00000104	3.5mm / USB adaptor cable

Table 4 : Additional Items

## 2.3. Interface Description

The SLD4 detector has three main interfaces;

### 2.3.1. LED's and push button

Each detector channel has one LED, mounted on the front of the detector, which gives a visual indication of the detector and fault status.

One LED per channel to indicate presence and fault status.

Power and mode LED's to indicate mode and other fault status.

Front panel push button for LED enable/disable and reset functions.

LEDs are enabled for 20 minutes.

### Configuration DIP Switches and Links

2 x 8 way DIP switches accessed on the front panel, 4 DIP switches per loop for manual sensitivity setting.

2 x 8 way DIP switches accessed on the PCB for presence, mode and manual frequency setting.

2 hand bag links per channel for loop connection range shows the switch and link positions for user selectable parameters.

### Serial Interface - Front


A serial interface for PC on the front panel of the module using a 3 pole 3.5mm jack socket.

This is used with a 3.5mm / USB adaptor cable<sup>3</sup>.

### High Speed Interface - DIN connector

The rear DIN connector carries the High Speed Serial IO (RS422, RS485, Logic Level) which all use the same UART on the CPU so only one interface can be used at any one time.

- The 4 wire RS422 interface is configured for multi-drop operation use where the transmitter can be disabled.
- The 2 wire RS485 interface is configured for multi-drop operation.
- A 3.3V logic level interface providing the following signals:
- Serial Data Input
- Serial Data Output
- Data Direction Control Output
- All interfaces autobaud and can communicate using both GSPI and SiTOS protocols.



<sup>3</sup> Part No. 702/4/08535/000 or A8D00000104.

## 2.4. Functional Description

The following section is designed to give an overview of the processing within the detector to enable greater understanding of internal operation and the advanced configuration modes.

The SLD4 is a 4 channel loop detector and therefore provides 2 loop pair processing streams as shown in Figure 2.

These two processing streams can be configured to operate in single loop mode if just vehicle presence information is required.

The two processing streams are run asynchronously.




Figure 2 : SLD4 Internal Processing for Each Loop Pair

Figure 3 shows the data flow within the detector for each loop pair stream. The following sections describe each module and some of the configuration options available.

## 2.4.1. Loop Input

For each loop pair there is an (A) loop and a (U) loop. In double loop mode the A loop should be the upstream loop and the U loop the downstream loop so that a vehicle travelling in the Normal direction would traverse A then U and in the reverse direction travel U then A. In single loop mode the position of A and U relative to each other is irrelevant.




Figure 3 : SLD4 Lane and channel processing in the default mode

### Note

This section uses loop definitions A and U. The X and Y Lane identifications are used as the outputs are configurable which gives maximum flexibility.

## 2.4.2. Detection processing

The detection processing module analyses the data from each loop and determines individual loop detect and fault states. There are a number of configuration items that can influence the individual loop detection processing including:

- Detection sensitivity threshold – various auto and fixed modes
- Presence time – time after which a detected vehicle is “tuned out”
- Operating frequency – various auto and fixed modes
- Sampling duration and frequency
- Fault suppression time

### Automatic Mode

Under a wide range of conditions, the automatic setting is sufficient for most users to obtain optimum operation.

In order to automatically generate the thresholds, the detection processing stores the peak frequency deviation for the proceeding twenty (configurable) vehicles. The automatic threshold is set at a level that is 4% (configurable) below the average of the twenty peaks stored.

Therefore the thresholds will be biased by the predominant vehicle type.

For example, loops that located such that cars are the predominant vehicle will have automatically set thresholds that are likely to be de-sensitised to bikes. Visa versa, loops that located such that bikes are the predominant vehicle will have automatically set thresholds that maybe overly sensitive to cars and could, dependant on topology, pick up vehicles in adjacent lanes.

### 2.4.3. Channel processing

The channel processing module interprets the individual and combined loop states to set virtual (internal software) channel IO bit detect and fault states. Each channel can be configured to operate individually or during a number of predetermined detection sequences from the loop pair to indicate vehicles travelling in a particular direction only. For channel unidirectional detection the loops must be positioned so that when vehicles traverse the loops there must be a time where both loops are in the detect state simultaneously.

Table 5 below details the Output Channel Modes which can be configured and Figure 4 shows examples of each mode.

Channel Output Modes			
Mode	Detect Output	Detect output under single loop failure	Fault output
Single A	Single loop mode using loop A	Fault (Permanent Detect)	With Fault A
Single U	Single loop mode using loop U	Fault (Permanent Detect)	With Fault U
Normal A	Normal direction only, output active with loop A	Single mode with remaining loop	With Fault A or U
Normal U	Normal direction only, output active with loop U	Single mode with remaining loop	With Fault A or U
Reverse A	Reverse direction only, output active with loop A	Single mode with remaining loop	With Fault A or U
Reverse U	Reverse direction only, output active with loop U	Single mode with remaining loop	With Fault A or U

Channel Output Modes			
Normal A	Normal direction only, output active with loop A	Fault A: Fault (Permanent Detect)	With Fault A or U
Fault A		Fault U: Single mode with loop A	
Reverse U	Reverse direction only, output active with loop U	Fault A: Single mode with loop U	With Fault A or U
Fault U		Fault U: Fault (Permanent Detect)	

Table 5 : Channel output modes - single and unidirectional




Figure 4 : Channel output mode examples

### 2.4.4. Lane Data Processing

The lane processing module analyses the detection state and timing data from single or double loops and converts this into individual vehicle data records. In single loop mode, the following vehicle data is calculated:

Times – entry, preceding gap, occupancy

In double loop mode the detection sequences from two loops are combined to calculate:

- Direction
- Speed
- Length
- Classification
- Times – second occupancy and travel time between loops

For each individual vehicle record a raw loop frequency profile is captured. The viewing of this profile can assist in setup and diagnostics of the detector.

The detector provides 8 configurable classification bins, which can be configured by length and speed ranges and also vehicle direction. The same classification definitions apply to both lane processing streams within the detector.

The lane/vehicle processing module accepts the following configuration options:

- Lane mode
- Single
- Double : bi-directional
- Double : unidirectional
- Double : reverse unidirectional
- Lane headway – distance between the leading edges of the loops when in double loop mode
- Loop length – The length of the loops
- Length Adjustment – Optional adjustment of the vehicle length reported for this lane

### Classification

The detector can provide nine (8+1) classification bins, which can be configured by length and speed ranges and also vehicle direction. The same classification definitions apply to both lane processing streams within the detector.

---

#### **Note**

Classification of the vehicle is performed once the vehicle has left the detection zone.

---

Individual vehicle classifications are mapped to virtual (internal software) IO bit states, which can then be mapped to the physical outputs of the detector (reference section 0 below). The individual vehicle data records are also entered into a shared multi interface FIFO (queue). It is implemented so that detected vehicles can be collected simultaneously from any of the

## General Description

multiple serial interfaces on the detector. When the FIFO overflows, the oldest vehicle is discarded. The overflow count can be retrieved from the detector if required.

---

### **Note**

The classification vehicle queue is 25 deep and shared across both lanes and all serial interfaces.

---

## 2.4.5. Output mapping

The LEDs operate a fixed mapping from the respective internal output channel as shown in Table 6. This therefore means that the LEDs can indicate single or unidirectional detection depending on the detector configuration.

LED Output Mapping Table		
Detect	Fault	LED State
0	0	Off
1	0	On
X (Don't care)	1	Fast Flashing

Table 6 : LED Output Mapping Table

There are up to 9 physical outputs on the detector<sup>4</sup>. The function of these outputs can be configured to activate on a logical combination of current internal bit states (channel detect and fault state, system fault state and vehicle classifications).

Each physical output can be converted to a pulse, delayed, extended and inverted.




Figure 5 : Output Pulse, Delay & Extension

<sup>4</sup> Variant dependant

## 3. General Installation Guidance

### 3.1. Tools Required

As well as a standard Installers tool kit, the following are required when installing and maintaining the SLD4 Detector:

Small flat bladed screwdriver – for DIP switch adjustment.

### 3.2. Loop Installation Guidance

It is recommended that installation of the loops is in accordance with local best practice guidance<sup>5,6</sup>.

---

#### Note

Multi-pair feeder cables must not be shared between two or more detector cards.


---

---

#### Note

When using 2-pair cable the pairs are the opposite conductors.

---



---

#### Note

In the case of 3 or more pairs, the pairs must be twisted, then the pairs must be twisted together to make up the total cable.

---

---

#### Note

Loop/feeder installations must be mechanically and electrically stable. The conductors must not be able to move in the slots, there should not be lengths of loop tails laid untwisted in ducts or soft sand.

---

---

#### Note

Loops that are near to each other in the carriageway or occupy the same feeder cable should be connected to the same detector card.

---

---

<sup>5</sup> UK installations should follow guidance provided in - Installation Handbook for Detectors and Loops (667/HE/20663/000 - Installation Handbook No. 3 (Detectors and Loops)

<sup>6</sup> DE Installations may follow guidance in Schleifendetektor M-Detektor D1A, D2A – Anleitung für Projektierung und Montage

### 3.3. Detector Card Installation

From factory, the card will be configured such that the card is set to;

- Automatic Sensitivity (optimised for VA operation)
- Automatic Frequency allocation
- Four minute Presence time
- Single Loop operation

Carefully insert the board making sure that the contacts of the plug connector are not bent.

Check that backplane connector is engaged and tighten the two retaining screws.

Switch on the voltage (the SLD4 may also be fitted while the power is on – ‘Hot plug’).

When the detector card is operating normally, without faults, the power LED will slow flash. The Mode LED status will depend on how the channel has been configured.

#### 3.3.1. Auto-Configuration

In large installations, manual setting of frequency and sensitivity parameters can often be a challenge and failure to achieve this correctly can cause detectors to ‘chatter’ or otherwise fail to operate correctly.

The SLD4 offers a unique feature<sup>7</sup> that allows multiple SLD4 detectors to communicate with each other so as to automatically set critical parameters. Once all the detectors are fully set-up, LED’s on the front panel of each detector flash in synchronism to signal that auto-setup has been achieved and the selected parameters stored in non-volatile EEPROM memory. This allows the detector to rapidly return to the same operating mode after a power cycle.

When a detector rack is populated with more than one detector card the left hand card (looking from the front) will be the Master card and will communicate with the other cards via an on-board infra-red link.

Where detectors are positioned one above another and use Intelligent Detector Backplanes, an interlinking cable between these backplanes allows the infra-red link to be extended to the set of detectors below creating one group of detectors.

If some detectors are manually set to operate at specific frequencies (e.g. using DIP switches) the remaining cards, setup in automatic mode within the communicating group, will be assigned frequencies that do not clash with those set manually.

---

#### Note

If the SLD4 card is inserted alongside a number of other SLD4 cards, a ‘synchronization’ flash should be observed on all cards simultaneously<sup>8</sup>.

---

---

<sup>7</sup> Variant dependant (reference Appendix A.2)

<sup>8</sup> Variant dependant (reference Appendix A.2)

## 4. Basic Operation

The following sections outline many of the features and functionalities available to the user. Without the use of a PC, the user can interact with the SLD card in three main ways;

- Reset(LED Enable) Button
- LED indicators
- Configuration Switches

### 4.1. Reset (LED Enable) Button

The reset button, accessed from the front of the card, enables various functions by applying the appropriate sequence;

Reset (LED Enable) Button		
Mode	Function	Operation
1	LED enable	1 tap
2	LED disable	2 taps
3	Reset (software)	3 taps
4	Revert to default configuration <sup>#</sup>	4 taps
5	Reset (hardware)	hold 3sec
6	LED enable ALL LED's in a rack when done on the master*	1 tap
7	LED disable ALL LED's in a rack when done on the master*	2 taps
8	Reset (software) ALL in a rack when done on the master*	3 taps

**Table 7 : Reset (LED Enable) Button**

# - All switches must be in the off position. This is a safety measure to stop the user accidentally erasing a configuration. The user should make a note of the switch settings prior to the default configuration reset and return them to those positions after the reset has taken place.

This feature allows the user to reset to the default configuration without the need for the configuration tool and a PC.

\* - The master is the left hand most card in the rack

## 4.2. LED Indicators

Each detector loop channel has one LED, mounted on the front of the detector, which gives a visual indication of the detector and fault status. There is also a Power and a Mode LED.

Loop Status LED	
Status	Operation
Loop Detect	On (Vehicle Detect)
Loop Fault	Fast Flash

Table 8 : Status LED


Power and Mode LED		
Status	LED	
	Power	Mode
Manual mode – Sensitivity and Frequency	Slow flash	Off
Auto mode and set up complete*	Slow flash	Slow flash
Software modified configuration - in sync and auto set up complete*	Slow flash	Double pulse at slow flash rate
Software modified configuration - out of sync and auto set up complete*	Slow flash	Double pulse at slow flash rate offset 50% duty
Other (system) faults	Fast flash	As per states below

Table 9 : Power and Mode LED

\*Auto mode is completed after 20 vehicles have been detected on each loop.


When the detector card is operating normally, the power LED will slow flash. The illumination of the Mode LED will depend on how the channel has been configured. When there are a number of boards in the rack it should be very easy to identify a faulty board by the Power LED status.

LEDs are normally only enabled for 20 minutes but can re-enabled by pressing the Reset (LED enable) button.



### 4.3. Switch and Link Operation

The SLD4 detector card can be installed with default settings, configured using DIP switches and links or, for the more advanced requirements, configured using a PC configuration tool. This section outlines the configurations that can be made using the links and switches.



#### Link Function (where applicable)

Link	Function
LK1	Software Update Link – not normally fitted
LK4	Inter-card link speed – not normally fitted
LK5	RS422/RS485 select. Link installed for RS422 operation, Uninstalled for RS485 Installed by default on UK variant /003, and DE variants: 667/1/45200/506 (S24763-A82-A5), 667/1/45200/507 (S24763-A82-A6)
PL3	Loop 1 inductance setup links
PL4	Loop 2 inductance setup links
PL5	Loop 3 inductance setup links
PL6	Loop 4 inductance setup links

Table 10 : Link and Switch Function

### 4.3.1. Default Configuration

The SLD4 detector card is shipped from the factory configured as follows;

- Automatic Sensitivity (optimised for VA operation)
- Automatic Frequency allocation
- Four minute Presence time
- Single Loop operation

#### Auto-Configuration

The SLD4 offers a unique feature<sup>9</sup> that allows multiple SLD4 detectors to communicate with each other so as to automatically set critical parameters. Once all the detectors are fully set-up, LED's on the front panel of each detector flash in synchronism to signal that auto-setup has been achieved.

When a detector rack is populated with more than one detector card the left hand card (looking from the front) will be the Master card and will communicate with the other cards via an on-board infra-red link.

Where detectors are positioned one above another and use Intelligent Detector Backplanes, an interlinking cable between these backplanes allows the infra-red link to be extended to the set of detectors below creating one group of detectors.

If some detectors are manually set to operate at specific frequencies (e.g. using DIP switches) the remaining cards, setup in automatic mode within the communicating group, will be assigned frequencies that do not clash with those set manually.

---

<sup>9</sup> Variant dependant (reference Appendix A.2)

### 4.3.2. Sensitivity selection

There may be reasons why the auto-tune facility needs to be over-ridden.

Sensitivity selection for each channel is via the DIP switches on the front panel, with 4 switches per channel (see Table 11).

Sensitivity Selection				
S4	S3	S2	S1	%ΔL/L
0	0	0	0	OFF <sup>10</sup>
0	0	0	1	0.01
0	0	1	0	0.02
0	0	1	1	0.04
0	1	0	0	0.08
0	1	0	1	0.1
0	1	1	0	0.25
0	1	1	1	0.5
1	0	0	0	1.0
1	x	x	x	N/A <sup>11</sup>
1	1	1	1	AUTO

Table 11 : Sensitivity Selection

The following table provides some of the typical sensitivities used for particular applications.

Suggested Sensitivity Settings	
Loop Mode	Sensitivity %ΔL/L
VA	0.02% - 0.04%
SCOOT	Loop dependant See 667/HE/20663/000 Section 2.11
MOVA	0.1%
MOVA Stopleveline	0.1% - 0.5%
Cycle <sup>12</sup>	0.02% - 0.04%

Table 12 : Suggested Sensitivity Settings

<sup>10</sup> This switch setting will disable the loop.

<sup>11</sup> These switch settings are engineering settings and should not be used.

<sup>12</sup> For accurate bicycle detection manual setting is recommended.

### 4.3.3. Frequency Selection

To manually select individual card frequencies the table printed on the side panel should be followed. The frequencies allocated are in 15 bands where band 1 is the highest frequency and band 15 the lowest frequency.

Normally auto frequency allocation should be used but manual frequency allocation may be desirable if the system is suspected to suffer from interaction between cards, loop, and environmental conditions.

Manual Frequency Selection				
F4	F3	F2	F1	
0	0	0	0	<b>AUTO</b>
0	0	0	1	<b>1</b>
0	0	1	0	<b>2</b>
0	0	1	1	<b>3</b>
0	1	0	0	<b>4</b>
0	1	0	1	<b>5</b>
0	1	1	0	<b>6</b>
0	1	1	1	<b>7</b>
1	0	0	0	<b>8</b>
1	0	0	1	<b>9</b>
1	0	1	0	<b>10</b>
1	0	1	1	<b>11</b>
1	1	0	0	<b>12</b>
1	1	0	1	<b>13</b>
1	1	1	0	<b>14</b>
1	1	1	1	<b>15</b>

Table 13 : Manual Frequency Selection

**Note**

Higher frequencies give better accuracy for vehicle types so the aim should be to select higher frequencies where possible.

**4.3.4. Presence time selection**

The default setting of 4 minutes should be used standard traffic applications. Certain situations may require different times. Different times can be set using P1 & P2 switches on the Presence switch on the PCB for each channel.

Presence Time Selection		
P2	P1	Presence Time
0	0	4 min
0	1	35 min
1	0	3.5 sec
1	1	2 hours

**Table 14 : Manual Presence Time Selection**

### 4.3.5. Loop Mode configuration

The default setting is single loop operation where all four channels operate independently. The MODE/FREQ DIP switch is used to configure the loop operating mode.

Double loop operation is available<sup>13</sup>, which allows 2 loops to operate together (L1 & L2) and (L3 & L4).

Double loop operation allows speed, length and classification to be determined. This information can then be mapped to a digital output, on the high speed interface and in the Configuration tool.

Loop Mode Selection		
M2	M1	Loop Type
0	0	Single
0	1	Double Loop 2.5 / 4m*
1	0	Double Loop 1 / 2.5m*
1	1	Double Loop 1.5 / 2.5m*

**MODE/FREQ**

ON (1)  
OFF (0)

1 2 3 4 5 6 7 8


M2 M1 M2 M1 F4 F3 F2 F1

L1/L2 L3/L4 Frequency

**Table 15 : Manual Loop Mode Selection**

\* 1<sup>st</sup> dimension – length of loops – X

2<sup>nd</sup> dimension – Headway - front edge to front edge distance – Y



**Figure 6 : Loop Dimensions**

<sup>13</sup> Variant dependant (reference Appendix A.2)

### 4.3.6. Loop connection range

The correct connection ranges must be chosen appropriate to the loop inductance and the feeder length, so as to ensure that the desired loop frequency can be set. In most cases, range 1 will be suitable (default). If the range selected is unsuitable, automatic frequency adjustment will not be possible and the LED flashes to indicate a setting error.

Loop Connection Range				
Range	L1	Jumper PL3	Example Loop Type	Loop inductance
	L2	Jumper PL4		
	L3	Jumper PL5		
	L4	Jumper PL6		
1		1-2, 3-4	Low inductance values and/or short feeder lengths	Approx. 20 – 150µH
2		2-3, 4-5	Medium inductance values and/or medium feeder lengths	Approx. 150 – 300µH
3		1-2, 4-5	High inductance values and/or high feeder lengths	Approx. 260 – 2000µH

Table 16 : Loop Connection Range

Loop feeder length is normally in the range of 0 - 300M but is extendable up to 1000M where the recommended loop cable core size is 1.5 mm<sup>2</sup> or 2.5 mm<sup>2</sup>.

The following provide a guide for users:

- Short feeder <100m
- Medium feeder 100-300m
- Long feeder >300m

---

#### Note

An estimate of the loop inductance can be read by the PC configuration tool. This estimate is only valid if the loop is configured in inductance range 1.

---

A loop inductance tool, 667/HE/31699/000, is available to help determine inductance based on loop size, cable length and number of turns. Appendix A.5 has suggested link ranges for typical loop configurations.



### Loop Performance

These jumpers must be set correctly to match the loop inductance. Failure to do so will degrade system performance.

To minimize the effect of loop interaction, the jumper should be set to maximize the available operating frequency range between 30KHz and 120KHz. The available range can be found using the **PC Configuration Tool** and viewing the minimum and maximum operating frequencies.

## 5. Advanced Operation and Configuration

The following sections outline many advance features and functionalities available to the user. Most, if not all, of these features are accessible via the serial interface.

---

### Note

A dedicated USB cable (702/4/08535/000 or A8D00000104) must be used and the cable driver must be installed.

---

The serial interface can be used in two ways. The one is via a serial command line interface and another is via the SLD Configuration tool.

The section below outlines the configuration tool. Details of the command line interface can be found in Appendix A.8.



### AC Supplies

When using 24 AC supply to the detector, only use battery powered interface equipment (e.g. laptop). Do not connect mains powered/connected interface equipment to the SLD4. Failure to observe these precautions may damage the detector and/or the connected device.

### 5.1. General

For information on an item, help text is displayed for each item in the 'Help' Window at the bottom of the application. To view help for a particular item, click on its data entry field.

All data values that are entered are checked for validity and the appropriate symbol displayed:



Valid Data Flag



Invalid Data Flag

### 5.2. Main Window

The Main Window provides at all times, the available pages within the application, the connection status and options, card selection (when connected) and language selection:




Figure 7 : SLD4 Configuration Tool - Main Window

Language selection will only be available if at least one alternative language dictionary is picked up from the translations directory in the directory where SLD4 has been installed. (All language packs will be available for use when the application is installed)

Card Selection will become available once a connection has been made to a master device. The drop down box is updated when used, therefore will always show all slaves connected to a master.

### 5.3. Connection Status

#### Connect/Disconnect

Use this to connect to an SLD4 device. A check will be made before the connection is established to ensure the device is an SLD4.

Upon a successful connection, the text will change to 'Disconnect' which can then be used to disconnect the application from the connected device. A local copy of the configuration definition for each card type is kept so if the card is of a new type, the configuration will be downloaded once as shown. The connected card description and firmware information will be displayed. This should be done if connecting to a different SLD4 device to ensure the correct device information is available.




Figure 8 : Connection Status

#### Configure

Connection configuration allows selection of the COM port on which a device is connected.

## 5.4. Configuration

This page allows the creation of new configurations, writing of newly created configurations to SLD4 and reading and modification of configurations from connected SLD4s. Tabs group related configuration items.

For all configurable items the valid range is displayed to the right of the entry location with a valid/invalid flag. Clicking in the entry location will display help text for that entry in the help box at the bottom of the screen. For each tab, the default values can be loaded by pressing the **Revert to Default** button.

The example screen shot below shows a configuration after connection. Only parameters that can be altered for that variant are editable otherwise the default values are displayed.




Figure 9 : Configuration Window

When a parameter is modified, the box border changes to blue colour to show that it has been modified but not saved to the detector. The tab colour also changes to a blue colour to indicate a value on that tab has been changed. Examples for the modified element and tab can be seen below:




Figure 10 : Blue colour indicates configuration changed




Figure 11 : Configuration changed in the blue coloured tab

## Toolbar Options

Tool Bar Options - Configuration	
 New	Creates a new blank configuration, all items will be set to their default values.
 Open	Opens a previously saved configuration.
 Save	Saves the configuration.
 Close	Closes the configuration.
 Write	Writes the configuration to the currently selected device. Writing will not be possible if the configuration is invalid. Invalid items will be marked with a yellow exclamation mark  .
 Read	Reads the configuration from the currently selected device. Note: A configuration does not need to be open.
 Convert	Converts configurations between different variants of the detector

Table 17 : Toolbar Options - Configuration

### Note

If more than one configuration type is available locally, the blank configuration can be set based on one of the locally stored configuration as shown on the left. Click on the desired configuration and then on [Select]. Unwanted configurations can be deleted using the [Delete] button.

Not until a configuration is loaded either from the local store or a detector are the configuration tabs shown.




Figure 12 : Select Target device

### General

This tab covers configuration items that apply to the whole detector and are not loop specific.

### Loops

Configuration items specific to each loop are set here.

### Lanes

This tab covers the configuration of single & double loop operating modes allowing the user to set loop sizes and separation for each pair of channels. Lane 1 is associated with loop channels L1 & L2 and Lane 2 with loop channels L3 & L4.

### Classification

This tab covers configuration of the classifier classes. Nine (8+1) classification classes can be set within the advanced detector.

### Digital Outputs

This tab provides a graphical interface for configuring the digital outputs and allows logical signals from the detector (such as detect, fault, classification type) to be mapped to physical outputs. The default state is shown on the screen shots below:





Figure 13 : Configuration of Digital Outputs

This configurable logical mapping process is made simple for the user by a matrix of tick boxes that allow one or more input state(s) (Horizontal) to be linked to one or more physical output(s) (Vertical)


The first click on a box links a state to an output. A second click links the state to the output but is inverted as shown in the key below.



The 'Pulse' Output tick box provides a 1 ms active output pulse

Classification outputs provide a 100ms pulse by default which can be overridden by the 'Pulse', 'Delay' & 'Extension' modifiers.

The effect of output activation using 'Pulse', 'Delay' & 'Extension' is shown below in Figure 14. Values for 'Delay' and 'Extension' are entered in milliseconds.





**Figure 14 :Output Pulse, Delay & Extension**

The physical outputs are listed across the bottom of the matrix.

SLD4 Outputs	
Output Name	Default Function
D0 - D3	4 Detect outputs (Open Collector)
F0 - F3	4 Fault outputs (Open Collector)
DF	Common Detector Fault output (Open Collector)

**Table 18 : SLD4 Outputs**

Clicking on the  button on the configuration tab will populate the matrix with the detectors configuration.

Output changes made on the matrix are not written to the detector unless the  button is clicked on the configuration tab.

## 5.5. Status

This page displays status information for the selected detector when connected and the [Refresh] button clicked. Help for each item displayed at the bottom of the page. Additionally, current status codes are displayed on the right-hand side of the screen. Individual tabs for loops and device time are available.




Figure 15: Status Window

### Note

For each loop the detector estimates the loop inductance based on the tuning of that loop. This estimation is only valid when the loop inductance range links are set to range 1 - 20 – 150 $\mu$ H.

## 5.6. System Log

This page is used for displaying log data from connected cards.

Items displayed in red identify those with an estimated time that can only be used as a reference. This is due to the item being logged before the last reboot, without knowledge of how long the device has been off.

### Toolbar Options

Tool Bar Options – System Log	
 Retrieve Log	Retrieves the log from the currently selected card only.
 Retrieve All Logs	Retrieves logs from master and all connected slaves.
 Clear Log	Clears the log on the currently selected card

Table 19 : Toolbar Options - System Log

## 5.7. Monitoring & Simulation

This page has multiple uses as implied by the title; as a work area for creating vehicles to simulate and as a window to monitor vehicles currently passing over the loops of the connected device(s).

The [Edit] section on the right side shows the data of captured vehicles and allows editing of the data when simulating vehicles on one or more detectors. All numeric values are validated before being sent to the detector. Note: If an invalid entry is entered and then focus is moved to another vehicle in the list, the invalid entry will be defaulted back to 0 or will remain as the last valid value.

The detector buffers the last 25 vehicle profiles and when capture is enabled the buffer contents will be downloaded to first empty the buffer prior to displaying vehicle data in 'real time'.

The Overview box contains a graphical representation of the frequency versus time data as the vehicle passed over the loop. The detect threshold is shown as a green line. This is useful for checking that vehicles are 'well over' the detect threshold and not marginal detections.

The IO Port indicators at the bottom of the page are displayed during capture and indicate when outputs are active.




Figure 16 : Monitoring & Simulation Window

## Toolbar Options

Toolbar options – Monitoring and Simulation	
 <i>Load</i>	Loads a previously saved list of vehicles.
 <i>Save</i>	Saves the current list of vehicles.
 <i>Capture Vehicles</i>	Captures vehicles from the currently selected card.
 <i>Capture All Vehicles</i>	Captures vehicles from master and all connected slaves.
 <i>End Capture</i>	Stops an active capture session.
 <i>Add</i>	Add a new blank vehicle to the list.
 <i>Delete</i>	Delete the selected vehicle in the list.
 <i>Delete All</i>	Delete all vehicles in the list.
 <i>Move Up</i>	Move selected vehicle up in the list.
 <i>Move Down</i>	Move selected vehicle down in the list.
 <i>Duplicate</i>	Duplicate selected vehicle. The copied vehicle will appear under the selected vehicle.
 <i>Simulate Vehicles</i>	Simulate (once) vehicles on the selected card. The card that the vehicles should be sent to can be selected in the Edit box under [Card Selection].
 <i>End Simulation</i>  <i>End Simulation</i>	Begin cyclic simulation. Continues cyclic simulation until [end simulation] pressed.

**Table 20 : Toolbar Options - System Log**

---

### Note

While capture is in progress no other tabs can be activated.

---

### 5.7.1. Vehicle Simulation

The tool can simulate vehicles that have been previously captured, added manually or loaded (or a mix). There are a number of important points to remember when configuring a simulation:

- The total time for all simulated vehicles MUST be less than 30 seconds.
- There is a 25 vehicle limit for a simulation so no more than 25 vehicles can appear in the list
- The simulation order is automatically calculated from the [Preceding Gap Time] and [Primary Occupied Time].

## 5.8. Tools

This page provides additional features for a connected device consisting of upgrading SLD4 firmware, rebooting a device, restoring a device to factory defaults or reverting a device back to switch settings.

---

### Note

Updating will only take place on the card which is connected via the serial USB cable. The [Card Selection] box has no effect with these functions.

---

### 5.8.1. Firmware Update

The detector allows new versions of firmware to be loaded into the device via the SLD4-Configuration Tool. The user must select a new firmware distribution file from the file system and upload it to the device after a confirmation message has been displayed. The tool is packaged with the latest firmware version that can be found on the local machine here:


Windows XP:

C:\Program Files\Siemens Traffic Solutions\Siemens SLD4 Configurator\Firmware

Windows 7:


C:\Program Files (x86)\Siemens Traffic Solutions\Siemens SLD4 Configurator\Firmware

- 1 Select the firmware file. (.fwr file)



- 2 Make sure a connection is already established from the application to the device. This allows a check of the firmware currently installed on the device.

- Once [Start Update] is clicked, the firmware versions will be compared and details on proceedings will be displayed.



- For the downloading of the new firmware, the application will be disconnected from the device so the update process can make its own connection. Progress information will be displayed during the download.
- A message will finally be displayed stating the outcome of the update.

### 5.8.2. Reboot Device [Reboot]

This will reboot the device selected in the [Card Selection] box.

### 5.8.3. Restore Factory Defaults [Restore]

This will restore the selected device to the factory defaults. All configuration information will be lost including logs and loop configuration.

The [Restore] will invoke loop profiling as if the detector were powered up for the first time.

### 5.8.4. Revert to Switch Settings [Delete Configuration]

The configuration stored in the selected device will be erased and the device will revert to parameters set by the DIP switches.

Both [Restore] and [Delete Configuration] will reinitialise the loop processing and detection state as if the detector were rebooted.

## 6. Maintenance

Before starting any maintenance work, read the Safety Warnings on page 6 of this Handbook. The SLD4 Detector unit is designed for 'return to base' repair i.e. there are no user serviceable parts on the card.

### 6.1. Modifications

There are no approved modifications for this product.



#### Modifications

Use of components, other than those permitted in this document, or modifications or enhancements that have not been authorised by Siemens, will invalidate Type Approval of this product.

### 6.2. Routine Maintenance Visits

The interval between visits are dependent on local conditions.

The periodic inspection should include the following:

- 1 Checking the detector securing screws are tight.
- 2 Checking that no debris, for example spiders webs, are in the vicinity of the inter-board IR links. These are located on the bottom edge of the board (reference section 4.3)

### 6.3. First Line Maintenance

First line maintenance will be achieved on a modular replacement basis.

- 1 Check which type of detector is fitted.
- 2 Note the detector configuration (This can be switches and/or firmware configuration depending on the type of detector)
- 3 Fit a replacement detector of the same type.
- 4 Configure the replacement detector in the same way as the detector that was removed.

### 6.4. Second Line Maintenance

The faulty parts being returned must always be sent back in the original packaging if available or in an approved Anti Static packaging, along with a fully completed Fault Label to the following address:

Logistics Spares Returns Centre  
Siemens Mobility  
Traffic Solutions  
Coalfield Way  
Ashby Park  
Ashby de la Zouch  
LE65 1JD

For UK users, any queries should be directed to the Service Logistics Manager on:  
(01530) 258181

# A Appendix

## A.1 SLD4 Loop Detector Specification

SLD4 Loop Detector Specification	
Power Supply	24VAC +20%, -25%, 50/60Hz 10-32VDC 
Power Consumption @24VDC /001 /011 variant /002 variant	1.0W with LEDs off, 1.5W with LEDs on 0.75W with LEDs off, 1.0W with LEDs on
Power break support times	50ms @24VAC, 20ms @24VAC -25%
Size	160mm x 100mm x 25mm
Operating Temperature Range	-25°C +80°C
Loop Inductance Tuning Range	0-300m, See Appendix C for longer feeder lengths
Loop Operating Frequency	30KHz – 120KHz
Vehicle Speed Range	0 to 250 km/h using loops as specified in 667/HE/20663/000
Isolated Relay Outputs (/001 & /011 variants only)	One isolated changeover 'detect' output per loop. Withstand: 75VDC Capacity: 50mA continuous with 2.5V max drop 300mA/10ms pulse
Non-Isolated Open Collector Outputs (/002 & /504 to /507 variants only)	One non-isolated open collector 'detect' output per loop. Withstand: 35VDC Capacity: 50mA continuous with 2.5V max drop 100mA/10ms pulse
Approvals	TR2512A Compliant (/001 and /011 variants) ETSI 300-330 Radio Approval CE Approved RoHS Compliant

Table 21 : SLDS4 Loop Detector Specification



### AC Supplies

When using 24 AC supply to the detector, only use battery powered interface equipment (e.g. laptop). Do not connect mains powered/connected interface equipment to the SLD4. Failure to observe these precautions may damage the detector and/or the connected device.



## AC Supplies

It is highly recommended that only the isolated relay output connections on variants /001 & /011 are used when powered from an AC supply.

### Recommended Power Supply Operation

Recommended Power Supply Operation		
Variant	Power Supply	Reason
001, 011	AC or DC	Isolated detect relay outputs allow the use of AC supplies
002	AC or DC	Open collector transistor outputs are referenced to logic ground If AC supply is used this <b>MUST</b> be floating
003	DC only	Serial interfaces are referenced to logic ground
504-507	DC only	Open collector transistor outputs & Serial interfaces are referenced to logic ground

Table 22 : Recommended Power Supply Operation

A.2 SLD4 Loop Detector Variant Features

SLD4 Loop Detector Variant Feature Set									
	Hardware Feature vs Variant	001	002	003	504 -A3	505 -A4	506	507	011
	Available (In full production)	✓			✓	✓	✓	✓	✓
Hardware Feature	DC power	✓	✓	✓	✓	✓	✓	✓	✓
	AC power	✓	✓						✓
	4x Isolated SSR detect outputs (Changeover)	✓							✓
	4x Non Isolated O.C. detect outputs		✓		✓	✓	✓	✓	
	4x Non Isolated O.C. Aux (fault) outputs		✓		✓	✓	✓	✓	
	1x Non Isolated O.C. common fault output		✓		✓	✓	✓	✓	
	RS485 High Speed Serial				✓	✓	✓	✓	
	RS422 High Speed Serial			✓	✓	✓	✓	✓	
	TTL High Speed Serial				✓	✓	✓	✓	
	USB Handset (FTDI cable & 3.5mm socket)	✓	✓	✓	✓	✓	✓	✓	✓
	Front panel	✓	✓	✓	✓*		✓*		✓
	Backplane pin out	UK1	UK2	UK3	DE	DE	DE	DE	UK1
Firmware Feature	Single loop processing	✓	✓	✓	✓	✓	✓	✓	✓
	Double Loop processing (speed, length & speed/length based classification)				✓	✓	✓	✓	✓
	Vehicle profile based advanced (8+1) Classification				✓	✓			✓
	Event Log (Faults etc)	✓	✓	✓	✓	✓	✓	✓	✓
	Configuration & Monitoring via PC software	✓	✓	✓	✓	✓	✓	✓	✓
	GSPI / SITOS (High Speed Serial Interface)			✓	✓	✓	✓	✓	
	Programmable Digital Output Configurations				✓	✓	✓	✓	✓

Table 23 : SLD4 Loop Detector Feature Set

\* Silver front panels

### A.3 Backplane Connector

Using Siemens Backplane 667/1/17205/000

Suitable for detector variants /001 and /011.




Figure 17 : UK Backplane Connections

## A.4 Backplane Connections

Pinouts are colour coded to similar function types

SLD4 UK1 Pinout – Variants 001 & 011 [TR2512A – SSR outputs]		
Pin	Row a function	Row b function
1	Channel 1 relay N/C output	NC
2	NC	Channel 1 relay Common output
3	Channel 1 relay N/O output	NC
4	Frequency selection bit 1 - LS bit [TR2512A]	NC
5	Channel 1 Loop A	Frequency selection bit 2 [TR2512A]
6	Frequency selection bit 3 [TR2512A]	Channel 1 Loop B
7	NC	Frequency selection bit 4 - MS bit [TR2512A]
8	NC	Channel 2 relay N/C output
9	Channel 2 relay Common output	NC
10	NC	Channel 2 relay N/O output
11	NC	Downstream Rx
12	Downstream Tx	Channel 2 Loop B
13	Channel 2 Loop A	Upstream Tx
14	Upstream Rx	Chassis Ground (GDT earth point)
15	Channel 3 relay N/C output	NC
16	NC	Channel 3 relay Common output
17	Channel 3 relay N/O output	NC
18	NC	24V AC 2 power supply input
19	Channel 3 Loop A	NC
20	NC	Channel 3 Loop B
21	24V AC 1 power supply input	NC
22	NC	Channel 4 relay N/C output
23	Channel 4 relay Common output	NC
24	NC	Channel 4 relay N/O output
25	NC	NC
26	NC	Channel 4 Loop B
27	Channel 4 Loop A	NC
28	NC	NC
29	-Reset input	NC
30	NC	+24V DC supply input
31	NC	NC
32	NC	0V DC supply input

SLD4 UK2 Pinout – Variant 002 [Open Collector Detect + Fault outputs]		
Pin	Row a function	Row b function
1	Channel 1 O.C. detect output	Channel 1 O.C. fault output
2	NC	NC
3	NC	NC
4	Frequency selection bit 1 - LS bit [TR2512A]	Master Fault O.C. output
5	Channel 1 Loop A	Frequency selection bit 2 [TR2512A]
6	Frequency selection bit 3 [TR2512A]	Channel 1 Loop B
7	NC	Frequency selection bit 4 - MS bit [TR2512A]
8	Channel 2 O.C. fault output	Channel 2 O.C. detect output
9	NC	NC
10	NC	NC
11	Common return for all O.C. outputs**	Downstream Rx
12	Downstream Tx	Channel 2 Loop B
13	Channel 2 Loop A	Upstream Tx
14	Upstream Rx	Chassis Ground (GDT earth point)
15	Channel 3 O.C. detect output	Channel 3 O.C. fault output
16	NC	NC
17	NC	NC
18	NC	24V AC 2 power supply input
19	Channel 3 Loop A	NC
20	NC	Channel 3 Loop B
21	24V AC 1 power supply input	NC
22	Channel 4 O.C. fault output	Channel 4 O.C. detect output
23	NC	NC
24	NC	NC
25	NC	NC
26	NC	Channel 4 Loop B
27	Channel 4 Loop A	NC
28	NC	NC
29	-Reset input	NC
30	NC	+24V DC supply input
31	NC	NC
32	NC	0V DC supply input
	Only use variant B when powered from 24V DC	** - Factory Option to link to 0V DC supply

(If AC power used [not recommended] – this supply **MUST** be floating)

SLD4 UK3 Pinout– Variant 003 [Serial Only – integrated UK for IDB]		
Pin	Row a function	Row b function
1	NC	NC
2	NC	NC
3	NC	NC
4	Frequency selection bit 1 - LS bit [TR2512A]	NC
5	Channel 1 Loop A	Frequency selection bit 2 [TR2512A]
6	Frequency selection bit 3 [TR2512A]	Channel 1 Loop B
7	NC	Frequency selection bit 4 - MS bit [TR2512A]
8	NC	NC
9	NC	NC
10	NC	NC
11	NC	Downstream Rx
12	Downstream Tx	Channel 2 Loop B
13	Channel 2 Loop A	Upstream Tx
14	Upstream Rx	Chassis Ground (GDT earth point)
15	NC	NC
16	NC	NC
17	NC	NC
18	NC	NC
19	Channel 3 Loop A	NC
20	NC	Channel 3 Loop B
21	NC	Detector Address bit 1 - LS bit
22	NC	NC
23	NC	NC
24	NC	NC
25	RS422 TxD+ (Y) - GSPI	RS422 TxD- (Z) - GSPI
26	NC	Channel 4 Loop B
27	Channel 4 Loop A	RS422 Gnd – this is board logic GND **
28	RS422 RxD- (B) - GSPI	RS422 RxD+ (A) - GSPI
29	-Reset input	Detector Address bit 2
30	Detector Address bit 3	+24V DC supply input
31	NC	Detector Address bit 4
32	Detector Address bit 5	0V DC supply input
	Must be used with negative ground 24V DC PSU	** - Factory Option to link to 0V DC supply

SLD4 DE Pinout – Variants 504-507		
Pin	Row a function	Row b function
1	NC	Channel 1 O.C. fault output - FEHL1
2	Channel 1 O.C. detect output	NC
3	NC	[This pin grounded on DE backplane]
4	Frequency selection bit 1 - LS bit [TR2512A]	Master Fault O.C. output
5	Channel 1 Loop A	Frequency selection bit 2 [TR2512A]
6	Frequency selection bit 3 [TR2512A]	Channel 1 Loop B
7	NC	Frequency selection bit 4 - MS bit [TR2512A]
8	Channel 2 O.C. fault output - FEHL2	NC
9	NC	Channel 2 O.C. detect output
10	[This pin grounded on DE backplane]	NC
11	Common return for all O.C. outputs **	NC
12	Downstream Tx	Channel 2 Loop B
13	Channel 2 Loop A	Upstream Tx
14	Upstream Rx	Chassis Ground (GDT earth point)
15	NC	Channel 3 O.C. fault output - FEHL3
16	Channel 3 O.C. detect output	NC
17	NC	[This pin grounded on DE backplane]
18	RS422 RxD+ (A) - GSPI	Downstream Rx
19	Channel 3 Loop A	RS422 TxD- (Z) - GSPI
20	RS422 TxD+ (Y) - GSPI	Channel 3 Loop B
21	NC	Detector Address bit 1 - LS bit
22	Channel 4 O.C. fault output - FEHL4	NC
23	NC	Channel 4 O.C. detect output
24	[This pin grounded on DE backplane]	NC
25	Sout - TTL	RS485 A - SiTOS
26	-Sen [direction control]	Channel 4 Loop B
27	Channel 4 Loop A	RS485/RS422 Gnd - this is board logic GND **
28	RS485 B - SiTOS	Sin - TTL
29	-Reset input	Detector Address bit 2
30	Detector Address bit 3	+24V DC supply input
31	RS422 RxD- (B) - GSPI	Detector Address bit 4
32	Detector Address bit 5	0V DC supply input
		** - Factory Option to link to 0V DC supply

## A.5 Link Ranges for Example Loop Configurations

The table below shows the link ranges for typical loop configurations. This should only be used as a guide as feeder cable will increase apparent inductance.

Inductance of Standard Sized Loops					
Length of Long Side (m)	Length of Short Side (m)	Number of Turns		Inductance (uH)	Link Range
1	1	1		5.8	N/A
1	1	2		19.2	1
1	1	3		41.8	1
1	1	4		72.4	1
1	1	5		110.4	1
2	2	1		12.7	1
2	2	2		42.8	1
2	2	3		93.6	1
2	2	4		162.5	2
2	2	5		248.6	2
3	3	1		20.1	1
3	3	2		68.1	1
3	3	3		149.2	1
3	3	4		259.3	2
3	3	5		397.2	3
4	4	1		27.7	1
4	4	2		94.4	1
4	4	3		207.2	2
4	4	4		360.5	3
4	4	5		552.6	3

Table 24 : Inductance of Standard Sized Loops

### A.6 Impact of Long Loop Feeder Lengths

#### A.6.1. Summary

Feeder lengths more than 300m may be used, provided that detection of bicycles and motorcycles are not required.

In particular when installing loops on heavily reinforced concrete the sensitivity will be reduced if the spacing of loop conductors from the reinforcing bars is less than specified. Also where a tarmac surface includes furnace slag or similar materials the sensitivity will be impaired. Both of these effects will be made worse by long feeders.

The following information is provided for users who need to use the detector outside of the normal working parameters. (i.e. above 300M cable length, in highly reinforced road surfaces, loops with unusual numbers of turns).


#### A.6.2. Effect of feeder length

The SLD4 has been tested with feeder lengths up to 1000 meters. Increasing feeder length will make the apparent sensitivity decrease. This is because the detector functions by measuring the percentage change of inductance as seen at its terminals. The loop inductance is altered when metal objects (vehicles) enter the loop. However adding feeder cable increases the apparent inductance at the detector terminals – and this additional inductance is not affected by the vehicle. As only part of the inductance is changing, the effect is to reduce the apparent sensitivity of the detector. The method by which the detector calculates the inductance means that the effect of longer feeders is minimized as the SLD4 characterizes the connected loops.

For applications where detection of bicycles and motorcycles is not required (e.g. SCOOT) feeder lengths greater than 300m may be used. In order to overcome the loss of apparent sensitivity, the detector may be set to a more sensitive setting than normal.

Putting loops in reinforced concrete surfaces is standard practice and the sensitivity of the detector is adequate for this. However the effect of long feeders on sensitivity adds to the effect of steel reinforcing mesh and the user must be aware of the risk of combining risk factors.

The graph shown in Figure 18 shows a guide to the loss in sensitivity due to feeder.



**Figure 18 : Loss of Sensitivity due to Feeder**

This graph shown above should be used as a guide only as there are many factors that affect the actual sensitivity.

### **A.6.3. Maximum inductance**

Long feeders increase the apparent inductance as seen at the detector terminals. (Note that measurement of inductance with an LCR meter is invalid for this purpose as these operate at a low fixed frequency - usually 1KHz - and the detector is not a true inductance measuring device). Large values of inductance restrict the use of higher frequency settings via switches F1-F4 or the frequencies allocated when in automatic mode. The limits of allowable inductance are shown in section 4.3.6

## A.7 Installing USB Drivers

This section describes how to install the USB drivers for the dedicated USB interface cable.

The example given for Windows XP 32 bit Operating System

Acquire driver pack from <www.ftdichip.com> (or supplied in installation directory of PC tool):

- Select 'Drivers' from the left hand menu
- Select the 'VCP' driver link
- Select drivers for the appropriate operating system – in this example 'Windows x86 (32-bit) WHQL certified drivers and save the zip file.
- Unzip the driver pack to a known location on the machine.


1 Plug the USB cable into a USB socket –Windows will detect the new device:



2 Select 'Install from a list or specific location (Advanced)'



3 Select 'Include this location in the search'




- 4 Browse to the folder where the drivers were unzipped to and press 'OK'
- 5 Select 'Next', the USB Serial converter will be installed:



If Windows XP is configured to warn when unsigned (non-WHQL certified) drivers are about to be installed, the message dialogue shown below will be displayed unless installing a Microsoft WHQL certified driver. Select 'Continue Anyway' to continue with the installation. If Windows XP is configured to ignore file signature warnings, no message will appear.



6 Select 'Finish', Windows will now detect a USB Serial Port:



7 Follow steps 3 to 7 again to install the USB Serial Port Drivers:



If Windows XP is configured to warn when unsigned (non-WHQL certified) drivers are about to be installed, the message dialogue shown below will be displayed unless installing a Microsoft WHQL certified driver. Select 'Continue Anyway' to continue with the installation. If Windows XP is configured to ignore file signature warnings, no message will appear.



8 After installation, Windows will display the completed message:



The driver installation is now complete.

---

**Note**

Plugging the cable into a different USB port on a PC will invoke the driver installation again.

---

### A.8 Command Line Operation

A terminal program such as HyperTerminal for Windows can be used to connect to the virtual serial port of the connected device. The com port number allocated by the PC when the unit is plugged in is needed so that the correct port can be opened in the terminal program. The com port number can be identified in Windows XP in the following way:

- 1 Start Menu -> Settings -> Control Panel
- 2 System -> Hardware -> Device Manager
- 3 Ports (COM & LPT)
- 4 The port will be identified as 'USB Serial Port (COMx)' where 'x' is the port number allocated.

The connection parameters are:

115200 Baud, 8 bits, 1 stop, no parity, no handshaking

To confirm connection press ENTER in the terminal window and the detector will respond:  
SLD4>

The available commands are listed below in bold with the required format and a description of the function. Commands are case insensitive.

The following commands are available (followed by the SLD4 reply):

#### **HELP**

reboot – info – time – revert

flts – led – linfo

Provides a list of help commands available

Entering HELP command will provide basic help on the command entered

#### **REBOOT**

reboot:1

This will perform a software reset of the detector. No parameters are altered. This is the software equivalent of pressing the reset button.

**INFO**

Lists details about the detector in the following format:

SIEMENS SLD4 Loop Detector

HW	667/1/xxxxx/yyy	Hardware part number & variant
DOM	Yyyy/mm/dd	Date of manufacture <yyyy> - Year <mm> - Month <dd> - Day
SN	Xxxxxxxxxxxxxxxxxxxxxxx	Serial Number
FW	667/TZ/45215 va.b.,c.d	Firmware ID & version where: A - Major version B - Minor version
V EXT	12,860 V	External raw supply voltage
V INT	1,209 V	The CPU core voltage
T INT	30,373°C	CPU Temperatur
BOARD	X	The board address
LINK	X	The total number of SLD4 devices found
BOOTC	X	The total number of power cycles or reboots
SWITCH	0x12345	The DIP switch state (all switches)

**TIME**

LifeTime:xxxx UpTime:yyyy

LifeTime – The total powered time for the detector in seconds

UpTime – The powered time since the last reset in seconds

**REVERT**

Revert:1

Reverts (deletes) the device configuration

**REVERT F**

Revert:1

Reverts the device to factory settings

**FLTS**

Lists any active detector faults. The following faults may be displayed:

Reported Fault	Description / Action
F/W Checksum Failure	The firmware is corrupt – The board should be replaced or firmware reloaded
Configuration Checksum Failure	Configuration may be corrupt – Reconfigure board
No or Corrupt Data File	Configuration may be corrupt – Reset board*
Watchdog Failure	Indicates that the watchdog has tripped. This flag can be reset by resetting the board. May indicate a faulty card if occurring regularly. Card will automatically reset and continue working.*
EEPROM Access Failure	Abnormal software function – Reset board*
Loop x Failure	The numbered loop has failed and cannot be tuned –Check loop information (LINFO) and loop integrity
Loop x Threshold Error	The threshold is close to the loop noise floor – Consider decreasing the sensitivity and/or check loop integrity
Software Initialization Failure	Abnormal software function – Reset board*
Software Timing Error	Abnormal software function – Reset board*
S/W Schedule Error	Abnormal software function – Reset board*
S/W State Machine Error	Abnormal software function – Reset board*
S/W General Error	Abnormal software function – Reset board*
Digital I/O SchedulingError	Abnormal software function – Reset board
Hardware Error	General hardware fault - The board should be replaced
Supply Voltage Low	Check power supply voltage
Unrecognized Hardware	General hardware fault - The board should be replaced
Link Error	The inter card link is suffering data loss/corruption. Check optical path and/or cabled link (if applicable)

**Table 25 : Fault Table**

\* If fault persists - replace the board

**LED=0**

led:0

LED=0 turns all LEDs off

### LED=1

led:1

LED=1 turns all LEDs on (Will turn off automatically after 20 minutes)

### LINFO

List details about the detector loops, operating frequency, tuning range etc.

Loop

FMax	The maximum frequency the loop can tune to
FMin	The minimum frequency the loop can tune to
MaxT	The maximum tuning value that the loop can use
FKHz	The allocated frequency band
Tune	The tuning value allocated in automatic mode: 0-511 (for development purpose only)
Bkgnd	The actual loop operating frequency in Hz
Noise	The noise level in Hz*
SenHz	The sensitivity threshold level in Hz **
PMax	The maximum peak deviation for the last 20 vehicles ***
PAvg	The average peak deviation for the last 20 vehicles ***
Dcnt	The loop detector count totals

\* This is a statistical value aimed to give a guide to loop 'quality'. Lower values indicate good quality, well placed/wired loops. This value should be at or below the sensitivity threshold

High 'Noise' values might indicate: Interference, poor quality joints or leaky feeders/loops.

\*\* The frequency threshold which a vehicle must pass before it can be detected.

\*\*\* This vehicle count is configurable using the SLD4-Configuration Tool.

---

### Note


All references to frequencies are in Hz.

---


## A.9 Installation of Configuration Tool

The tool must be installed onto the target PC. The installation files must be unzipped to a local drive before installation commences.


Run [Setup.exe] to start the installation process and follow the on screen instructions. This will install all necessary software:




1 Click 'Next'




2 Select a suitable folder for the installation



3 Start the installation



4 Installation in progress



5 Click 'Close'

The configuration tool has now been successfully installed.

The tool can now to run from Start Menu ->Programs ->Siemens Traffic Solutions ->SLD4 Configurator.

**More information**

Siemens Traffic  
[www.siemens.co.uk/traffic](http://www.siemens.co.uk/traffic)

Siemens Mobility  
<http://www.mobility.siemens.com/mobility>

Siemens Plc  
Sopers Lane  
Poole  
BH17 7ER  
United Kingdom

Subject to change without prior notice  
Order No. 667/HB/45200/000 /  
V24763-A82-B4-  
© Siemens Plc, 2016

For more information  
on SLD4 scan the QR  
code



[www.siemens.co.uk/traffic](http://www.siemens.co.uk/traffic)