

# SIEMENS

CATALOG NUMBER

## ECMLNKOP

### Back Plate without Knockouts



**⚠ DANGER**

**Hazardous Voltage.**  
Will cause death, serious injury  
or substantial property damage.

Turn off power supplying this  
equipment before working inside.

**Kit Contents:**

- (1) Back Plate without Knockouts
- (4) Screws, #10-32 x 5/16

**For Use On Type (W)ML Modules:**

2-4 Position, 100-225A (1 and 3 ph)

**For Use On Type (W)MT Modules:**

1-3 Position, 225A (except 3ph-out)

**Note:** This instruction outlines the recommended installation procedure. For installation by a qualified person, as defined by all local electrical codes and/or the National Electrical Code®.

1. Turn off and lock off the power supplying the device before working inside.
2. Clean and prepare surface; remove any old or damaged material before installing replacement part. Do not allow petroleum based (hydrocarbon) sprays, chemicals, solvents or any paint to contact plastic components.
3. Install Back Plate into position against back wall of enclosure. Secure in place with (4) #10-32 Screws. Tighten screws to 15-20 lb.-ins.

## Power Mod™ Modular Metering Accessories

