

CATALOG NUMBER

# ECQTH4

**electricCenter**  
ACCESSORIES

## 3" Wide - Padlocking Device

This kit fits (3) 1 pole SIEMENS and MURRAY breaker types:

QP, QPH, HQP, BQ, BQH, HBQ,  
MP-T, MP-HT, MP-MT, MP-AT, LQ.

**Note:** Not for use on three phase circuits.

Package contains 1 device.



## INSTALLATION INSTRUCTIONS



### ⚠ DANGER

**Hazardous Voltage.**  
Will cause death,  
serious injury or substantial  
property damage.

Turn off power supplying this  
equipment before working inside.



### SAFETY INSTRUCTIONS

**Note:** This instruction outlines the recommended installation procedure.

1. Turn off and lock off the power supplying this enclosure before working inside.
2. To install, press the padlocking assembly onto the circuit breakers (Fig.1). (The barbs on the lock mount will cause this to be a snug fit).
3. The circuit breaker can be padlocked in the "OFF" or "ON" position. Once the padlocking assembly is installed, the lock plate must be rotated to allow access to the circuit breaker handle(s) (Fig.2).
4. The installation of this padlocking device will be complete when the deadfront is secured to the panel.

