

Terminal Block Configurator Supplemental  
Component Arrangement Graphical Reference

You will need the 'Graphical Code' found in the right-hand column of this document to answer the question: *Component Arrangement: (\*)* when *Design/Function* = 'Diode' or 'Two-tier w/Solid State Cmpnts'; and, *Component Type* = 'Diode' or 'LED & Diode'.

Graphical Reference	Contact Arrangements: (*) Graphical Code
	Let through from right to left
	Let through from left to right
	Let through from top right-left
	Let through from bottom right-left
	Let thru fm bottom left-right
	Let through from top to bottom
	Let through from bottom to top
	FF
	TT
	GG
	UU
	HH
	II
	KK
	RR
	SS
	VV (V Not W)

(\*) Let through (a.k.a. Let thru) = the direction of current flow