SIEMENS

INSTALLATION GUIDE

VersiCharge[™] Dual Post and Cable Management System for an Electric Vehicle Charging Station



Index

VersiCharge Single/Dual/Back-to-Back Mounting	4
Warning	4
Dual Post and Cable Management System for Siemens VersiCharge	5
Concrete Pad, Power Feed and Anchor Requirements	6
Single VersiCharge Mounting	7
Dual VersiCharge Mounting	8
Single/Dual Post and Cable System Installation	9
Dual Cord Retractor Mounting	10
Power the Station(s)	11

Figures

igure 1. Post base	5
igure 2. Single post	5
igure 3. Single Post - back view	7
igure 4. Single Post - left-side view	7
igure 5. Single Post - front view	7
igure 6. Single Post - right-side view	7
igure 7. Dual mounting - back view	8
Figure 8. Dual mounting - left-side view	8
igure 9. Dual mounting - front view	8
igure 10. Dual mounting - right-side view	8
Figure 11. Single/Dual mounting with Cable System - right-side view	9
rigure 12. Single/Dual mounting with Cable System - left-side view	9
igure 13. Single/Dual mounting with Cable System - front view	9
rigure 14. Single/Dual mounting with Cable System - back view	9
igure 15. Dual Cord Retractor Mounting - right or left view	10
Figure 16. Dual Cord Retractor Mounting - front view	10
igure 17. Dual Cord Retractor Mounting - back view	10
Figure 18. Dual Cord Retractor Mounting - top view	10

VersiCharge Single/Dual/Back-to-Back Mounting:

Applications include any public or private place where Electric Vehicle (EV) charging is required. These places may include homes, both single and multifamily, places of business, commercial institutions, etc.

These instructions do not purport to cover all details or variations in equipment, or to provide for every possible contingency to be met in connection with installation, operation, or maintenance. Should further information be desired, or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local Siemens sales office or Siemens Customer Service available at 1-800-SIEMENS. The contents of this Instruction Manual shall not become part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of Siemens. The warranty contained in the contract between the parties is the sole warranty of Siemens. Any statements contained herein do not create new warranties or modify the existing warranty.

NOTE: This instruction outlines the recommended general installation procedure by a qualified person, as defined by all local electrical codes and/or the NEC[®].

PERMITS: Be aware that many areas require special permits and/or utility approvals to install EV charging equipment. Contact your local electrical inspector's office and your local utility prior to beginning work to understand local requirements.

WARRANTY: See Siemens' standard terms and conditions at <u>usa.siemens.com/versicharge</u>

TOUCH UP PAINT: See link below for replacement paint if needed for aesthetic restoration throughout post life. https://www.lvppaints.com/RAL7035-Color-Plate.html

Warning:



DANGER Hazardous voltage. Will cause death or serious injury. Disconnect before working on this equipment. This indicates a situation where the present voltage could cause injury or death. Extreme caution is required when servicing or installing the equipment referenced.



DANGER Explosion hazard. This equipment has arcing or sparking parts that should not be exposed to flammable vapors. Use extreme caution and follow instructions carefully.



WARNING! This indicates a situation where failure to follow instructions may be a safety hazard or cause equipment malfunction. Use extreme caution and follow instructions carefully.

[®] The National Electrical Code is a registered trademark of the National Fire Protection Association

Dual Post and Cable Management System for Siemens VersiCharge

VersiCharge units sold separately

Features:

- Single or dual mount pedestal
- Siemens VersiCharge standard bolt pattern
- 4" Aluminum pedestal post .120" thick
- Aluminum pedestal base 3/4" thick
- Powder coated with primer undercoat for environmental durability
- Pedestal doubles as an electrical raceway

Supplied Parts:

Pedestal


- One 4" x 4" x 48" Square Pedestal
- One 4" x 4" Plastic End Cap Plug
- Four ¼-20 x ½" Machine Button-Head Philips Screws
- Four 10-32 x 1" Machine Button-Head Tamper Resistant Screws
- Two ¾" NM Flex Right-Angle Connector
- Two ¾" NM Flex Straight Thru Connector
- Two 1" to 3/4" Reducer Washer
- Two ¾" x 16" NM Liquid-Tight Flexible Conduit

Miscellaneous

- Four Drop-In Anchors
- Four Stainless Anchor Bolts with Washers
- One Tube of Silicone Sealer
- Two .19" Locking Hole Plugs, 8mm
- Three 1" Locking Hole Plug
- Two .158 Hole Plugs, 4mm

Cord Retractor (Optional)

- One 2" x 2" x 78-3/4" Aluminum Post (1-for single unit or 2-for dual)
- One White Polyester Cable
- One 5/16" x 3/4" Bolt with Washer
- One $3/8" \times 1 \frac{1}{4}$ " Bolt with Washer
- One Cord Clamp for Cord Retractor
- One Cast Iron Counterweight (11 lbs.)



Viewed from Underneath Pedestal Base

Figure 1. Post base




Figure 2. Single post



DANGER Hazardous voltage. Will cause death or serious injury. Please consider all safety warnings in the VersiCharge Installation and Operations Manual refer to the Siemens web link: usa.siemens.com/versicharge prior to wiring. Ensure breaker is off during all electrical work.

All pedestals shall be factory pre-drilled for installing two (2) Siemens VersiCharge EVSE units. The post product is compatible with all VersiCharge models.

Installation height is regulated by NEC; however, this can vary based on local jurisdiction. NEC® 2011 specifies: Outdoor (NEC® Article 625.30B) = installation 24-48 inches above ground level. Use appropriate tools and hardware to fasten equipment, see details.

Concrete Pad, Power Feed and Anchor Requirements

Provide an approved concrete or composite base with the top flush at ground level, with 12" conduit stub-up centered. The conduit shall be sized to provide 3 wires (L1, L2, GND) for each charger being mounted. The base size should be a minimum of 18" x 18" x 18" and can be poured or pre-cast / pre-made. Installation of protective concrete-filled steel bollard posts and/ or curb stops to protect the charger from an automobile strike is recommended. Feed-wire size shall be determined by a qualified electrician using industry standard calculations. Using the provided drop-in anchors with a concrete base, secure the pedestal to the base. If using a composite base, secure per manufacturer's instructions. Remove the pedestal access plate and place to the side.


There is an option to run the power supply and shielded communication wires underground, feeding through the bottom opening in the pedestal or, if the conduits are run above ground, the wires may be brought in through the sides of the post using the lower 1" holes on each side of the pedestal base. When using above ground conduits, use 3/4" NPT fittings to enter through 1" holes in lower section of the pedestal.

Feed-wire size shall be determined by a qualified electrician using industry standard calculations.

The power conduit shall be sized to provide three wires (L1, L2, GND) for each charger being mounted. Install the wires so they extend sufficiently above the ground for direct attachment to the EVSE (the charger). The communication conduit shall be ³/₄" to run one (or two) CAT 5/6 communication cable(s) to each VersiCharge charger.

NOTE: Communications wires must be shielded and suitable to be run by power wires, or the power wires may cause interference.

Single VersiCharge Mounting using US2:VCPOSTGRY2




- 1. Locate center of pedestal to attach the VersiCharge mounting bracket.
- 2. Locate 2 mounting bracket holes as mentioned above (items A and B 9.75 inches apart and 0.75 inches from the top
- 3. Attach the Mounting Bracket to the pedestal using 4 ¼-20 Philips screws (D), torque to 14.5 lb.-in, placing silicone sealer at each hole to provide a liquid-tight securement.

NOTE: For installation, the mounting-bracket hinges will be pointing to the ceiling, and the flat side of the bracket will be against the pedestal.


- 4. Charger Mounting:
 - a. Slide the VersiCharge on to the hinges.
 - b. Rotate to the right until the unit clicks and is closed.
 - c. Secure Charger to Mounting Bracket: Using the kit-supplied tamper-resistant screw— secure the charger cover with one screw on the side.
 - d. Install Holster to Charger: Align Holster with guides in charger. Using the kit-supplied tamper-resistant screw, use the third screw to secure the holster to the charger (hole at the top of the holster).
 - Silicone sealer can be placed at each hole to provide a liquid-tight securement
- 5. Install NM flex conduit to the bottom opening of the VersiCharge unit and terminate using provided ¾" NM straight connector and reducer washers.
- 6. Attach the NM flex conduit to the center hole (underneath the charger) of the pedestal using the provided ¾" NM rightangle connector.
- 7. Pull/feed the power wires through the conduit and trim to the proper length to reach the charger connection points. Leave enough slack (15" to 20") in the wires inside the post to allow unrestricted access. Using a fold in the wires and a ziptie(s), secure the wire bundle so wires are not touching the inside of the pedestal post.
- 8. Continue with manufactures' instructions for 'Wiring Steps for Hard-Wired Installation' in the VersiCharge Quick Start Guide.

Dual VersiCharge Mounting (Back-to-Back) using US2:VCPOSTGRY2




1. All steps for single unit mounting shall be repeated on two (2) sides of the pedestal.

Single/Dual Post and Cable System Installation using US2:VCPOSTGRY2 and US2:VCCMSSP



- 1. Align the square Cord Retractor body along the right side of the charging station.
- 2. The upper retractor bracket is threaded and slides the length of the retractor post. Locate the ½" hole located at the top of the pedestal on right side, align unit with mounting bracket in place. Place the washers on the 5/16" x ¾" bolt before inserting to space the bracket bolt so it is fully threaded into the upper bracket but DOES NOT penetrate the retractor post. Insert bolt with washer from the inside of the post and tighten, torque to 14.5 lb.-in. Use silicone sealer between the pedestal post and retractor post to make it liquid-tight.
- 3. Make sure unit is plumb with hole at the baseplate, and anchor to baseplate with 3/8" anchor bolt.
- 4. Tighten all bolts. Seal pedestal bolt hole with an outdoor rated silicone to ensure it is watertight.
- 5. Install cord clamp in a location on the cord which keeps it off the ground when the connector is in the 'parked' or 'holstered' position. Use black electrical tape to take up any gap between the cord and the inside of the clamp. Tighten the clamp enough to not allow the cord to slide.

Dual Cord Retractor Mounting using US2:VCPOSTGRY2 and 2 US2:VCCMSSP parts






Figure 18. Dual Cord Retractor Mounting - top view

1. Steps for single cord retractor shall be repeated on two (2) sides of the pedestal.

Installing the Access Cover and Top Cap

Once all the above steps are complete and all screws, bolts, fittings, etc. are tight, place a thin bead of silicone sealer around the perimeter of the access plate and screw the plate onto the post using the provided stainless torx head screws. Wipe off any excess sealer. Place a generous bead of silicone sealer around the perimeter of the top cap and insert the cap into the pedestal post. A rubber mallet is recommended to properly seat the top cap. Wipe off any excess sealer.

Power the Station(s)

1. Turn on the power feed to the station(s) and test as per the VersiCharge installation manual.

Legal Manufacturer

Siemens Industry, Inc. 3617 Parkway Ln. Peachtree Corners, GA 30092 United States of America

Telephone: +1 (800) 333-7421 helpline.sii@siemens.com

Engineering Doc No: R814225-R04 Article No. SIDS-T40099-00-4AUS This document contains a general description of available technical options only, and its effectiveness will be subject to specific variables including field conditions and project parameters. Siemens does not make representations, warranties, or assurances as to the accuracy or completeness of the content contained herein. Siemens reserves the right to modify the technology and product specifications in its sole discretion without advance notice.

© 2021 by Siemens Industry, Inc.