

SIEMENS

QUICK REFERENCE GUIDE TO REPLACING TRACK CARD MEF'S IN THE GCP 4000

Document Number SIG-QG-08-03C.1

WARNING

DURING MODULE CHANGE OUT, SOFTWARE CHANGE, REBOOT, AND CALIBRATION PROCEDURES, WARNING DEVICES MAY NOT OPERATE AS INTENDED. TAKE ALTERNATE MEANS TO WARN PEDESTRIANS, EMPLOYEES AND VEHICULAR TRAFFIC.

AFTER INSTALLING THE NEW SOFTWARE, RECALIBRATE THE CROSSING AND FOLLOW ALL NORMAL PROCESSES FOLLOWING RECALIBRATION.

NOTE

Verify that the replacement MEF is compatible with the currently installed MCF.

1. Copy the new MEF to the laptop in a folder in the C:\Safetran\DT directory or another convenient folder on the PC which will be used to install the software.

2. Connect the serial cable between the PC and the Track Card DIAG port.



DIAG Port



3. Open the DT software by double clicking on the DT icon on the desktop, or by double clicking on the DT.exe file found in C:\SAFETRAN\DT\.


4. Select the **COMM** button.

COMM Button




5. A menu will appear. Select **Install Software**.


6. A dialog box prompt will ask if you are sure you want to **RESET MODULE**. Select the **YES** button.




7. Select the **MEF/F4** button.



8. At the **Erase the MEF (Y/N)?** prompt, type Y or select the **YES** button.




9. After erasing the previous MEF, the following dialog box will appear.




10. Select the file to be installed, **GCP03_30.MEF** (example only). Select the **Open** button. The file installation may take a few minutes.


11. While the file is downloading, progress will be indicated on the bottom line of the window.




12. When complete, the DT returns to the following screen.




13. When the download is complete, press **F8** or select the **EXIT** button. The DT closes the setup process.



14. Once the setup is finished, the DT starts loading the MEF.



15. Once the MEF has loaded, select the **CLOSE** button to return to the DT screen.



WARNING

AFTER DOWNLOADING THE MEF, RECALIBRATE THE AFFECTED TRACKS. TESTS MUST BE PERFORMED TO VERIFY PROPER OPERATION OF THE GCP SYSTEM PRIOR TO PLACING THE SYSTEM IN SERVICE.