


9. Reference Figure 9

Installing the Neutral Lug Assembly (item 14)

The Branch Neutral is mounted at the bottom of the Z-rails, or mirrored at the top depending upon the feed cable location. The Neutral Lug Assembly (item 14) can be mounted (as shown) on either side of the Branch Neutral depending on cable feed location. Torque all hardware as specified on the rear of the deadfront.



10. Install the Breaker Cover Plate (item 7):

Use Filler Plate Assemblies (item 15) to cover empty circuit breaker slots. Reinstall the deadfront using the breaker cover plate supplied with this kit. Other cover plates may be required for proper fit. See filler plate kits listed on the rear of the deadfront.

# SIEMENS

## Switchboard/Power Panel Kit SNBD/SNB for Branch Mounting Type GB Breakers

Installation  
Instructions

These instructions do not purport to cover all details or variations in equipment, or to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise, which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local Siemens sales office. The contents of this Instruction manual shall not become part of or modify any prior or existing agreement, commitment or relationship. The sales contract contains the entire obligation of Siemens. The warranty contained in the contract between the parties is the sole warranty of Siemens. Any statements contained herein do not create new warranties or modify the existing warranty.


Trademarks - Unless otherwise noted, all names identified by ® are registered trademarks of Siemens AG or Siemens Industry, Inc. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

# Installation Instructions

The following instructions are for the installation of Siemens Type GB breakers (NGB, HGB or LGB) in Switchboard or shallow/deep Panelboards. This kit will require 3-3/4" of unit space. The parts provided in this kit are for connections to a 3-phase, 3- or 4-wire system.



1. Lock off power supplying this equipment before working on it.
2. Reference Figure 1:  
Remove the (2) gutter covers and cover plates.



3. Reference Figure 2:  
To mount a Type GB Breaker, 3-3/4" of empty unit space is required. To locate the mounting position, measure from the top deadfront support to the top of the empty unit space filler on the deadfront. Transfer this dimension from the deadfront support along the Z-rail and mark. This will be the unit space as shown on Fig. 4. After marking the Z-rail, remove the deadfront.




Figure 2

4. Open the shipping box and check the hardware against the following list:

ITEM	DESCRIPTION	QTY.
1	GB BREAKER INSTALLATION INSTR	1
2	A/C PHASE STRAP	2
3	B PHASE STRAP	1
4	TOP BARRIER	1
5	BARRIER SUPPORT	2
6	A/C BRANCH CONNECTOR	2
7	BREAKER COVER PANEL	1
8	CARD HOLDER	6
9	CIRCUIT ID CARD	1
10	STRAP-SECTION BUS HARDWARE KIT	1
11	10-32 HEX WASHER HEAD SCREW	6
12	10-24 X 3/8" SHWHSW	2
13	1/4"-20 X 3/8" SHWHSW	6
14	NEUTRAL LUG ASSEMBLY	1
15	EQ FILLER PLATE	5
16	BOX	1
17	CARTON LABEL	1

5. Reference Figure 4:  
Installing the Phase Straps  
Locate two 0.228" diameter holes in the AØ bus 1-1/4" down from the top of the 3-3/4" empty unit space selected. Insert two 1/4"-20 thread-forming screws (see mounting hardware kit for the proper length) through two 0.281" diameter holes in an A/C Strap (item 2) and into the holes in the two selected holes in the AØ bus (orienting the A/C strap as shown) and tighten. Repeat this step to mount the second A/C Phase Strap to the CØ bus using two 0.228" diameter holes in the CØ bus down 1-1/4" from the holes used on the AØ bus and tighten. Insert another 1/4"-20 thread-forming screw through the 0.281" diameter hole in the BØ Strap (item 3) and into a 0.228" diameter hole in the BØ bus down 1-1/4" down from and 3-5/8" to the right of those used on the AØ bus (orienting the BØ strap as shown) and tighten. Torque all hardware as specified on the rear of the deadfront.




Figure 4

6. Reference Figure 5:  
Attach the Barrier Supports  
Locate a 0.228" diameter hole in the left Z-rail 1-7/8" below the top of the empty unit space selected. Insert a 1/4"-20 x 3/8" screw (item 13) through the 0.312" diameter hole in a Barrier Support (item 5) and into the selected hole in the Z-rail (orienting the Barrier Support as shown) and tighten. Repeat this step for the second Barrier Support. Torque all hardware as specified on the rear of the deadfront.




Figure 5

7. Reference Figure 6:  
Installing the Top Barrier and Branch Connectors  
Insert a 1/4"-20 x 3/8" screw (item 13) through each of the 0.25" diameter holes in the Top Barrier (item 4) and into the 0.228" diameter holes in the Barrier Supports and tighten. Insert a #10-24 x 3/8" screw (item 12) through the 0.218" diameter hole in a Branch Connector (item 6) and into the 0.171" diameter hole in the AØ Strap and tighten. Insert a #10-24 x 3/8" screw (item 12) through the 0.218" diameter hole in a Branch Connector (item 6) and into the 0.171" diameter hole in the CØ Strap and tighten. Torque all hardware as specified on the rear of the deadfront.




Figure 6

8. Reference Figures 7 & 8:  
Installing a Type GB Circuit Breaker  
Position a Type GB breaker so that the notch in the underside of the breaker case aligns with the uppermost latching tab on either side of the Top Barrier (item 4). Slide the breaker across the barrier surface until the breaker notch engages the tab in the barrier. Insert a #10-32 washer head screw (item 11) through each breaker line connector tab hole and fasten into the Branch Connector (item 6). Torque all hardware as specified on the rear of the deadfront.




Figure 7




Figure 8

NOTE: If a Branch Neutral Lug Assembly is NOT required, skip to step 10.