



Instructions

⚠ DANGER

Hazardous Voltage.
Will cause death, serious injury or substantial property damage.

Turn off power supplying this equipment before working inside.

⚠ SAFETY INSTRUCTIONS

This instruction outlines the recommended general installation procedure. For installation by a qualified person, as defined by all local electrical codes and/or the National Electrical Code®.

Turn off and lock off the power supplying the device before working inside.

Kit Contents:

- (1) 600 kcmil Lug Assembly (Lug Set Screw Torque 375 lb.-in.)
- (2) 1/4-20 x 1/2 Screws
- (2) Washers

1. Remove Insulating Barrier and retain for use later.
2. Remove (2) 1/4-20 Nut/Washer Assemblies as shown in Figure 1 and retain for use later. Remove Bus/Connector Assembly.
3. Remove (2) 1/4-20 Screws and Washers from back of Bus/Connector Assembly. Discard Screws, Washers, and Lug Assembly.
4. Secure new Lug Assembly (provided with kit) to Connector as shown in Detail A with the (2) 1/4-20 Screws and Washers provided with kit. Torque screws to 45-60 lb.-in.
5. Re-Install Bus/Connector Assembly to bus using Nut/Washer Assemblies from Step 2. Torque to 60-65 lb.-in.
6. Reinstall Insulating Barrier.

Figure 1

Figure may vary depending upon module used. Some modules may have multiple lugs per phase.

